DK

# ORIGINAL DOKUMENTATION

## Bruger- og vedligeholdelses instruktion




## TMP Kran type K, L, XL, KL, LS

**Leverandør:**
TMP Hydraulik A/S
Suurkjærvej 9
7790 Thyholm DK

Tlf.: +45 9787 1900
Mail: tmp@tmphydraulik.dk

Version 2/2020

# Indhold


Introduktion ... 3
Liste over relevante standarder ... 3
1 Original overensstemmelses-/komponent erklæring Original Declaration of Conformity/component ... 4
2 Produktbeskrivelse ... 5
2.1 Type ... 5
2.2 Standard teknisk data: ... 5
2.3 Tilsigtet brug: ... 5
3 Belastning ... 6
3.1 Belastningseksempel ... 6
4 Sikkerhed ... 6
4.1 Sikkerhed for belastning ... 6
4.2 Sikkerhed for brugere ... 7
4.3 Advarsler og andre vigtige forskrifter ... 7
5 Instruktioner ... 8
5.1 Bruger instruktion ... 8
5.1.1 Før ibrugtagning ... 8
5.1.2 Montering/opsætning/klargøring ... 8
5.1.3 Ibrugtagning og brug ... 8
5.1.4 Efter brug ... 8
5.1.5 Nødsituation ... 8
5.2 Vedligeholdelses instruktion ... 9
5.2.1 Lovpligtigt vedligehold ... 9
5.2.2 Jævnlig vedligehold ... 9
5.2.3 Daglig vedligehold ... 10
6 Konklusion ... 10
7 fejlfinding ... 11
8 Hydraulikdiagrammer ... 12
K + KL kran med spil ... 12
LS kran ... 13
L + XL kran med spil ... 14
LS kran med spil ... 15
Bilag indhold ... 16
Translation of original documentation ... 17
Introduction ... 18

1 Original overensstemmelses-/komponent erklæring Original Declaration of Conformity/component ..... 19
2 Product description ..... 20
2.1 Type: ..... 20
2.2 Standard technical data: ..... 20
2.3 Intended use: ..... 20
3 Load ..... 21
3.1 Load example ..... 21
4 Safety ..... 21
4.1 Safety of load ..... 21
4.2 Safety for users ..... 22
4.3 Warnings and other important regulations ..... 22
5 Instructions ..... 23
5.1 User instruction ..... 23
5.1.1 Before use ..... 23
5.1.2 Installation / configuration / preparing ..... 23
5.1.3 Commissioning ..... 23
5.1.4 After use ..... 23
5.1.5 Emergency situation ..... 23
5.2 Maintenance instruction ..... 24
5.2.1 Statutory maintenance ..... 24
5.2.2 Regular maintenance ..... 24
5.2.3 Daily maintenance ..... 25
6 Conclusion ..... 25
7 troubleshooting ..... 26
8 Hydraulic Diagrams ..... 27
K + KL crane with winch ..... 27
LS crane ..... 28
L + XL crane with winch ..... 29
LS crane with winch ..... 30
Appendix content ..... 31

# Introduktion

Det er afgørende for sikkerheden, at brugeren læser og forstå denne tekniske redegørelse, med tilhørende bruger- og vedligeholdelsesvejledning.

Der er gennem vejledningen benyttet følgende piktogrammer:

<table>
<tr>
<td>
</td>
<td>
</td>
<td>
</td>
<td>
</td>
<td>
</td>
<td>
</td>
</tr>
<tr>
<td>
</td>
<td>
</td>
<td>
</td>
<td>
Xn: Sundhedsskadelig<br>Xi: Lokalirriterende</td>
<td>
N: Miljøfarlig</td>
<td>
C: Ætsende</td>
</tr>
</table>

Denne tekniske redegørelse indeholder dokumentation for TMP kranen specificeret i kranspecifikationshæftet.

Formålet med dokumentet er at skabe overensstemmelse med nedenstående standarder.

## Liste over relevante standarder

Denne liste indeholder standarder, der helt eller delvist er fulgt i fremstillingen.

- *Maskindirektivet 2006/42/EF*
- *DS/EN 13001-3-1*
- *EN 13852-1*

# 1 Original overensstemmelses-/komponent erklæring
# Original Declaration of Conformity/component

| | |
|---|---|
| **Fabrikant/ Manufacturer** | TMP Hydraulik A/S |
| **Adresse / Address** | Suurkjærvej 9, 7790 Thyholm |
| **Land / Country** | Denmark |
| **Telefon nr. / Phone no.** | + 45 97 87 19 00 |
| **CVR nr. / company registreings no.** | 26642078 |

## -Erklære herved at /- Declare that:

| | |
|---|---|
| **Produkt navn / product name:** | TMP kran / TMP crane |
| **Type nr. / type no.** | TMP K, L, XL, KL og LS |

| | |
|---|---|
| **-Er fremstillet i overensstemmelse med eller dele af:**<br>• *Maskindirektivet 2006/42/EF*<br>• *DS/EN 13001-3-1*<br>• *EN 13852-1* | ***-Is manufactured according to or parts of:***<br>• *The Machinery Directive 2006/42 / EC*<br>• *DS/EN 13001-3-1*<br>• *EN 13852-1* |

Sted og dato / Place and date: Thyholm 07.10.2019

Underskrift og firmastempel / signature and company stamp:

TMP Hydraulik
KRANER, SPECIALMASKINER & LIFTTEKNIK
TLF. 97 87 19 00

**TMP Hydraulik A/S, Suurkjærvej 9, 7790 Thyholm DK, eller stedfortræder herfor, har bemyndigelse til at udlevere de tekniske dossier / TMP Hydraulik A / S, Suurkjærvej 9, 7790 Thyholm DK, or its representative, is authorized to hand over the technical files.**

# 2 Produktbeskrivelse

## 2.1 Type

| | |
|---|---|
| Navn | TMP marinekran |
| Type | TMP kran type K, L, XL, KL og LS |

## 2.2 Standard teknisk data:

Kranen er fremstillet i højstyrke stål, som er sandblæst, metalliseret og malet med 2-komponent maling. Alle stempelstænger, bolte og rør er fremstillet i rustfast materiale. Fundament og sving er fyldt med olie for at hindre vand og korrosion. Alle koblinger er som standard belagt med korrosionsbeskyttende tape.

Hvis kranen er udstyret med spil, er der som standard monteret justerbart wiresikringssystem.

## 2.3 Tilsigtet brug:

TMP marinekranen er designet og fremstillet til montage på fiskerbåde ol. Kranen bruges til at løfte og sænke forskellige byrder hængende i krog.



Kranen skal være godkendt og dimensioneret til at løfte byrden og tilhørende sling/kæder/sjækler osv.

Maksimal byrde for kranen må aldrig overskrides. Er der monteret ekstra tilbehør såsom spil, vil det være dennes max. WLL der er gældende.



Kranen må aldrig anvendes til andre formål, og skal være forsvarligt monteret.

Brug som ikke er i overensstemmelse med brugsanvisningen, involvere farer for operatøren, personer i nærheden og kranen osv. Dette medfører tab af enhver form for ansvar og garanti fra TMP Hydraulik A/S.



# 3 Belastning

## 3.1 Belastningseksempel

- Kranen er under normal drift udsat for følgende belastninger. Normal drift vil sige løfte-, sænke- og drejeoperationer foregår i anhugnings krog monteret på kranen.
  - Vertikal og horisontal belastning.
  - Belastningen består af hængende byrde.
  - Belastningen er lodret hængende under kranen.

# 4 Sikkerhed









- Det er den ansvarlige for arbejdets udførelse, der har ansvaret for at kranen er godkendt og korrekt vedligeholdt, og ikke er til fare for operatører/brugere.
- Det er operatørens ansvar at personlige værnemidler er intakte og bliver anvendt.
- Det er den ansvarlige for arbejdets udførelse, der bærer ansvaret for at alle operatører er korrekt udstyret med personlige værnemidler, samt har adgang til bruger og vedligeholdelsesinstruktionen.
- Ukyndige må ikke betjene kranen.
- Særlig forsigtighed ved brug af kranen i nærhed af el- og højspændingsledninger, kranen er ikke isoleret og der er direkte jordforbindelse gennem kranføreren.

## 4.1 Sikkerhed for belastning

- Belastningen som nævnt i pkt. 3.1 er sikret ved max WLL som er nævnt i kran specifikationshæftet, og denne må ikke overskrides.
- Det skal tilsigtes at byrden hænger så belastningen bliver ligeligt fordelt vertikal og horisontalt.
- Alle sling/kæder/kroge/wire osv. skal være godkendt til forestående løft og medregnes i byrdens vægt.
- Ved ethvert løft skal byrden og afstanden til kranen kontrolleres jf. kranens løftediagram, se kranspecifikationshæfte. Kranen må ikke hælde mere end 5 grader når fuld kapacitet udnyttes, da stabiliteten forringes væsentligt når kranen hælder.
- Uvedkommende må ikke opholde sig i kranens arbejdsområde.
- Kranen må ikke efterlades belastet.
- Kranen skal betjenes med langsomme og bløde bevægelser.
- Undgå at byrden kommer i sving.
- Kranen må ikke transporteres med hængende byrde, da det kan medføre svære skader på kranen.
- Kranen må ikke anvendes til negativ belastning dvs. bruges som rambuk, vægt eller anden form for tryk mod jorden eller andre genstande.
- Kranen eller dele heraf må ikke støttes af andre redskaber under belastning.
- Hvis kranen er monteret med manuelle arme og andet udstyr, skal disse altid sikres mod overlast og låses med dertil indrettet og godkendt udstyr.

## 4.2 Sikkerhed for brugere



- Brugeren skal være grundigt instrueret i brugen og anvendelsen af produktet.
- Brugeren skal læse vejledningen grundigt.
- Det er forbudt, og forbundet med livsfare at færdes under hængende byrde.
- Brugeren skal sikre frit udsyn, oversigt og ryddelighed over arbejdsområdet, for at undgå fare og skader.
- Brugeren skal udvise ekstra opmærksomhed ved færden indenfor arbejdsområdet, for at undgå fare og skader.
- Brugeren skal bære personligt beskyttelsesudstyr og værnemidler.
- Der kan på eller omkring kranen og anlægget være skarpe kanter og hjørner, der kan forsage skade/ulykker på ting og personer.





## 4.3 Advarsler og andre vigtige forskrifter

Hydraulikolie og smørefedt kan være sundheds- og miljøskadelig. Derfor er det vigtig at følge oliefabrikantens anvisninger og tilhørende datablade.




- Fysisk kontakt med olien og fedt kan bl.a. medføre allergi, lungelidelser ol.
- Olielækage under højt tryk, kan medføre betydelige skader på ting og personer.
- Ved opstart af anlæg, hvor sikkerhedsventiler m.m. skal justeres og udluftes, kan der forekomme pludselige oliestråler og -tåger, brug derfor altid egnede værnemidler under arbejdet.
- Ved adskillelse af anlægget, selvom denne er stoppet, kan der forekomme statisk tryk fra akkumulator, komprimeret olie ol. Dette kan medføre pludselige meget varme oliestråler, der kan medføre fare for skoldning/ætsning.
- Ved olielækage skal anlægget stoppes omgående og oliespild skal mindskes mest muligt og indberettes til rette myndighed.







## Andre vigtige forskrifter!



- Hvis dæksel til tilslutningsboks på elektromotor fjernes og/eller stik på magnetventiler afmonteres, SKAL sikkerheds-/hovedafbryder på elforsyningskabel slukkes og aflåses.
- Al elektrisk tilslutning fx elektromotor, magnetventiler skal foretages af autoriseret el-installatør.



# 5 Instruktioner

## 5.1 Bruger instruktion



Det er vigtigt for brugeren at læse og forstå denne bruger og vedligeholdelsesvejledning, af hensyn til brugerens og omgivelsernes sikkerhed og produktets stabilitet og driftssikkerhed.

### 5.1.1 Før ibrugtagning

Før ibrugtagning skal bruger sikre følgende:



- Læs tilhørende dokumentation på kranen grundigt igennem.
- Ingen synlige skader på kran.
- Alle bevægelige dele skal være frit bevægelige.
- Typeskilt skal være intakt.
- Byrden i det forestående løft skal vurderes mod WLL skilt -se kran specifikationshæftet.



### 5.1.2 Montering/opsætning/klargøring

- Kranen skal monteres på forsvarligt fundament.
- Tilslut kranen til el/hydraulik. Tilslutningen skal foretages af autoriseret personale.
- Sikre at alt er tilsluttet rigtigt.

### 5.1.3 Ibrugtagning og brug

- Efter gennemgang af denne dokumentation og montering er kranen klar til brug.
- Se betjeningsvejledninger på div. I bilag

### 5.1.4 Efter brug

- Kranen tjekkes for evt. fejl.
- Kranen pakkes sammen og placeres i parkeringsbeslag.
- Skal kranen stå ubenyttet i længere tid, køres alle cylindere sammen og alle ikke malede dele påsmøres med olie.

### 5.1.5 Nødsituation

- Ved en nødsituation skal kranen omgående bringes til standsning og situationen skal vurderes af den ansvarlige for arbejdets udførelse.
- Byrden sænkes til jorden, hvis dette ikke forværre situationen.
- Interne retningslinjer for ulykker/nødsituationer følges.

## 5.2 Vedligeholdelses instruktion

Det er vigtigt at følge nedenstående service/vedligeholdelses instruktioner, da det er medvirkende til at øge driftssikkerheden.



### 5.2.1 Lovpligtigt vedligehold



- Kranen skal som minimum efterses og godkendes en gang hver 12 måned.
- Eftersynet skal foretages af en kvalificeret/sagkyndig person.
  Kontakt evt. **TMP Hydraulik A/S på tlf. +45 97 87 19 00.**

### 5.2.2 Jævnlig vedligehold

- Olie og filterskift foretages minimum én gang årligt, eller ved konstant og hård belastning op til 4 gange årligt. Her anbefaler vi Texaco HDZ32 eller tilsvarende.
- For at opnå optimal levetid, bør snavs i olien undgås. Da der under indkøringen og opstarten produceres en mængde afslidte partikler fra alle bevægelige dele, bør anlægget derfor ikke fuldt belastes før alt snavs er separeret fra i filterne, som skiftes minimum én gang årligt.
- Ved lave temperaturer (under +10 grader) skal alle funktioner køres igennem nogle gange, så hydraulikolien varmes op.
- Kontroller korrekt påfyldning og stand af olien.
- Kontroller anlægget, komponenter, slanger, fittings, ekstra udstyr osv. for olielækager, fejl, brud osv. Og efterspænd.
- I tilfælde af uheld eller fejl, skal beskadigede slanger, rør, wire m.m. udskiftes straks.
- Overtryksventilen er forsejlet til angivet tryk beskrevet i tilhørende kran specifikationshæfte. Trykket på overtryksventilen må ikke justeres til større tryk end angivet. Justering må kun foretages af kvalificeret personer.

Bemærk: Pumpen ændrer ofte lyd, når olien er suget rigtigt an og varm.

- Alle nipler gennemsmøres jævnligt, her anbefaler vi EP2, hvis fedtet ikke kan presses igennem niplerne, kontaktes et autoriseret værksted.
- Udskudsarme skal altid være belagt med fedt EP2, se smørings oversigt i kran specifikationshæftet.
- Alle stempelstænger holdes rene for snavs og olieres let.
- Udluftning af systemet
  luft i hydraulik systemet forårsager unormalt stort slitage samt funktionsproblemer, det er derfor vigtigt at dette gøres omhyggeligt. Pumpen startes og alle udluftningsventiler åbnes og alle højt placerede fittings og forskruninger løsnes en ad gangen, disse lukkes igen når ren luft- og skumfri olie trænger ud. Alle retningsventiler betjenes en efter en flere gange, indtil olien i tanken er luft- og skumfri. Hver funktion aktiveres indtil den kører fejlfrit med jævn rotation eller lineær bevægelse. Udluftningen foretages indtil alt er skumfrit, og der ikke optræder megen støj fra systemet, hvilket ofte er et tegn på mere luft, hvorefter udluftningen forsættes. Hyletoner fra pumpen er et typisk tegn på luft i olien.

### 5.2.3 Daglig vedligehold

- Dokumenter tilhørende kranen skal altid forefindes sammen med kranen, og skal mod forlangende kunne forevises for relevant myndighed.
- Visuel kontrol for revner og misdannelser i svejsninger og materialet. Hvis der findes noget, må kranen ikke anvendes inden den er vurderet af en kvalificeret/sagkyndig person.
  Kontakt evt. TMP Hydraulik A/S på tlf. +45 97 87 19 00.
- Visuel kontrol af tilhørende løfteudstyr, som sjækler, sling, kæder, bolte osv. Der skal anvendes godkendt løfteudstyr. Hvis udstyret ikke er lovpligtig godkendt, må udstyret ikke anvendes inden udstyret er godkendt eller udskiftet med godkendt udstyr.
  Kontakt evt. TMP Hydraulik A/S på tlf. +45 97 87 19 00.
- Alle bevægelige dele skal kontrolleres for funktionalitet, dvs. bevægelige dele skal til enhver tid være fuldt funktionsdygtige.
- Kontroller at bolte, møtrikker, dorne osv. er fastspændte.
- Ved udskiftning af rør, bolte, kroge, wire osv. skal det sikres at ombytningen sker med tilsvarende kvalitet eller bedre.
- For at undgå korrosion bør malingen altid være intakt og vedligeholdt.
- Ved tab eller beskadigelse af typeskilt, må kranen ikke anvendes før den er positivt identificeret og skiltet er reetableret.
  Kontakt evt. TMP Hydraulik A/S på tlf. +45 97 87 19 00.

# 6 Konklusion

- Kranen er analyseret med henblik på at imødegå de stillede krav. Det konkluderes at kranen lever op til de stillede krav og er sikker at anvende, såfremt brugeren overholder brugs- og sikkerhedsanvisningerne, og ikke overskrider max WLL, som er nævnt i kran specifikationshæftet, eller foretager ændringer på kranen eller tilbehør hertil.
- Brug og afvigelser fra dette dokument, bortfalder straks enhver garanti givet af TMP Hydraulik A/S.

# 7 fejlfinding

| | |
|---|---|
| Kranen kan ikke køre. | Tjek tilslutningen hydraulik/el og olieniveau i tanken. |
| Kranen har ujævne bevægelser. | Pumpen suger luft. |
| Pumpen støjer. | Kontakt autoriseret reparatør. |

| | |
|---|---|
| Kranen køre i ryk. | Luft i olien.<br>For lidt olie i tanken.<br>Forsnævring i hydrauliksystemet. |
| Olien skummer. | |
| Olien overophedes. | |
| Støj i hydrauliksystemet. | |
| Slangerne slår eller vibrerer. | |

| | |
|---|---|
| Kranen kan ikke løfte fuld last. | Kontakt autoriseret reparatør. |

| | |
|---|---|
| Én ventilfunktion går ikke i neutral. | Håndtagshus på ventil smøres |
| | Kontakt autoriseret reparatør. |

| | |
|---|---|
| Én ventilfunktion vil ikke køre. | Tjek ledning til el modul |
| | Tjek om håndtag på ventil giver udslag. |
| | Kontakt autoriseret reparatør. |

| | |
|---|---|
| Kranen har nedsat løfteevne. | Kontakt autoriseret reparatør. |
| Kranbevægelser er langsomme. | |
| Udskud vil ikke køre. | |
| Hovedtryk svinger kraftigt op og ned. | |

| | |
|---|---|
| Kranen synker ved belastning. | Defekt lastholderventil |
| Kranen blokerer under sænkning | Kontakt autoriseret reparatør. |

| | |
|---|---|
| Knæklyde fra cylinderne | Stempelstænger er tørre. Afhjælpes ved at påføre stempelstængerne lidt olie. |
| Knæklyde fra kranarmens lejebolte, når kranen belastes | Foretag smøring af lejebolte. |


| | |
|---|---|
| Udskudsarme har stor nedbøjning ved belastning. | Slidplader slidt og skal udskiftes. |


| | |
|---|---|
| Olie løber ud af top fundament forsaget af vand i fundament. | Fjern bundprop, lad vand løbe ud indtil der kommer olie, og monter bundprop. |
| Olie løber ud af top fundament forsaget af utæt drejecylinder. | Fjern bundprop, og der kommer olie. Drejecylindere utæt. Kontakt autoriseret reparatør. |

| | |
|---|---|
| Wire på spil bygger sig op i den ene side af tromlen. | Afstand mellem spil og wireblok er for kort. |
| | Krogvægt er for lille, så krogvægten ikke kan holde wiren stram. |


# 8 Hydraulikdiagrammer


## K + KL kran med spil




Pumpe
Tank
Sving
Lift
Winch w.brake

L + XL kran med spil




DRÆN
NED
DOWN
OP
UP
LS
A
P
T

# Bilag indhold

Bilag indeholder tekniske data og datablade fra benyttede underleverandører på fx pumpe, ventiler, fjernstyring, spil osv.

## Bilag 1
Scanreco fjernstyring

## Bilag 2
Ventil

## Bilag 3
Spil

## Bilag 4
Drejekrans

## Bilag 5
Svinggear

GB

# Translation of original documentation

## Use and maintenance instructions

## TMP Kran type K, L, XL, KL, LS

**Supplier:**

TMP Hydraulik A/S
Suurkjærvej 9
7790 Thyholm
Denmark


Phone: +45 9787 1900
Mail: tmp@tmphydraulik.dk

Version 2/2020

# Introduction

It is essential for the safety that the user reads and understands this user manual, and its maintenance instructions.

The following pictograms have been used through the guide:




This instruction manual contains documentation for the product described in crane specifications book.

The purpose of the document is to conform to the standards below.

## List of relevant standards

This list includes standards that completely or partly are followed in the manufacturing.

- *Maskindirektivet 2006/42/EF*
- *DS/EN 13001-3-1*
- *EN 13852-1*

# 1 Original overensstemmelses-/komponent erklæring
# Original Declaration of Conformity/component

| | |
|---|---|
| **Fabrikant/ Manufacturer** | TMP Hydraulik A/S |
| **Adresse / Address** | Suurkjærvej 9, 7790 Thyholm |
| **Land / Country** | Denmark |
| **Telefon nr. / Phone no.** | + 45 97 87 19 00 |
| **CVR nr. / company registreings no.** | 26642078 |

## -Erklære herved at /- Declare that:

| | |
|---|---|
| **Produkt navn / product name:** | TMP kran / TMP crane |
| **Type nr. / type no.** | TMP kran K, L, XL, KL og LS |

| | |
|---|---|
| **-Er fremstillet i overensstemmelse med eller dele af:**<br>• *Maskindirektivet 2006/42/EF*<br>• *DS/EN 13001-3-1*<br>• *EN 13852-1* | ***-Is manufactured according to or parts of:***<br>• *The Machinery Directive 2006/42 / EC*<br>• *DS/EN 13001-3-1*<br>• *EN 13852-1* |

Sted og dato / Place and date: Thyholm 07.10.2019

Underskrift og firmastempel / signature and company stamp:

TMP Hydraulik
KRANER, SPECIALMASKINER & LIFTTEKNIK
TLF. 97 87 19 00

**TMP Hydraulik A/S, Suurkjærvej 9, 7790 Thyholm DK, eller stedfortræder herfor, har bemyndigelse til at udlevere de tekniske dossier / TMP Hydraulik A / S, Suurkjærvej 9, 7790 Thyholm DK, or its representative, is authorized to hand over the technical files.**

# 2 Product description

## 2.1 Type:

| | |
|---|---|
| Name | TMP Sea crane |
| Type | TMP kran type K, L, XL, KL og LS |

## 2.2 Standard technical data:

The crane is made of high-strength steel, which is sandblasted, metallized and painted with 2-component paint. All piston rods, bolts and pipes are made of stainless steel. Foundation and swing are filled with oil to prevent water and corrosion. All couplings are coated with corrosion protection tape as standard.

If the crane is equipped with winches, an adjustable wire protection system is fitted as standard.

## 2.3 Intended use:



The TMP marine crane is designed and manufactured for mounting on fishing boats.

The crane is used to lift and lower various loads hanging in the hook.



The crane must be approved and dimensioned to lift the load
and associated sling / chains / shackles, etc.

The maximum load on the crane must never be exceeded. If additional accessories such as winch are fitted, it will be the winchs max. WLL that applicable

The crane must never be used for other purposes and must be securely mounted.



Use that does not comply with the instructions for use may involve hazards to the operator, persons nearby and the crane, etc.
And this will result the loss of any form of responsibility and guarantee from
TMP Hydraulik A/S.

# 3 Load

## 3.1 Load example

The crane is in normal operation, exposed to the following stress. Normal operation means lifting and lowering operations are carried out in hook mounted on the crane.

- Vertical and horizontal load.
- The load consists of hanging load.
- The load is vertically suspended below the product.

# 4 Safety



- It is the person in charge of the work who is responsible for ensuring that the product is approved and properly maintained and does not endanger operators / users.
- It is the operator's responsibility that personal protective equipment is intact and used.



- It is the person in charge of the work who is responsible for ensuring that all operators are properly equipped with personal protective equipment and have access to the user and maintenance instructions.
- Unauthorized persons must not operate the product.



- Particular caution when using the product around power and high voltage cables, the product is not insulated and there is direct grounding through the operator.

## 4.1 Safety of load



- The load as mentioned in point 3.1 is assured by max WLL as mentioned in crane specifications book, this must not be exceeded.
- It must be ensured that the load hangs so that the load is evenly distributed vertically and horizontally.
- All loops / chains / hooks / wire etc. must be approved for upcoming lifting and be included in the weight of the load.



- For each lift, the load and distance to the crane must be checked according to the crane lift diagram, crane specifications book. The crane must not tilt more than 5 degrees when full capacity is utilized, as stability decreases significantly when the crane is inclined.
- Unauthorized persons must not stay in the crane's working area.
- Do not leave the crane loaded.



- For every lift, the load and distance must be checked, according to the lifting diagram
- Unauthorized persons must not be in the work area of the product.
- Do not leave the product loaded.
- Avoid the load from swinging.



- The product must not be used for negative load i.e. used as pile driver, weight or other kind of pressure against the ground or other objects.
- The product or parts may not be supported by other equipment under load.
- If you installed other equipment, always be protected against overload and locked with dedicated and approved equipment.

## 4.2 Safety for users



- The user must be thoroughly instructed in the use and application of the product.
- The user must read the instructions carefully.
- It is forbidden and associated with life-threatening to go under hanging burden.
- The user must ensure a clear view, overview and tidiness of the work area to avoid danger and damage.
- Users should show extra attention when moving within the work area to avoid danger and damage.
- The user must wear personal protective equipment.
- There may be sharp edges and corners on the product that can cause damage / accidents to things and persons.





## 4.3 Warnings and other important regulations

Hydraulic oil and grease can be harmful to health and the environment. Therefore, it is important to follow the oil manufacturer's instructions and data sheets.

- Physical contact with the oil and grease can cause allergies, lung disorders, etc.
- High pressure oil leakage can cause significant damage to objects and persons.
- When starting up installations where safety valves etc. must be adjusted, Watch out for sudden oil jets. use protective equipment.
- If the system must be disconnected, even if it has been stopped, static pressure may occur from the accumulator, compressed oil, etc. This can cause sudden very hot oil jets that can cause scalding / caustic of the skin.
- In case of oil leakage, the system must be stopped immediately and oil spills must be reduced as much as possible and reported to the correct authority.










## Other important regulations!



- If the cover for the connection box on the electric motor is removed and / or the plug on the solenoid valves is removed, the safety / main switch on the power supply cable MUST be switched off and locked.
- All electrical connections, e.g. electric motor, solenoid valves, must be made by an authorized electrician.



# 5 Instructions

## 5.1 User instruction



It is important for the user to read and understand this user and maintenance manual, for the sake of the safety of the user and the environment and the stability and operation of the product.

### 5.1.1 Before use

Before use the user must ensure:

- Read the documentation on the product carefully.
- No visible damage to the product.
- All moving parts must be freely movable.
- The name/type plate must be intact.
- The load in the upcoming lift must be estimated to WLL described in crane specifications book.



### 5.1.2 Installation / configuration / preparing

- The crane must be mounted in a secure foundation.
- Connect the crane to electrical / hydraulic. The connection must be made by authorized personnel.
- Make sure everything is connected properly.



### 5.1.3 Commissioning

- After reading the documentation and mounting the crane, the crane is ready for use.
- See operating instructions to various accessories in appendix

### 5.1.4 After use

- Check the crane for any errors and damage.
- Pack the crane and place in parking position.
- If the crane is left unused for a long time, all cylinders are driven together, and all unpainted parts are lubricated with oil.

### 5.1.5 Emergency situation

- In case of an emergency, the product must be stopped immediately, and the situation must be estimated by the person responsible for the work.
- The burden is lowered to the ground, without making the situation worse.
- The Internal guidelines for accidents / emergencies must be followed.

## 5.2 Maintenance instruction

It is important to follow the service / maintenance instructions below, this helps to increase reliability.



### 5.2.1 Statutory maintenance



- The product must be inspected and approved at least once every 12 months.
- The Inspection must be carried out by a qualified / expert person.
  You can contact TMP Hydraulik A / S +45 97 87 19 00.

### 5.2.2 Regular maintenance

- Oil and filter must be changed at least once a year, or in constant and heavy loads up to 4 times a year. Here we recommend Texaco HDZ32 or equivalent.
- For optimum life, dirt in the oil should be avoided. Therefore, since during run-in and start-up, a large amount of worn particles are produced from all moving parts, the system should not be fully loaded until all dirt is separated from the filters, which is changed at least once a year.
- At low temperatures (below +10 degrees), all functions must be run through, to heat the hydraulic oil.
- Check the correct filling and condition of the oil.
- Check the system, components, hoses, fittings, additional equipment etc. for oil leaks and tighten.
- In case of accident, damaged hoses, pipes, wire etc. must be replaced immediately.
- The overpressure valve is sealed to the specified pressure described in the corresponding crane journal / certificate. The pressure on the pressure relief valve must not be adjusted to greater pressure than indicated. Adjustment may only be made by qualified persons.

  Note: The pump often changes sound when the oil is properly and warm.

- All nipples are greased regularly, here we recommend EP2, if the grease cannot be pushed through the nipples, contact an authorized workshop.
- Extension arms must always be coated with grease EP2, see lubrication table in crane specificationbook.
- All piston rods are kept clean of dirt and lightly oiled.
- Venting the system
  Air in the hydraulic system causes abnormally large wear and function problems, so it is important to do this carefully. The pump is started, and all venting valves are opened and all high-placed fittings and gaskets are loosened one at a time, these are closed again when clean air and foam-free oil penetrate. All directional valves are operated one by one several times until the oil in the tank is air and foam free. Each function is activated until it runs smoothly with smooth rotation or linear motion. The venting is continued until the oil is foam-free and there is no discord from the system, which is often a sign of more air, after which the venting is continued. Whistling sounds from the pump are a typical sign of air in the oil.

### 5.2.3 Daily maintenance

- Documents belonging to the crane must always be provided with the crane and must be presented to the relevant authority by request.
- Visual inspection for cracks and deformities in welds and material. If something wrong the product must not be used before it is evaluated by a qualified / competent person.
  Contact TMP Hydraulik A/S +45 97 87 19 00.
- Visual inspection of associated lifting equipment, such as shackles, sling, chains, bolts, etc. only approved lifting equipment must be used. If the equipment is not legally approved, the equipment must not be used before it is approved or replaced with approved equipment.
  Contact TMP Hydraulik A/S +45 97 87 19 00.
- All moving parts must be checked for functionality, i.e. moving parts must always be fully functional.
- Check that bolts, nuts, mandrels, etc. are tightened.
- When replacing pipes, bolts, hooks, wire, etc., it must be ensured that the replacement takes place with similar quality or better. See spare part list / drawing in appendix.
- To avoid corrosion, the paint should always be intact and maintained.
- In case of loss or damage to the name/type plate, the product should not be used until it has been positively identified and the plate is re-established.
  Contact TMP Hydraulik A/S +45 97 87 19 00.

# 6 Conclusion

- The crane has been analyzed in order to the requirements settings. It is concluded that the product complies with the requirements and is safe to use, if the user complies with the use and safety instructions and does not exceed the maximum WLL mentioned in crane specifications book. or make changes to the crane or its accessories.
- Use and deviations from this document will immediately cancel any guarantee given from TMP Hydraulik A/S.

# 7 troubleshooting

| | |
|---|---|
| The crane cannot run.<br>The crane has irregular movements.<br>The pump makes noise. | Check the hydraulic / electricity connection and oil level in the tank.<br>The pump sucks air.<br>Contact authorized service center. |

| | |
|---|---|
| The crane run in jerky.<br>The oil foams.<br>The oil overheats.<br>Noise in the hydraulic system.<br>The hoses strike or vibrate. | Air in the oil.<br>Too little oil in the tank.<br>Narrowing in the hydraulic system. |

| | |
|---|---|
| The crane cannot lift full load. | Contact authorized service center. |

| | |
|---|---|
| One valve function does not go into neutral. | Lubricate handle housing on valve.<br>Contact authorized service center. |

| | |
|---|---|
| One valve function will not run. | Check cable for electrical module<br>Check the handle on the valve has an impact.<br>Contact authorized service center. |

| | |
|---|---|
| The crane has reduced lifting capacity.<br>Crane movements are slow.<br>Extending arms will not run.<br>Main pressure varies up and down. | Contact authorized service center. |

| | |
|---|---|
| The crane falls under load.<br>The crane blocks during lowering | Defective load carrier valve<br>Contact authorized service center. |

| | |
|---|---|
| Creaking sounds from the cylinders | Piston rods are dry. To remedy, apply a little oil to the piston rods. |
| Cracking noises from the crane arm bearing bolts when the crane is loaded | Lubricate the bearing bolts. |


| | |
|---|---|
| Extension arms have great deflection at load. | Wear plates worn and need to be replaced. |


| | |
|---|---|
| Oil flows out of the top foundation caused by water in the foundation. | Remove bottom plug, allow water to drain until oil comes, and install bottom plug. |
| Oil flows out of the top foundation caused by leaky rotation cylinder. | Remove bottom plug and oil will come. Rotary cylinders leaking. Contact authorized service center. |

| | |
|---|---|
| Wire at stake builds up on one side of the drum. | Distance between winch and wire block is too short.<br>The hook weight is too small, so the hook weight cannot keep the wire tight. |


# 8 Hydraulic Diagrams


## K + KL crane with winch




Pumpe
Tank
Sving
Lift
Winch w.brake

L + XL crane with winch




DRÆN
NED
DOWN
OP
UP
LS
A
P
T

# Appendix content

Appendix contains technical data and data sheets from used subcontractors on eg pump, valves, remote control, winch etc.

## Appendix 1
Scanreco remote

## Appendix 2
Valve

## Appendix 3
Winch

## Appendix 4
Slewing ring

## Appendix 5
Gear motor

SCANRECO
Radio Remote Control

# Betjeningsvejledning
## Fjernbetjeningssystem Scanreco RC-400






| Document | Revision | Language |
|---|---|---|
| 66038 | C | Dansk |

Bilag 1

# Indhold

**1 Generelt ..... 3**
1.1 Terminologi 3

**2 Forord ..... 4**
2.1 Generelle oplysninger 4

**3 Generel systembeskrivelse ..... 5**
3.1 Skematisk oversigt over Scanreco RC-400 5
3.2 Generel beskrivelse af Scanreco RC-400 6
3.3 Den bærbare kontrolenhed (PCU) 7
3.4 Centralenhed (CU) 13
3.5 Ventil- og tilslutningskabler 15
3.6 Funktionsboks for kranstop (ekstraudstyr) 19
3.7 Batteri 20
3.8 Batterioplader og batteriopladning 22

**4 Sikkerhedsbestemmelser og betjeningsanvisninger ..... 25**
4.1 Sikkerhedsbestemmelser 25
4.2 Betjeningsanvisninger 26

**5 Installationsanvisninger ..... 27**
5.1 Generel oversigt over RC 400 27
5.2 Vigtig bemærkning under svejsning 27
5.3 Placering af centralenheden 27
5.4 Anbefalinger for montering 28
5.5 Monteringsvejledning for kabelsæt 29

**6 Fejlfinding ..... 31**
6.1 Generelle oplysninger 31
6.2 Angivelser på den bærbare kontrolenhed 31
6.3 Angivelser på centralenheden 33
6.4 Systemet fungerer ikke 35

**7 Programmering af parametre og indstillinger ..... 36**
7.1 Generel beskrivelse 36
7.2 Autorisationsniveau 1 37

Alle rettigheder forbeholdes.

Design, udstyr, tekniske data and specifikationer kan blive ændret eller forbedret uden varsel. Teksten i denne vejledning eller nogen del heraf må ikke reproduceres eller overføres i nogen form eller på nogen måde, elektronisk eller mekanisk, herunder fotokopiering, optagelse, lagring i et datalagringssystem, eller på anden vis uden forudgående skriftlig tilladelse fra Scanreco AB, Sverige.

# Dokumentoplysninger

| Attribut | Information |
|---|---|
| Dokumenttype | Vejledning |
| Titel | Betjeningsvejledning |
| Undertitel | Fjernbetjeningssystem Scanreco RC-400 |
| Dokumentnummer | 66038 |
| Revision | C |
| Revisionsdato | 25-09-2009 |

# Revisionshistorik

| Revision | Dato | Navn | Bemærk |
|---|---|---|---|
| A | 09-12-2008 | SCANRECO AB | Første udgave af dokument |
| B | 15-06-2009 | SCANRECO AB | |
| C | 25-09-2009 | SCANRECO AB | |

# 1 Generelt

## 1.1 Terminologi

| Forkortelse | Beskrivelse |
|---|---|
| PCU | Bærbar kontrolenhed |
| CU | Central enhed |
| LED | Lysdiode |
| DV | Vippeventil |

# 2 Forord

## 2.1 Generelle oplysninger

Denne vejledning er beregnet som et supplement til kran/maskinvejledningen og dækker Scanreco RC 400 Fjernbetjeningssystem.

Scanreco RC 400 tilbyder føreren et ekstremt avanceret fjernbetjeningssystem med optimal hastighed, præcision, styring og sikkerhed.

Af hensyn til din sikkerhed og holdbarheden af din kran/maskine skal du læse og sætte dig ind i disse instruktioner. På denne måde kan du hurtigt lære det nye fjernbetjeningssystem at kende og finde ud af, hvordan du bedst udnytter det.

- Fjernbetjente kraner kan kun betjenes af kvalificerede medarbejdere. Føreren skal være opmærksom på indholdet af kapitel 4 "Sikkerhedsbestemmelser og betjeningsanvisninger", før enheden betjenes. Der kan forekomme alvorlige ulykker, hvis disse anvisninger ikke bliver fulgt.
- For at beskytte den bærbare kontrolenhed mod skader og af sikkerhedsmæssige hensyn, skal kontrolenheden opbevares i et lukket skab.
- Følg anvisningerne i kranvejledningen angående flytning af kranen fra parkeringspositionen, optimal armplacering under håndtering af last og parkering af kranen.
- På grund af de ubegrænsede variationer af kraner, maskiner, genstande, køretøjer og udstyr, som fjernbetjeningssystemet kan bruges til, og de utallige standarder, som ofte udsættes for varierende fortolkninger, er det umuligt for medarbejderne hos Scanreco at tilbyde ekspertrådgivning angående en given fjernbetjenings egnethed til et bestemt formål. Det er køberens ansvar at konstatere ethvert Scanreco-fjernbetjeningsprodukts egnethed til et tilsigtet formål og sikre, at det er installeret og afskærmet ifølge alle nationale, føderale, statslige, lokale og private sikkerheds- og sundhedsmæssige bestemmelser, koder, standarder og Scanreco-anbefalinger (denne vejledning). Hvis Scanreco RC 400 skal anvendes i et sikkerhedsmæssigt kritisk formål, skal kunden/føreren foretage relevant test og evaluering for at forhindre skader på den endelige bruger. Scanreco tager ikke ansvaret for eventuelle skader eller personskader.
- Uautoriseret håndtering af Scanreco ophæver automatisk garantien.

**Til operatøren:**

Hold en kort pause og tag dig tid til at læse kapitel 3 (Generel systembeskrivelse) og 4 (Sikkerhedsbestemmelser og betjeningsanvisninger).

**Til installatøren:**

Hold en pause og tag dig tid til at læse kapitel 5 (Installationsanvisninger) og "Inspektions-/installationsdokumenter".

# 3 Generel systembeskrivelse

## 3.1 Skematisk oversigt over Scanreco RC-400




Skematisk oversigt over Scanreco RC-400.

**Leveringens generelle omfang (se din specifikation og Figur 3.1).**

| Nr. | Beskrivelse | Antal |
|---|---|---|
| 1 | Bærbar kontrolenhed (PCU) | 1 |
| 2 | Centralenhed (CU) | 1 |
| 3 | Batterioplader | 1 |
| 4 | Batterikassette (NiMH 7.2 VDC) | 2 |
| 5 | Manøvreringskabel (10 meter) | 1 |
| 6 | Nødstopboks (ekstraudstyr) | 1 |
| 7 | Kabelsæt med forsyningskabler + digitale udgange | 1 |
| 8 | Kabelsæt med ventilkabler (analoge udgange) | 1 |

## 3.2 Generel beskrivelse af Scanreco RC-400

Scanreco RC 400-fjernbetjeningssystemet er udviklet specielt til hydraulisk drevne mobilkraner og maskiner. Systemet er et digitalt fjernbetjeningssystem, der er baseret på en ekstremt avanceret mikroprocessorteknologi. Flere års udmattende og krævende tests har vist, at fjernbetjeningssystemet kan klare selv de mest barske forhold.

Systemet er beskyttet mod elektromagnetisk og radiofrekvensudstråling og kan installeres på alle hydraulikventiltyper (strømspænding, aktuel pulsbredde eller protokolstyring), som findes på markedet.

I sin grundlæggende form består fjernbetjeningssystemet af en bærbar kontrolenhed med styregreb til proportional styring og kontakter til tænding/slukning af funktioner, en centralenhed med tilslutningskabel til brug af proportionale elektrohydrauliske kontrolenheder med skyderindstilling.

Digitalt kodede kontroloplysninger (håndtagsafvigelse og kontaktposition) sendes fra kontrolenheden via et elektrisk kabel eller via radio til centralenheden. Kontrolenheden og centralenheden oversætter omfanget og retningen for styregrebets afvigelser og kontaktpositioner til den tilsvarende ventilfunktion, hastighed og retning og dermed kranens bevægelser.

**Vigtig bemærkning:**

Scanreco-fjernbetjeningssystem RC-400, som er beskrevet i denne brugsvejledning, må ikke forveksles med de tilsvarende Scanreco-fjernbetjeningssystemer RC-400 G4, eftersom hovedkomponenterne i disse to systemtypers produktfamilie (bærbare kontrolenheder og centralenheder) ikke er kompatible med hinanden og varierer med hensyn til udseende og funktioner.

## 3.3 Den bærbare kontrolenhed (PCU)

Den bærbare kontrolenhed er en stødsikker, vejrresistent og kompakt letvægtsmodel. De bærbare kontrolenheder kan være lineære greb eller joysticks (se Figur 3.2 nedenfor).



Figur 3.2 Det tilgængelige interval for bærbare kontrolenheder.

| Nr. | Beskrivelse |
|---|---|
| 1 | MAXI-Joystick er tilgængelig for 1-8 (Konfiguration: 2-0-2 / 2-2-2 / 2-3-2 / 3-2-3 / 3-0-3). |
| 2 | MAXI-Linear er tilgængelig for 1-8 lineære greb |
| 3 | MINI-Joystick er tilgængelig for 1-6 (Konfiguration: 2-0-2 / 2-2-2). |
| 4 | MINI-Linear er tilgængelig for 1-6 lineære greb |

Styregrebene og joystickene er fuldt proportionale og har en fjederreturneringsfunktion, som nulstiller positionen, dvs. "dødemandshåndtag". Kontrolenhederne har en stopfunktion, som straks standser al bevægelse.

Alle styregreb/joystick er beskyttet af en sikkerhedsramme, som forhindrer utilsigtet aktivering og mekanisk beskadigelse. Kontrolenheden har som standard flertrinsbetjening med mikrohastighed, som muliggør en øjeblikkelig midlertidig hastighedssænkning. Den kan også udstyres med en lang række kontakter til tænding/slukning af funktioner. En LED-indikator og et lydsignal anvendes til f.eks. at angive betjenings- og batteristatus og sikre en enkel fejldiagnosticering (se Figur 3.4).

### 3.3.1 Anvendelse af batteri

Der er placeret et batteri i den nederste del af kontrolenheden, som anvendes til betjening af radiostyringen. Det er meget let at skifte.

- Batteriets effektive driftstid er ca. 8 timer på en opladning.
- Når batteriet snart skal oplades, bipper kontrolenheden tre (3) gange til varsel, og samtidigt begynder LED-indikatoren at blinke på kontrolenheden.
- Batteriet skal benyttes, indtil LED-indikatoren slukker. Derefter kan det oplades. Hvis batterikapaciteten er for lav, kan kontrolenheden ikke aktiveres.
- Batterikapaciteten og den driftsmæssige ydeevne reduceres ved meget kolde vejrforhold. Batteriet oplades automatisk under anvendelse med kabelstyring.
- For at reducere behovet for batteriopladning og øge sikkerheden slukkes kontrolenheden automatisk, når enheden ikke har været i brug i mere end ca. fem (5) minutter.

### 3.3.2 Styregreb/joystick

Kontrolenhed består af styregreb til proportional styring, kontakter til tænding/slukning, mikrobetjening og stopfunktion (se særskilte overskrifter



Figur 3.3 Oversigt over PCU-panel.

### 3.3.3 Panel for stopfunktion

Der er en rød stopfunktionskontakt (**STOP**) med manuel drejeknap til nulstilling, en trykknap og en rød LED-indikator på kontrolenhedens stopfunktionspanel, se Figur 3.4.

Kontrolenheden aktiveres med fjedertrykknappen til nulstilling (◈)
Al bevægelse af kranen standses, hvis stopfunktionen aktiveres på kontrolenheden.
Den røde LED-indikator angiver betjenings- og batteristatus.




Figur 3.4 Visning af stopfunktionspanel.

### 3.3.4 Ændring af radiokanaler

Det er muligt at ændre radiokanalen ved at trykke hurtigt to gange på knappen ◈.
Der findes 10 forskellige radiokanaler, hvor du kan skifte mellem dem ved at trykke på denne knap flere gange.

**Vigtig bemærkning:**

I slutningen af 2009 introducerede Scanreco automatisk frekvensstyring i RC400-systemerne og gjorde dermed den funktion overflødig, som er nævnt i kapitel 3.3.4 Ændring af radiokanaler.

Den automatiske frekvensstyring sikrer en mere pålidelig radiotransmission, som er meget modstandsdygtig over for interferens, i kraft af den intelligente frekvensændringsteknologi til automatisk håndtering af frekvensændringer.

Operatøren behøver ikke længere styre radiofrekvensen og risikoen for interferens er minimeret.

Denne brugervejledning er trykt før introduktionen af automatisk frekvensstyring. Kontakt venligst din distributør for at få yderligere oplysninger.

### 3.3.5 Kontaktpaneler

Kontakterne på kontaktpanelet muliggør aktivering af digitale funktioner via vippekontakter og tryknapper (se Figur 3.5 og 3.6). Digitale funktioner kan anvendes til styring af tænding/slukning af elektriske, hydrauliske og pneumatiske funktioner. Eksempler på funktioner:

- Stop og start af køretøjets motor, gearstang, bip/signal, omstillingsventiler, funktionsændring f.eks. for 7. og 8. funktion osv.

Sørg for altid at vide, hvilke digitale funktioner der er tilsluttet kontrol af tænding/styring.




Figur 3.5 Venstre kontrolpanel på MAXI PCU.




Figur 3.6 Venstre kontrolpanel på MINI PCU.

### 3.3.6 Styring af mikrohastighed

Denne returfjederkontakt kan anvendes til at reducere driftshastigheden i fem (5) trin fra 100 % til 60 %, 50 %, 40 %, 30 % og 20 % ved begrænsning af hydraulikstyringen. Reguleringen af funktionens hastighed foretages stadig over hele grebets bevægelse og med samme fasthed.

- Når du trykker fjederkontakten til venstre i retning af skildpadden , kan reduktionen af hastigheden ændres fra 100 % til 60 %, 50 %, 40 %, 30 % og 20 % styrekraft.
- Når du flytter kontakten til højre i retning af kaninen , genetableres 100 % styrekraft.
- Af sikkerhedsmæssige årsager kan genetablering af 100 % styrekraft kun foretages, hvis alle styregreb er nulstillede.
- Når den grønne LED-indikator blinker, aktiveres mikrohastighedsfunktionen. Antallet af blink angiver driftshastigheden ifølge tabellen nedenfor. **Hvid du aktiverer stopfunktionen på kontrolenheden, begynder kontrolenheden ved den sidst valgte hastighed.**

| **Grøn LED** | **Indikation** |
|---|---|
| lyser ikke | 0 - 100 % hastighed (normal hastighed) |
| 1 blink hvert 3. sekund | 0 - 60 % hastighed |
| 2 blink hvert 3. sekund | 0 - 50 % hastighed |
| 3 blink hvert 3. sekund | 0 - 40 % hastighed |
| 4 blink hvert 3. sekund | 0 - 30 % hastighed |
| 5 blink hvert 3. sekund | 0 - 20 % hastighed |

### 3.3.7 Kabel til kabelstyring

Kontrolenheden kan tilsluttes centralenheden via et tyndt og fleksibelt 5-trådet kabel. Kablet har runde stik (M12) i hver ende.

Kablet overfører digitalt kodede kontroloplysninger fra den bærbare kontrolenhed til centralenheden. Kablet fås i standardlængder á 10 meter.

| **Bennr.** | **Funktion** |
|---|---|
| 1 | Data |
| 2 | GND (jord) |
| 3 | RS232 TX |
| 4 | RS232 RX |
| 5 | +24 V jævnstrøm |

### 3.3.8 Tekniske data (PCU)

| **Element** | **Tekniske data** |
|---|---|
| Batteri | 7,2 V jævnstrøm |
| Bærbar kontrolenheds effektive driftstid | Ca. 8 timer pr. opladning |
| Vægt/MAXI/Lineær | 1,95/2,20 kg (uden/med batteri)* |
| Vægt/MAXI/Joystick | 1,75/2,00 kg (uden/med batteri)* |
| Vægt/MINI/Lineær | 1,45/1,70 kg (uden/med batteri)* |
| Vægt/MINI/Joystick | 1,30/1,55 kg (uden/med batteri)* |
| Størrelse MAXI (BxHxD) | 350x160x190 mm* |
| Størrelse MINI (BxHxD) | 290x160x190 mm* |
| IP-klasse | IP65 |
| Omgivelsers temperatur (Celsius/Fahrenheit) | -25 til +70° C/ca. -15 til +160° F |

* Vægt og størrelse er omtrentlige angivelser, der er afhængige af konfigurationen.

## 3.4 Centralenhed (CU)

Centralenheden er fremstillet af plastik og leveres med stik til tilslutning til den bærbare kontrolenhed (ved kabelbaseret fjernbetjening), til strømforsyning, de elektrohydrauliske omskifterventiler, vippeventil og tænd/sluk-funktioner.

Eftersom centralenheden kan blive udsat for meget barske forhold, er boksen indkapslet for at beskytte den mod fugt, varme, kulde, støv, rystelser og korrosion.

Centralenheden indeholder ind- og udgange, som er sikrede mod kortslutning, og er beskyttet mod polaritetsvending, overspænding, stor indgående spændingsovergange og EMC/RF. Tilslutningen af centralenheden kan derfor foretages uden risiko for skader. Den leverede centralenhed er beregnet til strømspændinger på +12/+24 V jævnstrøm (+/- 20 %) med negativ jordforbindelse. Der er anvendt en standardbilsikring i centralenheden.

**Plus-sikring: + 10 Amp.**

Der kan også benyttes en transformer, hvis der anvendes almindelig strømforsyning til centralenheden. Primær spænding: 110, 115, 220-240, 380, 440 V vekselstrøm og sekundær spænding + 12/+24 V jævnstrøm (+/- 10 %).

Centralenheden er udstyret med:

1. Standardantenne
2. Omskifter for driftstilstand (fjern/manuel: Se kapitel 4.2 Betjeningsanvisninger)
3. Kabelstik til kabelkontrol/programmeringsport
4. Statusindikatorer (LED)
5. 7-delt LED-display




### 3.4.1 Tekniske data (CU)

| Element | Tekniske data |
|---|---|
| Strømspænding | 12/24 V jævnstrøm (+/- 20 %/maks. 5 % V spidseffekt-til-spidseffekt) |
| Intern sikring | Plus: + 10 Amp. (Standardbilsikring/rød) |
| Maks. overspænding | Ca. 33 V jævnstrøm (sikring springer) |
| Proportionale funktioner | 1 - 8 proportionale dobbeltfunktioner |
| Vippeventildrev | Maks. 2,0 Amp (sikring mod kortslutning) |
| Tænd/sluk-drev | Maks. 1,8 Amp (sikring mod kortslutning) |
| Reguleringssignaler | Spænding eller PWM (andet efter anmodning) |
| Strømforbrug når ledig | 40 mA |
| Vægt | 1,20 kg (ventil- og tilslutningskabler ikke inkluderet) |
| Størrelse (BxHxD) | 227x205x78 mm |
| IP-klasse | IP65 |
| Omgivelsers temperatur (Celsius/Fahrenheit) | -25 til +70° C/ca. -15 til +160° F |


## 3.5 Ventil- og tilslutningskabler

Der findes flere forskellige tilslutningskabler, afhængigt af de anvendte ventiler og ekstrafunktioner. I Figur 3.8 vises et eksempel på et kabelsæt til Danfoss-ventiler.




Figur 3.8 Et eksempel på et kabelsæt til Danfoss-ventiler.

### 3.5.1 Terminaltilslutninger




Figur 3.9 Figuren illustrerer de indvendige terminaltilslutninger for standardcentralenheder af type 2000 (Danfoss) og type 3000 (PWM).

**Vigtig bemærkning:**

Hvis en centralenhed leveres uden formonterede kabler, anbefales det montøren at følge anvisningerne side 27 - 28 i kapitel 5.5 i denne vejledning: Installationsanvisninger - Monteringsvejledning for kabelsæt.

## 3.5.2 Terminaloversigt for centralenhed af Danfoss-type

**K7 Hoved**

| Ben nr. | Beskrivelse |
|---|---|
| K7.1 | Strøm (+12/24 V JÆVNSTRØM) |
| K7.2 | GND (jord) |
| K7.3 | DV + |
| K7.4 | DV GND (jord) |

**K1 Analoge udgange**

| Ben nr. | Nr. | Beskrivelse |
|---|---|---|
| K1.1 | 1 | Danfoss-moduls strømforsyning |
| K1.2 | | Danfoss-reguleret strømforsyning |
| K1.3 | | GND (jord) |
| K1.4 | | Fejlskærm |
| K1.5 | 2 | Danfoss-moduls strømforsyning |
| K1.6 | | Danfoss-reguleret strømforsyning |
| K1.7 | | GND (jord) |
| K1.8 | | Fejlskærm |
| K1.9 | 3 | Danfoss-moduls strømforsyning |
| K1.10 | | Danfoss-reguleret strømforsyning |
| K1.11 | | GND (jord) |
| K1.12 | | Fejlskærm |
| K1.13 | 4 | Danfoss-moduls strømforsyning |
| K1.14 | | Danfoss-reguleret strømforsyning |
| K1.15 | | GND (jord) |
| K1.16 | | Fejlskærm |

**K3 Analoge udgange**

| Ben nr. | Nr. | Beskrivelse |
|---|---|---|
| K3.1 | 5 | Danfoss-moduls strømforsyning |
| K3.2 | | Danfoss-reguleret strømforsyning |
| K3.3 | | GND (jord) |
| K3.4 | | Fejlskærm |
| K3.5 | 6 | Danfoss-moduls strømforsyning |
| K3.6 | | Danfoss-reguleret strømforsyning |
| K3.7 | | GND (jord) |
| K3.8 | | Fejlskærm |
| K3.9 | 7 | Danfoss-moduls strømforsyning |
| K3.10 | | Danfoss-reguleret strømforsyning |
| K3.11 | | GND (jord) |
| K3.12 | | Fejlskærm |
| K3.13 | 8 | Danfoss-moduls strømforsyning |
| K3.14 | | Danfoss-reguleret strømforsyning |
| K3.15 | | GND (jord) |
| K3.16 | | Fejlskærm |

**K4 EX1 - Digitale udgange/indgange**

| Ben nr. | Beskrivelse |
|---|---|
| K4.1 | Digital udgang 1 |
| K4.2 | Digital udgang 2 |
| K4.3 | Digital udgang 3 |
| K4.4 | Digital udgang 4 |
| K4.5 | Digital udgang 5 |
| K4.6 | Digital udgang 6 |
| K4.7 | GND (jord) |
| K4.8 | Digital indgang 1 |
| K4.9 | Digital indgang 2 |
| K4.10 | Digital indgang 3 |
| K4.11 | Indgangs strømforsyning (+V JÆVNSTRØM) |

**K6 EX2 - Digitale udgange/indgange**

| Ben nr. | Beskrivelse |
|---|---|
| K6.1 | On / Signal |
| K6.2 | Digital udgang 7 |
| K6.3 | Digital udgang 8 |
| K6.4 | Digital udgang 9 |
| K6.5 | GND (jord) |
| K6.6 | Digital udgang 10 |
| K6.7 | Digital udgang 11 |
| K6.8 | Digital udgang 12/Digital indgang 4 |
| K6.9 | Digital udgang 13 |
| K6.10 | GND (jord) |

**K8 EX3 - Ekstra funktioner**

| Ben nr. | Beskrivelse |
|---|---|
| K8.1 | Kundespecifik |
| K8.2 | Kundespecifik |
| K8.3 | Kundespecifik |
| K8.4 | Kundespecifik |
| K8.5 | Kundespecifik |

## 3.5.3 Terminaloversigt for centralenhed af PWM-type

**K7 Hoved**

| Ben nr. | Beskrivelse |
|---|---|
| K7.1 | Strømforsyning (+12/24 V jævnstrøm) |
| K7.2 | GND (jord) |
| K7.3 | DV + |
| K7.4 | DV GND (jord) |

**K1 Analoge udgange**

| Ben nr. | Nr. | Beskrivelse |
|---|---|---|
| K1.1 | 1A | PWM + |
| K1.2 | | GND (jord) |
| K1.3 | 1B | PWM + |
| K1.4 | | GND (jord) |
| K1.5 | 2A | PWM + |
| K1.6 | | GND (jord) |
| K1.7 | 2B | PWM + |
| K1.8 | | GND (jord) |
| K1.9 | 3A | PWM + |
| K1.10 | | GND (jord) |
| K1.11 | 3B | PWM + |
| K1.12 | | GND (jord) |
| K1.13 | 4A | PWM + |
| K1.14 | | GND (jord) |
| K1.15 | 4B | PWM + |
| K1.16 | | GND (jord) |

**K3 Analoge udgange**

| Ben nr. | Nr. | Beskrivelse |
|---|---|---|
| K3.1 | 5A | PWM + |
| K3.2 | | GND (jord) |
| K3.3 | 5B | PWM + |
| K3.4 | | GND (jord) |
| K3.5 | 6A | PWM + |
| K3.6 | | GND (jord) |
| K3.7 | 6B | PWM + |
| K3.8 | | GND (jord) |
| K3.9 | 7A | PWM + |
| K3.10 | | GND (jord) |
| K3.11 | 7B | PWM + |
| K3.12 | | GND (jord) |
| K3.13 | 8A | PWM + |
| K3.14 | | GND (jord) |
| K3.15 | 8B | PWM + |
| K3.16 | | GND (jord) |

**K4 EX1 - Digitale udgange/indgange**

| Ben nr. | Beskrivelse |
|---|---|
| K4.1 | Digital udgang 1 |
| K4.2 | Digital udgang 2 |
| K4.3 | Digital udgang 3 |
| K4.4 | Digital udgang 4 |
| K4.5 | Digital udgang 5 |
| K4.6 | Digital udgang 6 |
| K4.7 | GND (jord) |
| K4.8 | Digital indgang 1 |
| K4.9 | Digital indgang 2 |
| K4.10 | Digital indgang 3 |
| K4.11 | Indgangs strømforsyning (+V |

**K6 EX2 - Digitale udgange/indgange**

| Ben nr. | Beskrivelse |
|---|---|
| K6.1 | Tænd/signal |
| K6.2 | Digital udgang 7 |
| K6.3 | Digital udgang 8 |
| K6.4 | Digital udgang 9 |
| K6.5 | GND (jord) |
| K6.6 | Digital udgang 10 |
| K6.7 | Digital udgang 11 |
| K6.8 | Digital udgang 12/digital indg. 4 |
| K6.9 | Digital udgang 13 |
| K6.10 | GND (jord) |

**K8 EX3 - Ekstra funktioner**

| Ben nr. | Beskrivelse |
|---|---|
| K8.1 | Kundespecifik |
| K8.2 | Kundespecifik |
| K8.3 | Kundespecifik |
| K8.4 | Kundespecifik |
| K8.5 | Kundespecifik |

## 3.6 Funktionsboks for kranstop (ekstraudstyr)

Funktionsboksen for kranstop er en særskilt enhed til fast montering på køretøjer (se Figur 3.10). Funktionsboksen for kranstop skal tilsluttes mellem køretøjets batteri og centralenheden.

- Når stopfunktionen aktiveres, afbrydes hovedstrømforsyningen til hele fjernbetjeningssystemet.
- Kranstopfunktionen skal placeres et egnet og lettilgængeligt sted.
- Før du begynder at bruge enheden, skal føreren oplyse alle kolleger om stopfunktionen og dens placering.
- Funktionsboksen for kranstop er ikke omfattet af Scanrecos levering – det er montørens ansvar.

Når centralenhedskontakten er i positionen MANUAL (MANUEL) og en elektrisk vippeventil, er stopfunktionen også tilgængelig under brug af det manuelle håndgreb. (Se også kapitel 4 "Sikkerhedsbestemmelser og betjeningsanvisninger").



Figur 3.10 Stopfunktionsboks.

## 3.7 Batteri

Batteriet er stødsikkert og vejrresistent og er placeret i batteriholderen i den bærbare kontrolenhed. Batteriet er genopladeligt, af typen MiMH (Nickel Metal Hydride) på 7,2 V jævnstrøm (se Figur 3.11). Batteriet er sikret mod kortslutning.




Figur 3.11 Batteriet.

- Batteriets effektive driftskapacitet er ca. 8 timer pr. opladning.
- Når batteriet snart skal genoplades, bipper kontrolenheden tre (3) gange til varsel, og samtidigt begynder LED-indikatoren at blinke på kontrolenheden.
- Batteriet skal benyttes, indtil LED-indikatoren slukker. Derefter kan det oplades. Hvis batterikapaciteten er for lav, kan kontrolenheden ikke aktiveres.
- Batterikapaciteten og den driftsmæssige ydeevne reduceres ved meget kolde vejrforhold. Batteriet oplades automatisk under anvendelse med kabelstyring.
- For at reducere behovet for batteriopladning og øge sikkerheden slukkes kontrolenheden automatisk, når enheden ikke har været i brug i mere end ca. fem (5) minutter.

**Vigtig bemærkning:**

- Brug kun batterier/batteriopladere, som leveres af Scanreco, Sverige til det specifikke produkt.
- Undgå at oplade batterier i farlige miljøer.
- Forsøg ikke at anvende et batteri, som er beskadiget, utæt, opsvulmet eller korroderet.
- Undgå at anvende batteri/batterioplader ved temperaturer uden for det angivne interval.

### 3.7.1 Tekniske data (Batteri)

| Element | Tekniske data |
|---|---|
| Type | NiMH-batteri med 6 celler |
| Nominel spænding | 7,2 V jævnstrøm |
| Vægt | 0,20 kg |
| Størrelse (BxHxD) | 150x50x28 mm |
| IP-klasse | IP65 |
| Omgivelsers temperatur (Celsius/Fahrenheit) | -0 til +45° C/ca. -32 til +115°F |

# 3.8 Batterioplader og batteriopladning

## 3.8.1 Generel beskrivelse

Batteriopladeren anvender to forskellige opladningstilstande. I begyndelsen bliver enheden opladet med et højt strømniveau, indtil batteriet er opladet, og derefter skiftes der til en lavere opladningstilstand, indtil batteriet fjernes. Den normale opladningstid for et tomt batteri er ca. 3 timer. Batteriopladeren er beregnet til ikke at beskadige batteriet, selvom der oplades over lang tid (se Figur 3.12).




Figur 3.12 Batteriopladeren.

## 3.8.2 Installation

- Batteriopladeren skal monteres på et sted uden rystelser inde i kabinen eller indendøre og være beskyttet mod fugt, direkte sollys og temperaturvariationer.
- Temperaturen på anvendelsesstedet er 0° til +70° C, men intervallet kan være mindre, afhængigt af batteriets specifikationer.
- Spændingen for strømforsyningen til batteriopladeren skal være +10 til +35 V jævnstrøm, beskyttet af en ekstern sikring på 3.0 Amp.
- Batteriopladeren er konstrueret, så der ikke opstår skader ved opladning over lang tid.
- Polaritet for tilslutningskabel: Inkl. mærket kabel = +
- Maksimalt strømforbrug for batterioplader med batteri: ≈ 400 mA
- Strømforbrug for batterioplader uden batteri: ≈ 10 - 20 mA
- Efter tilslutning af kabelstikket, skal du placere kablet i kabelrillen som vist i Figur 3.13 nedenfor.




Figur 3.13 Når du har tilsluttet kabelstikket, skal du placere kablet i kabelrillen.

### 3.8.3 Betjening

Batteriopladeren starter en opladningscyklus, når der isættes et batteri (grøn LED-indikator begynder at blinke). Efter ca. tre timer er batteriet opladet og brugsklart (grøn LED-indikator lyser konstant). Hvis strømforsyningen bliver afbrudt, husker batteriopladeren opladningsstatussen og fortsætter med en hurtig eller langsom opladningstilstand, når strømmen tilsluttes igen. Som sikkerhedsmæssig foranstaltning afbrydes opladningen efter tre timer, uanset om batteriet er fuldt opladet eller ej. Den grønne LED-indikator lyser konstant.

Der findes to LED-indikatorer på batteriopladeren:

- Rød LED-indikator (strøm) - Angiver strømforsyning.
- Grøn LED-indikator (opladningsstatus) blinker - Batteri oplades (opladeren er i hurtig opladningstilstand).
- Grøn LED-indikator (opladningsstatus) lyser konstant - Batteri oplades (opladeren er i langsom opladningstilstand).

### 3.8.4 Batteriopladning via kabelkontrol

Hvis operatøren anvender kabelkontrolfunktionen, og batteriet er placeret i den bærbare kontrolenhed, oplades batteriet automatisk. Kabelkontrolfunktionen kan også anvendes som batterioplader, når systemet ikke er i brug. Placer batteriet i den bærbare kontrolenhed (mens stopfunktion er aktiveret), og tilslut kablet mellem den bærbare kontrolenhed og den elektroniske boks (nødstop på kranen er frigjort). Opladningstiden er ca. 12 - 14 timer.

Centralenheden skal dog være i fjernbetjeningstilstand.

### 3.8.5 Tekniske data (Batterioplader)

| Element | Tekniske data |
|---|---|
| Strømspænding | 10 - 30 V jævnstrøm |
| Sikring | Ikke inkluderet: Anvend kun med ekstern sikring på 3 Amp. |
| Batteriopladers strømforbrug uden batteri | ≈ 10 - 20 mA |
| Batteriopladers strømforbrug med batteri | ≈ 130 - 140 mA |
| Vægt | 0,25 kg |
| Størrelse (BxHxD) | 252x85x36 mm |
| IP-klasse | IP21 |
| Omgivelsers temperatur (Celsius/Fahrenheit) | -0 til +70° C/ca. -32 til +160° F |

# 4 Sikkerhedsbestemmelser og betjeningsanvisninger

## 4.1 Sikkerhedsbestemmelser

Disse anvisninger omfatter de særlige bestemmelser, der gælder for fjernbetjente kraner (kabel eller radio). Føreren skal være opmærksom på indholdet af disse sikkerhedsmæssige bestemmelser.

Fjernbetjente kraner kan kun betjenes af uddannede medarbejdere. Den bærbare kontrolenhed må aldrig overdrages til en person, som ikke har modtaget oplæring i brugen af fjernbetjente kraner. Hvis disse anvisninger ikke bliver fulgt, kan der ske alvorlige uheld.

**OPERATØREN SKAL:**

- Kontrollere, at kontrolenheden svarer til den kran/maskine, der skal betjenes.
- Lære symboler og positioner at kende for funktioner og retninger i brugen.
- Hver gang før arbejdets begyndelse, skal han kontrollere stopfunktionen på den bærbare kontrolenhed ved at gøre følgende:
  1. Betjene en krans/maskines funktion og trykke på stopknappen på den bærbare kontrolenhed. Kranen skal standse straks. Ingen yderligere kranbevægelser er mulige.
  2. Straks holde op med at bruge kranen og tilkalde en reparatør, hvis kranens bevægelse ikke standses.
- Gå eller stå på behørig afstand under brugen af kranen for at få et godt overblik over styringen. Der må ikke befinde sig uautoriserede personer inden for kranens arbejdsområde.
- Være opmærksom på, at det er forbudt at føre last hen over sig selv eller kolleger.
- Frigøre alle styregreb (dødemandshåndtag), hvis kranens bevægelseskontrol ikke fungerer, og derefter trykke på stopfunktionen på kontrolenheden og nødstopknappen på kranen.
- Sørge for, at stopfunktionen på kontrolenheden altid er trykket ned, når enheden ikke er i brug. Det gælder også for kortvarige stop, f.eks. hvis føreren vil flytte sig.
- Trykke på stopfunktionen på kontrolenheden og på kranen, når kørslen er fuldført. Kontrolenheden skal holdes uden for uautoriserede personers rækkevidde.
- Altid rapportere fejl på udstyret eller mangler til den person, der er ansvarlig for kranen.
- Kontrollere, at intet af sikkerhedsudstyret er blevet ændret eller fjernet.
- Se i de gældende bestemmelser/anvisninger angående "Løft af personer med kraner", "Beskyttelse mod overlastning/overbelastning", "Synlige signaler under betjening af kraner" og "Placering af kraner tæt på lufthavne og højspændingsledninger".
- Være opmærksom på andre relevante bestemmelser og alle eventuelle lokale bestemmelser, som kan være gældende. De findes i de relevante sikkerhedsbestemmelser for krantransport.

- Være opmærksom på indholdet af "BETJENINGSANVISNINGER" og håndtering af og arbejdsmetode for fjernbetjeningssystemet. Se næste afsnit "Betjeningsanvisninger".

## 4.2 Betjeningsanvisninger

Før kranen tages i brug, skal føreren sætte sig ind i indholdet af "SIKKERHEDSBESTEMMELSER" for fjernbetjente kraner. Føreren skal være opmærksom på alle styregrebs og kontakters funktioner.

1. Ved fjernbetjening: Indstil centralenhedens kontakt for driftstilstand til REMOTE (FJERN).
2. Ved manuel betjening/nøddrift: Indstil centralenhedens kontakt for driftstilstand til MANUAL (MANUEL). Der tilføres nu kun strøm til vippeventilen, og kranens funktioner kan styres direkte fra ventilens håndgreb.
3. Drej nødstopkontakterne op på kranen og kontrolenheden.
4. Kabelbetjening: Tilslut kontrolkablet mellem kontrolenheden og centralenheden (kranen).
5. Radiobetjening: Isæt et nyt opladet batteri i kontrolenhedens batteriholder.
6. Tryk på ⏀, og den røde LED-indikator lyser konstant.
7. Nu er systemet klart til brug. Føreren skal være kende til alle funktioner på styregreb/joystick og kontakter, før du tager enheden i brug.
8. Hvis du vil deaktivere eller aktivere stopfunktionen, skal du trykke på stopfunktionens kontakter på kontrolenheden og nødstopknappen på kranen. Stopfunktionen på kontrolenheden skal altid være trykket ned, når enheden ikke er i brug. Det gælder også for kortvarige stop, f.eks. hvis føreren vil flytte sig.
9. Hvis du vil sikre kontrolenheden lang levetid og gøre brugen sikker, skal du opbevare kontrolenheden i et aflåst skab. Kontrolenheden skal tørres af regelmæssigt, f.eks. med en fugtig klud.

# 5 Installationsanvisninger

## 5.1 Generel oversigt over RC 400

Når Scanreco RC 400 er installeret, skal der altid tilsluttes en elektrisk styret vippeventil mellem styreventilen og beholderen af sikkerhedsmæssige hensyn. Det betyder, at vippeventilen er uden strøm under en nødstopmanøvre, og at pumpens aktivitet overføres direkte til beholderen og det hydrauliske tryk dermed fjernes helt fra systemet.




Figur 5.1

## 5.2 Vigtig bemærkning under svejsning

**Vigtigt:** Nogle gange er det nødvendigt at svejse en truck/maskine. Under svejsningen skal systemets elektriske tilslutninger altid frakobles andet udstyr, herunder strømkabler (+ og -), alle ventilkontakter og EX-kabelstik.

## 5.3 Placering af centralenheden

**Vigtigt:** Centralenheden skal monteres ifølge anbefalingerne nedenfor (se Figur 5.2). For at sikre længst mulig levetid for centralenheden og dens kabler, skal centralenheden altid monteres, så ventilkontakterne er placeret nedad. Centralenheden må ikke monteres, så kablerne vender opad. Formålet er at forhindre, at der køber vand langs kablerne og ind i centralenheden.

(Kablerne på centralenheden udsættes således ikke for akkumuleret vand, fugt, salt osv. i længere tid ad gangen). Centralenheden skal monteres på et sted uden rystelser og væk fra kraftige varmekilder (f.eks. udstødningsrør o.lign.).



Figur 5.2 Sådan monteres centralenheden.

## 5.4 Anbefalinger for montering

- Af hensyn til optimal radiokommunikation skal centralenheden og dens antenne placeres så højt og frit som muligt. Radiosignalmodtagelsen for en antenne, der er afskærmet og omgivet af faste genstande, vil være betragteligt forringet. Der kan anskaffes en ekstern antenne, hvis der er behov for det.
- Antennestiften må ikke berøre nogen metalliske genstande.
- Centralenheden skal monteres på et sted uden rystelser og væk fra kraftige varmekilder (f.eks. udstødningsrør o.lign.).
- Strøm- og ventilkabler skal vende nedad ved montering!

## 5.5 Monteringsvejledning for kabelsæt

For at maksimere produktets levetid og forhindre uønskede driftsafbrydelser, skal du læse denne vejledning i kabelmontering, før du forsøger at montere kabelsættet.

Hvis der ikke allerede er påført smørelse på de områder, der er vist på billedet, skal du sørge for at påføre vandfast smørelse, som egner sig til elektronisk udstyr, i passende mængder på de nævnte områder.



Figur 5.3 Centralenhed med fjernet låg.

Bryd membranen, og før kablet gennem den. Der opnås en god forsegling ved at lade membranen slutte helt til.

Fastgør kablet med en kabelbinder eller lignende.




Figur 5.4 Membran.



Figur 5.5 Kabelbinder.

Påfør smørelse som vist på billedet. Tildæk alle eksponerede metaldele og fyld alle hulninger.

For at opnå det bedste mulige resultat skal du påføre smørelse i hulningerne på kontakten, før du tilslutter de enkelte ledninger til den.



Figur 5.6 Påført smørelse.



Figur 5.7 Kabels retning.

# 6 Fejlfinding

## 6.1 Generelle oplysninger

Hvis der opstår fejl:

**Operatøren** kan kontrollere følgende, før der tilkaldes en reparatør.

**Reparatøren** skal kontrollere følgende, før distributøren eller Scanreco AB, Sverige, kontaktes.

Kontroller **altid** type- og serienummeret på de relaterede systemers bærbare kontrolenhed og centralenhed, før du kontakter distributøren eller Scanreco AB, Sverige.

## 6.2 Angivelser på den bærbare kontrolenhed

Status- og alarmangivelser kan aflæses af den bærbare kontrolenheds indikatorer LED MICRO (MIKRO) og LED ON (TÆND) og den indbyggede alarm (se Figur 6.1).

1 = Venstre side af stopknappen: LED MICRO (MIKRO)

2 = Højre side af stopknappen: LED ON (TÆND)

3 = Lyd, via intern alarm




Figur 6.1 Status- og alarmangivelse på bærbar kontrolenhed.

### 6.2.1 Statusangivelser for drift

Den bærbare kontrolenhed anvender LED ON (TÆND) og LED MICRO (MIKRO) til at angive strømstatus og alarmer.

Et fungerende system skal vise følgende på LED ON (TÆND):

**LED ON lyser rødt**: Det betyder, at den bærbare kontrolenhed er aktiv og overfører data til centralenheden via kabel eller radio.

**LED ON blinker rødt hvert andet sekund**: Det betyder, at batteriet snart skal oplades. Denne angivelse går forud for alarmen, som bipper tre (3) gange.

LED MICRO anvendes til at angive mikrotilstand for strømforsyningen.

**LED MICRO blinker grønt en, to, tre, fire eller fem gange hvert 3. sekund**: Det betyder, at mikrofunktionen er aktiv (se kapitel 3.3.6 for at få yderligere oplysninger).


### 6.2.2 Fejlkoder

Under opstart af den bærbare enhed udføres en selvtest, og eventuelle fundne fejl angives med en fejlkode på LED ON og alarmen blinker/lyder et bestemt antal gange. Antallet af gange repræsenterer en bestemt fejl:

| Indikation | Betydning |
|---|---|
| 1 | Greb/joystick i position 1, ikke i neutral position ved opstart eller defekt |
| 2 | Greb/joystick i position 2, ikke i neutral position ved opstart eller defekt |
| 3 | Greb/joystick i position 3, ikke i neutral position ved opstart eller defekt |
| 4 | Greb/joystick i position 4, ikke i neutral position ved opstart eller defekt |
| 5 | Greb/joystick i position 5, ikke i neutral position ved opstart eller defekt |
| 6 | Greb/joystick i position 6, ikke i neutral position ved opstart eller defekt |
| 7 | Greb/joystick i position 7, ikke i neutral position ved opstart eller defekt |
| 8 | Greb/joystick i position 8, ikke i neutral position ved opstart eller defekt |
| 13 | Fejl i nødstop under selvtest |

## 6.3 Angivelser på centralenheden

Status- og fejlkoder kan aflæses af de to LED-indikatorer på centralenhedens forside (LED DV og LED STATUS) og via lågets vindue til overvågning af det interne, dobbelte og 7-delte LED-display. Placeringerne er vist på figuren nedenfor. (Se Figur 6.2).




Figur 6.2 Indikatorer på centralenheden.

### 6.3.1 Statusangivelser for drift

Statusangivelser for driften kan aflæses fra LED STATUS og LED DV.

Et fungerende system skal vise følgende på LED ON (TÆND):

**LED STATUS lyser rødt:** Centralenhed er i standby-tilstand

**LED STATUS lyser grønt:** Centralenhedens er i standby-tilstand eller i aktiv driftstilstand

**LED STATUS blinker rødt:** Række af fejlkoder (Kontroller dobbelt, 7-delt LED-display for yderligere oplysninger).

LED DV anvendes til at angive strømstatus for vippeventilens udgang.

**LED DV lyser rødt:** Angiver, at DV-udgangen er aktiv

### 6.3.2 Fejlkoder

Centralenheden angiver registrerede fejl via det dobbelte, 7-delte LED-display.

Hvis centralenheden registrerer en fejl, angives det af LED STATUS, som blinker rødt, mens det dobbelt, 7-delte LED-display angiver fejlkoden sammen med cifrene "Er", efterfulgt af fire cifre ti to blokke med den tilsvarende fejlkode.

Eksempel på række af fejlkoder:

"Er" -> "15" ->"1A" -> ""Er" -> "15" ->"1A" ->"Er" -> "15" ->"1A" ->

Rækken af fejlkoder gentages tre gange, hvis fejlen betragtes som en mindre fejl, og systemet genstarter til standby-tilstand, hvis fejlen betragtes som en alvorlig fejl. Fejlkoderækken vises fortsat, indtil strømmen afbrydes.

Under listen over fejlkoder og deres betydning

| **Indikation** | | **Betydning** |
|---|---|---|
| **Blok 1** | **Blok 2** | |
| 01. | 01-07 | Checksum-fejl (Blok 2 viser typer) |
| 02. | 02 | Kortslutning i DV-udgang |
| 04. | 01-14 | Kortslutning i digital udgang (Blok 2 viser hvilken udgang) |
| 07. | 1A-8B | Fejl i analog udgang (Blok 2 viser hvilken udgang) |
| 15. | 1A-8B | Kortslutning i analog udgang (Blok 2 viser hvilken udgang) |
| 16. | 1A-8B | Afbrydelse i analog udgang (Blok 2 viser hvilken udgang) |
| 17. | 01 | Strømspænding er for lav |
| 17. | 02 | Strømspænding er for høj |

## 6.4 Systemet fungerer ikke

**Kontroller altid følgende:**

- Er der strømforsyning på **+**12 V jævnstrøm/+24 V jævnstrøm, +/- 20 %, maks. 5 % V spidseffekt-til-spidseffekt til systemet? Måling foretages ved nødstopkontakt (lodset og lastet).
- Betjenes systemet via kabelkontrolfunktionen?
- Betjenes systemet manuelt, dvs. er systemet i tilstanden MANUAL (MANUEL)?
- Placer kontakten i positionen **"REMOTE"** (FJERN), kontroller og bekræft, hvad centralenhedens LED-indikatorer og det dobbelte, 7-delte LED-display angiver.
- Aktiver den bærbare kontrolenhed, kontroller og bekræft, hvad den bærbare kontrolenheds LED-indikatorer og alarmen angiver.
- Aktiver de enkelte funktioner en ad gangen, kontroller og bekræft hvad centralenheder og/eller den bærbare kontrolenhed angiver.

# 7 Programmering af parametre og indstillinger

## 7.1 Generel beskrivelse

Scanreco RC 400 tilbyder betragtelige muligheder for systemkonstruktører af hydraulisk drevne, mobile kraner og maskiner. Programmet i kontrolsystemet er meget omfattende, fleksibelt og har mange tilpasningsmuligheder til specifikke formål. Kontrolsystemet tilbyder enkel programmering af en række funktioner, som let kan aktiveres eller deaktiveres eller ændres under brugen.

Med henblik på at opnå de bedste mulige styringsegenskaber på den mest enkle måde, foretages al programmering/kalibrering af styreegenskaber under brugen (såkaldt online). Al programmering/kalibrering udføres fra den bærbare kontrolenhed. Programmering er enkel og kræver ingen værktøjer/instrumenter.

Kontrolsystemet er fyldt med og forberedt til tovejs (dupleks) kommunikation og signalhåndtering af funktioner som f.eks. rampe, parallel, lås, dødemandsfunktion, fastholdelse, dobbelt og overbelastning/løftreduktion osv.

Niveauerne i autorisationen er opdelt i fire hovedgrupper:

- Autorisationsniveau 1 (installatør)
- Autorisationsniveau 2 (veluddannet installatør, veluddannet servicepersonale)
- Autorisationsniveau 3 (veluddannede kran- og ventilproducent, veluddannet systemkonstruktør)
- Autorisationsniveau 4 (Scanreco AB, Sverige).

## 7.2 Autorisationsniveau 1

### 7.2.1 Ændring af bevægelsens retning

Dette afsnit beskriver, hvordan du ændrer bevægelsens retning, hvis kranen bevæger sig i modsat retning af den ønskede.

Eksempel:

Efter installationen og testkørslen er det konstateret, at 3. og 5. grebs bevægelser kører i modsat retning af den ønskede. Se eksemplet nedenfor for at ændre bevægelserne for 3. og 5. greb.

SÅDAN GØR DU

1. Fjern batteriet. Tilslut kablet mellem den bærbare kontrolenhed og centralenheden og testkør kranen. Tryk derefter på stop-knappen på den bærbare kontrolenhed og nødstopknappen på kranen.
2. Drej stopknappen opad på den bærbare kontrolenhed og på kranen.
3. Tryk på ON-knappen (TÆND) på den bærbare kontrolenhed. Den røde LED-indikator skal lyse konstant.
4. Pres returfjederkontakten MICRO (MIKRO) til HØJRE i retningen OFF (SLUK) flere gange efter hinanden, indtil den bærbare kontrolenhed giver et langt bipsignal. Vent ca. 12 sekunder indtil det næste lange bipsignal, og fortsæt derefter med nr. 5 nedenfor.

   Bemærk 1: Den røde LED-indikator slukkes, hver gang den bærbare kontrolenhed giver et bipsignal.

   Bemærk 2: Hvis det første lange bipsignal ikke høres, skal du begynde forfra fra nr. 1 ovenfor og udføre nr. 3 og nr. 4 hurtigere. Nr. 3 og nr. 4 skal udføres inden for maks. 5 sekunder.
5. Tryk på en gang på ON-knappen (TÆND).

   Den bærbare kontrolenheds indbyggede alarm giver et kort bip en gang hvert 5. sekund for at bekræfte, at punkterne ovenfor er udført korrekt. Hvis der høres andre bipsignaler, skal du starte fra punkt 1 igen. Nu kan du let ændre retningen. Se nr. 6 nedenfor.
6. Nu kan du betjene kranen. Flyt det 3. kontrolgreb (som fungerer i modsat retning end den ønskede), og pres kontakten MICRO (MIKRO) mod VENSTRE i retningen ON (TÆND).

   Kranen ændrer nu retning og fortsætter med samme valgte hastighed i den modsatte retning. Udfør samme procedure for det 5. styregreb.

   Flyt det 5. kontrolgreb (som fungerer i modsat retning end den ønskede), og pres omskifterkontakten MICRO (MIKRO) mod VENSTRE i retningen ON (TÆND). Kranen ændrer straks retning og fortsætter med samme valgte hastighed i den modsatte retning. Hvis der er foretaget en retningsændring tidligere for et bestemt greb, skal du gøre som vist ovenfor, men presse omskifterkontakten MICRO (MIKRO) til HØJRE i retningen OFF (SLUK).

   Betjen og kontroller, at alle kranbevægelser kører i de ønskede retninger.
7. Tryk på stopknappen på den bærbare kontrolenheden.

   Programmeringen er nu fuldført, og kranen kører i de retninger, som du angav under punkt 6. Ved radiobetjening skal du fjerne kabelkontrolenheden og teste kørslen af kranen.

Hvis du ikke er tilfreds med en eller flere bevægelsesretninger, skal du gentage proceduren ovenfor.

Bilag 1

www.scanreco.se

Bilag 1

| Document number<br>S071 | |
|---|---|
| Revision<br>C | Date<br>2011-10-17 |
| Document type<br>Manual | |

# SERVICE MANUAL

## Remote Control
## System RC400 G2B/G3B



# Contents


**1 General....3**
1.1 Synopsis 3
1.2 Distribution 3
1.3 Terminology 4
1.4 Applicable products 4
1.5 Product identification 5
**2 Preface....6**
2.1 General information 6
**3 General system description....7**
3.1 General description 7
3.2 Schematic overview of Scanreco RC-400 G2B 8
3.3 Schematic overview of Scanreco RC400 G3B 9
**4 Getting started....10**
4.1 Portable Control Unit definition 10
4.2 Central Unit G2B definition 11
4.3 Central Unit G3B definition 12
4.4 Cable or radio communication 13
4.5 Cable connection schematics 13
**5 Inputs & Outputs....14**
5.1 Analogue functions 14
5.2 Portable Control Unit MAXI digital inputs 16
5.3 Portable Control Unit MINI digital inputs 17
5.4 Digital functions 18
5.5 Terminal schematics for current controlled Central Unit G2B 19
5.6 Terminal schematics for voltage controlled Central Unit G2B 20
5.7 Terminal schematics for Central Unit G2B CAN interface 21
5.8 Connection schematics for Central Unit G3B 22
**6 Operational indications....23**
6.1 Central Unit status and operational indications 23
6.2 Central Unit LED-display 24
6.3 Portable Control Unit status indications 25
**7 Error code indications....26**
7.1 General description 26
7.2 Central Unit error codes 26
7.3 Portable Control Unit error codes 29
**8 Radio....30**
8.1 General description 30
8.2 Determining radio quality 30
8.3 Radio channel / Frequency 30
8.4 Range 30
**9 Diagnostics mode....31**
9.1 General description 31
9.2 Activating diagnostics mode 31
9.3 Table / Diagnostics data 32
**10 Online Programming mode....35**
10.1 General description 35
10.2 Activating online programming mode 36
10.3 Table / Programming options 37
**11 Portable Control Unit self test mode....40**
11.1 General description 40
11.2 Activating PCU Test Mode 40
**12 ID-code programming....41**
12.1 General description 41
12.2 Procedure 41
**13 G2B Standard cable kits....42**
13.1 General description 42
13.2 Standard supply cable kits 43
13.3 Standard valve cable kits for Sauer-Danfoss PVG-32 44
13.4 Standard valve cable kits for HAWE 45
13.5 Standard valve cable kits for PWM solenoids 46

# Document information

| Attribute | Information |
|---|---|
| Document type | Manual |
| Title | Remote Control System RC400 G2B / G3B |
| Subtitle | Service Manual |
| Document number | S071 |
| Filename | S071 |
| Revision | C |
| Revision date | 2011-10-17 |

# Revision history

| Revision | Date | Name | Note |
|---|---|---|---|
| A | 2010-10-29 | Scanreco AB | First release |
| B | 2011-08-14 | Scanreco AB | G3B Central Unit added<br>Major changes in document |
| C | 2011-10-17 | Scanreco AB | G2B Standard Cable kit chapter added<br>Minor changes in document |

# 1 General

## 1.1 Synopsis

Scanreco Remote Control System RC400 G2B/G3B Service Manual

This service manual is intended as a complement to the Remote Control System RC400 G2B Instruction manual and covers more in-depth information surrounding service and fault findings on the systems.

## 1.2 Distribution

| Name | Rule |
|---|---|
| Internal | Only within own organization |

## 1.3 Terminology

| Abbreviation | Description |
|---|---|
| n/a | Not applicable |
| PWM | Pulse Width Modulation |
| PCU | Portable Control Unit |
| CU | Central Unit |
| LED | Light Emitting Diode |
| ST | Status LED |
| DV | Dump Valve |

## 1.4 Applicable products


This document is applicable on the below declared products and program versions.

| Item no: | Description | Program version |
|---|---|---|
| 3010 | G2B Central Unit PWM EU | 4.10 |
| 3011 | G2B Central Unit PWM NAFTA | 4.10 |
| 2010 | G2B Central Unit Danfoss EU | 2.14 |
| 2011 | G2B Central Unit Danfoss NAFTA | 2.14 |
| 1602 | G3B Central Unit Type 1 EU | 1.00 |
| 1603 | G3B Central Unit Type 1 NAFTA | 1.00 |
| 1604 | G3B Central Unit Type 2 EU | 1.00 |
| 1605 | G3B Central Unit Type 2 NAFTA | 1.00 |
| n/a* | G2B Portable Control Unit Maxi Linear | 1.07 |
| n/a* | G2B Portable Control Unit Maxi Joystick | 1.07 |
| n/a* | G2B Portable Control Unit Mini Linear | 1.07 |
| n/a* | G2B Portable Control Unit Mini Joystick | 1.07 |


*Due to the variety of configurations available for the Portable Control Units, item numbers are not declared; only the available Portable Control Unit platform types are declared, for more detailed information refer to customer part list where available.

## 1.5 Product identification

All SCANRECO Products are labeled with product part number and serial number for verification. Below illustrations shows where these numbers can be located.




Central Unit G2B







Central Unit G3B




Portable Control Unit MAXI




Portable Control Unit MINI

Always check and verify product item- and serial no. before any type of service is commisioned, refer to customer parts list and system-/product technical specifications in order to determine system-/product configuration.

# 2 Preface

## 2.1 General information

This manual is intended as a complement to the crane / machine instruction book and covers the Scanreco RC 400 G2B/G3B Remote Control System.

The Scanreco RC 400 G2B/G3B offers the driver an extremely advanced remote control system with speed, precision, control and maximum safety.

In order to ensure your safety and the safety of your crane / machine you should study and learn these instructions. This will enable you to quickly familiarise yourself with your new remote control system and how to utilise it.

- Remotely controlled cranes may only be operated by qualified personnel. The driver must be aware of the contents of chapter 4 “Safety regulations and Operating instructions” available in the Intruction Manual before operation is started. Serious accidents may occur if these instructions are not followed.

- To protect the portable control unit from damage and for safety reasons, the control unit must be kept in a locked cabin

- Follow the instructions given in the crane handbook regarding moving the crane from its parking position, the best arm positioning while loads are being handled and parking of the crane.

- Due to the unlimited variety of cranes, machines, objects, vehicles and equipment on which the remote control system are used, and the numerous standards which are frequently the subject of varying interpretation, it is impossible for the personnel at Scanreco to provide expert advice regarding the suitability of a given remote control for a specific application. It is the responsibility of the purchaser to determine the suitability of any Scanreco remote control product for an intended application and to insure that it is installed and guarded in accordance with all country, federal, state, local, and private safety and health regulation, codes, standards and Scanreco recommendation (this manual). If the Scanreco RC 400 G2B/G3B will be used in a safety critical application, the customer / driver must undertake appropriate testing and evaluation to prevent injury to the ultimate user. Scanreco does not take responsibility for any damage or injury.

- Unauthorized tampering with a Scanreco remote control system automatically invalidates guarantee.

# 3 General system description

## 3.1 General description of Scanreco RC-400 G2B/G3B

The Scanreco RC 400 G2B/G3B remote control system has been especially developed for hydraulically driven mobile cranes and machinery. The system is a digital remote control system based on an extremely advanced microprocessor technology. Years of exhaustive and demanding testing have shown that the remote control system can cope with the roughest of environments.


The system is protected against electromagnetic and radio frequency radiation and can be installed onto most hydraulic valve types (voltage, current pulse width, or protocol steered) found on the market.

In its basic form the remote control system is comprised of a portable control unit with manoeuvre levers for proportional control and switches for ON/OFF functions, a central unit with connection cable for driving proportional electro-hydraulic slide controllers.

Digitally coded control information (lever deflection and switch position) is sent from the control unit via electric cable or via radio to the central unit. The control unit and central unit translate the magnitude and direction of the manoeuvre lever deflections and switch positions to corresponding valve function, speed and direction and thus crane movement.

## 3.2 Schematic overview of Scanreco RC-400 G2B

Below illustrations shows a typical system consistory for the G2B system




| No | Description | Qty |
|---|---|---|
| 1 | Portable Control unit (PCU) | 1 |
| 2 | Central unit G2B (CU) | 1 |
| 3 | Battery Charger (10 - 30 VDC) | 1 |
| 4 | Battery cassette (NiMH 7.2 VDC) | 2 |
| 5 | Manoeuvre cable (10 meters) | 1 |
| 6 | Emergency stop box (Optional) | 1 |
| 7 | Cable kit supply cables + digital outputs | 1 |
| 8 | Cable kit valves cables (analogue outputs) | 1 |

## 3.3 Schematic overview of Scanreco RC-400 G3B

Below illustrations shows a typical system consistory for the G3B system





| No | Description | Qty |
|---|---|---|
| 1 | Portable Control unit (PCU) | 1 |
| 2 | Central unit G3B (CU) | 1 |
| 3 | Battery Charger (10 - 30 VDC) | 1 |
| 4 | Battery cassette (NiMH 7.2 VDC) | 2 |
| 5 | Manoeuvre cable (10 meters) | 1 |

# 4 Getting started

## 4.1 Portable Control Unit definition

The illustrations below aims to delare all entities mentioned in this document.




### Activating the Portable Control Unit


**Insert battery or connect cable connector!**

1. Twist up the Stop-button
2. Press the On-button once
   - LED-Power will be illuminated RED



## 4.2 Central Unit G2B definition

The illustrations below aims to declare all entities mentioned in this document.




### Activating the Central Unit

The Central Unit can be activated in two modes via the R/M switch; REMOTE or MANUAL mode. In REMOTE mode the Central Unit is controlled by the PCU, in MANUAL mode the system supplies only the DV-output intended for Dump valve supply; the complete system is by-passed allowing manual operation of distributor bench (where available).





REMOTE MODE:

Operation via PCU
LED STATUS will be illuminated red at first then green when in contact with PCU.

MANUAL MODE:

System by-pass / Manual operation

LED DV will be illuminated red.



## 4.3 Central Unit G3B definition

The illustrations below aims to declare all entities mentioned in this document.




### Activating the Central Unit G3B

The Central Unit G3B is supplied thru Cable A and requires external power switching, see chapter 5.8 for further info.

The Central Unit G3B exists in 2 different versions; one with 2 cable outputs and one with 3 cable outputs. Refer to chapter 5.8 for further info.

## 4.4 Cable or radio communication

Cable communication has higher priority than radio communication, if a cable link is present between the PCU and Central Unit this will be detected by the system, disabling radio communication.


## 4.5 Cable connection schematics





| Cable connection | |
|---|---|
| Pin no. | Wire color |
| 1 | Brown |
| 2 | White |
| 3 | Blue |
| 4 | Black |
| 5 | Grey |


### Portable Control Unit Pin assignments

5- pole male
M12 connector




### Central Unit G2B/G3B Pin Assignments





5- pole female
M12 connector

| | |
|---|---|
| 1 | Brown / Data |
| 2 | White / GND |
| 3 | Blue / RS 232 TX |
| 4 | Black / RS 232 RX |
| 5 | Grey / Supply output |


# 5 Inputs & Outputs

## 5.1 Analogue functions


The analogue inputs available for each platform (MAXI Linear, MAXI Joystick, MINI Linear and MINI Joy stick) are by default assigned an analogue output on the Central Unit, below figures declares the standard assignments.




PCU MAXI Linear standard assignments




PCU MAXI Joystick standard assignments





PCU MINI Linear standard assignments




PCU MINI Joystick standard assignments

## 5.2 Portable Control Unit MAXI digital inputs

The digital inputs available are NOT all by default assigned an digital output on the Central Unit, below figures only declares digital input access.




| No. | Type | Colour code | AMP Pin no. |
|---|---|---|---|
| - | Common (GND) | Black | 1 |
| 10 | Digital input 33 | Pink | 2 |
| 9 | Digital input 06 | Grey | 3 |
| 8 | Digital input 02 | Brown | 4 |
| 7 | Digital input 32 | Purple | 5 |
| 6 | Digital input 05 | Orange | 6 |
| 5 | Digital input 31 | Black | 7 |
| 4 | Digital input 07 | White | 8 |
| 3 | Digital input 04 | Blue | 9 |
| 2 | Digital input 03 | Green | 10 |
| 1 | Digital input 01 | Yellow | 11 |
| - | Supply output | Red | 12 |

| No. | Type | Colour code | Amp Pin no. |
|---|---|---|---|
| - | Common (GND) | Black | 1 |
| 20 | Digital input 36 | Pink | 2 |
| 19 | Digital input 35 | Grey | 3 |
| 18 | Digital input 34 | Brown | 4 |
| 17 | Digital input 37 | Purple | 5 |
| 16 | Digital input 08 | Orange | 6 |
| 15 | Digital input 09 | Black | 7 |
| 14 | Digital input 13 | White | 8 |
| 13 | Digital input 12 | Blue | 9 |
| 12 | Digital input 11 | Green | 10 |
| 11 | Digital input 10 | Yellow | 11 |
| - | Supply output | Red | 12 |

Note that on the MAXI platform the Terminals 1 and 2 are mirrored and available on both left and right hand side of the stop button

## 5.3 Portable Control Unit MINI digital inputs

The digital inputs available are NOT all by default assigned an digital output on the Central Unit, below figures only declares digital input access.




**Terminal 1**

| No. | Type | Colour code | AMP Pin no. |
|---|---|---|---|
| - | Common (GND) | Black | 1 |
| 10 | Digital input 33 | Pink | 2 |
| 9 | Digital input 06 | Grey | 3 |
| 8 | Digital input 02 | Brown | 4 |
| 7 | Digital input 32 | Purple | 5 |
| 6 | Digital input 05 | Orange | 6 |
| 5 | Digital input 31 | Black | 7 |
| 4 | Digital input 07 | White | 8 |
| 3 | Digital input 04 | Blue | 9 |
| 2 | Digital input 03 | Green | 10 |
| 1 | Digital input 01 | Yellow | 11 |
| - | Supply output | Red | 12 |

**Terminal 2**

| No. | Type | Colour code | Amp Pin no. |
|---|---|---|---|
| - | Common (GND) | Black | 1 |
| 20 | Digital input 36 | Pink | 2 |
| 19 | Digital input 35 | Grey | 3 |
| 18 | Digital input 34 | Brown | 4 |
| 17 | Digital input 37 | Purple | 5 |
| 16 | Digital input 08 | Orange | 6 |
| 15 | Digital input 09 | Black | 7 |
| 14 | Digital input 13 | White | 8 |
| 13 | Digital input 12 | Blue | 9 |
| 12 | Digital input 11 | Green | 10 |
| 11 | Digital input 10 | Yellow | 11 |
| - | Supply output | Red | 12 |

## 5.4 Digital functions


The digital functions utilized varies depending on system configuration, up to 20 digital functions can be implemented thru left- and/or right switch panels with programmable assignments to up to 14 digital outputs.

In excess the On-button may also be assigned a digital output.

Below shows PCU platforms standard digital inputs and default Central Unit output assignment




PCU MINI Standard assignment





PCU MAXI Standard assignment

| Position | Type | Central Unit |
|---|---|---|
| 301 | 3 way detent toggle | Digital output 1 / Digital output 1 Parallel with analogue input movement (AutoRPM engine feature) |
| 302 | 3 way spring back toggle | Digital output 2 / Digital output 3 (Engine start / Engine stop) |
| 303 | 3 way spring back toggle | Digital output 4 / Digital output 5 (Engine RPM+ / Engine RPM-) |
| 304/305 | 2 way detent toggle | Digital output 6 (Optional) |
| On-button | Push button | Digital output 7 |


## 5.5 Terminal schematics for current controlled Central Unit G2B

The drawing below declares access points for each available input and output both from the inside terminal (above) and the standard cable kits (below). Standard cable wire number/marking is also declared.




## 5.6 Terminal schematics for voltage controlled Central Unit G2B

The drawing below declares access points for each available input and output both from the inside terminal (above) and the standard cable kits (below). Standard cable wire number/marking is also declared.



## 5.7 Terminal schematics for Central Unit G2B CAN interface

The Central Unit is equipped with terminal connections for CAN. The drawing below declares the access points both from the inside terminals (above) and the standard cable kit (below).




NOTE:

* as various cable kits exists, please refer to chapter 13 or system technical specification for further information

The Central Unit G2B is not equipped with a specific “STOP loop” connection, if needed a digital output are in such cases assigned; if more info is required; refer to system technical specification.

If required; a terminator resistor can be installed between points 4 & 5: the resistor value needs to be defined by the system installer.

## 5.8 Connection schematics for Central Unit G3B

The Central Unit G3B is equipped with either 2 or 3 circular M12 5-pole connectors (check item no). The drawing below declares Pin-assignments for both versions of the Central Unit G3B

Item no: 1602, 1603




**Cable A (3 meters)**

| Connection | |
|---|---|
| Pin no. | Colour / Function |
| 1 | Brown / DV1 |
| 2 | White /Power supply |
| 3 | Blue / GND |
| 4 | Black / CAN_HIGH |
| 5 | Grey / CAN_LOW |



5- pole male
M12 connector


**Cable B (3 meters)**

| Connection | |
|---|---|
| Pin no. | Colour / Function |
| 1 | Brown / DATA |
| 2 | White /GND |
| 3 | Blue / RS 232 TX |
| 4 | Black / RS 232 RX |
| 5 | Grey / Supply output |



5- pole female
M12 connector

Item no: 1604, 1605




**Cable C (3 meters)**

| Connection | |
|---|---|
| Pin no. | Colour / Function |
| 1 | Brown / DV2 |
| 2 | White / LOOP1_OUT |
| 3 | Blue / LOOP1_IN |
| 4 | Black / LOOP2_OUT |
| 5 | Grey / LOOP2_IN |



5- pole male
M12 connector

# 6 Operational indications

## 6.1 Central Unit status and operational indications

The Central Unit G2B is equipped with 2 individual positions where status and operational indications can be read, the external LEDs STATUS and DV provides basic limited information whilst the LED display provides more detailed information, the Central Unit G3B only have the LED-display as shown below.




Position 4: Status LEDs

Position 5: LED-display

### External LEDs (on Central Unit G2B only!)

| LED STATUS | Meaning |
|---|---|
| OFF | Off, Central Unit is deactivated |
| RED | ON – Central Unit is activated in REMOTE mode<br>No communication with PCU |
| GREEN | ON – Central Unit is activated in REMOTE mode<br>Communication link with Portable Control Unit |
| RED flashing 4/1 | Error code being displayed on internal LED Display |

| LED DV | Meaning |
|---|---|
| RED | Dump Valve output is supplied |

Note that the LED STATUS is used also for error code alarms and operator controlled functions and is then triggered by an event, the type of indication will be declared for each event further in this document.

## 6.2 Central Unit LED-display

Below table shows the variety of status indications available for both the Central Unit G2B and G3B:

| LED Display | Meaning |
|---|---|
|  | Off, deactivated |
|  | Standby mode, no communication link with PCU |
|  | Standby mode, communication link with PCU |
|  | Communication link via cable, ID-code approved |
|  | Communication link via cable, ID-code not approved |
|  | Communication link via radio, frequency hopping |
|  | Communication link via radio, frequency locked on channel 1 |
|  | Communication link via radio, frequency locked on channel 2 |
|  | Communication link via radio, frequency locked on channel 3 |
|  | Communication link via radio, frequency locked on channel 4 |
|  | Communication link via radio, frequency locked on channel 5 |
|  | Communication link via radio, frequency locked on channel 6 |
|  | Communication link via radio, frequency locked on channel 7 |
|  | Communication link via radio, frequency locked on channel 9 |
|  | Communication link via radio, frequency locked on channel 10 |
|  | Communication link via radio, frequency locked on channel 11 |
|  | Communication link via radio, frequency locked on channel 12 |
|  | Communication link via radio, frequency locked on channel 13 |
|  | Radio communication deactivated via program setting (WinSCI) |
|  | ID-programming procedure is active (See chapter 12 for further info) |
|  | ID-programming procedure rejected (See chapter 12 for further info) |

## 6.3 Portable Control Unit status indications

The Portable Control Unit uses 2 LEDs to indicate operational status, the Portable Control Unit is also equipped with an internal buzzer that emits sounds and alarms when required.




Typical status indications involving the Micro- and Power-LED are declared below:

| Power-LED | Meaning |
|---|---|
| OFF | Off, Portable Control Unit is deactivated |
| RED Fixed | ON – Transmitting data |
| RED Flashing 1/1 sec. | ON – Transmitting data<br>Low battery! (Buzzer will emit an alarm for the first three sequences when low level is detected) |

| Micro-LED | Meaning |
|---|---|
| OFF | Normal mode |
| Green Flashing 1/3th sec. | Micro step 1 active |
| 2 / 3rd sec | Micro step 2 active |
| 3 / 3rd sec | Micro step 3 active |
| 4 / 3rd sec | Micro step 4 active |
| 5 / 3rd sec | Micro step 5 active |

Note that these LEDs are used also for error code alarms and operator controlled functions and are then triggered by an event, the type of indication will be declared for each event further in this document.

# 7 Error code indications


## 7.1 General description

Both the Portable Control Unit and the Central Unit are embedded with constant fault monitoring, any errors noticed by the system will result in interruption of all operational commands.

## 7.2 Central Unit Error codes

All of the Central Units outputs are fault monitored for short circuits and/or overloads, in the event of an error being detected the Central Unit will alert that an error has occurred via the external LED Status and indicate the appropriate error code via the LED-display, the Central Unit will then reset to operational mode if possible.

Below example flowchart on behaviour:




This fault sequence will take an approximately 6 seconds The external LED STATUS will flash rapidly in red colour declaring that an error has been detected, for more detailed information; the LED-display must be monitored (or error code log available from diagnostics menu).

The LED-display Error codes are displayed in up to 3 sequences, this allows the Central Unit to declare exactly which output that is related to the error (where applicable).

First sequence: Letters E:r is presented declaring an error code

Second sequence: Type of error code

Third sequence: Additional information (where applicable)
In example:

 (Repeated 3 times)

The example would imply that there is an short circuit on output 1A

### 7.2.1 Error codes

| 2nd | 3rd | Description | Cause | Action |
|---|---|---|---|---|
| 01. | 01 | EEPROM failure. | Incorrect checksum on EEPROM, last stored data will be set. | Reset system, if persistent; Re-load application program. |
| 01. | 02 | Flash memory failure. | Incorrect checksum on flash memory. | Reset system, if persistent; Re-load application program. |
| 01. | 03 | Stack memory failure. | Incorrect sizes of data in CANopen protocol, incorrect dataflow or stack overflow. | System will self reset automatically. If persistent; Re-load application program. |
| 01. | 04 | RAM memory failure. | Incorret RAM and/or hardware identification. | System will self reset automatically. If persistent; Re-load application program. |
| 02. | 01 | Illegal voltage; DVoutput. | DV-output error; DV-output (DV+) externally supplied | System will self reset. Check DV-output connection. Remove terminal connector and reset system. |
| 02. | 02 | Short circuit; DV-output. | DV-output error; DV output (DV+) short circuited or overloaded. | System will self reset. Check DV-output connection. Remove terminal connector and reset system. |
| 02. | 03 | Safety switch error | Safety switch output read back error, incorrect voltage (High instead of Low) | System will self reset. Remove all terminal connectors and reset system. |
| 02. | 04 | Safety switch error | Safety switch output read back error, incorrect voltage (Low instead of High) | System will self reset. Remove all terminal connectors and reset system. |
| 03. | 00 | Illegal voltage; Digital output | Digital output (1-14) illegal voltage, expected low signal but read as high (Could be any of the available 14 | System will self reset. Check digital output connections. Remove terminal connector and reset |

### 7.2.1 Error codes (continued)

| 2nd | 3rd | Description | Outputs | system |
|---|---|---|---|---|
| 04. | 00 | Short circuit; Digital output | Digital output (1-14) short circuited or overloaded (Could be any of the available 14 outputs) | System will self reset. Check digital output connections. Remove terminal connector and reset system. |
| 05. | 00 | Error input triggered (Danfoss CU only). | Error signal for Danfoss valve triggered (Could be any of the available 8 inputs) | System will self reset. Check analogue output connections. Remove terminal connector and reset system. |
| 06. | x | Illegal voltage analogue output | Wrong voltage on analogue output (3rd sequence declares related output; 1A,1B....). | System will self reset. Check analogue output connections. Remove terminal connector and reset system. |
| 07. | x | Illegal voltage analogue output | Wrong current on analogue output (3rd sequence declares related output; 1A,1B....). | System will self reset. Check connections. Remove terminal connector and reset system. |
| 08. | 01 | CAN Passive | CAN bus in passive mode. | System will self reset. Check CAN connections. Check other nodes on bus and reset system. |
| 08. | 02 | CAN I/O Buffer overflow | CAN overrun; either the CAN input or CAN output buffer are full | System will self reset. Reset system, re-initiate via CAN controller. |
| 08. | 03 | CAN physical layer error | Bad communication/transmission | System will self reset. Check CAN connections. Check other nodes on bus and reset system. |
| 08. | 04 | CAN PDO length exceeded | PDO length is to long | System will self reset. Reset system, re-initiate via CAN controller. |
| 08. | 05 | CAN PDO length error | PDO length is too short | System will self reset. Reset system, re-initiate via CAN controller. |
| 08. | 06 | CAN Transmit COB-ID collision | To many collisions on CANbus | System will self reset. Check CAN connections. Check other nodes on bus and reset system, re-initiate via CAN controller. |
| 10. | 00 | PCU failure; Emergency stop | Error transmitted from PCU: Illegal signal from PCU emergency stop switch | System will self reset. Check emergency stop switch on PCU |
| 11. | 00 | PCU failure; Analogue input | Error transmitted from PCU: Analogue input active on start-up | System will self reset. Ensure all analogue inputs on PCU are at zero/neutral position. Restart PCU. |
| 12 | 00 | PCU failure; Analogue input | Error transmitted from PCU: Signal redundancy test; illegal signal from analogue input. | System will self reset; Diagnose PCU via TEST MODE |
| 13. | n/a | PCU failure; Analogue input | Error transmitted from PCU: Signal redundancy test; illegal signal from analogue input. | System will self reset; Diagnose PCU via TEST MODE |

### 7.2.1 Error codes (continued)

| | | | | |
|---|---|---|---|---|
| 14. | 01 | ID programming failure | ID-code and/or parameter settings not accepted. | System will self reset.<br>Verify ID-programming procedure.<br>Reset application program. |
| 14. | 02 | Program failure | Programmable logic parameter error | System will self reset.<br>Reset application program. |
| 15. | x | PWM output failure | Analogue output short circuited or overloaded.<br>(3rd sequence declares related output; 1A,1B....). | System will self reset.<br>Check analogue output connections.<br>Remove terminal connector and reset system. |
| 16. | x | PWM output failure | Analogue output not connected (Programmable feature).<br>(3rd sequence declares related output; 1A,1B....). | System will self reset.<br>Check analogue output connections.<br>Remove terminal connector and reset system. |
| 17. | 01 | Low supply power | Low power supply (Below 8,5 VDC) | System will self reset.<br>Check power supply and supply connections. |
| 17. | 02 | High supply power | High power supply (Above 36,0 VDC) | System will self reset.<br>Check power supply and supply connections. |
| 98. | n/a | Undefined PCU error | Undefined error in PCU. | Diagnose PCU via TEST MODE |
| 99. | n/a | Undefined CU error | Undefined error in CU. | System will self reset.<br>Remove all terminal connectors<br>Check power supply and supply connections.<br>Reset system. |

## 7.3 Portable Control Unit error codes

The Portable Control Unit monitors all analogue and digital inputs for faults and uses the Power-LED and BUZZER to indicate alarms.

Below available error codes:

| Indications | Meaning |
|---|---|
| 1 | Analogue input 1 not at zero position during start-up |
| 2 | Analogue input 2 not at zero position during start-up |
| 3 | Analogue input 3 not at zero position during start-up |
| 4 | Analogue input 4 not at zero position during start-up |
| 5 | Analogue input 5 not at zero position during start-up |
| 6 | Analogue input 6 not at zero position during start-up |
| 7 | Analogue input 7 not at zero position during start-up |
| 8 | Analogue input 8 not at zero position during start-up |

# 8 Radio

## 8.1 General description

Radio is used as a bus link for data packages between the transmitter (Portable Control Unit) and receiver (Central Unit), the radio continuously transmits the positions of the analogue and digital inputs available on the Portable Control Unit to the Central Unit for further processing.

The digitalized data transfer protocol uses a high security level for verification of each data package, no loss of individual functions due to radio interferences can occur.

The unique ID-code held in the Portable Control Unit ensures that the system can not be operated unintentionally by other Control Unit.

The transmission allows interferences to some extent as long as multiple data packages are not interfered successively.

## 8.2 Determining radio quality

The radio quality can be determined by the external status LED and/or the first 7- segment on the LED-display during radio communication

When an optimal communication is acquired the external Status LED will be fixed green and the Central Unit LED-display will indicate “1x” (x being dependent on program setting).

Short interruptions and losses of data packages will be indicated by irregular flashes of these indicators, an increasing intensity of flashes indicates a decreasing radio reception.

Note that irregular flashes is a common occurence, unless they cause an interuption in communication they should not be considered a cause for concern.




NOTE:
In such cases that a locked frequency is used the second 7-segment indication will be different, check chapter 6.2 for further information.

## 8.3 Radio channel / Frequency

Refer to separate document for radio channel used in your region

## 8.4 Range

Refer to separate document for radio channel used in your region

# 9 Diagnostics mode

## 9.1 General description

A diagnostics mode has been made available as to diagnose and manage the system, the LED-display is required to be monitored during diagnostics and will allow operator to read out recently occurred error codes, output characteristics and program information in order to diagnose the system.

## 9.2 Activating diagnostics mode

Note that the LED-display is required to be monitored during diagnostics mode.

Do as follows:

1. Remove the battery pack. Connect the cable between the Portable Control Unit and turn off the Central Unit via the R/M-switch.

2. Activate the Central Unit in REMOTE mode.

3. Press the Portable Control units On-button once.
-The Power-LED should be illuminated

4. Produce impulses in very quick succession with the Micro-toggle to the LEFT (MICRO-ON direction) 15 times or until the Central Units LED-display indicates D:i – 0:0.

5. Diagnostics mode is now active!

The diagnostics mode consist of 8 different menus' that can be toggled using the on-button, once a menu is entered the current values for that specific parameter is presented in the LED-display.

To exit diagnostics mode press Stop-button on Portable Control Unit.




If activation fails, the 4th step may have been done too slow, the toggle has to be done with a maximum 0,5 second interval.

Attention:
Note that system will operate outputs as in normal operational mode, real-time values (where available) are shown in the LED-display.

Note that by entering the diagnostics mode, the Micro function has been activated and analogue outputs may operate reduced speeds, if full speeds are desired; press Micro-toggle to the right once (MICRO-OFF direction).

## 9.3 Table / diagnosics data

| Position / LED Indication | Meaning |
|---|---|
| D:i - 0:0 | Default position |
| D:i - 0:1 | Analogue output status |
| D:i - 0:2 | Digital output status |
| D:i - 0:3 | Digital Input status |
| D:i - 0:4 | Error code Log |
| D:i - 0:5 | Program save |
| D:i - 0:6 | Program load |
| D:i - 0:7 | Central Unit firmware version |
| D:i - 08 | Portable Control Unit firmware version |
| - | Return to position 00 |

### 9.3.1 Position 1 - Analogue output status

Press On-button once from position D:i – 0:0

D:i – 0:1 is displayed

As to determine the current status for all analogue outputs. Lever/joystick assignments and analogue output start, stopp and ramp values.

While in this position, actuating a specific lever will result in the LED-display presenting which output that is assigned, the direction and the current real time value.

In example:

Lever is actuated, display responds by indicating related output for 1 second

In example

1:A, 2:A, 3:A, 4:A, 5:A, 6:A, 7:A, 8:A, 1:b, 2:b, 3:b, 4:b, 5:b, 6:b, 7:b, 8:b

Followed by the current value in correspondance to lever angle.

1-99, h:i*

*h:i indicating that 100% velocity is achieved

### 9.3.2 Position 2 - Digital output status

Press On-button two times from position D:i – 0:0

D:i – 0:2 is displayed for 1 second, the LED-display will then toggle all Central Unit digital outputs and present current value (High or Low)

O:n – 0:1 - 0:1 or 0:0 (High/Low)

O:n – 0:2 - 0:1 or 0:0 (High/Low)

O:n – 0:3 - 0:1 or 0:0 (High/Low)
...
O:n – 1:4 = 0:1 or 0:0 (High/Low)

As to determine the current status for all digital outputs.

While in this position the LED display will present each digital output from 1 to 14, high or low, continuously

### 9.3.3 Position 3 - Digital input status

Press On-button three times from position D:i – 0:0

D:i – 0:3 is displayed for 1 second, the LED-display will then toggle all Central Unit digital inputs and present current value (High or Low).

i:n – 0:1 - 0:1 or 0:0 (High/Low)

i:n – 0:2 - 0:1 or 0:0 (High/Low)

i:n – 0:3 - 0:1 or 0:0 (High/Low)

i:n – 0:4 - 0:1 or 0:0 (High/Low)

As to determine the current status for all digital inputs.

While in this position the LED-display will present each digital input from 1 to 4, high or low, continuously

### 9.3.4 Position 4 - Error code log

Press On-button four times from position D:i – 0:0

D:i – 0:4 is displayed for 1 second, the LED-display will then toggle the 5 most recent error codes that have been triggered in the Central Unit.

As to determine faults registered by the Central Unit, refer to chapter 7 for error code information.

The LED-display will toggle the logged error codes continuously.

#### 9.3.4.1 Clear error code log

Hold Micro-toggle in LEFT position for 5 seconds

E:r – C:L is displayed in the LED-display (Error Clear)

Release and press Micro-toggle once more to LEFT position to confirm.

Central Unit error code logg is cleared.

An error code clear is suitable to conduct after service!

### 9.3.5 Position 5 - Program save

Press On-button five times from position D:i – 0:0

D:i – 0:5 is displayed

Press and hold Micro-toggle in LEFT position for 3 seconds

C:o – F:A is displayed

Release and press Micro-toggle once more to LEFT position to confirm and store the current settings

Saves the current settings for DIRECTION and SPEEDS (START, STOPP, MICRO, RAMP) and DV-delay time as back-up for eventual future program load, see below chapter “program load”.

### 9.3.6 Position 6 - Program load

Press On-button six times from position D:i – 0:0

D:i – 0:6 is displayed

Press and hold Micro-toggle in LEFT position for 3 seconds

P:o – F:A is displayed

Release and press Micro-toggle once more to LEFT position to confirm and load the settings previosly stored

Enables a reset to previously stored application program setting “Program save”

### 9.3.7 Position 7 - Central Unit program version

Press On-button seven times from position D:i – 0:0

D:i – 0:7 is displayed followed by current firmware version

V:n – n:n

The current version of the Central Units program is presented in two sequences, continuously repeated

In example:




+




### 9.3.8 Position 8 - Portable Control Unit program version

Press On-button eight times from position D:i – 0:0

D:i – 0:8 is displayed followed by the current firmware version

V:n – n:n

The current version of the Portable Control Units program is presented in two sequences, continuously repeated

# 10 Online Programming mode

## 10.1 General description

The Scanreco RC 400 offers considerable possibilities for system constructors of hydraulically driven mobile cranes and machines. The program in the control system is very comprehensive, flexible and has many adaptation possibilities for specific applications. The control system offers simple programming of a number of functions which can easily be turned on or off or altered during operation.

To obtain the best manoeuvre characteristics in the simplest way, all programming / calibration of manoeuvre characteristics is made during operation (so called on-line programming). All programming / calibration is made from the Portable Control Unit.

Programming is simple and does not require tools / instruments.

**The installer/system designer is responsible for seeing that system is used correctly and is responsible for any re-programming of the system functions and the characteristics changes caused by this!**

The system has 4 levels of authorisation:

**Authorisation level 1**. (Installer)
Change direction of analogue movement

**Authorisation level 2.** (Well trained installer, well trained service personnel)

Change direction of analogue outputs A/B

Change start speeds for analogue outputs

Change stop speeds for analogue outputs

Change micro speed for analogue outputs

Change ramp speeds for analogue outputs

**Authorisation level 3.** (Well trained crane and valve manufacturer, well trained system constructor)
Not declared in this document

**Authorisation level 4.** (Scanreco AB)
Not declared in this document

IMPORTANT SAFETY NOTE:
In online programming mode, when you select a programming step, the system automatically activates the speeds of the corresponding selected lever. Speeds used are independent by SET selected in the system and depend only by programming step in which you are.

EXAMPLE:
Even if the system is working in SET1 (SET1 argument is valid), when you enter in the programming mode step no. 8 (SET2), the system will activate and work with the speeds of SET2

## 10.2 Activating online programming mode

The Central Units LED-display or Portable Control Units acoustic step signalling is required to be monitored during programming mode, check the table (10.3) for the indications given.

Do as follows:

1. Remove the battery pack. Connect the cable between the Portable Control Unit and the Central Unit and test run the system.

2. Press the Stop-button on the Portable Control Unit and deactivate the Central Unit via the R/M-switch.

2. Twist up the Stop-button on the Portable Control Unit and activate the Central Unit in REMOTE mode.

3. Press the Portable Control Units On-button once.
-The Power-LED should be illuminated

4. Produce impulses in very quick succession with the Micro-toggle to the RIGHT (MICRO-OFF direction) 10 times or until the Portable Control Unit gives a long beep signal and the Central Units LED-display indicates P:o – 0:0.

5. Online programming mode is now active, The online programming mode consist of 15 different menu's that can be toggled using the On-button, once a menu is entered the Central Units LED-display will indicate the current parameter value of any actuated analogue output, MICRO-ON (left) will decrease the value and MICRO OFF (right) will increase the value.

To exit online programming mode press the Stop-button on the Portable Control Unit.




If activation fails; the 4th step may have been done too slow, the toggle has to be done with a maximum 0,5 second interval.

Attention:
Note that the system will operate outputs as in normal operational mode!

Online programming is done in real time, any parameters set are immediately effecitve!

If not satisfied with the new settings you may be able to retrive previous/default parameter setting via the diagnostics mode, load program.

## 10.3 Table / Programming options

| Position via CU LED Indication | PCU Acoustic signal (L=Long, S=Short) | Meaning |
|---|---|---|
| P:0 - 0:0 | 1L | Start / Default position |
| P:0 - 0:1 | 1S | Direction |
| P:0 - 0:2 | 2S | Start value SET1 |
| P:0 - 0:3 | 3S | Stop value SET1 |
| P:0 - 0:4 | 4S | Micro value SET1 |
| P:0 - 0:5 | 1L, 1S | Ramp delay up SET1 |
| P:0 - 0:6 | 1L, 2S | Ramp delay down SET1 |
| P:0 - 0:7 | 1L, 3S | Start value SET2 |
| P:0 - 0:8 | 1L, 4S | Stop value SET2 |
| P:0 - 0:9 | 2L, 1S | Micro value SET2 |
| P:0 - 1:0 | 2L, 2S | Ramp delay up SET2 |
| P:0 - 1:1 | 2L, 3S | Ramp delay down SET2 |
| P:0 - 1:2 | 2L, 4S | Start value SET3 |
| P:0 - 1:3 | 3L, 1S | Stop value SET3 |
| P:0 - 1:4 | 3L, 2S | Micro value SET3 |
| P:0 - 1:5 | 3L, 3S | Dump valve delay time |
| - | | Return to position 00 |

### 10.3.1 Position 01 - Direction

For individual adjustment of the direction of lever movement
Available values
0 or 1 (Normal or reversed direction)

When actuating a lever/joystick the LED-display will indicate which output that is active and its corresponding direction.

Example:
1:b – 0:1 meaning reversed direction is enabled for output 1

### 10.3.2 Position 02 - Start speed SET1

For individual adjustment of start speed
Available values:
Values ranging from 1-100

When activating a lever/joystick the LED-display will indicate which output that is active and its corresponding start speed.

Example:
2:A – 2:0 meaning that the start speed is set to 20% of the maximum velocity on output 2A

### 10.3.3 Position 03 - Stop speed SET1

For individual adjustment of stop speed
Available values:
Values ranging from 1-100

When activating a lever/joystick the LED-display will indicate which output that is active and its corresponding start speed.

Example:
3:b – h:I meaning stop speed is set to 100% of maximum velocity on output 3B

### 10.3.4 Position 04 - Micro speed SET1

For individual adjustment of 1st step micro speed
Available values:
Values ranging from 1-100

When activating a lever/joystick the LED-display will indicate which output that is active and its corresponding 1st step micros speed.

Example:
4:b – 6:0 meaning micro speed is set to 60% of maximum velocity on output 4B.

### 10.3.5 Position 05 - Start ramp SET1

For individual adjustment of start ramp
Available values:
Values ranging from 0-100 (0 = No ramp delay, 1-50 = x100 ms delay/step)

When activating a lever/joystick the LED-display will indicate which output that is active and its corresponding start ramp speed.

### 10.3.6 Position 06 - Stop ramp SET1

For individual adjustment of stop ramp
Available values:
Values ranging from 0-100 (0 = No ramp delay, 1-50 = x100 ms delay/step)

When activating a lever/joystick the LED-display will indicate which output that is active and its corresponding stop ramp speed.

### 10.3.7 Position 07 - Start speed SET2

For individual adjustment of start speed
Available values:
Values ranging from 1-100

When activating a lever/joystick the LED-display will indicate which output that is active and its corresponding start speed.

### 10.3.8 Position 08 - Stop speed SET2

For individual adjustment of stop speed
Available values:
Values ranging from 1-99

When activating a lever/joystick the LED-display will indicate which output that is active and its corresponding stop speed.

### 10.3.9 Position 09 - Micro speed SET2

For individual adjustment of 1st step micro speed
Available values:
Values ranging from 1-100

When activating a lever/joystick the LED-display will indicate which output that is active and its corresponding 1st step micros speed.

### 10.3.10 Position 10 - Start ramp SET2

For individual adjustment of start ramp
Available values:
Values ranging from 0-100 (0 = No ramp delay, 1-50 = x100 ms delay/step)

When activating a lever/joystick the LED-display will indicate which output that is active and its corresponding start ramp speed.

### 10.3.11 Position 11 - Stop ramp SET2

For individual adjustment of stop ramp
Available values:
Values ranging from 0-100 (0 = No ramp delay, 1-50 = x100 ms delay/step)

When activating a lever/joystick the LED-display will indicate which output that is active and its corresponding stop ramp speed

### 10.3.12 Position 12 - Start speed SET3

For individual adjustment of start speed
Available values:
Values ranging from 1-100

When activating a lever/joystick the LED-display will indicate which output that is active and its corresponding start speed.

### 10.3.13 Position 13 - Stop speed SET3

For individual adjustment of stop speed
Available values:
Values ranging from 1-00

When activating a lever/joystick the LED-display will indicate which output that is active and its corresponding stop speed.

### 10.3.14 Position 14 - Micro speed SET3

For individual adjustment of 1st step micro speed
Available values:
Values ranging from 1-100

When activating a lever/joystick the LED-display will indicate which output that is active and its corresponding 1st step micros speed.

### 10.3.15 Position 15 - Dump valve delay time

For adjustment of the dump valve delay time

A lever/joystick is required to be actuated before value can be changed.

Available values:
Values ranging from 0-100 (0= No delay, 1-99= x100 ms delay/step, 100 = Always active*

*The DV output will remain active after lever/joystick actuation until CU is reset,

# 11 Portable Control Unit self test mode

## 11.1 General description

To simplify service and faultfinding, the portable control unit can be put into internal self test mode. This means that the service man can easily control the Portable Control unit's switches and manoeuvre levers, without the need to open the Portable Control Unit. When each switch or manoeuvre lever is activated / manoeuvred the Portable Control Unit gives a "beep - signal" to confirm that the function is working.

## 11.2 Activating Portable Control Unit Self Test Mode

1. Press the Stop-button on the Portable Control Unit to disable it.

2. Twist up the Stop-button and press On-button once so that the Power-LED is illuminated red.

3. Wait approx. 1 seconds from step 2 then press the On-button in quick successions until the Power-LED is distinguished (approx 10 times).

4. Portable Control Unit Self Test Mode is now active

Each time a switch is activated / manoeuvred the control unit should beep.

Each time a manoeuvre lever is activated / manoeuvred a beep signal should be heard from the Portable Control Unit which increases in "sound intensity" along with lever displacement. The control unit beeps with a continuous tone when the manoeuvre lever is manoeuvred to maximum. This gives a confirmation that the control unit's levers have been manoeuvred fully / max. (If a certain manoeuvre lever does not beep there is a fault in the manoeuvre lever, pin / socket contact or in the control unit's electronic card).

When testing of the Portable Control Unit is completed, press down the Stop-button to exit self test mode.

Note:
When self test mode is active no data is transmitted to the Central Unit.



# 12 ID-code programming

## 12.1 General description

The unique ID-code required for radio communication is programmed between the Portable Control Unit and Central Unit

The Central Unit may store the ID-code of maximum one (1) Portable Control Unit, if another Portable Control Unit is required to operate the Central Unit via radio the ID-code procedure is required to be done.

The previous ID-code will be overwritten.

## 12.2 Procedure

1. Remove the battery pack from the Portable Control Unit. Test run the system/application via cable control.

2. Leave the cable control connected between the Portable Control Unit and the Central Unit.

3. Press the Stop-button on the Portable Control Unit and deactivate the Central Unit via the R/M-switch

4. Activate the Central Unit in REMOTE mode, twist up the Stop-button on the Portable Control Unit.

5. Press and hold the On-button on the Portable Control Unit until you get a beep indication (approx 5 seconds). Release the On-button and wait; the Portable Control Unit will beep once followed by the indication “Po-Id” in the LED-display (approx 8 seconds) then further followed by 5 beeps and the deactivate.

6. When ID- programming is completed, remove the cable control, insert battery pack and test run the system/application with radio control.

-If the initial short beep is followed by one long beep, the Central Unit LED-display indication “bL” and Portable Control Unit then deactivates the ID-programming has been rejected, check below for further info.

Note:
Via cable control option you can easily determine via the LED-display if the ID-code is accepted; if the LED-display indicates “2-” the ID-code programming procedure is required prior to radio operation, if the LED-display indicates “1-”; the ID-code has already been programmed/accepted.

Typical reasons to ID-programming failure:

The 5th step, pressing and holdning the on-button, needs to be initialized from max. 10 seconds from activation of the Central Unit.

The cable control cable is damaged, ensure that no battery is inserted in the Portable Control Unit and that the system/application can be operated via cable alone.

The Portable Control Unit deactivates immediately upon start-up, check that the Power-LED remains lit during the procedure, the Power-LED should remain lit until the last 5 beeps can be heard; if the Portable Control Unit deactivates beforehand it has an internal malfunction.

# 13 G2B Standard Cable Kits

## 13.1 General description

Various standard cable kits exist to suit certain system configurations and valves/coils.

Typically two sets of cable kits are required, one for power supply and digital functions and one for analogue functions, see below illustration.




1 = Left side; “Supply Cable kit” for power supply and digital functions.
2 = Right side; “Valve Cable kit” for analouge functions.

## 13.2 Standard Supply cable kits


For connection of power supply input, DV-output, Digital functions and CANBUS.

Central Unit type:
2010
2011
3010
3011




+/- Power supply
See chapter 5.5 - 5.6 for assignments
+/-

DV - Dump Valve output
Hirchmann GDM3009
DV





EX1 - Digital functions
See chapter 5.5 - 5.6 for assignments
EX1

EX2 - Digital functions
See chapter 5.5 - 5.6 for assignments
EX2

EX3 - CANBUS
See chapter 5.7 for assignments
EX3

EX4 - CANBUS
See chapter 5.7 for assignments
EX4

Girder/cable alignment:




Cable specification:

| Cable | Lenght | Wires x Dim. |
|---|---|---|
| +/- | 2,5 meters | 2 x 2,5mm$^2$ |
| DV | 2 meters | 2 x 1,0mm$^2$ |
| EX1 | 3 meters | 11 x 0,5mm$^2$ |
| EX2 | 3 meters | 10 x 0,5mm$^2$ |
| EX3 | 3 meters | 5 x 0,5mm$^2$ |
| EX4 | 3 meters | 5 x 0,5mm$^2$ |

Part number information:

| Part no: | Output Cables |
|---|---|
| 47979 | Power supply, DV & EX1 |
| 47752 | Power supply, DV, EX1 & EX2 |
| 48810 | Power supply, DV, EX1, EX2, EX3 & EX4 |


## 13.3 Standard valve cable kits for Sauer-Danfoss PVG-32

For connection of analogue functions for Sauer-Danfoss PVG-32 module


Central Unit type:
2010
2011





Girder/cable alignment:




**CONNECTOR:**
**AMP-JPT 4-pol**




**CONNECTOR:**
**Hirchmann GDM3009**




Cable specification:

| Cable | Lenght | Wires x Dim. |
|---|---|---|
| 1-8 | 2 meters | 3 x 0,5mm |

Part number information:

| Part no: | No of outputs | Type of connector |
|---|---|---|
| 47753 | 8 | AMP-JTP 4-pol |
| 47961 | 8 | Hirchmann GDM3009 |


## 13.3 Standard valve cable kits for HAWE

For connection of analogue functions for HAWE module


Central Unit type:
3010
3011





Girder/cable alignment:




**CONNECTOR:**
**Hirchmann GDM3009**




Cable specification:

| Cable | Lenght | Wires x Dim. |
|---|---|---|
| 1-8 | 2 meters | 3 x 0,5mm |

Part number information:

| Part no: | No of outputs | Type of connector |
|---|---|---|
| 48046 | 8 | Hirchmann GDM3009 |


## 13.3 Standard valve cable kits for PWM solenoids

For connection of analogue functions for PWM solenoids


Central Unit type:
3010
3011





Girder/cable alignment:





**CONNECTOR:**
**AMP-JPT 2-pol**




**CONNECTOR:**
**Hirchmann GDM3009**




Cable specification:

| Cable | Lenght | Wires x Dim. |
|---|---|---|
| 1-8 (A/B) | 2 meters | 2 x 0,5mm |

Part number information:

| Part no: | No of outputs | Type of connector |
|---|---|---|
| 47925 | 8 (1A-4B) | Hirchmann GDM3009 |
| 47924 | 12 (1A-6B) | Hirchmann GDM3009 |
| 47903 | 16 (1A-8B) | Hirchmann GDM3009 |
| 48238 | 12 (1A-6B) | AMP-JPT 2-pol |
| 48362 | 16 (1A-8B) | AMP-JPT 2-pol |

Bilag 1


SCANRECO

Radio Remote Control

ENGINEERING
TOMORROW

Technical Information

# PVG 32
## Proportional Valve Group



## Revision history

*Table of revisions*

| Date | Changed | Rev |
|---|---|---|
| December 2018 | Major revision of document. | 1101 |
| September 2018 | Safety topic, new PVBS spools added. | 1001 |
| July 2018 | Major update. | 0901 |
| November 2017 | Dimenions section changes. | 0803 |
| August 2017 | Added informational note to Technical Data section. | 0802 |
| March 2016 | Pressure-compensated PVB, open center PVP; Characteristics for float position main spools. | 0801 |
| February 2006 - March 2016 | Various changes | BA - 0710 |
| January 2005 | New Edition | AA |

## Contents

**General Information**

General Description....7
PVG 32 Features....7
Other technical features....7
Safety in Systems....8
PVG 32 Modules Overview....10

**PVP Inlet Modules**

Open Center PVP....12
Open Center PVP with PPRV....15
Open center PVP with HPCO and PVE PPRV....19
Closed Center PVP....22
Closed Center PVP with PPRV....24
Closed center PVPV with PPRV....27
Closed center PVPVM with PPRV....29
Open/Closed center PVP with PPRV....31
Open/Closed center PVPM....34

**PVP Inlet Module Accessories**

PVPX Electrical LS Pressure Unloading Valve....35
Part numbers for PVPX....36
PVPC without Check Valve....38
PVPC with Check Valve....39

**PVB Basic Modules**

Uncompensated PVB....41
Uncompensated PVB with load drop check valve....44
Uncompensated PVBZ with POC....47
Compensated PVB....48
Dampened Compensated PVB....51
Dampened compensated PVB with LS A/B....54
Compensated PVB with LS A/B....57
Compensated high flow PVB....61
Compensated high flow PVB with LS A/B....64
Compensated PVBZ with POC....68
Compensated high flow PVBZ with POC....70
Compensated high flow PVBZ with POC and manifold interface....73

**PVB Basic Modules Accessories**

PVLP Shock and Anti-Cavitation Valve....76
PVLA Suction Valve....78

**PVSP and PVSPM Priority Modules**

PVSP and PSPVM Versions Overview....80
Sectional view of priority modules PVSP/PVSPM....82
Compensator spool for PVSP/PVSPM....83

**PVBD Diverter Module**

PVBD Diverter Principle....84
PVBD Diverter Module Overview....85

**PVBS Main Spools**

PVBS fluid flow characteristics—Theoretical performance....87

**PVBS Main Spools Part Numbers**

Flow Control Spools—Closed Neutral Position....92
Flow Control Spools—Closed Neutral Position with A-float....96
Flow Control Spools—Closed Neutral Position with B-float....96
Flow Control Spools—Closed Neutral Position with A-float for PVMF....98
Flow Control Spools—Closed Neutral Position with B-float for PVMF....98
Flow Control Spools—Closed Neutral Position for PVMR....99
Flow Control Spools—Open/Closed Neutral Position....99
Flow Control Spools—Open/Closed A and Closed B Position....100

## Contents

Flow Control Spools—Throttled Open Neutral Position ... 101
Flow Control Spools—Throttled Open Neutral Position for PVMR ... 105
Flow Control Spools—Throttled A to T Neutral Position ... 106
Flow Control Spools—Throttled B to T Neutral Position ... 107
Linear Flow Control Spools—Closed Neutral Position ... 108
Linear Flow Control Spools—Throttled Open Neutral Position ... 109
Linear Flow Control Spools—Open/Closed Neutral Position ... 110
Single Acting Cylinder Flow Control Spools—Neutral A-port Position ... 110
Single Acting Cylinder Flow Control Spools—Neutral B-port Position ... 112
Single Acting Cylinder Linear Flow Control Spools—Neutral B-port Position ... 112
Flow/Pressure Control Spools—Closed Neutral Position ... 113
Flow/Pressure Control Spools—Throttled Open Neutral Position ... 113
Flow/Pressure Control Spools—Throttled Open B to T in Neutral Position ... 114
Flow/Pressure Control Spools—Throttled Open A to T in Neutral Position ... 116
Flow/Pressure Control Spools—Throttled Open B to T in Neutral Position ... 117
Flow/Pressure Control Spools—Open/Closed in Neutral Position ... 117
Flow/Pressure Control Spools—Closed A and Open/Closed B Position ... 117
Pressure Control Spools—Closed Neutral Position ... 118
Pressure Control Spools—Throttled Open Neutral Position ... 119
Pressure Control Spools—Throttled A to T in Neutral Position ... 120
Pressure/Flow Control Spools—Closed Neutral Position ... 121
Pressure/Flow Control Spools—Closed Neutral Position with B-float ... 122
Pressure/Flow Control Spools—Throttled Open Neutral Position ... 122
Pressure/Flow Control Spools—Open/Closed Neutral Position ... 122
Pressure/Flow Control Spools—Open/Closed A and Closed B Position ... 123

**PVBS for PVBZ Main Spools Part Numbers**

PVBZ Flow Control Spools—Closed Neutral Position ... 124
PVBZ Flow Control Spools—Closed Neutral Position with A-float ... 124
PVBZ Flow Control Spools—Closed Neutral Position with B-float ... 125
PVBZ Flow Control Spools—Throttled Open Neutral Position with B-float ... 126
PVBZ Linear Flow Control Spools—Closed Neutral Position ... 127
PVBZ Single Acting Cylinder Flow Control Spools—Closed Neutral A-port Position ... 127
PVBZ Single Acting Cylinder Flow Control Spools—Closed Neutral B-port Position ... 128
PVBZ Single Acting Cylinder Linear Flow Control Spools—Closed Neutral B-port Position ... 128
PVBZ–HS Single Acting Cylinder Flow Control Spools—Closed Neutral Position ... 128

**PVDI Directional Indicator**

**PVG 32 Actuation**

PVM Manual Actuation ... 131
- PVM functionality ... 132
- PVMD/F/R Detention Covers ... 133
- Part Numbers for PVMD/F/R Covers ... 133
- PVML, Spring Centering Cover ... 134

PVH Hydraulic Actuation ... 135
PVHC Electro-Hydraulic Actuation ... 136

**PVE Electro-hydraulic Actuation**

PVE Series 4 ... 140
- PVEP ... 140
- PVEP Technical Data ... 142

PVE Series 5 ... 144
- PVED-CC Series 5 ... 144
- Operating data overview ... 145
- Connectors ... 146
- LED coloring for PVED-CC Series 5 ... 147
- PVED-CC Hysteresis and Ripple ... 147
- PVED-CC Reaction Times ... 148
- PVED-CC Part Numbers ... 148

PVE Series 7 ... 149

## Contents

PVEO....149
PVEO Technical Data....151
PVEO Reaction Times....152
PVEO Part Numbers....152
PVEO-HP....154
PVEO-HP Technical Data....155
PVEO-HP Reaction Times....156
PVEO-HP Part Numbers....157
PVEM....158
PVEM Technical Data....159
PVEM Reaction Times....160
PVE Hysteresis and Ripple....161
PVEM part numbers....161
PVEA....162
PVEA Technical Data....163
PVEA Reaction Times....164
PVE Hysteresis and Ripple....164
PVEA part numbers....164
PVEH....166
PVEH Technical Data....166
PVEH Reaction Times....168
PVE Hysteresis and Ripple....168
PVEH Part Numbers....168
PVES....170
PVES Technical Data....171
PVES Reaction Times....172
PVE Hysteresis and Ripple....172
PVES Part Numbers....172
Connector Overview....174
Extension plates for PVE Series 7....176

**Fault Monitoring and Reaction**

Generic Fault Reaction....177
Fault Reaction Overview....178
Error Pin Specification....178

**Functionality Overview**

PWM Voltage Control....179
Float A-Port (-FLA)....180
Float B-Port (-FLB)....180
PVE Power Save....180

**Special Features**

Direction Indication (-DI)....182
Dedicated Float Pin (UF)....183
Spool Position (SP)....184
Neutral Power-OFF (NP)....185
Disable Mode....186

**PVS End Plates**

PVS/PVSI....189
PVS/PVSI with LX-connection....191
PVSI with P-, T-, LX- and M-connection....193
PVST with T-connection....194
PVSI Start Plate....195
PVSD End Plate....196
PVSI with PVE PPRV....198
PVST with PVE PPRV and PP dump....200

**PVSKM Full Flow Cut Off Modules**

PVSKM Functionality....203

## Contents

PVSKM Spool ..... 205

**PVAS Stay Bolts**

PVAS Part Numbers ..... 207
PVG 32 modules total length ..... 208
PVG 32/16 Combinations ..... 208
PVG 256/128/32/16 Combinations ..... 209

**PVG 32 Combinations Valve Stack Dimensions**

PVG 32 Dimensions ..... 211
PVG 32/16 Dimensions ..... 213
PVG 100/32 Dimensions ..... 215
PVG 120/32 Dimensions ..... 217
PVG 128/32 Dimensions ..... 219
PVG 256/32 Dimensions ..... 221

## General Information

### General Description

PVG is a hydraulic, load-sensing proportional valve, designed for optimal machine performance and maximum design flexibility. The PVG valve design is based on a modular concept that enables machine designers to specify a valve solution suitable for multiple market segments across multiple applications.

The PVG 32 is a member of the PVG product platform and interfaces to other valve families enabling all machine functions being controlled from one single valve stack.

PVG 32 controls work port flow up to 125 l/min [33 US gal/min] l/min and up to 420 bar [6090 psi] bar work port pressure.

The load independent proportional control valve and high performance actuator technology combined with a low pressure drop design improves the machine performance and efficiency – increasing productivity and reducing energy consumption.

### PVG 32 Features

PVG load-sensing proportional valves features and benefits summarized in bullets below:

- Load-independent flow control:
  - Oil flow to an individual function is independent of the load pressure of this function
  - Oil flow to one function is independent of the load pressure of other functions
- Possible combination with the rest of the PVG family, when using an interface module
- Up to 12 basic modules per PVG 32 valve group
- Reliable regulation characteristics across the entire flow range
- Load sense relief valves for A and B port enables reduced energy loss at target pressure
- Several options for connection threads and flange mount
- Compact design, easy installation and serviceability
- Energy-saving
- Low weight

#### Other technical features

Inlets, work section housing, and actuation methods features are listed below:

***Inlets include:***

- Built-in pressure relief valve
- Pressure gauge connection
- Versions for different pump types
  - Open center systems with fixed displacement pumps
  - Closed center systems with variable displacement pumps
- Integrated pilot oil supply

***Work section housing include:***

- Interchangeable spools
- Pressure gauge connection
- Versions for different application needs:
  - Built-in compensator for load independent flow
  - Built-in load holding check valve in P-channel
  - Integrated shock/suction valve
  - Integrated local pressure relief valve

## General Information

***Actuation methods include:***

- Manual control
  - with lever
  - with friction detent
- Hydraulic control
- Electro-hydraulic
  - ON/OFF control
  - Ratiometric proportional control
  - CAN bus proportional control
  - PWM proportional control

## Safety in Systems

All types and brands of control valves, including proportional valves, can fail. Therefore, the necessary protection against the serious consequences of a functional failure should always be built into the system.

### General safety considerations

For each application an assessment should be made for the consequences of the system in case of pressure failure and uncontrolled or blocked movements.

**Warning**

Because the proportional valve is used in many different applications and under different operating conditions, it is the sole responsibility of the manufacturer to ensure that all performance, safety and warning requirements of the application is met in his selection of products and complies with relevant machine specific and generic standards.

### Control system example

An example of a control system using an aerial lift is shown below:

*Aerial lift*




## General Information

This example breaks down the control system into smaller bits explaining the architecture in depth. Even though many Danfoss components are used in the PVG control system.

The function of the control system is to use the output from the PVE together other external sensors to ensure the PLUS+1 main controllers correct function of the aerial lift.

*Electrical block diagram*




**Warning**

It is the responsibility of the equipment manufacturer that the control system incorporated in the machine is declared as being in conformity with the relevant machine directives.

**Caution**

A mix of electrical actuation and hydraulic actuation on the same valve stack is not safe. PVE and PVH are designed for different pilot pressure.


Cost-free repairs, as mentioned in Danfoss General Conditions of Sale, are carried out only at Danfoss or at service shops authorized by Danfoss.

## General Information

### PVG 32 Modules Overview

PVG proportional valve group shown in the exploded view illustration for a quick modules navigation.

*PVG 32 Modules Assembly Overview*




***PVG Modules Navigation:***

*PVP Inlet Modules* on page 11 and *PVP Inlet Module Accessories* on page 35

*PVB Basic Modules* on page 40

*PVSP and PVSPM Priority Modules* on page 79

*PVBD Diverter Module* on page 84

*PVBS Main Spools* on page 86

*PVM Manual Actuation* on page 131

*PVE Electro-hydraulic Actuation* on page 138

*PVH Hydraulic Actuation* on page 135

*PVHC Electro-Hydraulic Actuation* on page 136

*PVDI Directional Indicator* on page 129

*PVSKM Full Flow Cut Off Modules* on page 202

*PVS End Plates* on page 187

*PVAS Stay Bolts* on page 207


## PVP Inlet Modules

The PVG 32 PVP inlet modules, also referred to as pump side modules, act as an interface between the PVG 32 proportional valve group and the hydraulic pump and tank reservoir.

*PVP Inlet Module*





*PVP inlet module dimensions*





Weight: 3.1 kg [6.9 lb]

*Fixed displacement pump symbol*



*Variable displacement pump symbol*



The PVP inlet module variants are based on a generic platform with a selection of additional features, enabling you to tailor the PVP to suit the demands of any hydraulic system:

- *Open Center PVP* on page 12 (for fixed displacement pumps)
- *Open Center PVP with PPRV* on page 15 (for fixed displacement pumps)
- *Open center PVP with HPCO and PVE PPRV* on page 19 (for fixed displacement pumps)
- *Closed Center PVP* on page 22 (for variable displacement pumps)
- *Closed Center PVP with PPRV* on page 24 (for variable displacement pumps)
- *Closed center PVPV with PPRV* on page 27 (for variable displacement pumps)
- *Closed center PVPVM with PPRV* on page 29 (for variable displacement pumps)
- *Open/Closed center PVP with PPRV* on page 31
- *Open/Closed center PVPM* on page 34

## PVP Inlet Modules

### Open Center PVP


The basic Open Center PVP inlet module is intended for use with fixed displacement pumps in applications, where a valve group with mechanically controlled work sections is desired, or where the pilot pressure to the valve group is supplied externally.

**The Open Center PVP features:**

- Integrated LS pressure relief valve
- Threaded ports for P/T/LS and M measuring gauge
- Optional LS unloading valve, PVPX
- Optional T0 facility and external T0 port

All modules can be manually activated with the PVM actuation.

*Open center PVP schematic*




*Technical specification for PVP*

| Max. P-port continuous | Max. P-port intermittent | Max. T-port static/ dynamic | Max. rated flow |
|---|---|---|---|
| 350 [5076 psi] | 400 bar [5800 psi] | 25/40 bar [365/580 psi] | 140 l/min [37 US gal/min] |


*Technical specification*

| Parameter | Minimum | Recommended range | Maximum |
|---|---|---|---|
| **Fluid temperature** | -30°C [-22°F] | 30 to 60°C [86 to 140°F] | 90° [194°F] |
| **Fluid viscosity** | 4 $mm^2/s$ [39 SUS] | 12 to 75 $mm^2/s$ [65 to 347 SUS] | 460 $mm^2/s$ [2128 SUS] |
| **Fluid cleanliness** | 23/19/16 (according to ISO 4406) | | |
| **Operating temperature** | Ambient: -30 to 60°C [-22 to 140°F] | | |


## PVP Inlet Modules

### Theoretical Performance Graphs

*Integrated LS pressure relief valve characteristics*




*Neutral by-pass pressure drop characteristics*




*Part numbers for Open Center PVP*

| Part number | P-port | T-port | LS-, M-port (LS1**) | T0-port | Mounting | PVPX* |
|---|---|---|---|---|---|---|
| **157B5000** | G1/2" | G3/4" | G1/4" | - | M8 | – |
| **157B5100** | G3/4" | | | – | | - |
| **157B5102** | G3/4" | | | - | | Yes |
| **157B5200** | 7/8-14 UNF | 1 1/16-12 UNF | 1/2-20 UNF | - | 5/16-18 UNC | - |
| **157B5300** | 1-1/16 UN | | | - | | - |
| **11008852** | G1/2 | G3/4 | G1/4 (G1/8) | - | M8 | - |
| **11030545** | G3/4 | G3/4 | G1/4 (G1/4) | G1/4 | M8 | - |
| **11053947** | G3/4 | G3/4 | G1/4 (G1/4) | G1/4 | M8 | - |
| **11151852** | 1 1/16-12 UNF | 1 1/16-12 UNF | 9/16-18 UNF | 9/16-18 UNF | M8 | - |
| **157B5908** | 1 1/16-12 UNF | 1 1/16-12 UNF | 1/2-20 UNF | - | M8 | - |
| **157B5921** | JIS 1/2 | JIS 3/4 | JIS 1/4 | - | M8 | - |

## PVP Inlet Modules

*Part numbers for Open Center PVP (continued)*

| Part number | P-port | T-port | LS-, M-port (LS1**) | T0-port | Mounting | PVPX* |
|---|---|---|---|---|---|---|
| **157B5925** | JIS 1/2 | JIS 3/4 | JIS 1/4 | - | M8 | - |
| **157B5945** | G1/2 | G3/4 | G1/4 | - | M8 | - |
| **157B5990** | 1 1/16-12 UNF | 1 1/16-12 UNF | - | - | M8 | - |

** LS1 is an extra LS-port.

* For more information see *PVPX Electrical LS Pressure Unloading Valve* on page 35.

## PVP Inlet Modules

### Open Center PVP with PPRV


The Open Center PVP inlet with integrated pilot pressure reduction valve (PPRV) is intended for use with fixed displacement pumps in applications, where a valve group with electro-hydraulically or hydraulically controlled work sections is desired (PVE or PVH/PVHC).

**The Open Center PVP with PPRV features:**

- Integrated LS pressure relief valve
- Threaded ports for P/T/LS and M measuring gauge
- Integrated pilot pressure reducing valve (PPRV) for PVE or PVH/PVHC
- Optional T0 facility and external T0 port
- Optional external pilot pressure port (Pp)
- Optional LS unloading valve, PVPX

All modules can be manually activated with the PVM actuation.

*Open center PVP with PPRV schematic*




*Technical specification for PVP*

| Max. P-port continuous | Max. P-port intermittent | Max. T-port static/ dynamic | Max. rated flow |
|---|---|---|---|
| 350 [5076 psi] | 400 bar [5800 psi] | 25/40 bar [365/580 psi] | 140 l/min [37 US gal/min] |


*Technical specification*

| Parameter | Minimum | Recommended range | Maximum |
|---|---|---|---|
| **Fluid temperature** | -30°C [-22°F] | 30 to 60°C [86 to 140°F] | 90° [194°F] |
| **Fluid viscosity** | 4 $mm^2/s$ [39 SUS] | 12 to 75 $mm^2/s$ [65 to 347 SUS] | 460 $mm^2/s$ [2128 SUS] |
| **Fluid cleanliness** | 23/19/16 (according to ISO 4406) | | |
| **Operating temperature** | Ambient: -30 to 60°C [-22 to 140°F] | | |


## PVP Inlet Modules

### Theoretical Performance Graphs


*Integrated LS pressure relief valve characteristics*




*Neutral by-pass pressure drop characteristics*




*Pilot pressure reduction valve characteristics*



## PVP Inlet Modules

*Part numbers for Open Center PVP with PPRV*

| Part number | Actuation | P-port | T-port | LS-port | M-port | Pp-port | T0-port | Mounting | PVPX* |
|---|---|---|---|---|---|---|---|---|---|
| **11008849** | PVE | G3/4″ | G3/4″ | G1/4″ | G1/4″ | - | - | M8 | - |
| **11008851** | PVH/PVHC | G3/4″ | G3/4″ | G1/4″ | G1/4″ | G1/4″ | - | M8 | - |
| **11066027** | PVH/PVHC | G3/4″ | G3/4″ | G1/4″ | G1/4″ | - | - | M8 | Yes |
| **11072195** | PVE | M27x2 | M27x2 | M14x1.5 | M14x1.5 | - | M14x1.5 | M8 | - |
| **157B5010** | PVE | G1/2″ | G3/4″ | G1/4″ | G1/4″ | - | - | M8 | - |
| **157B5012** | PVE | G1/2″ | G3/4″ | G1/4″ | G1/4″ | - | - | M8 | Yes |
| **157B5110** | PVE | G3/4″ | G3/4″ | G1/4″ | G1/4″ | - | - | M8 | - |
| **157B5112** | PVE | G3/4″ | G3/4″ | G1/4″ | G1/4″ | - | - | M8 | Yes |
| **157B5130** | PVE | G3/4″ | G3/4″ | G1/4″ | G1/4″ | G1/4″ | G1/4″ | M8 | - |
| **157B5132** | PVE | G3/4″ | G3/4″ | G1/4″ | G1/4″ | G1/4″ | - | M8 | Yes |
| **157B5180** | PVE | G3/4″ | G3/4″ | G1/4″ | G1/4″ | G1/4″ | - | M8 | - |
| **157B5190** | PVH/PVHC | G3/4″ | G3/4″ | G1/4″ | G1/4″ | G1/4″ | - | M8 | - |
| **157B5210** | PVE | 7/8-14 UNF | 1 1/16-12 UNF | 1/2-20 UNF | 1/2-20 UNF | - | - | 5/16-18 UNC | - |
| **157B5212** | PVE | 7/8-14 UNF | 1 1/16-12 UNF | 1/2-20 UNF | 1/2-20 UNF | - | - | 5/16-18 UNC | Yes |
| **157B5310** | PVE | 1 1/16-12 UNF | 1 1/16-12 UNF | 1/2-20 UNF | 1/2-20 UNF | - | - | 5/16-18 UNC | - |
| **157B5312** | PVE | 1 1/16-12 UNF | 1 1/16-12 UNF | 1/2-20 UNF | 1/2-20 UNF | - | - | 5/16-18 UNC | Yes |
| **157B5330** | PVE | 1 1/16-12 UNF | 1 1/16-12 UNF | 1/2-20 UNF | 1/2-20 UNF | 1/2-20 UNF | - | 5/16-18 UNC | - |
| **157B5332** | PVE | 1 1/16-12 UNF | 1 1/16-12 UNF | 1/2-20 UNF | 1/2-20 UNF | - | - | 5/16-18 UNC | Yes |
| **157B5380** | PVE | 1 1/16-12 UNF | 1 1/16-12 UNF | 9/16-18 UNF | 9/16-18 UNF | 9/16-18 UNF | - | 5/16-18 UNC | - |
| **157B5390** | PVH/PVHC | 1 1/16-12 UNF | 1 1/16-12 UNF | 9/16-18 UNF | 9/16-18 UNF | 9/16-18 UNF | - | 5/16-18 UNC | - |
| **11101194** | PVE | M22x1.5<br>M16x1.5 (P2) | M22x1.5 | M12x1.5 | M10x1 | - | M16x1.5 | M8 | - |
| **11008850** | PVE | G3/4 | G3/4 | G1/4 | G1/4 | - | - | M8 | Yes |
| **11013317**[1] | PVE | G3/4 | G3/4 | G1/4 | G1/4 | G1/4 | G1/4 | M8 | - |
| **11020964** | PVE | 1 1/16-12 UNF | 1 1/16-12 UNF | 1/2-20 UNF | 1/2-20 UNF | - | - | M8 | - |
| **11087590**[1] | PVH/PVHC | G3/4 | G3/4 | G1/4 | G1/4 | G1/4 | - | M8 | - |
| **11090453** | PVE | JIS 3/4 | JIS 3/4 | JIS 1/4 | JIS 1/4 | JIS 1/4 | JIS 1/4 | M8 | - |
| **11119429**[2] | PVE | G3/4 | G3/4 | G1/4 | G1/4 | G1/4 | - | M8 | - |
| **11124965** | PVH/PVHC | G3/4 | G3/4 | G1/4 | G1/4 | G1/4 | - | M8 | Yes |
| **11124966** | PVH/PVHC | G3/4 | G3/4 | G1/4 | G1/4 | G1/4 | - | M8 | - |
| **11130941**[2] | PVE | 1 1/16-12 UNF | 1 1/16-12 UNF | 9/16-18 UNF | 9/16-18 UNF | 9/16-18 UNF | - | 5/16-18 UNC | - |
| **11167773** | PVH/PVHC | 1 1/16-12 UNF | 1 1/16-12 UNF | 1/2-20 UNF | 1/2-20 UNF | - | - | 5/16-18 UNC | Yes |
| **11187356** | PVE | G1/2 | G3/4 | G1/4 | G1/4 | - | - | M8 | Yes |
| **11190123** | PVH/PVHC | G1/2 | G3/4 | G1/4 | G1/4 | - | - | M8 | Yes |
| **11196947** | PVE | G3/4 | G3/4 | G1/4 | G1/4 | - | G1/4 | M8 | - |
| **11225941** | PVE | 1 1/16-12 UNF | 1 1/16-12 UNF | 9/16-18 UNF | 9/16-18 UNF | 9/16-18 UNF | 9/16-18 UNF | 5/16-18 UNC | - |
| **157B5135**[3] | PVE | G3/4 | G3/4 | G1/4 | G1/4 | G1/4 | G1/4 | M8 | - |
| **157B5904**[2] | PVE | G3/4 | G3/4 | G1/4 | G1/4 | G1/4 | - | M8 | - |
| **157B5923** | PVE | JIS 1/2 | JIS 3/4 | JIS 1/4 | JIS 1/4 | - | - | M8 | - |

## PVP Inlet Modules

*Part numbers for Open Center PVP with PPRV (continued)*

| Part number | Actuation | P-port | T-port | LS-port | M-port | Pp-port | T0-port | Mounting | PVPX* |
|---|---|---|---|---|---|---|---|---|---|
| **157B5926** | PVE | JIS 3/4 | JIS 3/4 | JIS 1/4 | JIS 1/4 | - | - | M8 | - |
| **157B5934** | PVE | G3/4 | G3/4 | G1/4 | G1/4 | - | - | M8 | - |
| **157B5943**[2] | PVH/PVHC | G3/4 | G3/4 | G1/4 | G1/4 | G1/4 | - | M8 | - |
| **157B5953**[2] | PVE | G3/4 | G3/4 | G1/4 | G1/4 | - | - | M8 | Yes |
| **157B5954** | PVE | G3/4 | G3/4 | G1/4 | G1/4 | G1/4 | - | M8 | - |
| **157B5960** | PVE | 1 1/16-12 UNF | 1 1/16-12 UNF | 9/16-18 UNF | 9/16-18 UNF | - | 9/16-18 UNF | 5/16-18 UNF | - |
| **157B5966** | PVE | G3/4 | G3/4 | G1/4 | G1/4 | - | - | M8 | Yes |
| **157B5976** | PVE | G3/4 | G3/4 | G1/4 | G1/4 | - | - | M8 | Yes |
| **157B5977**[1,4] | PVE | G3/4 | G3/4 | G1/4 | G1/4 | - | - | M8 | - |
| **11101194** | PVE | M22 x 1.5 | M22 x 1.5 | M12 x 1.5 | M10 x 1 | - | M16 x 1.5 | M8 | - |

* For more information please see the topic *PVPX Electrical LS Pressure Unloading Valve*.

[1] Dampened LS response

[2] Pressure adjustment spool with check valve

[3] Internal T0 connection

[4] Low flow pressure adjustment spool

## PVP Inlet Modules

### Open center PVP with HPCO and PVE PPRV

The Open Center PVP inlet with integrated High Pressure Carry Over (HPCO) functionality is intended for use with fixed displacement pumps in applications where one pump supply for multiple hydraulic subsystems is desired.


The integrated HPCO functionality guides the excess flow of the PVG 32 valve group to the external hydraulic subsystem(s), giving priority to the PVG 32 work functions.

**The Open Center PVP with HPCO and PVE PPRV features:**

- Integrated LS pressure relief valve
- Threaded ports for P/T/LS/HPCO and M measuring gauge
- Integrated pilot pressure reducing valve (PPRV) for PVE
- Optional T0 facility and external T0 port
- Optional external pilot pressure port (Pp)
- Optional LS unloading valve, PVPX

Only applicable with PVST end plates with separate T-port due to blocked T-lines for HPCO functionality.

*Open Center PVP with HPCO, PVE PPRV schematic*




*Technical specification for PVP*

| Max. P-port continuous | Max. P-port intermittent | Max. T-port static/ dynamic | Max. rated flow |
|---|---|---|---|
| 350 [5076 psi] | 400 bar [5800 psi] | 25/40 bar [365/580 psi] | 140 l/min [37 US gal/min] |


*Technical specification*

| Parameter | Minimum | Recommended range | Maximum |
|---|---|---|---|
| **Fluid temperature** | -30°C [-22°F] | 30 to 60°C [86 to 140°F] | 90° [194°F] |
| **Fluid viscosity** | 4 $mm^2/s$ [39 SUS] | 12 to 75 $mm^2/s$ [65 to 347 SUS] | 460 $mm^2/s$ [2128 SUS] |
| **Fluid cleanliness** | 23/19/16 (according to ISO 4406) | | |
| **Operating temperature** | Ambient: -30 to 60°C [-22 to 140°F] | | |


## PVP Inlet Modules

### Theoretical Performance Graphs


*Integrated LS pressure relief valve characteristics*




*Neutral by-pass pressure drop characteristics*




*Pilot pressure reduction valve characteristics*



## PVP Inlet Modules

*Part numbers for OC PVP (HPCO and PPRV)*

| Part number | P-port | HPCO-port | LS-port | M-port | Pp-port | T0-port | Mounting | PVPX* |
|---|---|---|---|---|---|---|---|---|
| **157B5140** | G3/4″ | G3/4" | G1/4″ | G1/4″ | G1/4″ | G1/4″ | M8 | - |
| **157B5142** | G3/4″ | G3/4" | G1/4″ | G1/4″ | G1/4″ | – | M8 | Yes |
| **157B5340** | 1 1/16-12 UNF | 1 1/16-12 UNF | 1/2-20 UNF | 1/2-20 UNF | 1/2-20 UNF | 1/2-20 UNF | 5/16-18 UNC | - |
| **157B5342** | 1 1/16-12 UNF | 1 1/16-12 UNF | 1/2-20 UNF | 1/2-20 UNF | 1/2-20 UNF | – | 5/16-18 UNC | Yes |
| **157B5961** | M27x2 | M27x2 | M14x1.5 | M14x1.5 | – | M14x1.5 | M8 | – |
| **11101195** | M22x1.5<br>M16x1.5 (P2) | M22x1.5 | M12x1.5 | M10x1 | – | M16x1.5 | M8 | – |

* For more information please see the topic *PVPX Electrical LS Pressure Unloading Valve*.

## PVP Inlet Modules


### Closed Center PVP

The basic Closed Center PVP inlet is intended for use with variable displacement pumps in applications where a valve group with mechanically controlled work sections is desired, or where the pilot pressure to the valve group is supplied externally.

**The Closed Center PVP features:**

- Integrated LS pressure relief valve
- Threaded ports for P/T/LS and M measuring gauge
- Optional LS unloading valve, PVPX
- Optional T0 facility and external T0 port

*Closed center PVP schematic*




*Technical specification for PVP*

| Max. P-port continuous | Max. P-port intermittent | Max. T-port static/ dynamic | Max. rated flow |
|---|---|---|---|
| 350 [5076 psi] | 400 bar [5800 psi] | 25/40 bar [365/580 psi] | 140 l/min [37 US gal/min] |


*Technical specification*

| Parameter | Minimum | Recommended range | Maximum |
|---|---|---|---|
| **Fluid temperature** | -30°C [-22°F] | 30 to 60°C [86 to 140°F] | 90° [194°F] |
| **Fluid viscosity** | 4 $mm^2/s$ [39 SUS] | 12 to 75 $mm^2/s$ [65 to 347 SUS] | 460 $mm^2/s$ [2128 SUS] |
| **Fluid cleanliness** | 23/19/16 (according to ISO 4406) | | |
| **Operating temperature** | Ambient: -30 to 60°C [-22 to 140°F] | | |

## PVP Inlet Modules

### Theoretical Performance Graphs

*Integrated LS pressure relief valve characteristics*




*Part numbers for Closed Center PVP*

| Part number | P-port | T-port | LS-port (LS1**) | M-port | T0-port | Mounting | PVPX* |
|---|---|---|---|---|---|---|---|
| 11030683 | G3/4 | G3/4 | G1/4 (G1/4) | G1/4 | G1/4 | M8 | - |
| 157B5001 | G1/2 | G3/4 | G1/4 | G1/4 | - | M8 | - |
| 157B5101 | G3/4 | G3/4 | G1/4 | G1/4 | - | M8 | - |
| 157B5103 | G3/4 | G3/4 | G1/4 | G1/4 | - | M8 | Yes |
| 157B5201 | 7/8-14 UNF | 1 1/16-12 UNF | 1/2-20 UNF | 1/2-20 UNF | -- | 5/16-18 UNC | - |
| 157B5301 | 1 1/16-12 UNF | 1 1/16-12 UNF | 1/2-20 UNF | 1/2-20 UNF | - | 5/16-18 UNC | - |
| 15B5907 | 1 1/16-12 UNF | 1 1/16-12 UNF | 1/2-20 UNF | 1/2-20 UNF | - | M8 | - |
| 157B5922 | JIS 1/2 | JIS 3/4 | JIS 1/4 | JIS 1/4 | - | M8 | - |
| 157B5927 | JIS 3/4 | JIS 3/4 | JIS 1/4 | JIS 1/4 | - | M8 | - |
| 157B5946 | G1/2 | G3/4 | G1/4 (G1/8) | G1/4 | - | M8 | - |

** LS1 is an extra LS-port

* For more information see *PVPX Electrical LS Pressure Unloading Valve* on page 35

## PVP Inlet Modules


### Closed Center PVP with PPRV

The Closed Center PVP inlet with integrated pilot pressure reduction valve (PPRV) is intended for use with variable displacement pumps in applications where a valve group with electro-hydraulic or hydraulically controlled work sections is desired.

**The Closed Center PVP with PPRV features:**

- Integrated LS pressure relief valve
- Threaded ports for P/T/LS and M measuring gauge
- Integrated pilot pressure reducing valve (PPRV) for PVE or PVH/PVHC
- Optional T0 facility and external T0 port
- Optional LS unloading valve, PVPX

*Closed center PVP with PPRV schematic*




*Technical specification for PVP*

| Max. P-port continuous | Max. P-port intermittent | Max. T-port static/ dynamic | Max. rated flow |
|---|---|---|---|
| 350 [5076 psi] | 400 bar [5800 psi] | 25/40 bar [365/580 psi] | 140 l/min [37 US gal/min] |


*Technical specification*

| Parameter | Minimum | Recommended range | Maximum |
|---|---|---|---|
| **Fluid temperature** | -30°C [-22°F] | 30 to 60°C [86 to 140°F] | 90° [194°F] |
| **Fluid viscosity** | 4 $mm^2/s$ [39 SUS] | 12 to 75 $mm^2/s$ [65 to 347 SUS] | 460 $mm^2/s$ [2128 SUS] |
| **Fluid cleanliness** | 23/19/16 (according to ISO 4406) | | |
| **Operating temperature** | Ambient: -30 to 60°C [-22 to 140°F] | | |


## PVP Inlet Modules

### Theoretical Performance Graphs

*Integrated LS pressure relief valve characteristics*




*Pilot pressure reduction valve characteristics*




*Part numbers for Closed Center PVP with PPRV*

| Part number | Actuation | P-port | T-port | LS-port (LS1**) | M-port | Pp-port | T0-port | Mounting | PVPX* |
|---|---|---|---|---|---|---|---|---|---|
| **11051802** | PVH/PVHC | 1 1/16-12 UNF | 1 1/16-12 UNF | 1/2-20 UNF | 1/2-20 UNF | 1/2-20 UNF | 1/2-20 UNF | 5/16-18 UNC | - |
| **157B5011** | PVE | G1/2" | G3/4" | G1/4" | G1/4" | - | - | M8 | - |
| **157B5013** | PVE | G1/2" | G3/4" | G1/4" | G1/4" | - | - | M8 | Yes |
| **157B5111** | PVE | G3/4" | G3/4" | G1/4" | G1/4" | - | - | M8 | - |
| **157B5113** | PVE | G3/4" | G3/4" | G1/4" | G1/4" | - | - | M8 | Yes |
| **157B5131** | PVE | G3/4" | G3/4" | G1/4" | G1/4" | G1/4" | G1/4" | M8 | - |
| **157B5133** | PVE | G3/4" | G3/4" | G1/4" | G1/4" | G1/4" | - | M8 | Yes |
| **157B5181** | PVE | G3/4" | G3/4" | G1/4" | G1/4" | G1/4" | - | M8 | - |
| **157B5191** | PVH/PVHC | G3/4" | G3/4" | G1/4" | G1/4" | G1/4" | - | M8 | - |
| **157B5211** | PVE | 7/8-14 UNF | 1 1/16-12 UNF | 1/2-20 UNF | 1/2-20 UNF | - | - | 5/16-18 UNC | - |

## PVP Inlet Modules

*Part numbers for Closed Center PVP with PPRV (continued)*

| Part number | Actuation | P-port | T-port | LS-port (LS1**) | M-port | Pp-port | T0-port | Mounting | PVPX* |
|---|---|---|---|---|---|---|---|---|---|
| **157B5213** | PVE | 7/8-14 UNF | 1 1/16-12 UNF | 1/2-20 UNF | 1/2-20 UNF | - | - | 5/16-18 UNC | Yes |
| **157B5311** | PVE | 1 1/16-12 UNF | 1 1/16-12 UNF | 1/2-20 UNF | 1/2-20 UNF | - | - | 5/16-18 UNC | - |
| **157B5313** | PVE | 1 1/16-12 UNF | 1 1/16-12 UNF | 1/2-20 UNF | 1/2-20 UNF | - | - | 5/16-18 UNC | Yes |
| **157B5331** | PVE | 1 1/16-12 UNF | 1 1/16-12 UNF | 1/2-20 UNF | 1/2-20 UNF | 1/2-20 UNF | 1/2-20 UNF | 5/16-18 UNC | - |
| **157B5333** | PVE | 1 1/16-12 UNF | 1 1/16-12 UNF | 1/2-20 UNF | 1/2-20 UNF | 1/2-20 UNF | 1/2-20 UNF | 5/16-18 UNC | Yes |
| **157B5381** | PVE | 1 1/16-12 UNF | 1 1/16-12 UNF | 9/16-18 UNF | 9/16-18 UNF | 9/16-18 UNF | - | 5/16-18 UNC | - |
| **157B5391** | PVH/PVHC | 1 1/16-12 UNF | 1 1/16-12 UNF | 9/16-18 UNF | 9/16-18 UNF | 9/16-18 UNF | - | 5/16-18 UNC | |

** LS1 is an extra LS-port

* For more information please see *PVPX Electrical LS Pressure Unloading Valve* on page 35

All modules can be manually activated with the PVM actuation.

## PVP Inlet Modules


### Closed center PVPV with PPRV

The Closed Center PVPV inlet with integrated pilot pressure reduction valve (PPRV) is intended for use with variable displacement pumps in applications where a valve group with electro-hydraulic or hydraulically controlled work sections is desired.

**The Closed Center PVPV with PPRV features:**

- Optional shock/anti-cavitation valve facility (PVLP)
- Threaded ports for P/T/LS and M measuring gauge
- Integrated pilot pressure reducing valve (PPRV) for PVE or PVH/PVHC

*Hydraulic schematic*





*Technical specification for PVP*

| Max. P-port continuous | Max. P-port intermittent | Max. T-port static/ dynamic | Max. rated flow |
|---|---|---|---|
| 350 [5076 psi] | 400 bar [5800 psi] | 25/40 bar [365/580 psi] | 140 l/min [37 US gal/min] |

*Technical specification*

| Parameter | Minimum | Recommended range | Maximum |
|---|---|---|---|
| **Fluid temperature** | -30°C [-22°F] | 30 to 60°C [86 to 140°F] | 90° [194°F] |
| **Fluid viscosity** | 4 $mm^2/s$ [39 SUS] | 12 to 75 $mm^2/s$ [65 to 347 SUS] | 460 $mm^2/s$ [2128 SUS] |
| **Fluid cleanliness** | 23/19/16 (according to ISO 4406) | | |
| **Operating temperature** | Ambient: -30 to 60°C [-22 to 140°F] | | |

*Pilot pressure reduction valve characteristics*



## PVP Inlet Modules

*Part numbers for Closed Center PVPV with PPRV*

| Part number | Actuation | P-, T-port | LS-, M-port | Mounting | TO-port | PVPX* |
|---|---|---|---|---|---|---|
| **11008856** | PVH/PVHC | G1″ | G1/4″ | M8 | – | Yes |
| **11051803** | | 1 5/16-12 UN | 9/16-18 UNF | 5/16-18 UNC | – | Yes |
| **11003806** | PVE | M27x2<br>M14x1.5 (P2) | M14x1.5 | M8 | M14x1.5 | – |
| **157B5911** | | 1 5/16-12 UN | 9/16-18 UNF | 5/16-18 UNC | – | – |
| **157B5913** | | | | | – | Yes |
| **157B5938** | | G1″ | G1/4″ | M8 | – | – |
| **157B5941** | | | | | – | Yes |
| **157B5969** | | M33x2<br>M14x1.5 (T2) | M14x1.5 | | M16x1.5 | Yes |

* For more information please see the topic *PVPX Electrical LS Pressure Unloading Valve*.

All modules can be manually activated with the PVM actuation.

## PVP Inlet Modules

### Closed center PVPVM with PPRV


The Closed Center PVPVM mid-inlet module with integrated pilot pressure reduction valve (PPRV) is intended for use with variable displacement pumps in applications where a valve group with electro-hydraulic or hydraulically controlled work sections is desired.

Using a PVPVM module in a valve group requires a 180° degree rotation of the PVG 32 work sections on one side.

**The Closed Center PVPVM with PPRV features:**

- Optional shock/anti-cavitation valve facility (PVLP)
- Threaded ports for P/T/LS and M measuring gauge
- Integrated pilot pressure reducing valve (PPRV) for PVE or PVH/PVHC

*Hydraulic schematic*





*Technical specification for PVP*

| Max. P-port continuous | Max. P-port intermittent | Max. T-port static/ dynamic | Max. rated flow |
|---|---|---|---|
| 350 [5076 psi] | 400 bar [5800 psi] | 25/40 bar [365/580 psi] | 140 l/min [37 US gal/min] |

*Technical specification*

| Parameter | Minimum | Recommended range | Maximum |
|---|---|---|---|
| **Fluid temperature** | -30°C [-22°F] | 30 to 60°C [86 to 140°F] | 90° [194°F] |
| **Fluid viscosity** | 4 $mm^2/s$ [39 SUS] | 12 to 75 $mm^2/s$ [65 to 347 SUS] | 460 $mm^2/s$ [2128 SUS] |
| **Fluid cleanliness** | 23/19/16 (according to ISO 4406) | | |
| **Operating temperature** | Ambient: -30 to 60°C [-22 to 140°F] | | |

*Pilot pressure reduction valve characteristics*



## PVP Inlet Modules

*Part numbers for Closed Center PVPVM with PPRV*

| Part number | Actuation | P-, T-port | LS-, M-port | Mounting | PVLP |
|---|---|---|---|---|---|
| **11083156** | PVH/PVHC | 1 5/16-12 UN | 9/16-18 UNF | 5/16-18 UNC | Yes |
| **157B5912** | PVE | | | | - |
| **157B5914** | | | | | Yes |
| **157B5937** | | G1″ | G1/4″ | M8 | - |
| **157B5940** | | | | | Yes |

All modules can be manually activated with the PVM actuation.

## PVP Inlet Modules

### Open/Closed center PVP with PPRV


The Open Center/Closed Center PVP with integrated pilot pressure reduction valve (PPRV) is intended for use with fixed or variable displacement pumps in applications where the application manufacturer does not determine the pump type.

The modules allow an easy switch between Open Center and Closed Center configuration by means of an external hexagon selector key. Variants also feature an LS boost functionality, increasing the LS pressure to the pump LS regulator with a constant 6 bar, compensating for potential LS bleed-off and leakage.

**The Open/closed center PVPV with PPRV features:**

- Integrated OC/CC selector
- Integrated LS pressure relief valve
- Threaded ports for P/T/LS and M measuring gauge
- Integrated pilot pressure reducing valve (PPRV) for PVE or PVH/PVHC
- Optional LS boost functionality

*Hydraulic schematic*




*Technical specification for PVP*

| Max. P-port continuous | Max. P-port intermittent | Max. T-port static/ dynamic | Max. rated flow |
|---|---|---|---|
| 350 [5076 psi] | 400 bar [5800 psi] | 25/40 bar [365/580 psi] | 140 l/min [37 US gal/min] |


*Technical specification*

| Parameter | Minimum | Recommended range | Maximum |
|---|---|---|---|
| **Fluid temperature** | -30°C [-22°F] | 30 to 60°C [86 to 140°F] | 90° [194°F] |
| **Fluid viscosity** | 4 $mm^2/s$ [39 SUS] | 12 to 75 $mm^2/s$ [65 to 347 SUS] | 460 $mm^2/s$ [2128 SUS] |
| **Fluid cleanliness** | 23/19/16 (according to ISO 4406) | | |
| **Operating temperature** | Ambient: -30 to 60°C [-22 to 140°F] | | |


## PVP Inlet Modules

### Theoretical Performance Graphs


*Integrated LS pressure relief valve characteristics*




*Neutral by-pass pressure drop characteristics*




*Pilot pressure reduction valve characteristics*



## PVP Inlet Modules

*Part numbers for Open/Closed Center PVP with PPRV*

| Part number | Actuation | P-port | T-port | LS-port (LS1**) | M-port | T0-port | Mounting | LS Boost |
|---|---|---|---|---|---|---|---|---|
| 11093273 | PVE | G3/4 | G3/4 | - | G1/4 | - | M8 | Yes |
| 11119094 | PVE | G3/4 | G3/4 | - | G1/4 | - | M8 | - |
| 11119095 | PVE | 1 1/16-12 UNF | 1 1/16-12 UNF | 1/2-20 UNF | 1/2-20 UNF | - | M8 | - |
| 11131344 | PVH/PVHC | G3/4 | G3/4 | - | G1/4 | - | M8 | Yes |
| 11168608[1] | PVE | G3/4 | G3/4 | - | G1/4 | - | M8 | Yes |

** LS1 is an extra LS-port

[1] Dampened LS response

All modules can be manually activated with the PVM actuation.

## PVP Inlet Modules

### Open/Closed center PVPM


The Open Center/Closed Center PVPM mid-inlet acts as a simple manifold and is intended for use with fixed or variable displacement pumps. The PVPM features no logic other than a PVLP shock/anti-cavitation valve facility for pressure peak protection and anti-cavitation prevention.

The PVPM module must be configured together with an Open Center PVP module for **fixed displacement pumps** and for **variable displacement pumps** can be configured together with a PVSI start plate or a Closed Center PVP/PVPV module.

**The Open center/closed center PVPM features:**

- Integrated shock/anti-cavitation valve facility (PVLP)
- Threaded ports for P/T
- Pilot pressure and T0 lines through module

*Hydraulic schematic*




*Technical specification for PVP*

| Max. P-port continuous | Max. P-port intermittent | Max. T-port static/ dynamic | Max. rated flow |
|---|---|---|---|
| 350 [5076 psi] | 400 bar [5800 psi] | 25/40 bar [365/580 psi] | 140 l/min [37 US gal/min] |

*Technical specification*

| Parameter | Minimum | Recommended range | Maximum |
|---|---|---|---|
| **Fluid temperature** | -30°C [-22°F] | 30 to 60°C [86 to 140°F] | 90° [194°F] |
| **Fluid viscosity** | 4 $mm^2/s$ [39 SUS] | 12 to 75 $mm^2/s$ [65 to 347 SUS] | 460 $mm^2/s$ [2128 SUS] |
| **Fluid cleanliness** | 23/19/16 (according to ISO 4406) | | |
| **Operating temperature** | Ambient: -30 to 60°C [-22 to 140°F] | | |

*Part numbers for Open Center/Closed Center PVPM*

| Part number | P-, T-port | Mounting | PVLP |
|---|---|---|---|
| **11093682** | 1 5/16-12 UN | 5/16-18 UNC | Yes |
| **11093684** | G1″ | M8 | Yes |

## PVP Inlet Module Accessories

The generic PVP inlet module accessory platform includes the PVPX Electrical LS pressure unloading valve, External pilot pressure adapters PVPC with or without check valve for all Open Center PVP with PPRV.


- *PVPX Electrical LS Pressure Unloading Valve* on page 35
- *PVPC without Check Valve* on page 38
- *PVPC with Check Valve* on page 39


### PVPX Electrical LS Pressure Unloading Valve

The electrical LS pressure unloading valve is an accessory available for PVP inlet modules with PVPX facility. The PVPX consist of a solenoid valve and a magnetic coil package, allowing the operator to relieve the LS pressure to tank electrically.




Configuration variants also feature a Manual Override functionality to activate the PVPX manually:

- Normally Open (NO),
- Normally Open with Manual Override (NOMO)

There are two types of NOMO-configurations - PUSH, and PUSH & TURN. With the TURN function you can keep the override function until you unlock it again.

- Normally Closed (NC)


*Configuration variants*

| Normally Open (NO) | Normally Open with MOR (NOMO) | Normally Closed (NC) |
|---|---|---|
|  |  |  |

Relieving the LS pressure to tank results in a reduced system pressure level, which is determined by:

- the sum of the tank and neutral by-pass pressure drop in a **Open Center** PVP configuration
- the sum of the tank and standby-pressure in a **Closed Center** PVP configuration

*PVPX with NOMO schematic*




*PVPX technical data*

| | |
|---|---|
| **Voltage supply** | 12/24 $V_{DC}$ ± 10% |
| **Resistance @ 12 $V_{DC}$** | 7.2 Ω ± 7% |
| **Resistance @ 24 $V_{DC}$** | 28.2 Ω ± 7% |
| **Power consumption** | 20 W |
| **Maximum LS response time** | 300 ms |
| **Max. pressure drop @ 0.1 l/min [2.6 US gal/min]** | 2 bar [30 psi] |

## PVP Inlet Module Accessories

*PVPX technical data (continued)*

| | |
|---|---|
| **Max. coil surface temperature** | 155°C [311°F] |
| **Thread size** | 3/4-16 UNF |

*Technical specification*

| Parameter | Minimum | Recommended range | Maximum |
|---|---|---|---|
| **Fluid temperature** | -30°C [-22°F] | 30 to 60°C [86 to 140°F] | 90° [194°F] |
| **Fluid viscosity** | 4 $mm^2/s$ [39 SUS] | 12 to 75 $mm^2/s$ [65 to 347 SUS] | 460 $mm^2/s$ [2128 SUS] |
| **Fluid cleanliness** | 23/19/16 (according to ISO 4406) | | |
| **Operating temperature** | Ambient: -30 to 60°C [-22 to 140°F] | | |

### Part numbers for PVPX

*Part numbers for PVPX, NO and NC configuration*

| Part number | Configuration | Voltage Supply | Connector | IP Rating |
|---|---|---|---|---|
| **157B4236** | NO | 12 $V_{DC}$ | 1x2 DIN | IP 65 |
| **157B4238** | NO | 24 $V_{DC}$ | | |
| **157B4246** | NC | 12 $V_{DC}$ | | |
| **157B4248** | NC | 24 $V_{DC}$ | | |
| **157B4976** | NC | 26 $V_{DC}$ | | |
| **157B4981** | NO | 12 $V_{DC}$ | 1x2 AMP | IP 66 |
| **157B4982** | NO | 24 $V_{DC}$ | | |
| **157B4983** | NC | 12 $V_{DC}$ | | |
| **157B4984** | NC | 24 $V_{DC}$ | | |
| **11180766** | NO | 12 $V_{DC}$ | 1x2 DEUTSCH | IP 67 |
| **11180767** | NO | 24 $V_{DC}$ | | |
| **11180768** | NC | 12 $V_{DC}$ | | |
| **11180769** | NC | 24 $V_{DC}$ | | |
| **11225108** | NO | 26 $V_{DC}$ | | |
| **11225109** | NC | 26 $V_{DC}$ | | |

*Part numbers for PVPX, NOMO configuration*

| Part number | Manual Override | Voltage Supply | Connector | IP Rating |
|---|---|---|---|---|
| **157B4256** | PUSH | 12 $V_{DC}$ | 1x2 DIN | IP 65 |
| **157B4257** | PUSH & TURN | 12 $V_{DC}$ | | |
| **157B4258** | PUSH | 24 $V_{DC}$ | | |
| **157B4259** | PUSH & TURN | 24 $V_{DC}$ | | |
| **157B4260** | PUSH | 26 $V_{DC}$ | | |
| **157B4985** | PUSH | 12 $V_{DC}$ | 1x2 AMP | IP 66 |
| **157B4986** | PUSH | 24 $V_{DC}$ | | |

## PVP Inlet Module Accessories

*Part numbers for PVPX, NOMO configuration (continued)*

| Part number | Manual Override | Voltage Supply | Connector | IP Rating |
|---|---|---|---|---|
| **11193839** | PUSH | 12 $V_{DC}$ | 1x2 DEUTSCH | IP 67 |
| **11193836** | PUSH | 24 $V_{DC}$ | | |
| **11225111** | PUSH | 26 $V_{DC}$ | | |
| **11225110** | PUSH & TURN | | | |


## PVP Inlet Module Accessories

### PVPC without Check Valve


The PVPC external pilot pressure adapter without check valve is an accessory in the M-port available for PVP inlet modules with integrated pilot pressure reduction valve (PPRV).

The PVPC without check valve cuts off the integrated PPRV to the PVE or PVH/PVHC in the valve group and enables an external pilot pressure supply through the PVPC adapter.

*PVPC without Check Valve*




*PVP with PVPC without check valve schematic*




One application example for the PVPC without check valve is where it is a wanted feature to supply the valve group with oil from a manually operated emergency pump without directing oil flow to the PPRV.

When the main pump is running in its normal operation mode, the oil is directed through the PVPC adapter via the PPRV to the PVE electrical actuators.

When the main pump flow fails, the external shuttle valve ensures that the oil flow from the manually operated emergency pump is used to pilot open the over-center valve and lower the load. The load is only possible to lower when using the mechanical operating lever of the PVG 32 valve group.

*Part numbers for Open Center/Closed Center PVPM*

| **Part number** | **157B5400** | **158X1000** |
|---|---|---|
| Thread | G1/2" | 1/2-20 UNF |


## PVP Inlet Module Accessories

### PVPC with Check Valve


The PVPC external pilot pressure adapter with check valve is an accessory in the M-port available for PVP inlet modules with integrated pilot pressure reduction valve (PPRV).

The PVPC with check valve enables an external pilot pressure supply through the PVPC adapter and the PPRV, while also allowing the main pump to supply the PPRV through the P-gallery as a standard Open Center PVP with PPRV.

*PVPC with Check Valve*




*PVP with PVPC with check valve schematic*




One application example for the PVPC with check valve is where it is a wanted feature to operate the valve group by means of the PVE electrical actuators without pump flow.

When the external solenoid valve is opened, oil from the pressure side of the cylinder is fed via the PVPC through the PPRV to act as the pilot supply for the PVE electrical actuators. This means that it is possible to lower a load by means of the PVE electrical actuators without starting the pump.

The built-in check valve prevents the oil from flowing via the pressure adjustment spool to tank. With the pump functioning normally the external solenoid valve is closed to ensure that the load is not lowered due to the pilot supply oil flow requirement of approximately 1 l/min [0.25 US gal/min].

With a Closed Center PVP the external pilot oil supply can be connected to the pressure gauge connection without the use of a PVPC plug.


*Part numbers for Open Center/Closed Center PVPM*

| **Part number** | **157B5600** | **157B5700** |
|---|---|---|
| Thread | G1/2" | 1/2-20 UNF |


## PVB Basic Modules

The PVG 32 PVB basic modules, also referred to as work sections, are the interface between the PVG 32 proportional valve group and the work function such as a cylinder or a motor.

*PVB Basic Module*




*PVB 32 dimensions*





Weight: 3.05 kg [6.73 lb]

*Uncompensated PVB schematic symbol*




*Compensated PVB schematic symbol*




The PVB basic module variants are based on a generic platform with a selection of additional features, enabling you to tailor the PVB to suit the demands of any hydraulic system. The generic PVB basic module platform includes the following main variants:


- *Uncompensated PVB* on page 41
- *Uncompensated PVB with load drop check valve* on page 44
- *Uncompensated PVBZ with POC* on page 47
- *Compensated PVB* on page 48
- *Dampened Compensated PVB* on page 51
- *Dampened compensated PVB with LS A/B* on page 54
- *Compensated PVB with LS A/B* on page 57
- *Compensated high flow PVB* on page 61
- *Compensated high flow PVB with LS A/B* on page 64
- *Compensated PVBZ with POC* on page 68
- *Compensated high flow PVBZ with POC* on page 70
- *Compensated high flow PVBZ with POC and manifold interface* on page 73

## PVB Basic Modules


### Uncompensated PVB

The uncompensated PVB is intended for controlling a work function where the function behavior in terms of flow and pressures requires independence on the load pressure of other functions used simultaneously.

***The Uncompensated PVB features:***

- Integrated LS shuttle network
- Optional shock/anti-cavitation valve facility (PVLP)
- Optional $LS_{A/B}$ shuttle valve facility for float spool use
- Optional T0 facility

*Schematic*




*Technical specification for A/B-port*

| Max. continuous pressure | Max. intermittent pressure | Max. rated flow |
|---|---|---|
| 350 bar [5076 psi]* | 420 bar [6090 psi]** | 125 l/min [33 US gal/min] |

* With PVSI end plate. With PVS end plate max. 300 [4351 psi]

** Intermittent pressure at max. 250,000 cycles of full PVG life time cycles, with PVSI end plate. The maximum intermittent pressure at max. 250,000 cycles stresses the need to confirm application duty cycle before proceeding with specification. For further information contact Danfoss Product Application Engineering.


*Technical specification*

| Parameter | Minimum | Recommended range | Maximum |
|---|---|---|---|
| **Fluid temperature** | -30°C [-22°F] | 30 to 60°C [86 to 140°F] | 90° [194°F] |
| **Fluid viscosity** | 4 $mm^2/s$ [39 SUS] | 12 to 75 $mm^2/s$ [65 to 347 SUS] | 460 $mm^2/s$ [2128 SUS] |
| **Fluid cleanliness** | 23/19/16 (according to ISO 4406) | | |
| **Operating temperature** | Ambient: -30 to 60°C [-22 to 140°F] | | |


## PVB Basic Modules

### Performance graphs (Theoretical)

*PVLP shock valve characteristics*




*PVLP/PVLA suction valve characteristics*




*Part numbers for uncompensated PVB*

| Part number | A/B-port | PVLP/PVLA | LS A/B shuttle | T0 facility |
|---|---|---|---|---|
| **157B6000** | G1/2" | — | — | — |
| **157B6010** | | — | — | Yes |
| **157B6030** | | Yes | — | — |
| **11071832** | | Yes | Yes | — |

## PVB Basic Modules

*Part numbers for uncompensated PVB (continued)*

| Part number | A/B-port | PVLP/PVLA | LS A/B shuttle | T0 facility |
|---|---|---|---|---|
| **157B6400** | 7/8–14 UNF | — | — | — |
| **157B6410** | | — | — | Yes |
| **157B6430** | | Yes | — | — |

## PVB Basic Modules


### Uncompensated PVB with load drop check valve

The uncompensated PVB is intended for controlling a work function where the function behavior in terms of flow and pressures allows dependency on the load pressure of other functions used simultaneously. The integrated load drop check valve prevents flow back from work ports influencing other functions.

***The Uncompensated PVB with load drop check valve features:***

- Integrated LS shuttle network
- Load drop check valve
- Optional shock/anti-cavitation valve facility (PVLP)
- Optional $LS_{A/B}$ shuttle valve facility for float spool use
- Optional T0 facility

*Schematic*




*Technical specification for A/B-port*

| Max. continuous pressure | Max. intermittent pressure | Max. rated flow |
|---|---|---|
| 350 bar [5076 psi] | 420 bar [6090 psi] | 125 l/min [33 US gal/min] |


*Technical specification*

| Parameter | Minimum | Recommended range | Maximum |
|---|---|---|---|
| **Fluid temperature** | -30°C [-22°F] | 30 to 60°C [86 to 140°F] | 90° [194°F] |
| **Fluid viscosity** | 4 $mm^2/s$ [39 SUS] | 12 to 75 $mm^2/s$ [65 to 347 SUS] | 460 $mm^2/s$ [2128 SUS] |
| **Fluid cleanliness** | 23/19/16 (according to ISO 4406) | | |
| **Operating temperature** | Ambient: -30 to 60°C [-22 to 140°F] | | |


## PVB Basic Modules

### Performance graphs (Theoretical)

*PVLP shock valve characteristics*




*PVLP/PVLA suction valve characteristics*




*Part numbers for Uncomp. PVB with load drop check valve*

| Part number | A/B-port | PVLP/PVLA | LS A/B shuttle | T0 facility |
|---|---|---|---|---|
| **157B6100** | G1/2" | — | — | — |
| **157B6500** | 7/8–14 UNF | — | — | — |
| **157B6110** | G1/2" | — | — | Yes |
| **157B6909** | 7/8–14 UNF | — | — | Yes |

## PVB Basic Modules

*Part numbers for Uncomp. PVB with load drop check valve (continued)*

| Part number | A/B-port | PVLP/PVLA | LS A/B shuttle | T0 facility |
|---|---|---|---|---|
| **157B6130** | G1/2" | Yes | — | — |
| **157B6530** | 7/8–14 UNF | Yes | — | — |
| **157B6140** | G1/2" | Yes | — | Yes |
| **157B6904** | 7/8–14 UNF | Yes | — | Yes |
| **157B6136** | G1/2" | Yes | Yes | — |
| **157B6536** | 7/8–14 UNF | Yes | Yes | — |

## PVB Basic Modules

### Uncompensated PVBZ with POC


The uncompensated PVBZ is intended for controlling a work function where the function behavior in terms of flow and pressures allows dependency on the load pressure of other functions used simultaneously.

The Pilot Operated Check valve giving very low leakage will prevent cylinder creep.

**The Uncompensated PVBZ with POC features:**

- Integrated LS shuttle network
- Integrated POC
- Optional T0 facility

*Schematic*




*Technical specification for A/B-port*

| Max. continuous pressure | Max. intermittent pressure | Max. rated flow |
|---|---|---|
| 350 bar [5076 psi] | 420 bar [6090 psi] | 125 l/min [33 US gal/min] |

*Technical specification*

| Parameter | Minimum | Recommended range | Maximum |
|---|---|---|---|
| **Fluid temperature** | -30°C [-22°F] | 30 to 60°C [86 to 140°F] | 90° [194°F] |
| **Fluid viscosity** | 4 $mm^2/s$ [39 SUS] | 12 to 75 $mm^2/s$ [65 to 347 SUS] | 460 $mm^2/s$ [2128 SUS] |
| **Fluid cleanliness** | 23/19/16 (according to ISO 4406) | | |
| **Operating temperature** | Ambient: -30 to 60°C [-22 to 140°F] | | |

*Part numbers for uncompensated PVBZ with POC*

| Part number | A/B-port | POC |
|---|---|---|
| **157B6051** | G½" | B-port |
| **157B6052** | | A/B-port |
| **157B6451** | 7/8–14 UNF | B-port |
| **157B6452** | | A/B-port |
| **157B6969** | None – machined top[1)] | A-port |

[1)] Prepared for mounting of a PVBD diverter. For more details, see *PVBD Diverter Module* on page 84.

## PVB Basic Modules


### Compensated PVB

The compensated PVB is intended for controlling a work function where the function behavior in terms of flow and pressures requires independence on the load pressure of other functions used simultaneously.

***The Compensated PVB features:***

- Integrated LS shuttle network
- Integrated compensator
- Optional shock/anti-cavitation valve facility (PVLP)
- Optional T0 facility and external T0 port

*Compensated PVB schematic*




*Technical specification for A/B-port*

| Max. continuous pressure | Max. intermittent pressure | Max. rated flow * |
|---|---|---|
| 350 bar [5067 psi] | 420 bar [6090 psi] | 125 l/min [33 US gal/min] |

* With turbo function spool @ max rated flow of 130 l/min is possible


*Technical specification*

| Parameter | Minimum | Recommended range | Maximum |
|---|---|---|---|
| **Fluid temperature** | -30°C [-22°F] | 30 to 60°C [86 to 140°F] | 90° [194°F] |
| **Fluid viscosity** | 4 $mm^2/s$ [39 SUS] | 12 to 75 $mm^2/s$ [65 to 347 SUS] | 460 $mm^2/s$ [2128 SUS] |
| **Fluid cleanliness** | 23/19/16 (according to ISO 4406) | | |
| **Operating temperature** | Ambient: -30 to 60°C [-22 to 140°F] | | |


## PVB Basic Modules

### Performance graphs (Theoretical)

*PVLP shock valve characteristics*





*Load Independent Fluid Flow – Pressure Compensated PVB*



## PVB Basic Modules

*PVLP/PVLA suction valve characteristics*




*Part numbers for compensated PVB*

| Part number | A/B-port | PVLP/PVLA | T0 |
|---|---|---|---|
| **157B6200** | G1/2" | – | – |
| **157B6210** | | – | Yes |
| **157B6230** | | Yes | – |
| **157B6240** | | Yes | Yes |
| **157B6600** | 7/8–14 UNF | – | – |
| **157B6922** | | – | Yes |
| **157B6630** | | Yes | – |
| **157B6906** | | Yes | Yes |
| **157B6850** | M22x1.5 | Yes | Yes |
| **157B6849** | None* | – | – |

* Machined top, prepared for mounting of a PVBD diverter.

## PVB Basic Modules


### Dampened Compensated PVB

The compensated PVB is intended for controlling a work function where the function behavior in terms of flow and pressures requires independence on the load pressure of other functions used simultaneously. The dampening of the compensator reaction will slow down the system thereby removing instability.

***The dampened compensated PVB features:***

- Integrated LS shuttle network
- Integrated compensator
- Optional shock/anti-cavitation valve facility (PVLP)

*Compensated PVB schematic*




*Technical specification for A/B-port*

| Max. continuous pressure | Max. intermittent pressure | Max. rated flow* |
|---|---|---|
| 350 bar [5076 psi] | 420 bar [6090 psi] | 125 l/min [33 US gal/min] |

* With turbo function spool @ max rated flow of 130 l/min is possible


*Technical specification*

| Parameter | Minimum | Recommended range | Maximum |
|---|---|---|---|
| **Fluid temperature** | -30°C [-22°F] | 30 to 60°C [86 to 140°F] | 90° [194°F] |
| **Fluid viscosity** | 4 $mm^2/s$ [39 SUS] | 12 to 75 $mm^2/s$ [65 to 347 SUS] | 460 $mm^2/s$ [2128 SUS] |
| **Fluid cleanliness** | 23/19/16 (according to ISO 4406) | | |
| **Operating temperature** | Ambient: -30 to 60°C [-22 to 140°F] | | |


## PVB Basic Modules

### Performance graphs (Theoretical)

*PVLP shock valve characteristics*





*Load Independent Fluid Flow – Pressure Compensated PVB*



## PVB Basic Modules

*PVLP/PVLA suction valve characteristics*




*Part numbers for damp. compensated PVB*

| Part number | A/B-port | PVLP/PVLA |
|---|---|---|
| **157B6206** | G1/2" | – |
| **157B6236** | | Yes |
| **11036629** | 7/8–14 UNF | – |
| **11036630** | | Yes |

## PVB Basic Modules


### Dampened compensated PVB with LS A/B

The compensated PVB is intended for controlling a work function where the function behavior in terms of flow and pressures requires independence on the load pressure of other functions used simultaneously. The dampening of the compensator reaction will slow down the system thereby removing instability. The integrated $LS_{A/B}$ relief valve is used to limit the maximum work port build-up on the A/B-ports individually.

**The dampened compensated PVB with LS A/B features:**

- Integrated LS shuttle network
- Integrated compensator
- Integrated adjustable $LS_{A/B}$ pressure relief valves
- External $LS_{A/B}$ port connection
- Optional shock/anti-cavitation valve facility (PVLP)

*Dampened compensated PVB with LS A/B schematic*




*Technical specification for A/B-port*

| Max. continuous pressure | Max. intermittent pressure | Max. rated flow* |
|---|---|---|
| 350 bar [5076 psi] | 420 bar [6090 psi] | 125 l/min [33 US gal/min] |


* With turbo function spool @ max rated flow of 130 l/min is possible

| Parameter | Minimum | Recommended range | Maximum |
|---|---|---|---|
| **Fluid temperature** | -30°C [-22°F] | 30 to 60°C [86 to 40°F] | 90°C [194°F] |
| **Fluid viscosity** | 4 mm2/s [39 SUS] | 12 to 75 mm2/s [65 to 347 SUS] | 460 mm2/s [2128 SUS] |
| **Fluid cleanliness** | 23/19/16 (according to ISO 4406) | | |
| **Operating temperature** | Ambient: -30 to 60°C [-22 to 140°F] | | |


## PVB Basic Modules

### Performance graphs (Theoretical)

*PVLP shock valve characteristics*





*Load Independent Fluid Flow – Pressure Compensated PVB*




## PVB Basic Modules

*PVLP/PVLA suction valve characteristics*




*PVB pressure compensated for LS A/B characteristics*




| Part number | A/B-port | LS-port | PVLP/PVLA |
|---|---|---|---|
| **157B6208** | G1/2 | G1/4 | - |
| **157B6238** | | | Yes |

## PVB Basic Modules


### Compensated PVB with LS A/B

The compensated PVB is intended for controlling a work function where the function behavior in terms of flow and pressures requires independency on the load pressure of other functions used simultaneously. The integrated $LS_{A/B}$ relief valve is used to limit the maximum work port build-up on the A/B-ports individually.

***The compensated PVB with $LS_{A/B}$ features:***

- Integrated LS shuttle network
- Integrated compensator
- Integrated adjustable $LS_{A/B}$ pressure relief valves
- External $LS_{A/B}$ port connection
- Integrated $LS_{A/B}$ shuttle valve for float spool usage
- Optional shock/anti-cavitation valve facility (PVLP)
- Optional T0 facility

*Compensated PVB with LS schematic*




*Technical specification for A/B-port*

| Max. continuous pressure | Max. intermittent pressure | Max. rated flow* |
|---|---|---|
| 350 bar [5076 psi] | 420 bar [6090 psi] | 125 l/min [33 US gal/min] |

* With turbo function spool @ max rated flow of 130 l/min is possible


*Technical specification*

| Parameter | Minimum | Recommended range | Maximum |
|---|---|---|---|
| **Fluid temperature** | -30°C [-22°F] | 30 to 60°C [86 to 140°F] | 90° [194°F] |
| **Fluid viscosity** | 4 $mm^2/s$ [39 SUS] | 12 to 75 $mm^2/s$ [65 to 347 SUS] | 460 $mm^2/s$ [2128 SUS] |
| **Fluid cleanliness** | 23/19/16 (according to ISO 4406) | | |
| **Operating temperature** | Ambient: -30 to 60°C [-22 to 140°F] | | |


## PVB Basic Modules

### Performance graphs (Theoretical)

*PVLP shock valve characteristics*





*Load Independent Fluid Flow – Pressure Compensated PVB*




## PVB Basic Modules

*PVLP/PVLA suction valve characteristics*




*PVB pressure compensated for LS A/B characteristics*



## PVB Basic Modules

*Part numbers for compensated PVB with LS A/B (all with shuttle)*

| Part number | A/B-port | LS–port | PVLP/PVLA | T0 |
|---|---|---|---|---|
| **157B6203** | G1/2" | G1/4" | – | – |
| **157B6213** | | | – | Yes |
| **157B6233** | | | Yes | – |
| **157B6243** | | | Yes | Yes |
| **157B6603** | 7/8–14 UNF | 1/2–20 UNF | – | – |
| **157B6613** | | | – | Yes |
| **157B6633** | | | Yes | – |
| **157B6643** | | | Yes | Yes |

## PVB Basic Modules

### Compensated high flow PVB


The compensated PVB is intended for controlling a work function where the function behavior in terms of flow and pressures requires independence on the load pressure of other functions used simultaneously.

The bleed-off will prevent pressure build-up on the work ports in neutral.

#### Features

- Integrated LS shuttle network
- Integrated high flow compensator with bleed-off
- Integrated adjustable $LS_{A/B}$ pressure relief valves
- Optional shock/anti-cavitation valve facility (PVLP)
- Optional T0 facility

*Compensated high flow PVB schematic*




*Technical specification for A/B-port*

| Max. continuous pressure | Max. intermittent pressure | Max. rated flow |
|---|---|---|
| 350 bar [5076 psi] | 420 bar [6090 psi] | 130 l/min [34 US gal/min] |


*Technical specification*

| Parameter | Minimum | Recommended range | Maximum |
|---|---|---|---|
| **Fluid temperature** | -30°C [-22°F] | 30 to 60°C [86 to 140°F] | 90° [194°F] |
| **Fluid viscosity** | 4 $mm^2/s$ [39 SUS] | 12 to 75 $mm^2/s$ [65 to 347 SUS] | 460 $mm^2/s$ [2128 SUS] |
| **Fluid cleanliness** | 23/19/16 (according to ISO 4406) | | |
| **Operating temperature** | Ambient: -30 to 60°C [-22 to 140°F] | | |


## PVB Basic Modules

### Performance graphs (Theoretical)

*PVLP shock valve characteristics*





*Load Independent Fluid Flow – Pressure Compensated PVB*



## PVB Basic Modules

*PVLP/PVLA suction valve characteristics*




*Part numbers for compensated high flow PVB*

| Part number | A/B-port | PVLP/PVLA | LS A/B shuttle | T0 facility |
|---|---|---|---|---|
| **11091947** | 7/8–14 UNF | Yes | Yes | Yes |
| **11119463** | | — | — | Yes |
| **11126962** | | — | — | Yes |
| **157B6938** | | Yes | — | — |
| **157B6852** | G½" | Yes | — | — |

## PVB Basic Modules

### Compensated high flow PVB with LS A/B


The compensated PVB is intended for controlling a work function where the function behavior in terms of flow and pressures requires independence on the load pressure of other functions used simultaneously. The integrated $LS_{A/B}$ relief valve is used to limit the maximum work port build-up on the A/B-ports individually.

The bleed-off will prevent pressure build-up on the work ports in neutral.

#### Features

- Integrated LS shuttle network
- Integrated high flow compensator with bleed-off
- Integrated adjustable $LS_{A/B}$ pressure relief valves
- Integrated $LS_{A/B}$ shuttle valve for float spool usage
- External $LS_{A/B}$ port connection
- Optional shock/anti-cavitation valve facility (PVLP)
- Optional T0 facility

*Compensated high flow PVB with LS A/B schematic*




*Technical specification for A/B-port*

| Max. continuous pressure | Max. intermittent pressure | Max. rated flow |
|---|---|---|
| 350 bar [5076 psi] | 420 bar [6090 psi] | 130 l/min [34 US gal/min] |


*Technical specification*

| Parameter | Minimum | Recommended range | Maximum |
|---|---|---|---|
| **Fluid temperature** | -30°C [-22°F] | 30 to 60°C [86 to 140°F] | 90° [194°F] |
| **Fluid viscosity** | 4 $mm^2/s$ [39 SUS] | 12 to 75 $mm^2/s$ [65 to 347 SUS] | 460 $mm^2/s$ [2128 SUS] |
| **Fluid cleanliness** | 23/19/16 (according to ISO 4406) | | |
| **Operating temperature** | Ambient: -30 to 60°C [-22 to 140°F] | | |


## PVB Basic Modules

### Performance graphs (Theoretical)

*PVLP shock valve characteristics*





*Load Independent Fluid Flow – Pressure Compensated PVB*




## PVB Basic Modules

*PVLP/PVLA suction valve characteristics*




*PVB pressure compensated for LS A/B characteristics*



## PVB Basic Modules

*Part numbers for comp. high flow PVB with LS*

| Part number | A/B-port | $LS_{A/B}$ port | PVLP/PVLA | $LS_{A/B}$ shuttle | T0 facility |
|---|---|---|---|---|---|
| **157B6855** | G½" | G¼" | — | Yes | — |
| **11059838** | | | — | | Yes |
| **157B6854** | | | Yes | | — |
| **11126963** | 7/8–14 UNF | ½-20 UNF | — | | Yes |
| **11126964** | | | Yes | | Yes |
| **11127277** | | | Yes | | — |

## PVB Basic Modules

### Compensated PVBZ with POC


The compensated PVB is intended for controlling a work function where the function behavior in terms of flow and pressures requires independence on the load pressure of other functions used simultaneously.

The bleed-off will prevent pressure build-up on the work ports in neutral.

#### Features

- Integrated LS shuttle network
- Integrated compensator
- Integrated POC
- T0 facility
- Optional $LS_{A/B}$ shuttle valve facility for float spool use
- Optional thermo-relief valve

*Schematic*




*Technical specification for A/B-port*

| Max. continuous pressure | Max. intermittent pressure | Max. rated flow |
|---|---|---|
| 350 bar [5076 psi] | 420 bar [6090 psi] | 100 l/min [26 US gal/min] |


*Technical specification*

| Parameter | Minimum | Recommended range | Maximum |
|---|---|---|---|
| **Fluid temperature** | -30°C [-22°F] | 30 to 60°C [86 to 140°F] | 90° [194°F] |
| **Fluid viscosity** | 4 $mm^2/s$ [39 SUS] | 12 to 75 $mm^2/s$ [65 to 347 SUS] | 460 $mm^2/s$ [2128 SUS] |
| **Fluid cleanliness** | 23/19/16 (according to ISO 4406) | | |
| **Operating temperature** | Ambient: -30 to 60°C [-22 to 140°F] | | |

## PVB Basic Modules

### Performance graphs (Theoretical)

*Load Independent Fluid Flow – Pressure Compensated PVB*




*Part numbers for compensated PVBZ with POC*

| Part number | A/B-port | POC | $LS_{A/B}$ shuttle | Thermo relief |
|---|---|---|---|---|
| **157B6251** | G1/2" | B-port | — | — |
| **157B6252** | | A/B-port | — | — |
| **157B6261** | | B-port | — | Yes |
| **157B6262** | | A/B-port | — | Yes |
| **157B6266** | | A/B-port | Yes | Yes |
| **157B6960** | | A-port | | — |
| **157B6651** | 7/8–14 UNF | B-port | — | — |
| **157B6652** | | A/B-port | — | — |
| **157B6661** | | A/B-port | — | Yes |
| **157B6662** | | A/B-port | — | Yes |
| **157B6666** | | A/B-port | Yes | Yes |
| **157B6954** | M22x1.5 mm | A/B-port | Yes | Yes |
| **157B6952** | None – machined top* | A/B-port | Yes | Yes |
| **157B6958** | None – machined top* | A/B-port | Yes | Yes |
| **11157082** | None – machined top* | A-port | — | — |

* Prepared for mounting of a PVBD diverter. For more details, see *PVBD Diverter Module* on page 84.

## PVB Basic Modules

### Compensated high flow PVBZ with POC

The compensated high flow PVBZ with POC is intended for controlling a work function where the function behavior in terms of flow and pressures requires independence on the load pressure of other functions used simultaneously.


The bleed-off will prevent pressure build-up on the work ports in neutral.

The Pilot Operated Check valve giving very low leakage will prevent cylinder creep.

#### Features

- Integrated LS shuttle network
- Integrated high flow compensator with bleed-off
- Integrated POC
- T0 facility
- Optional $LS_{A/B}$ shuttle valve facility for float spool use
- Optional shock/anti-cavitation valve facility (PVLP)

*Schematic*




*Technical specification for A/B-port*

| Max. continuous pressure | Max. intermittent pressure | Max. rated flow |
|---|---|---|
| 350 bar [5076 psi] | 420 bar [6090 psi] | 125 l/min [33 US gal/min] |


*Technical specification*

| Parameter | Minimum | Recommended range | Maximum |
|---|---|---|---|
| **Fluid temperature** | -30°C [-22°F] | 30 to 60°C [86 to 140°F] | 90° [194°F] |
| **Fluid viscosity** | 4 $mm^2/s$ [39 SUS] | 12 to 75 $mm^2/s$ [65 to 347 SUS] | 460 $mm^2/s$ [2128 SUS] |
| **Fluid cleanliness** | 23/19/16 (according to ISO 4406) | | |
| **Operating temperature** | Ambient: -30 to 60°C [-22 to 140°F] | | |


## PVB Basic Modules

### Performance graphs (Theoretical)

*PVLP shock valve characteristics*




*Load Independent Fluid Flow – Pressure Compensated PVB*



## PVB Basic Modules

*Part numbers for high flow PVBZ with POC*

| Part number | A/B-port | PVLP/PVLA | $LS_{A/B}$ shuttle | T0 facility |
|---|---|---|---|---|
| **11091947** | 7/8–14 UNF | Yes | Yes | Yes |
| **11119463** | | — | — | Yes |
| **11126962** | | — | — | Yes |
| **157B6938** | | Yes | — | — |
| **157B6852** | G½" | Yes | — | — |

## PVB Basic Modules

### Compensated high flow PVBZ with POC and manifold interface

The compensated PVB is intended for controlling a work function where the function behavior in terms of flow and pressures requires independence on the load pressure of other functions used simultaneously.


The integrated $LS_{A/B}$ relief valve is used to limit the maximum work port build-up on the A/B-ports individually.

The bleed-off will prevent pressure build-up on the work ports in neutral.

#### Features

- Integrated LS shuttle network
- Integrated high flow compensator with bleed-off
- Integrated POC
- T0 facility
- Integrated adjustable $LS_{A/B}$ pressure relief valves
- Optional thermo relief valve

*Schematic*




*Technical specification for A/B-port*

| Max. continuous pressure | Max. intermittent pressure | Max. rated flow |
|---|---|---|
| 350 bar [5076 psi] | 420 bar [6090 psi] | 125 l/min [33 US gal/min] |


*Technical specification*

| Parameter | Minimum | Recommended range | Maximum |
|---|---|---|---|
| **Fluid temperature** | -30°C [-22°F] | 30 to 60°C [86 to 140°F] | 90° [194°F] |
| **Fluid viscosity** | 4 $mm^2/s$ [39 SUS] | 12 to 75 $mm^2/s$ [65 to 347 SUS] | 460 $mm^2/s$ [2128 SUS] |
| **Fluid cleanliness** | 23/19/16 (according to ISO 4406) | | |
| **Operating temperature** | Ambient: -30 to 60°C [-22 to 140°F] | | |

## PVB Basic Modules

### Performance graphs (Theoretical)

*Load Independent Fluid Flow – Pressure Compensated PVB*




*Part numbers for PVBZ - POC, manifold interface*

| Part number | POC |
|---|---|
| **157B6958** | A/B-port |
| **11005475** | A/B-port |
| **11032961** | A/B-port |

## PVB Basic Modules Accessories

The generic PVB module accessory platform include the PVLP shock and anti-cavitation valve and PVLA suction valve.


- *PVLP Shock and Anti-Cavitation Valve* on page 76
- *PVLA Suction Valve* on page 78


## PVB Basic Modules Accessories

### PVLP Shock and Anti-Cavitation Valve


The PVLP shock and anti-cavitation valve will relieve a pressure peak to the internal tank galleries and will furthermore suck oil from the tank to the work port to prevent cavitation. Pressure settings range: 32–400 bar [460–5801 psi].

The pressure setting of the PVLP must always be 20 bar [290 psi] higher than $LS_{A/B}$ setting in the same module.

*PVLP schematic*





*PVLP shock valve characteristics*



## PVB Basic Modules Accessories

*PVLP/PVLA suction valve characteristics*




*Technical specification*

| Parameter | Minimum | Recommended range | Maximum |
|---|---|---|---|
| **Fluid temperature** | -30°C [-22°F] | 30 to 60°C [86 to 140°F] | 90° [194°F] |
| **Fluid viscosity** | 4 $mm^2/s$ [39 SUS] | 12 to 75 $mm^2/s$ [65 to 347 SUS] | 460 $mm^2/s$ [2128 SUS] |
| **Fluid cleanliness** | 23/19/16 (according to ISO 4406) | | |
| **Operating temperature** | Ambient: -30 to 60°C [-22 to 140°F] | | |

*Part numbers for PVLP according to pressure settings*

| Part number | Pressure in bar [psi] | Part number | Pressure in bar [psi] |
|---|---|---|---|
| **157B2032** | 32 [464] | **157B2210** | 210 [3045] |
| **157B2050** | 50 [725] | **157B2230** | 230 [3335] |
| **157B2063** | 63 [913] | **157B2240** | 240 [3480] |
| **157B2080** | 80 [1160] | **157B2250** | 250 [3626] |
| **157B2100** | 100 [1450] | **157B2265** | 265 [3844] |
| **157B2125** | 125 [1813] | **157B2280** | 280 [4061] |
| **157B2140** | 140 [2031] | **157B2300** | 300 [4351] |
| **157B2150** | 150 [2176] | **157B2320** | 320 [4641] |
| **157B2160** | 160 [2321] | **157B2350** | 350 [5076] |
| **157B2175** | 175 [2538] | **157B2380** | 380 [5511] |
| **157B2190** | 190 [2756] | — | |


## PVB Basic Modules Accessories

### PVLA Suction Valve


The PVLA valve is an accessory available for PVB basic modules.

The PVLA will suck fluid from the tank to the work port to prevent cavitation by the 0.5 bar spring. The plug will ensure that when using a single acting spool, all flow returning through the work port is led to tank.

*PVLA schematic*




*PVLP/PVLA suction valve characteristics*




*Technical specification*

| Parameter | Minimum | Recommended range | Maximum |
|---|---|---|---|
| **Fluid temperature** | -30°C [-22°F] | 30 to 60°C [86 to 140°F] | 90° [194°F] |
| **Fluid viscosity** | 4 $mm^2/s$ [39 SUS] | 12 to 75 $mm^2/s$ [65 to 347 SUS] | 460 $mm^2/s$ [2128 SUS] |
| **Fluid cleanliness** | 23/19/16 (according to ISO 4406) | | |
| **Operating temperature** | Ambient: -30 to 60°C [-22 to 140°F] | | |

*PVLA suction valve part number*

| PVLA suction valve | Plug |
|---|---|
| 157B2001 | 157B2002 |

## PVSP and PVSPM Priority Modules

The **PVSP** and **PVSPM** are work section modules with integrated priority functionality.


*The PVSP/PVSPM modules advantages:*

- Integrated priority function for the OSP steering unit and/or the working hydraulics PVB
- Compatibility with open center or closed center PVP inlet modules with flow up to 160 l/min

*PVSP module*



*PVSP dimensions*





**Caution**

The PVSP module must be installed as the **End module** of valve group instead of a PVS end plate.

*PVSPM module*



*PVSPM dimensions*





**Caution**

The PVSPM must be installed as a **Mid-Inlet** module.

## PVSP and PVSPM Priority Modules

*PVSP/PVSPM pressure drop characteristics*





## PVSP and PSPVM Versions Overview


The generic PVSP/PVSPM priority module platform includes the main five versions: **Open Center: PVSP** and **PVSPM, Closed Center: PVSP** and **PVSPM**; and **Open/Closed Center PVSPM**.

Compensator spool and shock valve has to be specified separately, see *Compensator spool for PVSP/PVSPM* on page 83.


**Open Center PVSP** module giving priority to OSP




**Closed Center PVSP** module giving priority to OSP





**Open Center PVSPM** giving priority to OSP+PVB





Prepared for PVLP 63 shock valve.

**Closed Center PVSPM** giving priority to OSP+PVB




Prepared for PVLP 63 shock valve.

**Open/Closed Center PVSPM** module giving priority to PVB



## PVSP and PVSPM Priority Modules

*Technical data*

| | |
|---|---|
| **Maximum pump pressure** | 350 bar [5076 psi] |
| **Maximum pump flow** | 160 l/min [42 US gal/min] |
| **CF flow to OSP** | 60 l/min [12 US gal/min] |
| **CF flow to PVB (PVSPM)** | 100 l/min [26.4 US gal/min] |

*PVSP/PSPVM part numbers*


| Part number | Type | CF-port | P-port | Weight |
|---|---|---|---|---|
| **157B6708** | Open center **PVSP** | G½“ | G1“ | 3.8 kg [8.38 lb] |
| **157B6808** | | 7/8-14 UNF | 1 5/16-12 UNF | |
| **157B6728** | Closed center**PVSP** | G½“ | G1“ | |
| **157B6828** | | 7/8-14 UNF | 1 5/16-12 UNF | |
| **157B6707** | Open center **PVSPM** | G½“ | G1“ | |
| **157B6727** | Closed center **PVSPM** | | | |
| **157B6709** | Open/closed **PVSPM** | | | |

## PVSP and PVSPM Priority Modules

### Sectional view of priority modules PVSP/PVSPM

The PVSP module can give priority to an OSP steering unit (or other valves) and/or to a PVB 32 module, and contains a P-connection for the pump and a CF-connection for flow control. The excessive flow is passed on through excess flow to non-prioritized PVB 32 basic modules.

*PVSP/PVSPM sectional view*




**1.** PP fixed orifice
**2.** Dynamic orifice
**3.** LS orifice for steering unit
**4.** Spring for compensator spool
**5.** Connection for LS-signal
**6.** Compensator spool for CF-connection
**7.** PVSP housing
**8.** Priority spool
**9.** Plug, open center
**10.** Plug, closed center steering unit

The standard pump connections in PVP and PVPVM must always be provided with a steel plug.

If priority is solely given to the OSP steering unit (**157B6708, 157B6728, 157B6808, 157B6828**), the PVSP module fills in the place of end plate PVS(I). When specifying valve groups of this nature, you are therefore not to give in any code number for PVS.

In valve groups that must give priority to PVB 32 (max. one PVB), PVSPM must be mounted as Mid-Inlet (**157B6707, 157B6727, 157B6709**). The PVB module that is given priority must be turned a 180° and installed on the right of PVSP, see orientation of ports in dimension drawings.

In closed center systems, the system relief valve in PVP opens at a higher pressure (max. 20 bar) on the prioritized functions. It is therefore recommended to use PVB and OSP with integrated relief valve.

If an OSP steering unit and a PVB working function are given priority at the same time (PVSPM, **157B6707, 157B6727**), it is necessary to ensure that the OSP will always have an adequate pump flow available.


In prioritized PVB modules, always remember to dismantle the LS shuttle valve. And together with prioritized PVB modules, always use end plate **157B2018** (without O-rings).

In open center systems, prioritized PVB modules and steering units must always embody an integrated relief valve to avoid that an unintended, high pressure buildup.

## PVSP and PVSPM Priority Modules

### Compensator spool for PVSP/PVSPM

*Compensator spool sectional view*




**1.** PP internal fixed orifice: 0.6 mm [0.024 in]
**2.** Dynamic orifice: 0.9 or 1 mm [0.035 in]
**3.** LS orifice EU: G¼" or US: 9/16-18 UNF
**4.** Spring

*Part numbers for compensator spool with dynamic orifice*

| Part number | Dynamic orifice | LS orifice | Spring |
|---|---|---|---|
| **157B7900** | 0.9 mm | 1.2 mm | 7 bar |
| **157B7902** | | – | |
| **157B7904** | | 1.2 mm | 10 bar |
| **157B7903** | 1.0 mm | | |
| **157B7905** | | – | 7 bar |
| **157B7950*** | 0.035 in | 0.047 in | 101.5 psi |

* US version.

*Part numbers for compensator spool with static LS*

| Part number | Dynamic orifice | LS orifice | Spring |
|---|---|---|---|
| **157B7901** | Plug | 1.2 mm | 7 bar |
| **157B7951*** | Plug | 0.047 in | 101.5 psi |

* US version.

## PVBD Diverter Module


The PVBD is a diverter module to be mounted on top of PVB or PVBZ modules to enlarge the application range of the work section up to 2 functions.

- Pilot operated with PVC
- Auxiliary valve on tractors for function control on implements
- Cylinder positioning when the demand on neutral port leakage is limited

*PVBD Diverter Module*



*PVBD Dimensions*




## PVBD Diverter Principle

**PVC off:**


The shift spool is held in position (flow to A1/B1) by the spring in the right-hand side (opposite the PVC). The spring chamber is always connected to the T0 gallery in the PVBZ body.

**PVC on:**

Pilot pressure is led into the chamber next to the PVC. A limited flow is passing through the shift spool and the two orifices and into the spring chamber connected to T0. Pressure-drop across the orifices creates the shift force moving the shift spool towards the spring. As a result, port A2/B2 becomes active.

Leakage (along the spool clearance) from pressurized work ports A1/B1 or A2/B2 will always be drained to T0 either directly in the spring chamber or through the shift spool. This secures safe positioning of the shift spool as leakage never will build up pressure up in the control chambers.

*PVBD sectional view*




**Safety recommendation**

Shift of the diverter should only be possible when the main spool is in neutral. This has to be ensured through a proper set-up in the controller/MMI hardware.


## PVBD Diverter Module

### PVBD Diverter Module Overview


PVBD Diverter Modules are actuated with included PVC solenoid; NC and have two variants: PVBD 6/2 shift valve and Multi-valve for PVBZ **11032961**.

- PVBD 6/2 shift valve shifts between A1 & B1 / A2 & B2
- Multi-valve for PVBZ shifts A-port between PVBZ or tank gallery, for example between single and double acting actuation. B-port is prepared for PVLP.

*PVBD schematic*




*Multi-valve schematic*




*Technical data*

| Description | PVBD 6/2 shift | Multi-valve for PVBZ |
|---|---|---|
| Oil flow max. recommended | 80 l/min [21.1 US gal/min] | 100 l/min [26.4 US gal/min] |
| Max. port pressure | 280 bar [4061 psi] | |
| Voltage Supply | 12 $V_{DC}$; 14 bar | |
| Connector type | AMP JPT 2-pin | |

*Part numbers for PVBD diverter*

| Part numbers for 6/2 shift | 157B1501 | 157B1503 |
|---|---|---|
| Part number for Multi-valve | 11027604 | — |
| Port size | M22 x 1.5 mm | 7/8-14 UNF |

## PVBS Main Spools

The main spools (PVBS) determine the flow out of the work section or the pressure build up, and are based on a generic platform with a wide selection of additional features, enabling you to tailor the PVBS to suit the demands of any hydraulic system and any function.


The PVBS main spool can be activated in three different ways:

- Mechanically by a PVM lever
- Electrically by a PVE/PVHC actuator
- Hydraulically by a PVH actuator

*PVBS main spool*



*PVBS main spool dimensions*




Weight: 0.25 kg [ 0.55 lb]

*Technical specification*

| Parameter | Minimum | Recommended range | Maximum |
|---|---|---|---|
| **Fluid temperature** | -30°C [-22°F] | 30 to 60°C [86 to 140°F] | 90° [194°F] |
| **Fluid viscosity** | 4 $mm^2/s$ [39 SUS] | 12 to 75 $mm^2/s$ [65 to 347 SUS] | 460 $mm^2/s$ [2128 SUS] |
| **Fluid cleanliness** | 23/19/16 (according to ISO 4406) | | |
| **Operating temperature** | Ambient: -30 to 60°C [-22 to 140°F] | | |

| | |
|---|---|
| **Flow Control Spools (FC)** | Flow control spools are for work sections where you want to control the speed (flow) of the work port |
| **Pressure Control Spools (PC)** | Pressure control spools are for work sections where you want to control the power (pressure) of the work port |


For more information on where to use flow control or pressure control spools see application guide **AB00000079 -** *"Using flow or pressure control spools"*

| | |
|---|---|
| **Closed neutral position** | In neutral position and inside of the deadband area the connection to tank is closed |
| **Throttled open neutral position** | In neutral position and inside of the deadband area the connection to tank is 10 % of the full flow function |
| **Open/closed neutral position (drain)** | In total neutral position the connection to tank is less than 10 % of the full flow function. But when moving the spool out of neutral position but still within dead band area the connection will close. |

## PVBS Main Spools


### PVBS fluid flow characteristics—Theoretical performance

*Fluid flow at different spool travel + 10 bar margin*




## PVBS Main Spools

*Fluid flow at different spool travel + 20 bar margin*




## PVBS Main Spools

*Progressive fluid flow characteristic depending on spool type*





*Linear fluid flow characteristic depending on spool type*




## PVBS Main Spools

*Progressive fluid flow characteristic of spool with A-float*





*Progressive fluid flow characteristic of spool with B-float*




## PVBS Main Spools


*Pressure drop at maximum spool travel position*




*Pressure drop for open spool in neutral position*





*Pressure drop A/B to T in float position*




## PVBS Main Spools Part Numbers

### Flow Control Spools—Closed Neutral Position

Schematic for PVBS without shuttle valve



Schematic for PVBS with shuttle valve



*Part numbers for Symmetric Flow Control Spools*

| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **157B9672** | PVE | - | 1 [0,26] | 1 [0,26] | 1 [0,26] | 1 [0,26] |
| **157B7005** | PVE | - | 5 [1,3] | 5 [1,3] | 5 [1,3] | 5 [1,3] |
| **157B9543** | PVE | - | 10 [2,6] | 5 [1,3] | 5 [1,3] | 10 [2,6] |
| **157B7000** | PVE | - | 10 [2,6] | 10 [2,6] | 10 [2,6] | 10 [2,6] |
| **157B9509** | PVE | - | 15 [4,0] | 15 [4,0] | 15 [4,0] | 15 [4,0] |
| **157B7001** | PVE | - | 25 [6,6] | 25 [6,6] | 25 [6,6] | 25 [6,6] |
| **157B7002** | PVE | - | 40 [10,6] | 40 [10,6] | 40 [10,6] | 40 [10,6] |
| **157B9903** | PVE | - | 50 [13,2] | 50 [13,2] | 50 [13,2] | 50 [13,2] |
| **157B7003** | PVE | - | 65 [17,2] | 65 [17,2] | 65 [17,2] | 65 [17,2] |
| **157B9920** | PVE | - | 75 [19,8] | 75 [19,8] | 75 [19,8] | 130 [34,3] |
| **157B7004** | PVE | - | 100 [26,4] | 100 [26,4] | 100 [26,4] | 100 [26,4] |
| **157B9977** | PVE | - | 100 [26,4] | 100 [26,4] | 100 [26,4] | 130 [34,3] |
| **11140830** | PVE | - | 100 [26,4] | 100 [26,4] | 100 [26,4] | 130 [34,3] |
| **157B9674** | PVE | - | 130 [34,3] | 100 [26,4] | 100 [26,4] | 100 [26,4] |
| **157B9503** | PVE | - | [2)] | 100 [26,4] | 100 [26,4] | 100 [26,4] |
| **157B7006**[1)] | PVE | - | 130 [34,3] | 130 [34,3] | 130 [34,3] | 130 [34,3] |
| **11137391** | PVE | Yes | 1 [0,26] | 1 [0,26] | 1 [0,26] | 1 [0,26] |
| **157B7025** | PVE | Yes | 5 [1,3] | 5 [1,3] | 5 [1,3] | 5 [1,3] |
| **157B7020** | PVE | Yes | 10 [2,6] | 10 [2,6] | 10 [2,6] | 10 [2,6] |
| **157B7021** | PVE | Yes | 25 [6,6] | 25 [6,6] | 25 [6,6] | 25 [6,6] |
| **157B7022** | PVE | Yes | 40 [10,6] | 40 [10,6] | 40 [10,6] | 40 [10,6] |
| **157B7023** | PVE | Yes | 65 [17,2] | 65 [17,2] | 65 [17,2] | 65 [17,2] |
| **11223875** | PVE | Yes | 65 [17,2] | 65 [17,2] | 65 [17,2] | 65 [17,2] |
| **11212900** | PVE | Yes | 80 [21.1] | 80 [21.1] | 80 [21.1] | 80 [21.1] |
| **157B7024** | PVE | Yes | 100 [26,4] | 100 [26,4] | 100 [26,4] | 100 [26,4] |
| **157B7026**[1)] | PVE | Yes | 130 [34,3] | 130 [34,3] | 130 [34,3] | 130 [34,3] |
| **11201284** | PVE | Yes | 130 [34,3] | 130 [34,3] | 130 [34,3] | 130 [34,3] |
| **157B9005** | PVH/PVHC | - | 5 [1,3] | 5 [1,3] | 5 [1,3] | 5 [1,3] |
| **157B9000** | PVH/PVHC | - | 10 [2,6] | 10 [2,6] | 10 [2,6] | 10 [2,6] |
| **11225674** | PVH/PVHC | - | 15 [4,0] | 15 [4,0] | 15 [4,0] | 15 [4,0] |
| **157B9001** | PVH/PVHC | - | 25 [6,6] | 25 [6,6] | 25 [6,6] | 25 [6,6] |
| **157B9002** | PVH/PVHC | - | 40 [10,6] | 40 [10,6] | 40 [10,6] | 40 [10,6] |
| **157B9003** | PVH/PVHC | - | 65 [17,2] | 65 [17,2] | 65 [17,2] | 65 [17,2] |

## PVBS Main Spools Part Numbers

*Part numbers for Symmetric Flow Control Spools (continued)*

| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **157B9816** | PVH/PVHC | - | 75 [19,8] | 75 [19,8] | 75 [19,8] | 130 [34,3] |
| **157B9004** | PVH/PVHC | - | 100 [26,4] | 100 [26,4] | 100 [26,4] | 100 [26,4] |
| **157B9006**[1)] | PVH/PVHC | - | 130 [34,3] | 130 [34,3] | 130 [34,3] | 130 [34,3] |
| **157B9025** | PVH/PVHC | Yes | 5 [1,3] | 5 [1,3] | 5 [1,3] | 5 [1,3] |
| **157B9020** | PVH/PVHC | Yes | 10 [2,6] | 10 [2,6] | 10 [2,6] | 10 [2,6] |
| **11122055** | PVH/PVHC | Yes | 15 [4,0] | 15 [4,0] | 15 [4,0] | 15 [4,0] |
| **157B9021** | PVH/PVHC | Yes | 25 [6,6] | 25 [6,6] | 25 [6,6] | 25 [6,6] |
| **157B9022** | PVH/PVHC | Yes | 40 [10,6] | 40 [10,6] | 40 [10,6] | 40 [10,6] |
| **157B9023** | PVH/PVHC | Yes | 65 [17,2] | 65 [17,2] | 65 [17,2] | 65 [17,2] |
| **11196171** | PVH/PVHC | Yes | * | 90 [23,8] | 90 [23,8] | * |
| **157B9024** | PVH/PVHC | Yes | 100 [26,4] | 100 [26,4] | 100 [26,4] | 100 [26,4] |
| **157B9026**[1)] | PVH/PVHC | Yes | 130 [34,3] | 130 [34,3] | 130 [34,3] | 130 [34,3] |

[2)] Fully opened, no flow restriction notch.

[1)] Turbo on A-port.

*Part numbers for Asymmetric Flow Control Spools*

| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **157B9524** | PVE | - | 5 [1,3] | 5 [1,3] | 10 [2,6] | 10 [2,6] |
| **11004213** | PVE | - | 5 [1,3] | 5 [1,3] | 65 [17,2] | 65 [17,2] |
| **157B9092** | PVE | - | 10 [2,6] | 10 [2,6] | 5 [1,3] | 5 [1,3] |
| **157B9514** | PVE | - | 10 [2,6] | 10 [2,6] | 15 [4,0] | 15 [4,0] |
| **157B9579** | PVE | - | 10 [2,6] | 10 [2,6] | 65 [17,2] | 65 [17,2] |
| **157B9579** | PVE | - | 65 [17,2] | 10 [2,6] | 65 [17,2] | 65 [17,2] |
| **157B9856** | PVE | - | 15 [4,0] | 15 [4,0] | 10 [2,6] | 10 [2,6] |
| **157B9516** | PVE | - | 15 [4,0] | 15 [4,0] | 10 [2,6] | 10 [2,6] |
| **11137748** | PVE | - | 20 [5,3] | 20 [5,3] | 15 [4,0] | 15 [4,0] |
| **157B9515** | PVE | - | 20 [5,3] | 20 [5,3] | 25 [6,6] | 25 [6,6] |
| **157B9950** | PVE | - | 25 [6,6] | 25 [6,6] | 10 [2,6] | 10 [2,6] |
| **11130056** | PVE | - | 25 [6,6] | 25 [6,6] | 15 [4,0] | 15 [4,0] |
| **157B9975** | PVE | - | 100 [26,4] | 25 [6,6] | 100 [26,4] | 100 [26,4] |
| **11119792** | PVE | - | 40 [10,6] | 40 [10,6] | 25 [6,6] | 25 [6,6] |
| **11022810** | PVE | - | 65 [17,2] | 65 [17,2] | 40 [10,6] | 40 [10,6] |
| **157B9566** | PVE | - | 65 [17,2] | 65 [17,2] | 10 [2,6] | 10 [2,6] |
| **11119557** | PVE | - | 75 [19,8] | 75 [19,8] | 65 [17,2] | 65 [17,2] |
| **157B9947** | PVE | Yes | 5 [1,3] | 5 [1,3] | 25 [6,6] | 25 [6,6] |
| **157B9555** | PVE | Yes | 7 [1,8] | 7 [1,8] | 10 [2,6] | 10 [2,6] |
| **11212898** | PVE | Yes | 10 [2,6] | 10 [2,6] | 5 [1,3] | 5 [1,3] |

## PVBS Main Spools Part Numbers

*Part numbers for Asymmetric Flow Control Spools (continued)*

| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **157B9915** | PVE | Yes | 15 [4,0] | 15 [4,0] | 35 [9,2] | 35 [9,2] |
| **11088763** | PVE | Yes | 25 [6,6] | 25 [6,6] | 40 [10,6] | 40 [10,6] |
| **11078499** | PVE | Yes | 40 [10,6] | 25 [6,6] | 40 [10,6] | 40 [10,6] |
| **157B9810** | PVE | Yes | 30 [7,9] | 30 [7,9] | 20 [5,3] | 20 [5,3] |
| **11015763** | PVE | Yes | 40 [10,6] | 40 [10,6] | 25 [6,6] | 25 [6,6] |
| **11015765** | PVE | Yes | 40 [10,6] | 40 [10,6] | 65 [17,2] | 65 [17,2] |
| **11216150** | PVE | Yes | 40 [10,6] | 40 [10,6] | 65 [17,2] | 65 [17,2] |
| **157B9907** | PVE | Yes | 50 [13,2] | 50 [13,2] | 5 [1,3] | 5 [1,3] |
| **157B9828** | PVE | Yes | 65 [17,2] | 65 [17,2] | 40 [10,6] | 40 [10,6] |
| **11021888** | PVE | Yes | 65 [17,2] | 65 [17,2] | 40 [10,6] | 65 [17,2] |
| **11216162** | PVE | Yes | 65 [17,2] | 65 [17,2] | 100 [26,4] | 100 [26,4] |
| **11036502** | PVE | Yes | 100 [26,4] | 100 [26,4] | 65 [17,2] | 65 [17,2] |
| **157B9857**[1)] | PVE | Yes | 130 [34,3] | 130 [34,3] | 65 [17,2] | 65 [17,2] |
| **11119552** | PVH/PVHC | - | 15 [4,0] | 15 [4,0] | 10 [2,6] | 10 [2,6] |
| **11066371** | PVH/PVHC | - | 20 [5,3] | 20 [5,3] | 15 [4,0] | 15 [4,0] |
| **11130928** | PVH/PVHC | - | 25 [6,6] | 25 [6,6] | 15 [4,0] | 15 [4,0] |
| **11130924** | PVH/PVHC | - | 40 [10,6] | 40 [10,6] | 25 [6,6] | 25 [6,6] |
| **11130831** | PVH/PVHC | - | 75 [19,8] | 75 [19,8] | 65 [17,2] | 65 [17,2] |
| **11094986** | PVH/PVHC | - | [2)] | 100 [26,4] | 100 [26,4] | [2)] |
| **11219179** | PVH/PVHC | Yes | 40 [10,6] | 40 [10,6] | 25 [6,6] | 25 [6,6] |
| **157B9084** | PVH/PVHC | Yes | 50 [13,2] | 50 [13,2] | 5 [1,3] | 5 [1,3] |
| **11145741**[1)] | PVH/PVHC | Yes | 130 [34,3] | 130 [34,3] | 65 [17,2] | 65 [17,2] |
| **11145955** | PVH/PVHC | Yes | 150 [39,6] | 60 [15,9] | 90 [23,8] | 150 [39,6] |

[1)] Turbo on A-port.

[2)] Fully open, no flow restriction notch.

*Part numbers for Back pressure Flow Control Spools (A/B->T flow track smaller than P->A/B)*

| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **11124636** | PVE | - | 40 [10,6] | 65 [17,2] | 65 [17,2] | 40 [10,6] |
| **11084778** | PVE | - | 2 [0,53] | 10 [2,6] | 10 [2,6] | 5 [1,3] |
| **11104114** | PVE | - | 3 [0,79] | 10 [2,6] | 15 [4,0] | 5 [1,3] |
| **11075794** | PVE | - | 5 [1,3] | 10 [2,6] | 5 [1,3] | 10 [2,6] |
| **11098883** | PVE | - | 5 [1,3] | 10 [2,6] | 10 [2,6] | 2 [0,53] |
| **11104452** | PVE | - | 5 [1,3] | 15 [4,0] | 10 [2,6] | 3 [0,79] |
| **157B9633** | PVE | - | 5 [1,3] | 25 [6,6] | 25 [6,6] | 5 [1,3] |
| **11098881** | PVE | - | 5 [1,3] | 25 [6,6] | 25 [6,6] | 25 [6,6] |
| **11126414** | PVE | - | 10 [2,6] | 25 [6,6] | 25 [6,6] | 25 [6,6] |

## PVBS Main Spools Part Numbers

*Part numbers for Back pressure Flow Control Spools (A/B->T flow track smaller than P->A/B) (continued)*

| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **11129522** | PVE | - | 10 [2,6] | 25 [6,6] | 50 [13,2] | 25 [6,6] |
| **157B9952** | PVE | - | 25 [6,6] | 38 [10,0] | 38 [10,0] | 25 [6,6] |
| **157B9635** | PVE | - | 10 [2,6] | 40 [10,6] | 40 [10,6] | 25 [6,6] |
| **11129523** | PVE | - | 10 [2,6] | 40 [10,6] | 50 [13,2] | 40 [10,6] |
| **157B9638** | PVE | - | 25 [6,6] | 40 [10,6] | 40 [10,6] | 25 [6,6] |
| **157B9818** | PVE | - | 40 [10,6] | 55 [14,5] | 55 [14,5] | 40 [10,6] |
| **11022164** | PVE | - | 10 [2,6] | 65 [17,2] | 65 [17,2] | 10 [2,6] |
| **157B9634** | PVE | - | 25 [6,6] | 65 [17,2] | 65 [17,2] | 25 [6,6] |
| **157B9931** | PVE | - | 40 [10,6] | 65 [17,2] | 65 [17,2] | 65 [17,2] |
| **157B9551** | PVE | - | 65 [17,2] | 65 [17,2] | 65 [17,2] | 10 [2,6] |
| **157B9978** | PVE | - | 100 [26,4] | 65 [17,2] | 100 [26,4] | 40 [10,6] |
| **157B9976** | PVE | - | 40 [10,6] | 100 [26,4] | 65 [17,2] | 100 [26,4] |
| **157B9541** | PVE | - | 40 [10,6] | 100 [26,4] | 65 [17,2] | * |
| **157B9949** | PVE | - | 40 [10,6] | 100 [26,4] | 100 [26,4] | 100 [26,4] |
| **157B9932** | PVE | - | 100 [26,4] | 100 [26,4] | 100 [26,4] | 40 [10,6] |
| **11129528** | PVE | Yes | 5 [1,3] | 15 [4,0] | 20 [5,3] | 10 [2,6] |
| **157B9827** | PVE | Yes | 10 [2,6] | 20 [5,3] | 20 [5,3] | 10 [2,6] |
| **157B9863** | PVE | Yes | 5 [1,3] | 25 [6,6] | 25 [6,6] | 5 [1,3] |
| **11100489** | PVE | Yes | 5 [1,3] | 25 [6,6] | 40 [10,6] | 20 [5,3] |
| **157B9946** | PVE | Yes | 25 [6,6] | 25 [6,6] | 10 [2,6] | 10 [2,6] |
| **157B9858** | PVE | Yes | 10 [2,6] | 40 [10,6] | 40 [10,6] | 10 [2,6] |
| **157B9639** | PVE | Yes | 25 [6,6] | 40 [10,6] | 40 [10,6] | 25 [6,6] |
| **157B9906** | PVE | Yes | 30 [7,9] | 40 [10,6] | 15 [4,0] | 20 [5,3] |
| **157B9632** | PVE | Yes | 25 [6,6] | 65 [17,2] | 65 [17,2] | 25 [6,6] |
| **157B9640** | PVE | Yes | 40 [10,6] | 100 [26,4] | 65 [17,2] | 65 [17,2] |
| **157B9839** | PVH/PVHC | - | 5 [1,3] | 25 [6,6] | 25 [6,6] | 5 [1,3] |
| **11104487** | PVH/PVHC | - | 5 [1,3] | 25 [6,6] | 25 [6,6] | 25 [6,6] |
| **11111729** | PVH/PVHC | - | 25 [6,6] | 40 [10,6] | 40 [10,6] | 25 [6,6] |
| **11074169** | PVH/PVHC | - | 100 [26,4] | 100 [26,4] | 100 [26,4] | 40 [10,6] |
| **11218880** | PVH/PVHC | Yes | 5 [1,3] | 25 [6,6] | 25 [6,6] | 5 [1,3] |
| **11119474** | PVH/PVHC | Yes | 25 [6,6] | 40 [10,6] | 40 [10,6] | 25 [6,6] |
| **11145741** | PVH/PVHC | Yes | 150 [39,6] | 150 [39,6] | 150 [39,6] | 65 [17,2] |

* Fully opened, no flow restriction notch.

## PVBS Main Spools Part Numbers


*Part numbers for Flow Control Spools for PVML*

| Part Number | Actuation | PVB with shuttle valve | Flow - l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **11088178** | PVE | - | 65 [17,2] | 65 [17,2] | 65 [17,2] | 65 [17,2] |
| **11076336** | PVE | - | 100 [26,4] | 100 [26,4] | 100 [26,4] | 100 [26,4] |
| **11075706*** | PVE | - | 130 [34,3] | 130 [34,3] | 130 [34,3] | 130 [34,3] |
| **11088177** | PVE | Yes | 100 [26,4] | 100 [26,4] | 100 [26,4] | 100 [26,4] |
| **11145032** | PVH/PVHC | Yes | 25 [6,6] | 25 [6,6] | 25 [6,6] | 25 [6,6] |
| **11079716** | PVH/PVHC | Yes | 75 [19,8] | 75 [19,8] | 75 [19,8] | 75 [19,8] |
| **11144181** | PVH/PVHC | Yes | 90 [23,8] | 90 [23,8] | 90 [23,8] | 90 [23,8] |
| **11145641** | PVH/PVHC | Yes | 150 [39,6] | 150 [39,6] | 150 [39,6] | 150 [39,6] |

* Turbo on A-port.

### Flow Control Spools—Closed Neutral Position with A-float

*Schematic for PVBS with shuttle valve*




*Part numbers for Asymmetric Flow Control Spools*

| Part Number | Actuation | PVB with shuttle valve | Flow - l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **11020293** | PVE | Yes | * | 100 [26,4] | 65 [17,2] | * |

* Fully opened, no flow restriction notch

### Flow Control Spools—Closed Neutral Position with B-float

*Schematic for PVBS with shuttle valve*



*Part numbers for Symmetric Flow Control Spools*

| Part Number | Actuation | PVB with shuttle valve | Flow - l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **157B7620** | PVE | Yes | 10 [2,6] | 10 [2,6] | 10 [2,6] | 10 [2,6] |
| **157B7621** | PVE | Yes | 25 [6,6] | 25 [6,6] | 25 [6,6] | 25 [6,6] |
| **157B7622** | PVE | Yes | 40 [10,6] | 40 [10,6] | 40 [10,6] | 40 [10,6] |
| **157B7623** | PVE | Yes | 65 [17,2] | 65 [17,2] | 65 [17,2] | 65 [17,2] |
| **157B7624**[1] | PVE | Yes | 100 [26,4] | 100 [26,4] | 100 [26,4] | 100 [26,4] |
| **157B9620** | PVH/PVHC | Yes | 10 [2,6] | 10 [2,6] | 10 [2,6] | 10 [2,6] |
| **157B9636** | PVH/PVHC | Yes | 25 [6,6] | 25 [6,6] | 25 [6,6] | 25 [6,6] |

## PVBS Main Spools Part Numbers

*Part numbers for Symmetric Flow Control Spools (continued)*

| Part Number | Actuation | PVB with shuttle valve | Flow - l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **11051805** | PVH/PVHC | Yes | 65 [17,2] | 65 [17,2] | 65 [17,2] | 65 [17,2] |
| **11085501**[1] | PVH/PVHC | Yes | 100 [26,4] | 100 [26,4] | 100 [26,4] | 100 [26,4] |

[1] Turbo on A and B port.

*Part numbers for Asymmetric Flow Control Spools*

| Part Number | Actuation | PVB with shuttle valve | Flow - l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **157B9911** | PVE | Yes | 30 [7,9] | 30 [7,9] | 65 [17,2] | 65 [17,2] |
| **157B9518**[1] | PVE | Yes | 100 [26,4] | 100 [26,4] | 65 [17,2] | 100 [26,4] |

[1] Turbo on A port.

*Part numbers for Back pressure Flow Control Spools (A/B->T flow track smaller than P->A/B)*

| Part Number | Actuation | PVB with shuttle valve | Flow - l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **11129529** | PVE | Yes | 3 [0,8] | 10 [2,6] | 13 [3,4] | 5 [1,3] |
| **157B9691** | PVE | Yes | 15 [4,0] | 30 [7,9] | 30 [7,9] | 15 [4,0] |
| **157B9692** | PVE | Yes | 25 [6,6] | 50 [13,2] | 65 [17,2] | 65 [17,2] |
| **157B9941**[1] | PVE | Yes | 100 [26,4] | 130 [34,3] | 130 [34,3] | 130 [34,3] |
| **157B9691** | PVH/PVHC | Yes | 15 [4,0] | 30 [7,9] | 30 [7,9] | 15 [4,0] |
| **157B9692** | PVH/PVHC | Yes | 25 [6,6] | 50 [13,2] | 65 [17,2] | 65 [17,2] |

[1] Turbo on A and B port.


*Part number for Flow Control Spools for PVML*

| Part Number | Actuation | PVB with shuttle valve | Flow - l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| 11145032 | PVH/PVHC | Yes | 150 [39.6] | 110 [29.1] | 5 [19.8] | 70 [18.5] |

## PVBS Main Spools Part Numbers

### Flow Control Spools—Closed Neutral Position with A-float for PVMF

*Schematic for PVBS with shuttle valve*




*Part numbers for Symmetric Flow Control Spools*

| Part Number | Actuation | PVB with shuttle valve | Flow - l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **157B9825** | PVE | Yes | 5 [1,3] | 5 [1,3] | 5 [1,3] | 5 [1,3] |
| **157B9820** | PVE | Yes | 10 [2,6] | 10 [2,6] | 10 [2,6] | 10 [2,6] |
| **157B9821** | PVE | Yes | 25 [6,6] | 25 [6,6] | 25 [6,6] | 25 [6,6] |
| **157B9822** | PVE | Yes | 40 [10,6] | 40 [10,6] | 40 [10,6] | 40 [10,6] |
| **157B9823** | PVE | Yes | 65 [17,2] | 65 [17,2] | 65 [17,2] | 65 [17,2] |
| **157B9824**[1)] | PVE | Yes | 100 [26,4] | 100 [26,4] | 100 [26,4] | 100 [26,4] |

[1)] Turbo on A and B port.

### Flow Control Spools—Closed Neutral Position with B-float for PVMF

*Schematic for PVBS with shuttle valve*



*Part numbers for Symmetric Flow Control Spools*


| Part Number | Actuation | PVB with shuttle valve | Flow - l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **157B9821** | PVE | Yes | 25 [6,6] | 25 [6,6] | 25 [6,6] | 25 [6,6] |
| **157B9822** | PVE | Yes | 40 [10,6] | 40 [10,6] | 40 [10,6] | 40 [10,6] |
| **157B9823** | PVE | Yes | 65 [17,2] | 65 [17,2] | 65 [17,2] | 65 [17,2] |
| **157B9824**[1)] | PVE | Yes | 100 [26,4] | 100 [26,4] | 100 [26,4] | 100 [26,4] |

[1)] Turbo on A and B port.


## PVBS Main Spools Part Numbers

### Flow Control Spools—Closed Neutral Position for PVMR

Schematic for PVBS without shuttle valve



Schematic for PVBS with shuttle valve




*Part numbers for Symmetric Flow Control Spools*


| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **157B9705** | PVE | - | 5 [1,3] | 5 [1,3] | 5 [1,3] | 5 [1,3] |
| **157B9700** | PVE | - | 10 [2,6] | 10 [2,6] | 10 [2,6] | 10 [2,6] |
| **11095634** | PVE | - | 15 [4,0] | 15 [4,0] | 15 [4,0] | 15 [4,0] |
| **157B9701** | PVE | - | 25 [6,6] | 25 [6,6] | 25 [6,6] | 25 [6,6] |
| **157B9702** | PVE | - | 40 [10,6] | 40 [10,6] | 40 [10,6] | 40 [10,6] |
| **157B9703** | PVE | - | 65 [17,2] | 65 [17,2] | 65 [17,2] | 65 [17,2] |
| **157B9704** | PVE | - | 100 [26,4] | 100 [26,4] | 100 [26,4] | 100 [26,4] |
| **157B9725** | PVE | Yes | 5 [1,3] | 5 [1,3] | 5 [1,3] | 5 [1,3] |
| **157B9720** | PVE | Yes | 10 [2,6] | 10 [2,6] | 10 [2,6] | 10 [2,6] |
| **157B9721** | PVE | Yes | 25 [6,6] | 25 [6,6] | 25 [6,6] | 25 [6,6] |
| **157B9722** | PVE | Yes | 40 [10,6] | 40 [10,6] | 40 [10,6] | 40 [10,6] |
| **157B9723** | PVE | Yes | 65 [17,2] | 65 [17,2] | 65 [17,2] | 65 [17,2] |
| **157B9724** | PVE | Yes | 100 [26,4] | 100 [26,4] | 100 [26,4] | 100 [26,4] |

### Flow Control Spools—Open/Closed Neutral Position

Schematic for PVBS without shuttle valve



Schematic for PVBS with shuttle valve



*Part numbers for Symmetric Flow Control Spools*

| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **157B7101** | PVE | - | 25 [6,6] | 25 [6,6] | 25 [6,6] | 25 [6,6] |
| **157B9537** | PVE | - | 40 [10,6] | 40 [10,6] | 40 [10,6] | 65 [10,6] |
| **157B7103** | PVE | - | 65 [17,2] | 65 [17,2] | 65 [17,2] | 65 [17,2] |
| **11100878** | PVE | Yes | 35 [9,2] | 35 [9,2] | 35 [9,2] | 35 [9,2] |
| **11027254** | PVE | Yes | 75 [19,8] | 75 [19,8] | 75 [19,8] | 75 [19,8] |

## PVBS Main Spools Part Numbers

*Part numbers for Asymmetric Flow Control Spools*


| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **157B9698** | PVE | Yes | 15 [4,0] | 15 [4,0] | 10 [2,6] | 10 [2,6] |
| **11055532** | PVE | Yes | 35 [9,2] | 35 [9,2] | 65 [17,2] | 65 [17,2] |
| **11025812** | PVE | Yes | 50 [13,2] | 50 [13,2] | 75 [19,8] | 75 [19,8] |

*Back pressure Flow Control Spools (A/B->T flow track smaller than P->A/B)*

| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **11094317** | PVE | Yes | 2 [0,5] | 5 [1,3] | 5 [1,3] | 2 [0,5] |
| **11051992** | PVE | Yes | 5 [1,3] | 18 [4,8] | 18 [4,8] | 5 [1,3] |
| **11027284** | PVE | Yes | 6 [1,6] | 25 [6,6] | 25 [6,6] | 6 [1,6] |
| **11117573** | PVE | Yes | 25 [6,6] | 35 [9,2] | 65 [17,2] | 65 [17,2] |
| **11025212** | PVE | Yes | 35 [9,2] | 35 [9,2] | 18 [4,8] | 12 [3,2] |
| **11137744** | PVE | Yes | 35 [9,2] | 50 [13,2] | 75 [19,8] | 75 [19,8] |
| **11027911** | PVE | Yes | 65 [17,2] | 65 [17,2] | 35 [9,2] | 25 [6,6] |
| **11027922** | PVE | Yes | 75 [19,8] | 75 [19,8] | 50 [13,2] | 35 [9,2] |

## Flow Control Spools—Open/Closed A and Closed B Position

*Schematic for PVBS with shuttle valve*



*Part numbers for Symmetric Flow Control Spools*

| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **11213583** | PVE | Yes | 100 [26.4] | 100 [26.4] | 100 [26.4] | 100 [26.4] |


*Part numbers for Asymmetric Flow Control Spools*

| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **11201798** | PVE | Yes | 100 [26.4] | 100 [26.4] | 65 [17.2] | 65 [17.2] |


## PVBS Main Spools Part Numbers

### Flow Control Spools—Throttled Open Neutral Position

Schematic for PVBS without shuttle valve



Schematic for PVBS with shuttle valve



*Part numbers for Symmetric Flow Control Spools*

| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **157B9697** | PVE | - | 1 [0,26] | 1 [0,26] | 1 [0,26] | 1 [0,26] |
| **157B7105** | PVE | - | 5 [1,3] | 5 [1,3] | 5 [1,3] | 5 [1,3] |
| **157B7100** | PVE | - | 10 [2,6] | 10 [2,6] | 10 [2,6] | 10 [2,6] |
| **157B7101** | PVE | - | 25 [6,6] | 25 [6,6] | 25 [6,6] | 25 [6,6] |
| **157B9534** | PVE | - | 25 [6,6] | 25 [6,6] | 25 [6,6] | 40 [6,6] |
| **157B7102** | PVE | - | 40 [10,6] | 40 [10,6] | 40 [10,6] | 40 [10,6] |
| **157B9537** | PVE | - | 40 [10,6] | 40 [10,6] | 40 [10,6] | 65 [10,6] |
| **11091340** | PVE | - | [3] | 40 [10,6] | 40 [10,6] | [3] |
| **157B9521** | PVE | - | [3] | 40 [10,6] | 40 [10,6] | [3] |
| **157B9677** | PVE | - | 50 [13,2] | 50 [13,2] | 50 [13,2] | 50 [13,2] |
| **157B7103** | PVE | - | 65 [17,2] | 65 [17,2] | 65 [17,2] | 65 [17,2] |
| **11007176** | PVE | - | [3] | 65 [17,2] | 65 [17,2] | [3] |
| **11122809** | PVE | - | 75 [19,8] | 75 [19,8] | 75 [19,8] | 75 [19,8] |
| **157B7104** | PVE | - | 100 [26,4] | 100 [26,4] | 100 [26,4] | 100 [26,4] |
| **11144269** | PVE | - | 100 [26,4] | 100 [26,4] | 100 [26,4] | [3] |
| **157B9098**[2] | PVE | - | 130 [34,3] | 130 [34,3] | 130 [34,3] | 130 [34,3] |
| **157B7106**[1] | PVE | - | 130 [34,3] | 130 [34,3] | 130 [34,3] | 130 [34,3] |
| **157B9675** | PVE | Yes | 3 [0,8] | 3 [0,8] | 3 [0,8] | 3 [0,8] |
| **157B7125** | PVE | Yes | 5 [1,3] | 5 [1,3] | 5 [1,3] | 5 [1,3] |
| **157B7120** | PVE | Yes | 10 [2,6] | 10 [2,6] | 10 [2,6] | 10 [2,6] |
| **157B9647** | PVE | Yes | 15 [4,0] | 15 [4,0] | 15 [4,0] | 15 [4,0] |
| **157B9594** | PVE | Yes | 20 [5,3] | 20 [5,3] | 20 [5,3] | 20 [5,3] |
| **157B7121** | PVE | Yes | 25 [6,6] | 25 [6,6] | 25 [6,6] | 25 [6,6] |
| **11029379** | PVE | Yes | 25 [6,6] | 25 [6,6] | 25 [6,6] | 25 [6,6] |
| **11153790** | PVE | Yes | [3] | 25 [6,6] | 25 [6,6] | [3] |
| **157B7122** | PVE | Yes | 40 [10,6] | 40 [10,6] | 40 [10,6] | 40 [10,6] |
| **157B9538** | PVE | Yes | 40 [10,6] | 40 [10,6] | 40 [10,6] | 40 [10,6] |
| **11121691** | PVE | Yes | 65 [17,2] | 65 [17,2] | 65 [17,2] | 65 [17,2] |
| **11108808** | PVE | Yes | 100 [26,4] | 100 [26,4] | 100 [26,4] | 100 [26,4] |
| **157B9649** | PVE | Yes | 55 [14,5] | 55 [14,5] | 55 [14,5] | 55 [14,5] |
| **157B7123** | PVE | Yes | 65 [17,2] | 65 [17,2] | 65 [17,2] | 65 [17,2] |
| **157B9650** | PVE | Yes | 75 [19,8] | 75 [19,8] | 75 [19,8] | 75 [19,8] |
| **11217660** | PVE | Yes | * | 90 | 90 | * |

## PVBS Main Spools Part Numbers

*Part numbers for Symmetric Flow Control Spools (continued)*

| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **157B9930**[2)] | PVE | Yes | 100 [26,4] | 100 [26,4] | 100 [26,4] | 100 [26,4] |
| **157B7124** | PVE | Yes | 100 [26,4] | 100 [26,4] | 100 [26,4] | 100 [26,4] |
| **11122118** | PVE | Yes | [3)] | 100 [26,4] | 100 [26,4] | [3)] |
| **11142634**[2)] | PVE | Yes | 130 [34,3] | 130 [34,3] | 130 [34,3] | 130 [34,3] |
| **157B7126**[1)] | PVE | Yes | 130 [34,3] | 130 [34,3] | 130 [34,3] | 130 [34,3] |
| **157B9854**[1)] | PVE | Yes | 130 [34,3] | 130 [34,3] | 130 [34,3] | [3)] |
| **157B9105** | PVH/PVHC | - | 5 [1,3] | 5 [1,3] | 5 [1,3] | 5 [1,3] |
| **157B9100** | PVH/PVHC | - | 10 [2,6] | 10 [2,6] | 10 [2,6] | 10 [2,6] |
| **157B9101** | PVH/PVHC | - | 25 [6,6] | 25 [6,6] | 25 [6,6] | 25 [6,6] |
| **157B9102** | PVH/PVHC | - | 40 [10,6] | 40 [10,6] | 40 [10,6] | 40 [10,6] |
| **157B9103** | PVH/PVHC | - | 65 [17,2] | 65 [17,2] | 65 [17,2] | 65 [17,2] |
| **157B9104** | PVH/PVHC | - | 100 [26,4] | 100 [26,4] | 100 [26,4] | 100 [26,4] |
| **157B9106**[1)] | PVH/PVHC | - | 130 [34,3] | 130 [34,3] | 130 [34,3] | 130 [34,3] |
| **157B9125** | PVH/PVHC | Yes | 5 [1,3] | 5 [1,3] | 5 [1,3] | 5 [1,3] |
| **157B9120** | PVH/PVHC | Yes | 10 [2,6] | 10 [2,6] | 10 [2,6] | 10 [2,6] |
| **157B9121** | PVH/PVHC | Yes | 25 [6,6] | 25 [6,6] | 25 [6,6] | 25 [6,6] |
| **157B9122** | PVH/PVHC | Yes | 40 [10,6] | 40 [10,6] | 40 [10,6] | 40 [10,6] |
| **157B9123** | PVH/PVHC | Yes | 65 [17,2] | 65 [17,2] | 65 [17,2] | 65 [17,2] |
| **157B9124**[2)] | PVH/PVHC | Yes | 100 [26,4] | 100 [26,4] | 100 [26,4] | 100 [26,4] |
| **157B9126**[1)] | PVH/PVHC | Yes | 130 [34,3] | 130 [34,3] | 130 [34,3] | 130 [34,3] |
| **11201697** | PVH/PVHC | Yes | 40 | 40 | 40 | 40 |

[3)] Fully opened, no flow restriction notch

[2)] Dead band 0.8 mm [0.03 in]

[1)] Turbo on A and B port

*Part numbers for Asymmetric Flow Control Spools*

| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **11004389** | PVE | - | 5 [1,3] | 5 [1,3] | 65 [17,2] | 65 [17,2] |
| **157B9094** | PVE | - | 15 [4,0] | 15 [4,0] | 30 [7,9] | 30 [7,9] |
| **157B9544** | PVE | - | 100 [26,4] | 15 [4,0] | 25 [6,6] | 40 [10,6] |
| **157B9526** | PVE | - | 30 [7,9] | 30 [7,9] | 15 [4,0] | 15 [4,0] |
| **157B9815** | PVE | - | 30 [7,9] | 30 [7,9] | 20 [5,3] | 20 [5,3] |
| **157B9545** | PVE | - | 40 [10,6] | 40 [10,6] | 15 [4,0] | 40 [10,6] |
| **11093116** | PVE | - | 40 [10,6] | 40 [10,6] | 20 [5,3] | 20 [5,3] |
| **11005204** | PVE | - | 40 [10,6] | 40 [10,6] | 65 [17,2] | 65 [17,2] |
| **157B9595** | PVE | - | 40 [10,6] | 40 [10,6] | 100 [26,4] | 100 [26,4] |
| **157B9860** | PVE | - | 50 [13,2] | 50 [13,2] | 20 [5,3] | 20 [5,3] |

## PVBS Main Spools Part Numbers

*Part numbers for Asymmetric Flow Control Spools (continued)*

| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **11091575** | PVE | - | 55 [14,5] | 55 [14,5] | 30 [7,9] | 30 [7,9] |
| **157B9696** | PVE | - | 65 [17,2] | 65 [17,2] | 10 [2,6] | 10 [2,6] |
| **157B9506** | PVE | - | 65 [17,2] | 65 [17,2] | 40 [10,6] | 40 [10,6] |
| **157B9586** | PVE | - | 65 [17,2] | 65 [17,2] | 100 [26,4] | 100 [26,4] |
| **11137895** | PVE | - | * | 65 [17,2] | 40 [10,6] | * |
| **11122941** | PVE | Yes | 15 [4,0] | 15 [4,0] | 100 [26,4] | 100 [26,4] |
| **157B9830** | PVE | Yes | 25 [6,6] | 25 [6,6] | 40 [10,6] | 40 [10,6] |
| **11070681** | PVE | Yes | 25 [6,6] | 25 [6,6] | 50 [13,2] | 50 [13,2] |
| **11217665** | PVE | Yes | 25 [6,6] | 25 [6,6] | 100 [26,4] | 100 [26,4] |
| **157B9547** | PVE | Yes | 40 [10,6] | 25 [6,6] | 20 [5,3] | 40 [10,6] |
| **157B9558** | PVE | Yes | 30 [7,9] | 30 [7,9] | 10 [2,6] | 10 [2,6] |
| **157B9833** | PVE | Yes | 30 [7,9] | 30 [7,9] | 20 [5,3] | 20 [5,3] |
| **157B9813** | PVE | Yes | 30 [7,9] | 30 [7,9] | 55 [14,5] | 55 [14,5] |
| **11100875** | PVE | Yes | * | 35 [9,2] | 18 [4,8] | * |
| **11100881** | PVE | Yes | * | 35 [9,2] | 50 [13,2] | * |
| **157B9567** | PVE | Yes | 40 [10,6] | 40 [10,6] | 20 [5,3] | 20 [5,3] |
| **157B9865** | PVE | Yes | 40 [10,6] | 40 [10,6] | 25 [6,6] | 25 [6,6] |
| **11125125** | PVE | Yes | 40 [10,6] | 40 [10,6] | 65 [17,2] | 65 [17,2] |
| **157B9505** | PVE | Yes | 40 [10,6] | 40 [10,6] | 100 [26,4] | 100 [26,4] |
| **11096423** | PVE | Yes | 50 [13,2] | 50 [13,2] | 65 [17,2] | 65 [17,2] |
| **157B9681** | PVE | Yes | 55 [14,5] | 55 [14,5] | 30 [7,9] | 30 [7,9] |
| **157B9814** | PVE | Yes | 65 [17,2] | 65 [17,2] | 40 [10,6] | 40 [10,6] |
| **11202615** | PVH/PVHC | - | 25 [6,6] | 25 [6,6] | 25 [6,6] | 40 [10,6] |
| **157B9847** | PVH/PVHC | - | 30 [7,9] | 30 [7,9] | 20 [5,3] | 20 [5,3] |
| **157B9546** | PVH/PVHC | - | 40 [10,6] | 25 [6,6] | 20 [5,3] | 40 [10,6] |
| **157B9686** | PVH/PVHC | - | 40 [10,6] | 30 [7,9] | 25 [6,6] | 40 [10,6] |
| **157B9685** | PVH/PVHC | - | 40 [10,6] | 40 [10,6] | 35 [9,2] | 40 [10,6] |
| **157B9498** | PVH/PVHC | - | 65 [17,2] | 65 [17,2] | 40 [10,6] | 40 [10,6] |
| **11140120** | PVH/PVHC | - | * | 65 [17,2] | 65 [17,2] | * |
| **157B9688** | PVH/PVHC | - | 100 [26,4] | 20 [5,3] | 30 [7,9] | 40 [10,6] |
| **11079579** | PVH/PVHC | Yes | 25 [6,6] | 25 [6,6] | 50 [13,2] | 50 [13,2] |
| **11218879** | PVH/PVHC | Yes | 40 [10,6] | 40 [10,6] | 15 [4.0] | 15 [4.0] |
| **157B9689** | PVH/PVHC | Yes | 40 [10,6] | 30 [7,9] | 30 [7,9] | 40 [10,6] |
| **11200936** | PVH/PVHC | Yes | 40 [10,6] | 40 [10,6] | 25 [6,6] | 25 [6,6] |
| **11092123** | PVH/PVHC | Yes | 40 [10,6] | 40 [10,6] | 100 [26,4] | 100 [26,4] |
| **11147574** | PVH/PVHC | Yes | * | 65 [17,2] | 65 [17,2] | * |

## PVBS Main Spools Part Numbers

*Part numbers for Asymmetric Flow Control Spools (continued)*

| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **11200922** | PVH/PVHC | Yes | 65 [17,2] | 65 [17,2] | 40 [10,6] | 40 [10,6] |
| **11153474** | PVH/PVHC | Yes | 80 [21,1] | 80 [21,1] | 65 [17,2] | 65 [17,2] |

* Fully opened, no flow restriction notch

*Back pressure Flow Control Spools (A/B->T flow track smaller than P->A/B)*

| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **11034321** | PVE | - | 3 [0,79] | 3 [0,79] | 10 [2,6] | 1 [0,26] |
| **11074918** | PVE | - | 5 [1,3] | 10 [2,6] | 5 [1,3] | 10 [2,6] |
| **11006879** | PVE | - | 25 [6,6] | 25 [6,6] | 65 [17,2] | 25 [6,6] |
| **11097891** | PVE | Yes | 40 [10,6] | 100 [26,4] | 40 [10,6] | 40 [10,6] |
| **157B9684** | PVH/PVHC | - | 25 [6,6] | 30 [7,9] | 30 [7,9] | 25 [6,6] |
| **157B9687** | PVH/PVHC | - | 25 [6,6] | 35 [9,2] | 35 [9,2] | 25 [6,6] |


*Flow Control Spools for PVML*

| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **157B9803** | PVE | - | 65 [17,2] | 65 [17,2] | 65 [17,2] | 65 [17,2] |
| **11122774** | PVE | - | 90 [23,8] | 90 [23,8] | 90 [23,8] | 90 [23,8] |
| **157B9802** | PVE | - | 100 [26,4] | 100 [26,4] | 100 [26,4] | 100 [26,4] |


## PVBS Main Spools Part Numbers

### Flow Control Spools—Throttled Open Neutral Position for PVMR

Schematic for PVBS without shuttle valve



Schematic for PVBS with shuttle valve



*Part numbers for Symmetric Flow Control Spools*

| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **157B9715** | PVE | - | 5 [1,3] | 5 [1,3] | 5 [1,3] | 5 [1,3] |
| **157B9710** | PVE | - | 10 [2,6] | 10 [2,6] | 10 [2,6] | 10 [2,6] |
| **157B9711** | PVE | - | 25 [6,6] | 25 [6,6] | 25 [6,6] | 25 [6,6] |
| **157B9712** | PVE | - | 40 [10,6] | 40 [10,6] | 40 [10,6] | 40 [10,6] |
| **157B9678** | PVE | - | 50 [13,2] | 50 [13,2] | 50 [13,2] | 50 [13,2] |
| **157B9713** | PVE | - | 65 [17,2] | 65 [17,2] | 65 [17,2] | 65 [17,2] |
| **11128430** | PVE | - | 80 [21,1] | 80 [21,1] | 80 [21,1] | 80 [21,1] |
| **157B9714** | PVE | - | 100 [26,4] | 100 [26,4] | 100 [26,4] | 100 [26,4] |
| **157B9716**[1)] | PVE | - | 130 [34,3] | 130 [34,3] | 130 [34,3] | 130 [34,3] |
| **157B9735** | PVE | Yes | 5 [1,3] | 5 [1,3] | 5 [1,3] | 5 [1,3] |
| **157B9730** | PVE | Yes | 10 [2,6] | 10 [2,6] | 10 [2,6] | 10 [2,6] |
| **157B9731** | PVE | Yes | 25 [6,6] | 25 [6,6] | 25 [6,6] | 25 [6,6] |
| **157B9732** | PVE | Yes | 40 [10,6] | 40 [10,6] | 40 [10,6] | 40 [10,6] |
| **157B9733** | PVE | Yes | 65 [17,2] | 65 [17,2] | 65 [17,2] | 65 [17,2] |
| **157B9734** | PVE | Yes | 100 [26,4] | 100 [26,4] | 100 [26,4] | 100 [26,4] |

[1)] Turbo on A and B port


*Part numbers for Asymmetric Flow Control Spools*

| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **11107125** | PVE | - | 5 [1,3] | 5 [1,3] | 65 [17,2] | 65 [17,2] |
| **11119504** | PVE | - | 40 [10,6] | 40 [10,6] | 65 [17,2] | 65 [17,2] |
| **11071543** | PVE | Yes | 30 [7,9] | 30 [7,9] | 10 [2,6] | 10 [2,6] |


## PVBS Main Spools Part Numbers

### Flow Control Spools—Throttled A to T Neutral Position

Schematic for PVBS without shuttle valve



Schematic for PVBS with shuttle valve



*Part numbers for Symmetric Flow Control Spools*

| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **157B9504** | PVE | - | 15 [4,0] | 15 [4,0] | 15 [4,0] | 15 [4,0] |
| **157B7401** | PVE | - | 25 [6,6] | 25 [6,6] | 25 [6,6] | 25 [6,6] |
| **157B7402** | PVE | - | 40 [10,6] | 40 [10,6] | 40 [10,6] | 40 [10,6] |
| **157B7403** | PVE | - | 65 [17,2] | 65 [17,2] | 65 [17,2] | 65 [17,2] |
| **157B7404** | PVE | - | 100 [26,4] | 100 [26,4] | 100 [26,4] | 100 [26,4] |
| **157B7406**[1)] | PVE | - | 130 [34,3] | 130 [34,3] | 130 [34,3] | 130 [34,3] |
| **157B9846** | PVE | - | [2)] | 130 [34,3] | 130 [34,3] | 130 [34,3] |
| **157B9527** | PVE | Yes | 15 [4,0] | 15 [4,0] | 15 [4,0] | 15 [4,0] |
| **157B7421** | PVE | Yes | 25 [6,6] | 25 [6,6] | 25 [6,6] | 25 [6,6] |
| **157B7422** | PVE | Yes | 40 [10,6] | 40 [10,6] | 40 [10,6] | 40 [10,6] |
| **157B7423** | PVE | Yes | 65 [17,2] | 65 [17,2] | 65 [17,2] | 65 [17,2] |
| **157B7424** | PVE | Yes | 100 [26,4] | 100 [26,4] | 100 [26,4] | 100 [26,4] |
| **157B7404** | PVH/PVHC | - | 100 [26,4] | 100 [26,4] | 100 [26,4] | 100 [26,4] |
| **157B7424** | PVH/PVHC | Yes | 100 [26,4] | 100 [26,4] | 100 [26,4] | 100 [26,4] |

[1)] Turbo on A and B port.

[2)] Fully opened, no flow restriction notch.


*Part numbers for Asymmetric Flow Control Spools*

| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **11022518** | PVE | - | 25 [6,6] | 25 [6,6] | 40 [10,6] | 40 [10,6] |
| **157B9834** | PVE | - | 30 [7,9] | 30 [7,9] | 20 [5,3] | 20 [5,3] |
| **11201797** | PVE | Yes | 150 [39.6] | 150 [39.6] | 100 [26,4] | 100 [26,4] |


## PVBS Main Spools Part Numbers

### Flow Control Spools—Throttled B to T Neutral Position

Schematic for PVBS without shuttle valve



Schematic for PVBS with shuttle valve



*Part numbers for Symmetric Flow Control Spools*

| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **157B7500** | PVE | - | 10 [2,6] | 10 [2,6] | 10 [2,6] | 10 [2,6] |
| **157B7501** | PVE | - | 25 [6,6] | 25 [6,6] | 25 [6,6] | 25 [6,6] |
| **157B7502** | PVE | - | 40 [10,6] | 40 [10,6] | 40 [10,6] | 40 [10,6] |
| **157B7503** | PVE | - | 65 [17,2] | 65 [17,2] | 65 [17,2] | 65 [17,2] |
| **157B7504** | PVE | - | 100 [26,4] | 100 [26,4] | 100 [26,4] | 100 [26,4] |
| **11064144**[1)] | PVE | - | 130 [34,3] | 130 [34,3] | 130 [34,3] | 130 [34,3] |
| **157B7520** | PVE | Yes | 10 [2,6] | 10 [2,6] | 10 [2,6] | 10 [2,6] |
| **157B7521** | PVE | Yes | 25 [6,6] | 25 [6,6] | 25 [6,6] | 25 [6,6] |
| **157B7522** | PVE | Yes | 40 [10,6] | 40 [10,6] | 40 [10,6] | 40 [10,6] |
| **157B7523** | PVE | Yes | 65 [17,2] | 65 [17,2] | 65 [17,2] | 65 [17,2] |
| **157B7524** | PVE | Yes | 100 [26,4] | 100 [26,4] | 100 [26,4] | 100 [26,4] |
| **11202731** | PVH/PVHC | Yes | 25 [6,6] | 25 [6,6] | 25 [6,6] | 25 [6,6] |

[1)] Turbo on A and B port.

*Part numbers for Asymmetric Flow Control Spools*

| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **157B9948** | PVE | Yes | 25 [6,6] | 25 [6,6] | 10 [2,6] | 10 [2,6] |
| **11008038** | PVE | Yes | 40 [10,6] | 40 [10,6] | 25 [6,6] | 25 [6,6] |
| **11037198** | PVE | Yes | 100 [26,4] | 40 [10,6] | 40 [10,6] | 40 [10,6] |
| **11126490** | PVE | Yes | 65 [17,2] | 65 [17,2] | 40 [10,6] | 40 [10,6] |


*Part numbers for Full open B → T*

| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **11131447** | PVE | - | 10 [2.6] | 10 [2.6] | 10 [2.6] | 10 [2.6] |


## PVBS Main Spools Part Numbers

### Linear Flow Control Spools—Closed Neutral Position

Schematic for PVBS without shuttle valve



Schematic for PVBS with shuttle valve



*Part numbers for Symmetric Flow Control Spools*

| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **157B9770** | PVE | Yes | 10 [2,6] | 10 [2,6] | 10 [2,6] | 10 [2,6] |
| **157B9771** | PVE | Yes | 25 [6,6] | 25 [6,6] | 25 [6,6] | 25 [6,6] |
| **157B9511**[1)] | PVE | Yes | 25 [6,6] | 25 [6,6] | 25 [6,6] | 25 [6,6] |
| **157B9772** | PVE | Yes | 40 [10,6] | 40 [10,6] | 40 [10,6] | 40 [10,6] |
| **157B9773** | PVE | Yes | 65 [17,2] | 65 [17,2] | 65 [17,2] | 65 [17,2] |
| **157B9655**[1)] | PVE | Yes | 85 [17,2] | 85 [17,2] | 85 [17,2] | 85 [17,2] |
| **11073991** | PVH/PVHC | - | 40 [10,6] | 40 [10,6] | 40 [10,6] | 40 [10,6] |
| **11051903** | PVH/PVHC | - | 100 [26,4] | 100 [26,4] | 100 [26,4] | 100 [26,4] |
| **11107159** | PVH/PVHC | Yes | 10 [2,6] | 10 [2,6] | 10 [2,6] | 10 [2,6] |
| **11107222** | PVH/PVHC | Yes | 40 [10,6] | 40 [10,6] | 40 [10,6] | 40 [10,6] |
| **157B9080** | PVH/PVHC | Yes | 65 [17,2] | 65 [17,2] | 65 [17,2] | 65 [17,2] |
| **11083650** | PVH/PVHC | Yes | [2)] | 85 [17,2] | 85 [17,2] | [2)] |

[1)] Dead band 1,1 mm [0,04 in].

[2)] Fully opened, no flow restriction notch.

*Part numbers for Asymmetric Flow Control Spools*

| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **157B9086** | PVH/PVHC | - | 65 [17,2] | 65 [17,2] | 100 [26,4] | 100 [26,4] |

Dead band 1,5 mm [0,06 in].

*Part number for Back pressure Flow Control Spools (A/B->T flow track smaller than P->A/B)*

| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **11151485** | PVE | Yes | 30 [7.9] | 85 [22.5] | 110 [29,1] | 35 [9.2] |

Dead band 0.8 mm [0,03 in].


*Part numbers for Flow Control Spools for PVML*

| Part Number | Actuation | PVB with shuttle valve | Flow - l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **11127700** | PVH/PVHC | Yes | 100 [26.4] | 100 [26.4] | 100 [26.4] | 100 [26.4] |


## PVBS Main Spools Part Numbers

### Linear Flow Control Spools—Throttled Open Neutral Position

Schematic for PVBS without shuttle valve



Schematic for PVBS with shuttle valve



*Part numbers for Symmetric Flow Control Spools*

| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **11140460** | PVE | Yes | 5 [1,3] | 5 [1,3] | 5 [1,3] | 5 [1,3] |
| **157B9780** | PVE | Yes | 10 [2,6] | 10 [2,6] | 10 [2,6] | 10 [2,6] |
| **157B9781** | PVE | Yes | 25 [6,6] | 25 [6,6] | 25 [6,6] | 25 [6,6] |
| **157B9782** | PVE | Yes | 40 [10,6] | 40 [10,6] | 40 [10,6] | 40 [10,6] |
| **11076654** | PVE | Yes | 50 [13,2] | 50 [13,2] | 50 [13,2] | 50 [13,2] |
| **157B9783** | PVE | Yes | 65 [17,2] | 65 [17,2] | 65 [17,2] | 65 [17,2] |
| **157B9784** | PVE | Yes | 100 [26,4] | 100 [26,4] | 100 [26,4] | 100 [26,4] |
| **157B9577*** | PVE | Yes | 130 [34,3] | 130 [34,3] | 130 [34,3] | 130 [34,3] |
| **157B9807** | PVH/PVHC | - | 10 [2,6] | 10 [2,6] | 10 [2,6] | 10 [2,6] |
| **157B9805** | PVH/PVHC | - | 25 [6,6] | 25 [6,6] | 25 [6,6] | 25 [6,6] |
| **11046738** | PVH/PVHC | - | 40 [10,6] | 40 [10,6] | 40 [10,6] | 40 [10,6] |
| **11080984** | PVH/PVHC | - | 65 [17,2] | 65 [17,2] | 65 [17,2] | 65 [17,2] |
| **11153567** | PVH/PVHC | - | 100 [26,4] | 40 [10,6] | 40 [10,6] | 100 [26,4] |
| **11218248**[1)] | PVH/PVHC | - | 130 [34,3] | 130 [34,3] | 130 [34,3] | 130 [34,3] |
| **157B9806** | PVH/PVHC | Yes | 25 [6,6] | 25 [6,6] | 25 [6,6] | 25 [6,6] |
| **157B9079** | PVH/PVHC | Yes | 40 [10,6] | 40 [10,6] | 40 [10,6] | 40 [10,6] |
| **157B9081** | PVH/PVHC | Yes | 65 [17,2] | 65 [17,2] | 65 [17,2] | 65 [17,2] |
| **157B9082** | PVH/PVHC | Yes | 100 [26,4] | 100 [26,4] | 100 [26,4] | 100 [26,4] |
| **11140180** | PVH/PVHC | Yes | [2)] | 100 [26,4] | 100 [26,4] | [2)] |
| **11216148** | PVE | - | * | 55 [14,5] | 55 [14,5] | * |

* Turbo on A and B port

*Part numbers for Assymmetric Flow Control Spools*

| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **11201830**[1)] | PVH/PVHC | - | [2)] | 65 [17,2] | 65 [17,2] | [2)] |

[1)] Dead band 0.8 mm [0,03 in].

[2)] Fully opened, no flow restriction notch


## PVBS Main Spools Part Numbers

*Flow Control Spools for PVML*


| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **11141375** | PVE | - | 25 [6.6] | 25 [6.6] | 25 [6.6] | 25 [6.6] |
| **11142973** | PVH/PVHC | - | 100 [26,4] | 100 [26,4] | 100 [26,4] | 100 [26,4] |

### Linear Flow Control Spools—Open/Closed Neutral Position

Schematic for PVBS without shuttle valve



Schematic for PVBS with shuttle valve




*Part numbers for Back pressure Flow Control Spools (A/B->T flow track smaller than P->A/B)*

| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **11146795** | PVE | Yes | 15 [4.0] | 40 [10.6] | 65 [17.2] | 15 [4.0] |
| **11146797** | PVE | Yes | 15 [4.0] | 65 [17.2] | 40 [10.6] | 10 [2.6] |
| **11151486*** | PVE | Yes | 20 [5.3] | 80 [21.1] | 110 [29,1] | 40 [10.6] |

* Dead band 0.8 mm [0,03 in].

### Single Acting Cylinder Flow Control Spools—Neutral A-port Position

*Schematic for PVBS without shuttle valve*



*Symmetric flow control spools*

| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **11077423** | PVE | - | 5 [1,3] | 5 [1,3] | - | - |
| **157B7200** | PVE | - | 10 [2,6] | 10 [2,6] | - | - |
| **157B7201** | PVE | - | 25 [6,6] | 25 [6,6] | - | - |
| **157B7202** | PVE | - | 40 [10,6] | 40 [10,6] | - | - |
| **157B7203** | PVE | - | 65 [17,2] | 65 [17,2] | - | - |
| **157B7204** | PVE | - | 100 [26,4] | 100 [26,4] | - | - |
| **11015830** | PVE | - | 130 [34,3] | 130 [34,3] | - | - |
| **157B9200** | PVH/PVHC | - | 10 [2,6] | 10 [2,6] | - | - |
| **157B9201** | PVH/PVHC | - | 25 [6,6] | 25 [6,6] | - | - |
| **157B9202** | PVH/PVHC | - | 40 [10,6] | 40 [10,6] | - | - |
| **157B9203** | PVH/PVHC | - | 65 [17,2] | 65 [17,2] | - | - |
| **157B9204** | PVH/PVHC | - | 100 [26,4] | 100 [26,4] | - | - |
| **11085447** | PVH/PVHC | - | 130 [34,3] | 130 [34,3] | - | - |

## PVBS Main Spools Part Numbers


*Back pressure Flow Control Spool (A/B->T flow track smaller than P->A/B)*

| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **157B9905** | PVE | - | 25 [6.6] | 65 [17.2] | - | - |

## PVBS Main Spools Part Numbers

### Single Acting Cylinder Flow Control Spools—Neutral B-port Position

*Schematic for PVBS without shuttle valve*



*Symmetric flow control spools*


| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **157B7300** | PVE | - | - | - | 10 [2,6] | 10 [2,6] |
| **157B7301** | PVE | - | - | - | 25 [6,6] | 25 [6,6] |
| **157B7302** | PVE | - | - | - | 40 [10,6] | 40 [10,6] |
| **157B7303** | PVE | - | - | - | 65 [17,2] | 65 [17,2] |
| **157B7304** | PVE | - | - | - | 100 [26,4] | 100 [26,4] |
| **157B9301** | PVH/PVHC | - | - | - | 25 [6,6] | 25 [6,6] |

*Back pressure Flow Control Spool (A/B->T flow track smaller than P->A/B)*

| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **157B9912** | PVE | - | - | - | 65 [17,2] | 25 [6,6] |
| **11098878** | PVE | - | - | - | 25 [6,6] | 5 [1,3] |
| **11104486** | PVH/PVHC | - | - | - | 25 [6,6] | 5 [1,3] |

### Single Acting Cylinder Linear Flow Control Spools—Neutral B-port Position

*Schematic for PVBS without shuttle valve*



*Back pressure Flow Control Spool (A/B->T flow track smaller than P->A/B)*


| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **157B9668** | PVE | - | - | - | 65 [17,2] | 40 [10,6] |

## PVBS Main Spools Part Numbers


### Flow/Pressure Control Spools—Closed Neutral Position

All spools have flow control on port A, pressure control on port B and a dead band on 1,5 mm [0,06 in].

Schematic for PVBS without shuttle valve



Schematic for PVBS with shuttle valve



*Part numbers for Symmetric PC/FC Spools*

| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **157B7050** | PVE | - | 10 [2,6] | 10 [2,6] | 10 [2,6] | 10 [2,6] |
| **157B7051** | PVE | - | 25 [6,6] | 25 [6,6] | 25 [6,6] | 25 [6,6] |
| **157B7052** | PVE | - | 40 [10,6] | 40 [10,6] | 40 [10,6] | 40 [10,6] |
| **157B7053** | PVE | - | 65 [17,2] | 65 [17,2] | 65 [17,2] | 65 [17,2] |
| **157B7071** | PVE | Yes | 25 [6,6] | 25 [6,6] | 25 [6,6] | 25 [6,6] |
| **157B7072** | PVE | Yes | 40 [10,6] | 40 [10,6] | 40 [10,6] | 40 [10,6] |
| **157B7073** | PVE | Yes | 65 [17,2] | 65 [17,2] | 65 [17,2] | 65 [17,2] |
| **157B7074** | PVE | Yes | 100 [26,4] | 100 [26,4] | 100 [26,4] | 100 [26,4] |
| **157B9052** | PVH/PVHC | - | 40 [10,6] | 40 [10,6] | 40 [10,6] | 40 [10,6] |
| **157B9053** | PVH/PVHC | - | 65 [17,2] | 65 [17,2] | 65 [17,2] | 65 [17,2] |
| **157B9054** | PVH/PVHC | - | 100 [26,4] | 100 [26,4] | 100 [26,4] | 100 [26,4] |
| **157B9072** | PVH/PVHC | Yes | 40 [10,6] | 40 [10,6] | 40 [10,6] | 40 [10,6] |
| **157B9073** | PVH/PVHC | Yes | 65 [17,2] | 65 [17,2] | 65 [17,2] | 65 [17,2] |
| **157B9074** | PVH/PVHC | Yes | 100 [26,4] | 100 [26,4] | 100 [26,4] | 100 [26,4] |

*Part numbers for Asymmetric PC/FC Spools*

| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **157B9529** | PVE | Yes | 65 [17,2] | 65 [17,2] | 40 [10,6] | 65 [17,2] |

*Back pressure PC/FC Spools (A/B->T flow track smaller than P->A/B)*

| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **157B9533** | PVE | Yes | 10 [2,6] | 25 [6,6] | 5 [1,3] | 25 [6,6] |
| **11120728** | PVE | Yes | 10 [2,6] | 40 [10,6] | 25 [6,6] | 25 [6,6] |
| **157B9536** | PVE | Yes | 25 [6,6] | 40 [10,6] | 10 [2,6] | 40 [10,6] |


### Flow/Pressure Control Spools—Throttled Open Neutral Position

All spools have flow control on port A, pressure control on port B and a dead band on 1,5 mm [0,06 in].

Schematic for PVBS without shuttle valve

Schematic for PVBS with shuttle valve

## PVBS Main Spools Part Numbers



*Part numbers for Symmetric FC/PC Control Spools*

| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **157B7150** | PVE | - | 10 [2,6] | 10 [2,6] | 10 [2,6] | 10 [2,6] |
| **157B7151** | PVE | - | 25 [6,6] | 25 [6,6] | 25 [6,6] | 25 [6,6] |
| **157B7152** | PVE | - | 40 [10,6] | 40 [10,6] | 40 [10,6] | 40 [10,6] |
| **157B7153** | PVE | - | 65 [17,2] | 65 [17,2] | 65 [17,2] | 65 [17,2] |
| **157B7154** | PVE | - | 100 [26,4] | 100 [26,4] | 100 [26,4] | 100 [26,4] |
| **11067130** | PVE | Yes | 10 [2,6] | 10 [2,6] | 10 [2,6] | 10 [2,6] |
| **157B7171** | PVE | Yes | 25 [6,6] | 25 [6,6] | 25 [6,6] | 25 [6,6] |
| **157B9556** | PVE | Yes | 30 [7,9] | 30 [7,9] | 30 [7,9] | 30 [7,9] |
| **157B7172** | PVE | Yes | 40 [10,6] | 40 [10,6] | 40 [10,6] | 40 [10,6] |
| **157B7173** | PVE | Yes | 65 [17,2] | 65 [17,2] | 65 [17,2] | 65 [17,2] |
| **157B7174** | PVE | Yes | 100 [26,4] | 100 [26,4] | 100 [26,4] | 100 [26,4] |
| **11107242** | PVH/PVHC | Yes | 40 [10,6] | 40 [10,6] | 40 [10,6] | 40 [10,6] |
| **157B9173** | PVH/PVHC | Yes | 65 [17,2] | 65 [17,2] | 65 [17,2] | 65 [17,2] |

*Part numbers for Asymmetric FC/PC Control Spools*

| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **157B9592** | PVE | Yes | 40 [10,6] | 40 [10,6] | 15 [4,0] | 15 [4,0] |
| **11051961** | PVE | Yes | 100 [26,4] | 100 [26,4] | 65 [17,2] | 65 [17,2] |
| **11139550** | PVE | Yes | 115 [30,4] | 115 [30,4] | 65 [17,2] | 65 [17,2] |


*Part number for Back pressure, FC/PC Spools (A/B->T flow track smaller than P->A/B)*

| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **157B9548** | PVE | Yes | 25 [6.6] | 25 [6.6] | 25 [6.6] | 5 [1.3] |


### Flow/Pressure Control Spools—Throttled Open B to T in Neutral Position

All spools have pressure control on port A, flow control on port B and a dead band on 1,5 mm [0,06 in].

Schematic for PVBS without shuttle valve



Schematic for PVBS with shuttle valve



## PVBS Main Spools Part Numbers

*Part numbers for Symmetric FC/PC Control Spools*

| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **157B7150** | PVE | - | 10 [2,6] | 10 [2,6] | 10 [2,6] | 10 [2,6] |
| **157B7151** | PVE | - | 25 [6,6] | 25 [6,6] | 25 [6,6] | 25 [6,6] |
| **157B7152** | PVE | - | 40 [10,6] | 40 [10,6] | 40 [10,6] | 40 [10,6] |
| **157B7153** | PVE | - | 65 [17,2] | 65 [17,2] | 65 [17,2] | 65 [17,2] |
| **11122525** | PVE | Yes | 10 [2,6] | 10 [2,6] | 10 [2,6] | 10 [2,6] |
| **157B7562** | PVE | Yes | 40 [10,6] | 40 [10,6] | 40 [10,6] | 40 [10,6] |
| **157B7563** | PVE | Yes | 65 [17,2] | 65 [17,2] | 65 [17,2] | 65 [17,2] |

*Part numbers for Asymmetric FC/PC Control Spools*


| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **157B9198** | PVE | Yes | 10 [2.6] | 10 [2.6] | 40 [10.6] | 40 [10.6] |

## PVBS Main Spools Part Numbers


### Flow/Pressure Control Spools—Throttled Open A to T in Neutral Position

All spools have flow control on port A, pressure control on port B and a dead band on 1,5 mm [0,06 in].

Schematic for PVBS without shuttle valve



Schematic for PVBS with shuttle valve



*Part numbers for Symmetric Control Spools*

| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **157B7450** | PVE | - | 10 [2,6] | 10 [2,6] | 10 [2,6] | 10 [2,6] |
| **157B7451** | PVE | - | 25 [6,6] | 25 [6,6] | 25 [6,6] | 25 [6,6] |
| **157B7452** | PVE | - | 40 [10,6] | 40 [10,6] | 40 [10,6] | 40 [10,6] |
| **157B7453** | PVE | - | 65 [17,2] | 65 [17,2] | 65 [17,2] | 65 [17,2] |
| **157B7470** | PVE | Yes | 10 [2,6] | 10 [2,6] | 10 [2,6] | 10 [2,6] |
| **157B7471** | PVE | Yes | 25 [6,6] | 25 [6,6] | 25 [6,6] | 25 [6,6] |
| **157B7472** | PVE | Yes | 40 [10,6] | 40 [10,6] | 40 [10,6] | 40 [10,6] |
| **157B7473** | PVE | Yes | 65 [17,2] | 65 [17,2] | 65 [17,2] | 65 [17,2] |
| **157B9083** | PVH/PVHC | Yes | 65 [17,2] | 65 [17,2] | 65 [17,2] | 65 [17,2] |

*Part numbers for Asymmetric Control Spools*


| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **157B9660** | PVE | Yes | 40 [10.6] | 40 [10.6] | 25 [6.6] | 40 [10.6] |

## PVBS Main Spools Part Numbers


### Flow/Pressure Control Spools—Throttled Open B to T in Neutral Position

All spools have flow control on port A, pressure control on port B and a dead band on 1,5 mm [0,06 in].

Schematic for PVBS without shuttle valve



Schematic for PVBS with shuttle valve




*Part numbers for Asymmetric Control Spools*

| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **157B9591** | PVE | - | 40 [10,6] | 40 [10,6] | 25 [6,6] | 40 [10,6] |
| **157B9641** | PVE | - | 50 [13,2] | 50 [13,2] | 10 [2,6] | 10 [2,6] |
| **157B9660** | PVE | Yes | 50 [13,2] | 50 [13,2] | 10 [2,6] | 10 [2,6] |
| **157B9832** | PVE | Yes | 55 [14,5] | 55 [14,5] | 25 [6,6] | 25 [6,6] |

### Flow/Pressure Control Spools—Open/Closed in Neutral Position

All spools have flow control on port A, pressure control on port B and a dead band on 1,0 mm [0,04 in].

*Schematic for PVBS without shuttle valve*




*Part number for Back pressure FC/PC Spools (A/B->T flow track smaller than P->A/B)*

| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **11067514** | PVE | — | 40 [10.6] | 40 [10.6] | 25 [6.6] | 25 [6.6] |

### Flow/Pressure Control Spools—Closed A and Open/Closed B Position

*Schematic for PVBS with shuttle valve*




*Part numbers for Symmetric Flow Control Spools*

| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **11213570** | PVE | Yes | 40 [10.6] | 40 [10.6] | 40 [10.6] | 40 [10.6] |


## PVBS Main Spools Part Numbers

### Pressure Control Spools—Closed Neutral Position

Schematic for PVBS without shuttle valve



Schematic for PVBS with shuttle valve



*Part numbers for Symmetric PC Spools*

| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **157B7015** | PVE | - | 5 [1,3] | 5 [1,3] | 5 [1,3] | 5 [1,3] |
| **157B7010** | PVE | - | 10 [2,6] | 10 [2,6] | 10 [2,6] | 10 [2,6] |
| **157B9540** | PVE | - | 18 [4,8] | 18 [4,8] | 18 [4,8] | 18 [4,8] |
| **157B7011** | PVE | - | 25 [6,6] | 25 [6,6] | 25 [6,6] | 25 [6,6] |
| **157B7012** | PVE | - | 40 [10,6] | 40 [10,6] | 40 [10,6] | 40 [10,6] |
| **157B7013** | PVE | - | 65 [17,2] | 65 [17,2] | 65 [17,2] | 65 [17,2] |
| **157B7035** | PVE | Yes | 5 [1,3] | 5 [1,3] | 5 [1,3] | 5 [1,3] |
| **157B7030** | PVE | Yes | 10 [2,6] | 10 [2,6] | 10 [2,6] | 10 [2,6] |
| **11081829** | PVE | Yes | 18 [4,8] | 18 [4,8] | 18 [4,8] | 18 [4,8] |
| **157B7031** | PVE | Yes | 25 [6,6] | 25 [6,6] | 25 [6,6] | 25 [6,6] |
| **157B7032** | PVE | Yes | 40 [10,6] | 40 [10,6] | 40 [10,6] | 40 [10,6] |
| **157B7033** | PVE | Yes | 65 [17,2] | 65 [17,2] | 65 [17,2] | 65 [17,2] |
| **157B9683** | PVE | Yes | 100 [26,4] | 100 [26,4] | 100 [26,4] | 100 [26,4] |
| **157B9015** | PVH/PVHC | - | 5 [1,3] | 5 [1,3] | 5 [1,3] | 5 [1,3] |
| **157B9010** | PVH/PVHC | - | 10 [2,6] | 10 [2,6] | 10 [2,6] | 10 [2,6] |
| **157B9540** | PVH/PVHC | - | 18 [4,8] | 18 [4,8] | 18 [4,8] | 18 [4,8] |
| **157B9011** | PVH/PVHC | - | 25 [6,6] | 25 [6,6] | 25 [6,6] | 25 [6,6] |
| **157B9012** | PVH/PVHC | - | 40 [10,6] | 40 [10,6] | 40 [10,6] | 40 [10,6] |
| **157B9013** | PVH/PVHC | - | 65 [17,2] | 65 [17,2] | 65 [17,2] | 65 [17,2] |

*Back pressure PC Spools (A/B->T flow track smaller than P->A/B)*


| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **11177945** | PVE | - | 40 [10,6] | 65 [17,2] | 65 [17,2] | 65 [17,2] |

## PVBS Main Spools Part Numbers


### Pressure Control Spools—Throttled Open Neutral Position

All spools have pressure control on port A and B and a dead band on 1,5 mm [0,06 in].

Schematic for PVBS without shuttle valve



Schematic for PVBS with shuttle valve



*Part numbers for Symmetric Flow Control Spools*

| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **157B7115** | PVE | - | 5 [1,3] | 5 [1,3] | 5 [1,3] | 5 [1,3] |
| **157B7110** | PVE | - | 10 [2,6] | 10 [2,6] | 10 [2,6] | 10 [2,6] |
| **157B7111** | PVE | - | 25 [6,6] | 25 [6,6] | 25 [6,6] | 25 [6,6] |
| **157B7112** | PVE | - | 40 [10,6] | 40 [10,6] | 40 [10,6] | 40 [10,6] |
| **157B7113** | PVE | - | 65 [17,2] | 65 [17,2] | 65 [17,2] | 65 [17,2] |
| **157B9853** | PVE | Yes | 3 [0,8] | 3 [0,8] | 3 [0,8] | 3 [0,8] |
| **157B7135** | PVE | Yes | 5 [1,3] | 5 [1,3] | 5 [1,3] | 5 [1,3] |
| **157B7130** | PVE | Yes | 10 [2,6] | 10 [2,6] | 10 [2,6] | 10 [2,6] |
| **157B7131** | PVE | Yes | 25 [6,6] | 25 [6,6] | 25 [6,6] | 25 [6,6] |
| **157B7132** | PVE | Yes | 40 [10,6] | 40 [10,6] | 40 [10,6] | 40 [10,6] |
| **157B7133** | PVE | Yes | 65 [17,2] | 65 [17,2] | 65 [17,2] | 65 [17,2] |
| **157B7134** | PVE | Yes | 100 [26,4] | 100 [26,4] | 100 [26,4] | 100 [26,4] |
| **11057575** | PVH/PVHC | - | 5 [1,3] | 5 [1,3] | 5 [1,3] | 5 [1,3] |
| **157B9110** | PVH/PVHC | - | 10 [2,6] | 10 [2,6] | 10 [2,6] | 10 [2,6] |
| **157B9112** | PVH/PVHC | - | 40 [10,6] | 40 [10,6] | 40 [10,6] | 40 [10,6] |
| **157B9113** | PVH/PVHC | - | 65 [17,2] | 65 [17,2] | 65 [17,2] | 65 [17,2] |
| **11057314** | PVH/PVHC | Yes | 5 [1,3] | 5 [1,3] | 5 [1,3] | 5 [1,3] |
| **157B9130** | PVH/PVHC | Yes | 10 [2,6] | 10 [2,6] | 10 [2,6] | 10 [2,6] |
| **157B9131** | PVH/PVHC | Yes | 25 [6,6] | 25 [6,6] | 25 [6,6] | 25 [6,6] |


*Part numbers for Asymmetric Flow Control Spools*

| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **157B9525** | PVE | - | 20 [5,3] | 20 [5,3] | 10 [2,6] | 10 [2,6] |
| **11041330** | PVE | - | 40 [10,6] | 40 [10,6] | 20 [5,3] | 20 [5,3] |
| **157B9634** | PVH/PVHC | Yes | 10 [2,6] | 10 [2,6] | 5 [1,3] | 5 [1,3] |

## PVBS Main Spools Part Numbers

### Pressure Control Spools—Throttled A to T in Neutral Position

*Schematic for PVBS with shuttle valve*



*Part numbers for PC Spools Throttled A to T in Neutral Position*


| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **157B9646** | PVE | Yes | 15 [4] | 15 [4] | 15 [4] | 15 [4] |
| **157B9199** | PVE | Yes | 10 [2.6] | 10 [2.6] | 40 [10.6] | 40 [10.6] |

## PVBS Main Spools Part Numbers


### Pressure/Flow Control Spools—Closed Neutral Position

All spools have pressure control on port A, flow control on port B and a dead band on 1,5 mm [0,06 in].

Schematic for PVBS without shuttle valve



Schematic for PVBS with shuttle valve



*Part numbers for Symmetric PC/FC Spools*

| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **157B7040** | PVE | - | 10 [2,6] | 10 [2,6] | 10 [2,6] | 10 [2,6] |
| **157B7041** | PVE | - | 25 [6,6] | 25 [6,6] | 25 [6,6] | 25 [6,6] |
| **157B7042** | PVE | - | 40 [10,6] | 40 [10,6] | 40 [10,6] | 40 [10,6] |
| **157B7043** | PVE | - | 65 [17,2] | 65 [17,2] | 65 [17,2] | 65 [17,2] |
| **157B7044** | PVE | - | 100 [26,4] | 100 [26,4] | 100 [26,4] | 100 [26,4] |
| **157B7061** | PVE | Yes | 25 [6,6] | 25 [6,6] | 25 [6,6] | 25 [6,6] |
| **157B7062** | PVE | Yes | 40 [10,6] | 40 [10,6] | 40 [10,6] | 40 [10,6] |
| **157B7063** | PVE | Yes | 65 [17,2] | 65 [17,2] | 65 [17,2] | 65 [17,2] |
| **157B7064** | PVE | Yes | 100 [26,4] | 100 [26,4] | 100 [26,4] | 100 [26,4] |
| **157B9040** | PVH/PVHC | - | 10 [2,6] | 10 [2,6] | 10 [2,6] | 10 [2,6] |
| **157B9041** | PVH/PVHC | - | 25 [6,6] | 25 [6,6] | 25 [6,6] | 25 [6,6] |
| **157B9042** | PVH/PVHC | - | 40 [10,6] | 40 [10,6] | 40 [10,6] | 40 [10,6] |
| **157B9043** | PVH/PVHC | - | 65 [17,2] | 65 [17,2] | 65 [17,2] | 65 [17,2] |
| **157B9044** | PVH/PVHC | - | 100 [26,4] | 100 [26,4] | 100 [26,4] | 100 [26,4] |
| **157B9062** | PVH/PVHC | Yes | 40 [10,6] | 40 [10,6] | 40 [10,6] | 40 [10,6] |
| **157B9063** | PVH/PVHC | Yes | 65 [17,2] | 65 [17,2] | 65 [17,2] | 65 [17,2] |

*Part numbers for Asymmetric PC/FC Spools*

| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| 157B9589 | PVE | Yes | 25 [6.6] | 25 [6.6] | 40 [10,6] | 40 [10,6] |
| 157B9528 | PVE | Yes | 65 [17,2] | 40 [10,6] | 65 [17,2] | 65 [17,2] |
| 11223873 | PVE | Yes | 65 [17,2] | 40 [10,6] | 65 [17,2] | 40 [10,6] |

*Back pressure PC/FC Spools (A/B->T flow track smaller than P->A/B)*


| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| 157B9532 | PVE | Yes | 25 [6,6] | 65 [17,2] | 25 [6,6] | 10 [2,6] |
| 11051179 | PVE | Yes | 25 [6,6] | 10 [2,6] | 25 [6,6] | 5 [1,3] |
| 157B9535 | PVE | Yes | 40 [10,6] | 10 [2,6] | 40 [10,6] | 25 [6,6] |
| 11051177 | PVE | Yes | 25 [6,6] | 25 [6,6] | 40 [10,6] | 10 [2,6] |

## PVBS Main Spools Part Numbers

### Pressure/Flow Control Spools—Closed Neutral Position with B-float

All spools have pressure control on port A, flow control on port B and a dead band on 1,5 mm [0,06 in].

*Schematic for PVBS without shuttle valve*




*Part number for Symmetric PC/FC Spools*

| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **157B9637** | PVE | — | 10 [2.6] | 10 [2.6] | 10 [2.6] | 10 [2.6] |


### Pressure/Flow Control Spools—Throttled Open Neutral Position

All spools have pressure control on port A, flow control on port B and a dead band on 1,5 mm [0,06 in].

Schematic for PVBS without shuttle valve



Schematic for PVBS with shuttle valve



*Part numbers for Symmetric PC/FC Control Spools*


| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **11122564** | PVE | - | 10 [2,6] | 10 [2,6] | 10 [2,6] | 10 [2,6] |
| **157B7141** | PVE | - | 25 [6,6] | 25 [6,6] | 25 [6,6] | 25 [6,6] |
| **157B7142** | PVE | - | 40 [10,6] | 40 [10,6] | 40 [10,6] | 40 [10,6] |
| **157B7143** | PVE | - | 65 [17,2] | 65 [17,2] | 65 [17,2] | 65 [17,2] |
| **157B7144** | PVE | - | 100 [26,4] | 100 [26,4] | 100 [26,4] | 100 [26,4] |
| **157B7161** | PVE | Yes | 25 [6,6] | 25 [6,6] | 25 [6,6] | 25 [6,6] |
| **157B7162** | PVE | Yes | 40 [10,6] | 40 [10,6] | 40 [10,6] | 40 [10,6] |
| **157B7163** | PVE | Yes | 65 [17,2] | 65 [17,2] | 65 [17,2] | 65 [17,2] |
| **157B7164** | PVE | Yes | 100 [26,4] | 100 [26,4] | 100 [26,4] | 100 [26,4] |
| **157B9163** | PVH/PVHC | Yes | 65 [17,2] | 65 [17,2] | 65 [17,2] | 65 [17,2] |

*Part numbers for Asymmetric PC/FC Control Spools*

| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **157B9811** | PVE | Yes | 10 [2,6] | 10 [2,6] | 40 [10,6] | 65 [17,2] |
| **157B9988** | PVE | Yes | 25 [6,6] | 10 [2,6] | 25 [6,6] | 25 [6,6] |

### Pressure/Flow Control Spools—Open/Closed Neutral Position

*Schematic for PVBS without shuttle valve*




## PVBS Main Spools Part Numbers

*Part number for PC/FC Spool Open/Closed in Neutral Position*

| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **11104931** | PVE | — | 40 [10.6] | 40 [10.6] | 40 [10.6] | 40 [10.6] |

### Pressure/Flow Control Spools—Open/Closed A and Closed B Position

*Schematic for PVBS with shuttle valve*




*Part numbers for Symmetric Flow Control Spools*

| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **11213571** | PVE | Yes | 40 [10.6] | 40 [10.6] | 40 [10.6] | 40 [10.6] |
| **11198095** | PVE | Yes | 65 [17.2] | 65 [17.2] | 65 [17.2] | 65 [17.2] |


## PVBS for PVBZ Main Spools Part Numbers

### PVBZ Flow Control Spools—Closed Neutral Position

Schematic for PVBZ without shuttle valve



Schematic for PVBZ with shuttle valve



*Part numbers for Symmetric Flow Control Spools*

| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **157B9405** | PVE | - | 5 [1,3] | 5 [1,3] | 5 [1,3] | 5 [1,3] |
| **157B9400** | PVE | - | 10 [2,6] | 10 [2,6] | 10 [2,6] | 10 [2,6] |
| **157B9401** | PVE | - | 25 [6,6] | 25 [6,6] | 25 [6,6] | 25 [6,6] |
| **157B9402** | PVE | - | 40 [10,6] | 40 [10,6] | 40 [10,6] | 40 [10,6] |
| **157B9403** | PVE | - | 65 [17,2] | 65 [17,2] | 65 [17,2] | 65 [17,2] |
| **157B9404** | PVE | - | 100 [26,4] | 100 [26,4] | 100 [26,4] | 100 [26,4] |
| **11051945** | PVE | Yes | 5 [1,3] | 5 [1,3] | 5 [1,3] | 5 [1,3] |
| **11019630** | PVE | Yes | 10 [2,6] | 10 [2,6] | 10 [2,6] | 10 [2,6] |
| **11019631** | PVE | Yes | 25 [6,6] | 25 [6,6] | 25 [6,6] | 25 [6,6] |
| **11019633** | PVE | Yes | 40 [10,6] | 40 [10,6] | 40 [10,6] | 40 [10,6] |
| **11019634** | PVE | Yes | 65 [17,2] | 65 [17,2] | 65 [17,2] | 65 [17,2] |
| **11019635** | PVE | Yes | 100 [26,4] | 100 [26,4] | 100 [26,4] | 100 [26,4] |
| **11105665** | PVH/PVHC | - | 5 [1,3] | 5 [1,3] | 5 [1,3] | 5 [1,3] |
| **11105445** | PVH/PVHC | - | 10 [2,6] | 10 [2,6] | 10 [2,6] | 10 [2,6] |
| **11105446** | PVH/PVHC | - | 25 [6,6] | 25 [6,6] | 25 [6,6] | 25 [6,6] |
| **11125900** | PVH/PVHC | - | 100 [26,4] | 100 [26,4] | 100 [26,4] | 100 [26,4] |
| **11140563** | PVH/PVHC | Yes | 25 [6,6] | 25 [6,6] | 25 [6,6] | 25 [6,6] |
| **11140564** | PVH/PVHC | Yes | 65 [17,2] | 65 [17,2] | 65 [17,2] | 65 [17,2] |


*Part numbers for Back pressure Flow Control Spools (A/B->T flow track smaller than P->A/B)*

| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **157B9573*** | PVH/PVHC | - | 38 [10,0] | 25 [6,6] | 65 [17,2] | 15 [4,0] |
| **157B9651** | PVE | - | 38 [10,0] | 25 [6,6] | 65 [17,2] | 15 [4,0] |
| **11084227** | PVE | Yes | 5 [1,3] | 25 [6,6] | 25 [6,6] | 25 [6,6] |
| **11129527** | PVE | Yes | 40 [10,6] | 10 [2,6] | 40 [10,6] | 10 [2,6] |
| **11085297** | PVE | Yes | 20 [5,2] | 40 [10,6] | 40 [10,6] | 10 [2,6] |

* Deadband 1,5 mm [0,06].

### PVBZ Flow Control Spools—Closed Neutral Position with A-float

*Schematic for PVBZ with shuttle valve*



## PVBS for PVBZ Main Spools Part Numbers

*Part numbers for Symmetric Flow Control Spools*

| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **157B9415** | PVE | Yes | 5 [1,3] | 5 [1,3] | 5 [1,3] | 5 [1,3] |
| **157B9410** | PVE | Yes | 10 [2,6] | 10 [2,6] | 10 [2,6] | 10 [2,6] |
| **157B9411** | PVE | Yes | 25 [6,6] | 25 [6,6] | 25 [6,6] | 25 [6,6] |
| **157B9412** | PVE | Yes | 40 [10,6] | 40 [10,6] | 40 [10,6] | 40 [10,6] |
| **157B9413** | PVE | Yes | 65 [17,2] | 65 [17,2] | 65 [17,2] | 65 [17,2] |
| **157B9414** | PVE | Yes | 100 [26,4] | 100 [26,4] | 100 [26,4] | 100 [26,4] |
| **11027130** | PVH/PVHC | Yes | 25 [6,6] | 25 [6,6] | 25 [6,6] | 25 [6,6] |
| **11124250** | PVH/PVHC | Yes | 100 [26,4] | 100 [26,4] | 100 [26,4] | 100 [26,4] |

*Part numbers for Back pressure Flow Control Spools (A/B->T flow track smaller than P->A/B)*

| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **11085128** | PVE | Yes | 2 [0,5] | 10 [2,6] | 10 [2,6] | 5 [1,3] |


*Part number Flow Control Spools for PVML*

| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **11128843** | PVE | Yes | 40 [10,6] | 40 [10,6] | 40 [10,6] | 40 [10,6] |
| **157B9596** | PVE | Yes | 100 [26,4] | 100 [26,4] | 100 [26,4] | 100 [26,4] |
| **157B9631** | PVE | Yes | 100 [26,4] | 100 [26,4] | 100 [26,4] | 100 [26,4] |
| **11017592** | PVE | Yes | 120 [31,7] | 120 [31,7] | 120 [31,7] | 120 [31,7] |
| **157B9434**[1)] | PVE | Yes | 120 [31,7] | 120 [31,7] | 120 [31,7] | 120 [31,7] |

[1)] Dead band 0,8 mm [0,03 in].

## PVBZ Flow Control Spools—Closed Neutral Position with B-float

*Schematic for PVBZ with shuttle valve*



*Part numbers for Symmetric Flow Control Spools*

| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| 11147069 | PVE | Yes | 100 [26.4] | 100 [26.4] | 100 [26.4] | 100 [26.4] |


*Part number Flow Control Spools for PVML*

| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| 11146502 | PVE | Yes | 100 [26.4] | 100 [26.4] | 100 [26.4] | 100 [26.4] |

## PVBS for PVBZ Main Spools Part Numbers

### PVBZ Flow Control Spools—Throttled Open Neutral Position with B-float

*Schematic for PVBZ with shuttle valve*



*Part number for Symmetric Flow Control Spools*

| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **157B9690** | PVE | Yes | 15 [4] | 15 [4] | 15 [4] | 15 [4] |


*Part number Flow Control Spools for PVML*

| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **11146502** | PVE | Yes | 100 [26.4] | 100 [26.4] | 100 [26.4] | 100 [26.4] |


## PVBS for PVBZ Main Spools Part Numbers

### PVBZ Linear Flow Control Spools—Closed Neutral Position

Schematic for PVBZ without shuttle valve



Schematic for PVBZ with shuttle valve



*Part numbers for Symmetric Flow Control Spools*

| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| **157B9664** | PVE | - | 25 [6,6] | 25 [6,6] | 25 [6,6] | 25 [6,6] |
| **157B9809** | PVE | - | 80 [21,1] | 80 [21,1] | 80 [21,1] | 80 [21,1] |

*Part numbers for Asymmetric Flow Control Spools*


| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| 11130939 | PVE | Yes | 25 [6,6] | 40 [10,6] | 40 [10,6] | 25 [6,6] |

*Part numbers for Flow Control Spools for PVML*

| Part Number | Actuation | PVB with shuttle valve | Flow - l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| 157B9866 | PVE | Yes | 25 [6,6] | 40 [10,6] | 40 [10,6] | 25 [6,6] |

### PVBZ Single Acting Cylinder Flow Control Spools—Closed Neutral A-port Position

*Schematic for PVBS without shuttle valve*




*Symmetric flow control spools*

| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| 157B9859 | PVE | - | 25 [6.6] | 25 [6.6] | - | - |

## PVBS for PVBZ Main Spools Part Numbers

### PVBZ Single Acting Cylinder Flow Control Spools—Closed Neutral B-port Position

*Schematic for PVBS without shuttle valve*




*Symmetric flow control spools*

| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| 11149444 | PVE | - | - | - | 140 [37] | 140 [37] |

### PVBZ Single Acting Cylinder Linear Flow Control Spools—Closed Neutral B-port Position

*Schematic for PVBS without shuttle valve*




*Symmetric flow control spools*

| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| 157B9859 | PVE | - | 25 [6.6] | 25 [6.6] | - | - |

### PVBZ–HS Single Acting Cylinder Flow Control Spools—Closed Neutral Position

*Schematic for PVBS with or without shuttle valve*



*Back pressure Flow Control Spools (B->T flow track smaller than P->B)*

| Part Number | Actuation | PVB with shuttle valve | Flow – l/min [US gal/min] | | | |
|---|---|---|---|---|---|---|
| | | | A → T | P → A | P → B | B → T |
| 157B9912 | PVE | Yes | - | - | 40 [10,6] | 25 [6,6] |
| 11098878 | PVE | Yes | - | - | 100 [26,4] | 65 [17,2] |

## PVDI Directional Indicator

The PVDI Directional Indicator offers an independent electrical direction feedback and monitoring on the spool position relative neutral for a redundant feedback to the system controller. It can be used in combination with manual (PVM), hydraulic (PVH) and electrical (PVE) controls.

**The PVDI features:**

- Redundant spool movement detection
- Fits with PVBS 1.5 mm [0.059 in]
- Electrical feedback can supply a relay


The PVDI can not be used with PVMF or PVMR and must be shielded.

*PVDI Directional Indicator module*



Weight: 0.6 kg [1.32 lb]

*PVDI Directional Indicator dimensions*




*Technical specifications*

| | |
|---|---|
| **Voltage** | 12 V – 24 V (min.10 V / max. 38 V) |
| **Current consumption** | 10 mA – 100 mA |
| **Maximum current draw on pins** | 5 A |
| **Switch position** | ± 0.7 mm (+0.3/-0.2) [± 0.028 in (±0.01)] |
| **Connector type** | 1x4 DIN |
| **Grade of enclosure** | IP 65 |

According to the standard IEC 60529 Edition 2.2 2013-08, protection in the form of screening is recommended.

*Part numbers for PVDI*

| Part number | Description |
|---|---|
| **157B0101** | PVDI type, PVE cover. |
| **157B0102** | |
| **157B0103** | |
| **157B0104** | PVDI-H; PVH cover; Must be used with an intermediate plate. |
| **157B0105** | PVDI type with two NO switches; PVE cover. |

## PVG 32 Actuation

PVG 32 actuation can be done manually, hydraulically, electro-hydraulically and electrically.

PVG 32 actuation overview:


- *PVM Manual Actuation* on page 131
  - *PVML, Spring Centering Cover* on page 134
  - *PVMD/F/R Detention Covers* on page 133
- *PVH Hydraulic Actuation* on page 135
- *PVHC Electro-Hydraulic Actuation* on page 136
- *PVE Electro-hydraulic Actuation* on page 138
- *PVE Series 4* on page 140
  - *PVEP* on page 140
- *PVE Series 5* on page 144
  - *PVED-CC Series 5* on page 144
- *PVE Series 7* on page 149
  - *PVEO* on page 149
  - *PVEO-HP* on page 154
  - *PVEM* on page 158
  - *PVEA* on page 162
  - *PVEH* on page 166
  - *PVES* on page 170

## PVG 32 Actuation

### PVM Manual Actuation


The PVM manual actuation cover is intended for use on any work section where the operator has to have the ability to interact with the spool manually.

The PVM variants are based on a generic platform with a selection of additional features, enabling you to tailor the PVM to suit the demands of any hydraulic system, which includes the following main variants:


- PVM manual actuation or override of a function
- Spring centering cover without manual override (PVML)
  - Optional with lever base
  - Optional with lever base and lever
  - Optional flow adjustment screws

The adjustment screws are intended for limiting the spool travel and thereby the maximum achievable flow.

*PVM cover*



*PVM dimensions*




*Control lever data*

| No lever position | Standard control range | Control lever range | Control lever range + float position |
|---|---|---|---|
| 2 x 6 | ± 13.4° | ± 19.5° | 22.3° |

*PVM versions torque data*

| Spool displacement | PVM+PVMD<br>PVM+PVE | PVM+PVH | PVM+PVMR | PVM+PVMF |
|---|---|---|---|---|
| From neutral position | 2.2 ±0.2 N•m<br>[19.5 ±1.8 lb•in] | 2.5 ±0.2 N•m<br>[22.1 ± 1.8 lb•in] | 17 N•m [3.8 lb•in] | 22 N•m [5.0 lb•in] |
| Max. spool travel | 2.8 ±0.2 N•m<br>[24.8 ±1.8 lb•in] | 6.9 ±0.2 N•m<br>[61.0 ±1.8 lb•in] | – | – |
| Into float position | – | – | – | 60 N•m<br>[13.5 lb•in] |

## PVG 32 Actuation

*PVM versions torque data (continued)*

| Spool displacement | PVM+PVMD<br>PVM+PVE | PVM+PVH | PVM+PVMR | PVM+PVMF |
|---|---|---|---|---|
| Away from float position | – | – | – | 28 N•m [6.3 lb•in] |
| From any other position | – | – | 8.5 N•m [73.3 lb•in] | – |

| Part number | Material | Adjustment screws | Lever base | Lever base and lever | Weight |
|---|---|---|---|---|---|
| **157B3161** | Cast iron | Yes | — | Yes | 0,4 kg [0,88 lb] |
| **157B3171** | Aluminum | Yes | — | Yes | |
| **157B3173** | Aluminum | Yes | — | — | |
| **157B3174** | Aluminum | Yes | Yes | — | |
| **157B3184** | Anodized aluminum | Yes | — | Yes | |
| **157B3186** | Anodized aluminum | Yes | — | — | |
| **157B3191** | Aluminum | — | — | Yes | |
| **157B3193** | Aluminum | — | — | — | |
| **157B3194** | Aluminum | — | Yes | — | |


### PVM functionality

The PVMF is available in standard or optional mount. The friction detent allows the directional spool to be held in any position, resulting in infinitely variable, reversible, pressure compensated flow.

This can be sustained indefinitely without having to continue to hold the mechanical lever. Friction detent spool position may be affected by high differential actuator flow forces and system vibration resulting in work function flow reduction.

**PVMF standard mount**


*P → A → F (Push–in)*



157-205.10

**PVMF optional mount**


*P → A → F (Pull–out)*



157-206.10

**PVMR**

*Friction detent*



## PVG 32 Actuation


### PVMD/F/R Detention Covers

The PVMD/F/R covers, also referred to as detention covers, are intended for manually activated PVB sections.


The generic PVMD/F/R cover platform includes the following main variants:

- **PVMD** detention cover
- **PVMF** mechanical float position cover
- **PVMR** friction cover


*PVMD symbol*




*PVMF symbol*





*PVMR symbol*




*PVMD detention cover*




*Dimensions, mm [in]*




*PVMF/R Cover*



*Dimensions, mm [in]*




### Part Numbers for PVMD/F/R Covers

| Part number | Type | Material | Weight |
|---|---|---|---|
| **157B0001** | PVMD | Aluminum | 0,15 – 0,38 kg [0.33 – 0.84 lb] |
| **157B0009** | | Anodized aluminum | |
| **157B0021** | | Cast iron | |
| **157B0005** | PVMF | Aluminum | 0,34 – 0,57 kg [0.75 – 1.26 lb] |
| **157B0004** | PVMR | Aluminum | |
| **157B0012** | | Anodized aluminum | |
| **157B0024** | | Cast iron | |

## PVG 32 Actuation

### PVML, Spring Centering Cover

The PVML spring centering cover is intended for use on any work section where the operator is not allowed to have a possibility to interact with the spool manually.

The adjustment screws are intended for limiting the spool travel and thereby the maximum achievable flow.

*Part numbers for PVML*

| Part number | Material | Adjustment screws |
|---|---|---|
| **157B3202** | Aluminum | – |
| **157B3203** | | Yes (single direction) |

## PVG 32 Actuation


### PVH Hydraulic Actuation

The PVH hydraulic actuation is intended for use on any work section where the operator wants to have a possibility to interact with the main spool via a hydraulic joystick. The spool spring package must match with this activation method.

*PVH cover*



*PVH 32 cover dimensions*




The hydraulic remote control lever should be connected directly to the tank.

*Technical data*

| | |
|---|---|
| **Main spool spring control pressure range** | 5 – 15 bar [73 – 218 psi] |
| **Operating torque from neutral** | 2.5 ±0.2 N•m [22.1±1.8 lb•in] |
| **Operating torque max spool position** | 6.9 ±0.2 N•m [61.0±1.8 lb•in] |
| **Maximum pilot oil pressure** | 30 bar [435 psi] |

*Part numbers for PVH Hydraulic Actuation*

| Part number | Material | Connection | Weight |
|---|---|---|---|
| **157B0007** | Aluminum | 9/16-18 UNF | 0.2 – 0.75 kg [0.44 – 1.65 lb] |
| **157B0008** | | G1/4" | |
| **157B0010** | Anodized aluminum | 9/16-18 UNF | |
| **157B0011** | | G1/4" | |
| **157B0014** | Cast iron | 9/16-18 UNF | |
| **157B0016** | | G1/4" | |


## PVG 32 Actuation

### PVHC Electro-Hydraulic Actuation


The PVHC is an electrical actuator module for main spool control. The PVHC control is done by dual Pulse Width Modulated, high current supply 100-400 Hz PWM control signals. The spool position will shift when conditions are changed such as temperature change.

Inlet with Hydraulic Pilot Pressure is needed.

*PVHC, Electro-Hydraulic Actuator*




*PVHC dimensions*




Weight: 0,93 kg [2.05 lb]


*PVHC schematic*



Dither frequency with a certain amplitude is needed for optimal application performance.

## PVG 32 Actuation

*PVHC spool stroke vs current characteristics*




The hysteresis is affected by viscosity, friction, flow forces, dither frequency and modulation frequency.

*Technical data*

| **Supply Voltage $U_{DC}$** | **12 $V_{DC}$** | **24 $V_{DC}$** |
|---|---|---|
| Current input | 0 – 1500 mA | 0 – 750 mA |
| Resistance | 4.75 Ω ± 5 % | 20.8 Ω ± 5 % |
| Response time | 150 to 200 ms | |
| PWM frequency | 100 to 400 Hz | |
| Pilot oil pressure range | 20 – 25 bar [290 – 362 psi] | |
| Ambient temperature range | -30°C to 80°C [-22 °F to 176°F] | |
| Temperature range | -20°C to 80°C [-4 °F to 176°F] | |
| Fluid cleanliness | 23/19/16 (according to ISO 4406) | |

*Part numbers for PVHC Actuators*

| **Part number** | **Power supply** | **Connector type** | **Protection Class** |
|---|---|---|---|
| 11112037 | 12V | AMP | IP 66 |
| 11112036 | 24V | | |
| 11112038 | 12V | 2x2 DEUTSCH | IP 67 |
| 11112039 | 24V | | |

## PVE Electro-hydraulic Actuation


The analog PVE Series 4, 5 and 7 are electro-hydraulic actuators used to control a single work section of a PVG proportional valve group. The PVE actuator program for PVG 32 includes variants with different performance levels and features.

The actuator positions the main spool in a PVG work section to control either the flow or the pressure of the oil distributed to and from the work function. The control signal to the actuator is an analog voltage signal, enabling the user to operate the work function remotely by means of a joystick, a controller or the similar.

The electro-hydraulic solenoid valve bridge of the actuator is available in different designs utilizing different regulation principles, depending on performance variant. The actuator positions the main spool by distributing pilot oil pressure to either side of it, pressurizing one side by pilot pressure while relieving the opposite side to tank and vice versa. All proportional actuators feature a closed- loop spool control and continuous fault monitoring.


The different hydraulic principles combined with the different solenoid valve regulation principles determine whether the actuator controls the spool proportionally according to a demand signal or ON/OFF according to a voltage signal. The voltage control characteristic of the PVE actuators is shown in the figure below on the left side.

*PVG 32 with PVEO/PVEM (PVEO without LVDT)*



### PVE Electro-hydraulic Actuation

*PVG 32 with PVEH/PVES*



## PVE Electro-hydraulic Actuation

### PVE Series 4


#### PVEP

The PVEP actuator is a proportional control actuator with closed-loop spool control primarily used to control work functions with very high performance requirements.

*PVEP*




*PVEP schematic*



## PVE Electro-hydraulic Actuation

*PVEP functionality*





The PVEP functionality includes an electric circuit with a closed-loop logic. An embedded micro-controller processes the signal voltage and the LVDT feedback signal and regulates the solenoid valves accordingly. Features such as active or passive fault monitoring, LED indicating fault state and error output pin are all default PVEP features.

Controlling a PVEP requires two PWM signals. The basic concept between a controller and the PVEP is shown in the picture below. Current control is not possible with PVEP.

It is important that the Power supply ($V_{bat}$) is connected before the PWM signal. PWM signals are low power voltage signals; hence no current drivers are needed. The PVEP performs a true time difference measurement on the PWM input, thus there is no filtering or conversion involved

*PVEP dimensions*



## PVE Electro-hydraulic Actuation

Weight: 0.9 kg [1.98 lbs]

All connector terminals are short-circuit protected, protected against reverse connection and their combinations. Connecting error pins from two or more PVE's will cause the surveillance system to malfunction.

### PVEP Technical Data

*Pilot pressure*

| Minimum | Nominal | Maximum |
|---|---|---|
| 10.0 bar [145 psi] | 13.5 bar [196 psi] | 15.0 bar [218 psi] |

*Fluid consumption*

| Neutral | Locked position | Actuating |
|---|---|---|
| 0.03 l/min<br>[0.106 US gal/min] | 0.01 l/min<br>[0.026 US gal/min] | 0.8 l/min<br>[0.21 US gal/min] |

*Fluid temperature*

| Minimum | Recommended | Maximum | Ambient Recommended |
|---|---|---|---|
| -30°C [-22°F] | 30 to 60°C [86 to 140°F] | 90° [194°F] | -30 to 60°C [-22 to 140°F] |

*Fluid viscosity*

| | |
|---|---|
| **Operating range** | 12 to 75 $mm^2/s$ [65 to 347 SUS] |
| **Minimum** | 4 $mm^2/s$ [39 SUS] |
| **Maximum** | 460 $mm^2/s$ [2128 SUS] |
| **Cleanliness** | 18/16/13 (according to ISO 4406) |

*Control Electric Specification*

| | | |
|---|---|---|
| **Supply voltage** $U_{DC}$ | range | 11 → 32 V |
| | max. ripple | 5% |
| | over voltage (max. 5 min) | 36 V |
| **PWM control range** (duty cycle) | | 10 → 80% |
| **PWM frequency** | | 100 → 1000 Hz |
| **PWM input voltage swing** | | 0 → $U_{DC}$ |
| **PWM Trigger point** | | 70% of $U_{DC}$ |
| **Input impedance** (standard pull down) | | 5 kΩ |
| **Input capacitor** | | --- |
| **Power consumption** | | 7 W |
| **Error voltage** | Fault | $U_{DC}$ |
| | No Fault | < 2 V |

*LED Characteristic*

| Color | LED Characteristic | Description |
|---|---|---|
| Green constant |  | No error – Actuating |
| Green flashing @ 1.5 Hz |  | Neutral – Power save |

## PVE Electro-hydraulic Actuation

*LED Characteristic (continued)*

| Color | LED Characteristic | Description |
|---|---|---|
| Red constant |  | Internal error |
| Red flashing @ 1.5 Hz |  | External or Float error |
| Yellow |  | Disable mode |

*PVEP 6-pin Connector*

| Pinout | Pin 1 | Pin 2 | Pin 3 | Pin 4 | Pin 5 | Pin 6 |
|---|---|---|---|---|---|---|
| 1x6 DEUTSCH | PWM_A | Error | PWM_B | - | GND | $U_{DC}$ |

*Part number for PVEP*

| Part number | Connector | IP | Fault Monitoring |
|---|---|---|---|
| **11034832** | 1x6 DEUTSCH | IP 67 | Active |

## PVE Electro-hydraulic Actuation

### PVE Series 5

#### PVED-CC Series 5


The PVED-CC Series 5 is a high performance digital actuator for the PVG 32 and PVG 100 valves, which can use two different protocols: CANopen and ISObus/J1939.

The PVED-CC Series 5 offers CAN bus control through loop cables simplifying the wire harness and build-in intelligence, where actuator specific features tailor the actuator behavior to the exact function need.


*PVED-CC Series 5*



*PVED-CC S5 schematic*



*PVED-CC Series 5 dimensions*




For more information, see *PVED-CC Series 5 CANopen Technical Information*, **BC00000354**.

For more information, see *PVED-CC Series 5 ISObus Technical Information*, **BC00000361**.

## PVE Electro-hydraulic Actuation

### Operating data overview

*Electrical data*

| Voltage | | 12 $V_{DC}$ | 24 $V_{DC}$ |
|---|---|---|---|
| **Current consumption** | **Operating** | 520 mA | 260 mA |
| | **Neutral - Power state** | 80 mA | 45 mA |
| **Energy consumption** | **Operating** | 6.24 W | 6.24 W |
| | **Neutral - Power state** | 1 W | 1.1 W |
| **Supply voltage ($V_{bat}$)** | **Nominal** | 11 – 32 $V_{DC}$ | |
| | **Range** | 9 – 35.9 $V_{DC}$ | |
| | **Maximum ripple** | 5% | |
| **CAN bus** | Alive | 5.5 – 36 $V_{DC}$* | |

* PVED communicating on CAN bus, but not fully operable.

*Temperature range*

| | | Min. | Max. |
|---|---|---|---|
| **Temperature** | **Ambient** | –40°C | 90°C |
| | **Oil** | | |
| | **Storage** | | 110°C |

*Hydraulic data*

| Pilot pressure | | 13.5 ± 1.5 bar |
|---|---|---|
| **Tank pressure** | **Continues** | 25 bar |
| | **Intermittent** | 40 bar |
| **Oil consumption** | **Electrical de-energized** | 0 l/min |
| | **Spool locked position** | |
| | **Continuous changing spool position** | 0.7 l/min |
| **Contamination** | (ISO 4406) | 23/19/16 |
| **Viscosity range** | **Nominal** | 12 – 75 $mm^2/s$ |
| | **Minimum** | 4.2 – 12 $mm^2/s$* |
| | **Maximum** | 75 – 1000 $mm^2/s$ |

* PVED have reduced operating performance

*Government regulations*

| Description | Standard |
|---|---|
| **Low Voltage** | 2006/95/EC |
| **EMC Directive** | 2004/108/EC |
| **Safety** | ISO4413:2010 |


## PVE Electro-hydraulic Actuation

### Connectors

Available 2x4 pin connectors: AMP Junior Power Timer andDEUTSCH DT06-4S-E003. Pins are internally connected in pairs between connectors. Mating connectors are not supplied by Danfoss.

#### *AMP connector*

*AMP Junior Power Timer (2x4 pin)*





*Pinout:*
**1.** CAN Low
**2.** Vbat+
**3.** GND
**4.** CAN High

| Terminal | Seal | Housing | IP rating |
|---|---|---|---|
| 929930-1<br>(4 pcs) | 828901-1<br>(4 pcs) | 2-967059-1 (gray) or<br>1-967059-1 (black)<br>* | IP66 |

* There is no black/gray coding of the connector

#### *DEUTSCH connector*

*DT06-4S-E003 (2x4 pin)*




V310451.A

*Pinout:*
**1.** CAN High
**2.** CAN Low
**3.** Vbat+
**4.** GND
*IP rating:* IP67; IP69K without connector


## PVE Electro-hydraulic Actuation

### LED coloring for PVED-CC Series 5

*LED Characteristic*

| Color | LED Characteristic | Description |
|---|---|---|
| Green constant | | No error – Actuating |
| Green flashing @ 1.5 Hz | | Neutral – Power save |
| Red constant | | Internal error |
| Red flashing @ 1.5 Hz | | External or Float error |
| Yellow | | Disable mode |

### PVED-CC Hysteresis and Ripple





*Definition of hysteresis*

| | | |
|---|---|---|
| Hysteresis (h) | Rated [%] | 1.45% |
| Steady state ripple at constant command signal | Rated [%] | 0.29% |

## PVE Electro-hydraulic Actuation

### PVED-CC Reaction Times

*Reaction times*




*Definition of Step Response*

| Reaction | Time (nominal) |
|---|---|
| T0 – Boot-up | 440 ms* |
| T1 – Constant PFC command | 177 ms |
| T2 – Constant PFC command | 114 ms |

* Including Power-On-Self-Test (POST) and safety sub-system initialization.

The stated values are preliminary values and can be subject to change once an increased statistical basis is achieved.

### PVED-CC Part Numbers

PVED-CC part numbers according to connector type (IP67).

| Part number | 11107869 | 11107870 |
|---|---|---|
| Connector type | 1x4 DEUTSCH | 1x4 AMP |


## PVE Electro-hydraulic Actuation

### PVE Series 7

#### PVEO

The PVEO actuator is a non-proportional ON/OFF control actuator with open-loop spool control primarily used to control simple ON/OFF work functions where a proportional control of speed or oil flow is not a requirement.


*PVEO Series 7*



- Neutral position or max. spool stroke according to control signal
- 12 $V_{DC}$ or 24 $V_{DC}$ supply voltage
- DEUTSCH, AMP or DIN/Hirschman connectors
- Standard PVE pilot oil pressure of 13.5 bar [196 psi]
- LED only indicating Power ON or Power OFF
- Ramp (-R) or Direction Indication output (-DI) functionality

#### *Functionality principle*

*PVEO-DI functionality*





The standard PVEO/PVEO-HP functionality includes the simplest electric circuit of the PVE actuator program, using a fixed 12 $V_{DC}$ or 24 $V_{DC}$ supply voltage or signal voltage and a simple LED circuit to control the LED light indicating Power ON/OFF.

The PVEO-DI variant includes an LVDT spool position monitor and a more advanced electric circuit with an embedded micro-controller and separate power supply to handle the Direction Indication functionality.

## PVE Electro-hydraulic Actuation


An energization of solenoid valve SV1 and a simultaneous de-energization of SV2 will cause the main spool to move to the right direction and vice versa. If both SV1 and SV2 are energized or de-energized simultaneously, the main spool stays locked in its neutral position.

*PVEO/PVEO-DI schematic*




P109195

*PVEO-R schematic*



P109200




*Connector height and weight*

| DEUTSCH | AMP | DIN | Weight |
|---|---|---|---|
| 30 mm [1.2 in] | 38 mm [1.5 in] | 40 mm [1.6 in] | 0.7 kg [1.54 lb] |

## PVE Electro-hydraulic Actuation

### *PVEO Technical Data*

*Control Specifications*

| Description | Type | 12 $V_{DC}$ | 24 $V_{DC}$ |
|---|---|---|---|
| Supply Voltage ($U_{DC}$) | Range | 11 to 15 $V_{DC}$ | 22 to 30 $V_{DC}$ |
| | Max. ripple | 5% | 5% |
| Current Consumption | Typical | 480 mA | 250 mA |
| | Minimum | 430 mA | 220 mA |
| | Maximum | 950 mA | 480 mA |

*Pilot pressure*

| Minimum | Nominal | Maximum |
|---|---|---|
| 10.0 bar [145 psi] | 13.5 bar [196 psi] | 15.0 bar [218 psi] |

*Fluid consumption*

| Neutral/Locked position | Actuating (PVEO-R) | Actuating |
|---|---|---|
| 0 l/min | 0.3 l/min<br>[0.08 US gal/min] | 0.9 l/min<br>[0.24 US gal/min] |

*Technical specification*

| Parameter | Minimum | Recommended range | Maximum |
|---|---|---|---|
| **Fluid viscosity** | 4 $mm^2/s$ [39 SUS] | 12 to 75 $mm^2/s$ [65 to 347 SUS] | 460 $mm^2/s$ [2128 SUS] |
| **Fluid cleanliness** | 18/16/13 (according to ISO 4406) | | |
| **Storage temperature** | Ambient: -50 to 90°C [-58 to 194°F] | | |
| **Operating temperature** | Ambient: -30 to 60°C [-22 to 140°F] | | |


*LED characteristic*

| Color | LED characteristic | Description |
|---|---|---|
| Green constant | | Power ON |

## PVE Electro-hydraulic Actuation

### *PVEO Reaction Times*

*Reaction times*




*Definition of Step Response*

| Reaction | PVEO<br>PVEO-DI | PVEO-R |
|---|---|---|
| T0 – Boot-up | 0 | 0 |
| T1 – Neutral to max. spool stroke @ Power ON/ @ Constant $U_{DC}$ | 110 ms | 300 ms |
| T2 – Max. spool stroke to neutral @ Power OFF/@ Constant $U_{DC}$ | 110 ms | 110 ms |

The stated values are preliminary values and can be subject to change once an increased statistical basis is achieved.

### *PVEO Part Numbers*

*Part numbers for PVEO and PVEO-DI*

| Part number | Type | Connector | Protection Class | Voltage | Interface |
|---|---|---|---|---|---|
| **11166843** | PVEO | 1x4 DEU | IP 67 | 12 $V_{DC}$ | Standard |
| **11166838** | | 1x4 DEU | IP 67 | 24 $V_{DC}$ | |
| **11166866** | | 1x4 AMP | IP 66 | 12 $V_{DC}$ | |
| **11166837** | | 1x4 AMP | IP 66 | 24 $V_{DC}$ | |
| **11166836** | | 1x4 DIN | IP 65 | 12 $V_{DC}$ | |
| **11166743** | | 1x4 DIN | IP 65 | 24 $V_{DC}$ | |
| **111687401*** | PVEO-DI | 2x4 AMP | IP 66 | 12 $V_{DC}$ | |
| **111668691*** | | 2x4 AMP | IP 66 | 24 $V_{DC}$ | |

## PVE Electro-hydraulic Actuation

*Part numbers for PVEO and PVEO-DI (continued)*

| Part number | Type | Connector | Protection Class | Voltage | Interface |
|---|---|---|---|---|---|
| **11166753** | PVEO-R | 1x4 DEU | IP 67 | 12 $V_{DC}$ | Ramp |
| **11166754** | | 1x4 DEU | IP 67 | 24 $V_{DC}$ | |
| **11166867** | | 1x4 AMP | IP 66 | 12 $V_{DC}$ | |
| **11166776** | | 1x4 AMP | IP 66 | 24 $V_{DC}$ | |
| **11166831** | | 1x4 DIN | IP 65 | 12 $V_{DC}$ | |
| **11166908** | | 1x4 DIN | IP 65 | 24 $V_{DC}$ | |


* Includes Direction Indication special features.

## PVE Electro-hydraulic Actuation

### PVEO-HP

The PVEO-HP actuator is a non-proportional ON/OFF control actuator with open-loop spool control primarily used to control simple ON/OFF work functions where a proportional control of speed or oil flow is not a requirement.


*PVEO-HP*



All variants are available with following features:

- Neutral position or max. spool stroke according to control signal
- 12 $V_{DC}$ or 24 $V_{DC}$ supply voltage
- DEUTSCH, AMP or DIN/Hirschman connectors
- PVH/PVHC pilot oil pressure of 25 bar [362.6 psi]
- LED only indicating Power ON or Power OFF

*PVEO-HP functionality diagram*





The standard PVEO/PVEO-HP functionality includes the simplest electric circuit of the PVE actuator program, using a fixed 12 $V_{DC}$ or 24 $V_{DC}$ supply voltage or signal voltage and a simple LED circuit to control the LED light indicating Power ON/OFF.


An energization of solenoid valve SV1 and a simultaneous de-energization of SV2 will cause the main spool to move to the right direction and vice versa. If both SV1 and SV2 are energized or de-energized simultaneously, the main spool stays locked in its neutral position.

## PVE Electro-hydraulic Actuation

*PVEO-HP Schematic*



P109195




*Connector height and weight*

| DEUTSCH | AMP | DIN | Weight |
|---|---|---|---|
| 30 mm [1.2 in] | 38 mm [1.5 in] | 40 mm [1.6 in] | 0.7 kg [1.54 lb] |

### *PVEO-HP Technical Data*

*Control Specification*

| Description | Type | 12 $V_{DC}$ | 24 $V_{DC}$ |
|---|---|---|---|
| Supply Voltage ($U_{DC}$) | Range | 11 to 15 $V_{DC}$ | 22 to 30 $V_{DC}$ |
| | Max. ripple | 5% | |
| Current Consumption | Typical | 750 mA | 380 mA |
| | Minimum | 660 mA | 340 mA |
| | Maximum | 1460 mA | 740 mA |

*Technical data*

| | | |
|---|---|---|
| **Pilot pressure** | Nominal | 25 bar [363 psi] |
| | Minimum | 21 bar [305 psi] |
| | Maximum | 25 bar [363 psi] |
| **Fluid consumption** | Neutral | 0 l/min [0 US gal/min] |
| | Locked position | 0 l/min [0 US gal/min] |
| | Actuating | 0.9 l/min [0.24 US gal/min] |

## PVE Electro-hydraulic Actuation

*Technical specification*


| Parameter | Minimum | Recommended range | Maximum |
|---|---|---|---|
| **Fluid viscosity** | 4 $mm^2/s$ [39 SUS] | 12 to 75 $mm^2/s$ [65 to 347 SUS] | 460 $mm^2/s$ [2128 SUS] |
| **Fluid cleanliness** | 18/16/13 (according to ISO 4406) | | |
| **Storage temperature** | Ambient: -50 to 90°C [-58 to 194°F] | | |
| **Operating temperature** | Ambient: -30 to 60°C [-22 to 140°F] | | |

*LED characteristic*

| Color | LED characteristic | Description |
|---|---|---|
| Green constant | | Power ON |

### *PVEO-HP Reaction Times*

*Reaction times*




*Definition of Step Response*

| Reaction | PVEO-HP |
|---|---|
| T0 – Boot-up | 0 |
| T1 – Neutral to max. spool stroke @ Power ON/@ Constant $U_{DC}$ | 90 ms |
| T2 – Max. spool stroke to neutral @ Power OFF/@ Constant $U_{DC}$ | 70 ms |

The stated values are preliminary values and can be subject to change once an increased statistical basis is achieved.

## PVE Electro-hydraulic Actuation

### *PVEO-HP Part Numbers*

*PVEO-HP Standard Part Numbers*


| Part number | Connector | IP | $U_{DC}$ | Functionality |
|---|---|---|---|---|
| **11166765** | 1x4 DEUTSCH | IP 67 | 12 $V_{DC}$ | Standard |
| **11166766** | 1x4 DEUTSCH | IP 67 | 24 $V_{DC}$ | |
| **11166763** | 1x4 AMP | 66 | 12 $V_{DC}$ | |
| **11187524** | 1x4 AMP | 66 | 24 $V_{DC}$ | |
| **11187551** | 1x4 DIN | 65 | 12 $V_{DC}$ | |
| **11187562** | 1x4 DIN | 65 | 24 $V_{DC}$ | |

## PVE Electro-hydraulic Actuation

### PVEM

The PVEM actuator is a proportional control actuator with closed-loop spool control primarily used to control work functions with medium performance requirements. The PVEM is available in three different performance variants, the standard PVEM, the PVEM-R with ramp and the PVEM-Q with quick reaction.


*PVEM*



Variants are available with following features:

- 9–32 $V_{DC}$ multi-voltage power supply
- Analog voltage control signal 25–75% of supply voltage
- DIN or Hirschman connectors
- Standard PVE pilot oil pressure of 13.5 bar [196 psi]
- LED indicating error state and passive fault monitoring
- Float (-F), quick Ramp (-R) or Quick reaction functionality (-Q)

***PVEM functionality***





The PVE functionality includes an electric circuit with a closed-loop logic. An embedded micro-controller processes the signal voltage and the LVDT feedback signal and regulates the solenoid valves accordingly.

An energization of solenoid valve SV1 and a simultaneous de-energization of SV2 will cause the main spool to move to the right direction and vice versa. If both SV1 and SV2 are energized or de-energized simultaneously, the main spool stays locked in its neutral position.

## PVE Electro-hydraulic Actuation


### *Schematics*

*PVEM*




P109196

*PVEM-Q*



P109201

### *Dimensions*




*Connector height and weight*

| DEUTSCH | AMP | DIN | Weight |
|---|---|---|---|
| 30 mm [1.2 in] | 38 mm [1.5 in] | 40 mm [1.6 in] | 0.7 kg [1.54 lb] |

### *PVEM Technical Data*

*Control Specification*

| Description | Type | Value |
|---|---|---|
| Supply Voltage ($U_{DC}$) | Rated Range | 11 to 32 $V_{DC}$ |
| | Max. ripple | 5% |
| Signal Voltage PWM ($U_S$) | Neutral | $U_S$ = 0.5 $U_{DC}$ = 50% DUT |
| | Q: P to A | $U_S$ = (0.5 to 0.25) $U_{DC}$ = 50% to 25% DUT |
| | Q: P to B | $U_S$ = (0.5 to 0.75) $U_{DC}$ = 50% to 75% DUT |
| Input Impedance | Rated | 12 kΩ |
| Input Capacitance | Rated | 100 nF |

*Current consumption*

| Description | @ 12 $V_{DC}$ | @ 24 $V_{DC}$ |
|---|---|---|
| PWM Frequency ($U_S$) recommended | > 200 Hz | > 200 Hz |
| Current Consumption | 690 mA | 350 mA |

## PVE Electro-hydraulic Actuation

*Pilot pressure*

| Minimum | Nominal | Maximum |
|---|---|---|
| 10.0 bar [145 psi] | 13.5 bar [196 psi] | 15.0 bar [218 psi] |

*Fluid consumption*

| Neutral/Locked position | Actuating (PVEM-R) | Actuating (PVEM-Q) | Actuating |
|---|---|---|---|
| 0 l/min | 0.3 l/min | 1.0 l/min [0.26 US gal/min][0.08 US gal/min] | 0.5 l/min [0.13 US gal/min] |

*Technical specification*


| Parameter | Minimum | Recommended range | Maximum |
|---|---|---|---|
| **Fluid viscosity** | 4 $mm^2/s$ [39 SUS] | 12 to 75 $mm^2/s$ [65 to 347 SUS] | 460 $mm^2/s$ [2128 SUS] |
| **Fluid cleanliness** | 18/16/13 (according to ISO 4406) | | |
| **Storage temperature** | Ambient: -50 to 90°C [-58 to 194°F] | | |
| **Operating temperature** | Ambient: -30 to 60°C [-22 to 140°F] | | |

*LED characteristic*

| Color | LED characteristic | Description |
|---|---|---|
| Green constant | | No error – Actuating |
| Green flashing @ 1.5 Hz | | Neutral – Power save |
| Red constant | | Internal error |
| Red flashing @ 1.5 Hz | | External or Float error |

### *PVEM Reaction Times*

*Reaction times*



## PVE Electro-hydraulic Actuation

*Definition of Step Response*

| Reaction | PVEM-R | PVEM-FLB | PVEM-Q |
|---|---|---|---|
| T0 – Boot-up | 15 ms | 15 ms | 15 ms |
| T1 – Neutral to max. spool stroke @ Power ON | 325 ms | 225 ms | 125 ms |
| T2 – Max. spool stroke to neutral @ Power OFF | 110 ms | 110 ms | 110 ms |
| T1 – Neutral to max. spool stroke @ Constant $U_{DC}$ | 310 ms | 210 ms | 110 ms |
| T2 – Max. spool stroke to neutral @ Constant $U_{DC}$ | 90 ms | 90 ms | 90 ms |

The stated values are preliminary values and can be subject to change once an increased statistical basis is achieved.

### *PVE Hysteresis and Ripple*

*PVE hysteresis overview*

| PVE type | PVEP, PVES PVEH | PVEA | PVEM |
|---|---|---|---|
| Hysteresis (h) | <0.5 % | 2 % | 15 % |
| Steady state ripple @constant Us | 0.2 mm | 0.3 mm | 0.0 mm |

### *PVEM part numbers*

Part numbers for PVEM variants with Passive Fault Monitoring; IP rating IP65 and DIN 1x4 connector.

*Part numbers for PVEM variants*


| Part number | Type | Functionality |
|---|---|---|
| **11166829** | PVEM | Standard |
| **11166852** | PVEM-FLB | Float B-port |
| **11166845** | PVEM-R | Ramp |
| **11166853** | PVEM-Q | Quick Reaction |

## PVE Electro-hydraulic Actuation

### PVEA

The PVEA actuator is a proportional control actuator with a closed-loop spool control primarily used to control work functions with above medium performance requirements.


*PVEA*



- 9–32 $V_{DC}$ multi-voltage power supply
- Analog voltage control signal 25–75% of supply voltage
- Standard PVE pilot oil pressure of 13.5 bar [196 psi]
- DEUTSCH, AMP or DIN/Hirschman connectors
- LED indicating error state and active or passive fault monitoring
- Direction Indication output (-DI) or Neutral Power-Off (-NP) functionality

#### *PVEA-DI functionality*

*PVEA-DI functionality*




The PVE functionality includes an electric circuit with a closed-loop logic. An embedded micro-controller processes the signal voltage and the LVDT feedback signal and regulates the solenoid valves accordingly.

A continuous modulation of solenoid valve NC1 and a simultaneous de-energization of NC3 causes the main spool to move to the right direction and vice versa. When the main spool is stroked to the far right, a simultaneous modulation of both NC1 and NC3 balances the main spool in its stroked position. The main spool oscillates in its stroked position at a frequency corresponding to the modulation frequency. When both NC1 and NC3 are de-energized, the main spool moves back to its neutral position by means of the main spool neutral spring and the hydraulic principle.

## PVE Electro-hydraulic Actuation

### *PVEA Technical Data*

*Control Specification*

| Description | Type | Value |
|---|---|---|
| Supply Voltage ($U_{DC}$) | Rated Range | 11 to 32 $V_{DC}$ |
| | Max. ripple | 5% |
| Signal Voltage PWM ($U_S$) | Neutral | $U_S$ = 0.5 $U_{DC}$ = 50% DUT |
| | Q: P to A | $U_S$ = (0.5 to 0.25) $U_{DC}$ = 50% to 25% DUT |
| | Q: P to B | $U_S$ = (0.5 to 0.75) $U_{DC}$ = 50% to 75% DUT |
| Input Impedance | Rated | 12 kΩ |
| Input Capacitance | Rated | 100 nF |

*Current consumption*

| Description | @ 12 $V_{DC}$ | @ 24 $V_{DC}$ |
|---|---|---|
| PWM Frequency ($U_S$) recommended | > 1000 Hz | > 1000 Hz |
| Current Consumption | 290 mA | 150 mA |

*Pilot pressure*

| Minimum | Nominal | Maximum |
|---|---|---|
| 10.0 bar [145 psi] | 13.5 bar [196 psi] | 15.0 bar [218 psi] |

*Fluid consumption*

| Neutral | Locked position | Actuating |
|---|---|---|
| 0 l/min | 0 l/min | 1.0 l/min<br>[0.26 US gal/min] |

*Technical specification*

| Parameter | Minimum | Recommended range | Maximum |
|---|---|---|---|
| **Fluid viscosity** | 4 $mm^2/s$ [39 SUS] | 12 to 75 $mm^2/s$ [65 to 347 SUS] | 460 $mm^2/s$ [2128 SUS] |
| **Fluid cleanliness** | 18/16/13 (according to ISO 4406) | | |
| **Storage temperature** | Ambient: -50 to 90°C [-58 to 194°F] | | |
| **Operating temperature** | Ambient: -30 to 60°C [-22 to 140°F] | | |


*LED characteristic*

| Color | LED characteristic | Description |
|---|---|---|
| Green constant |  | No error – Actuating |
| Green flashing @ 1.5 Hz |  | Neutral – Power save |
| Red constant |  | Internal error |
| Red flashing @ 1.5 Hz |  | External or Float error |

## PVE Electro-hydraulic Actuation

### *PVEA Reaction Times*

*Reaction times*




| Reaction | PVEA |
|---|---|
| T0 – Boot-up [ms] | 15 ms |
| T1 – Neutral to max. spool stroke @ Power ON | 280 ms |
| T2 – Max. spool stroke to neutral @ Power OFF | 200 ms |
| T1 – Neutral to max. spool stroke @ Constant $U_{DC}$ | 265 ms |
| T2 – Max. spool stroke to neutral @ Constant $U_{DC}$ | 200 ms |

The stated values are preliminary values and can be subject to change once an increased statistical basis is achieved.

### *PVE Hysteresis and Ripple*

*PVE hysteresis overview*

| PVE type | PVEP, PVES PVEH | PVEA | PVEM |
|---|---|---|---|
| Hysteresis (h) | <0.5 % | 2 % | 15 % |
| Steady state ripple @constant Us | 0.2 mm | 0.3 mm | 0.0 mm |

### *PVEA part numbers*

Part numbers for PVEA variants with Standard Functionality.

*Part numbers for PVEA variants*

| Part number | Type | Connector | IP rating | Fault Monitoring |
|---|---|---|---|---|
| **11177346** | PVEA | 1x4 DEU | IP67 | Passive |
| **11177347** | PVEA | | IP67 | Active |
| **11177353** | PVEA | 1x4 AMP | IP66 | Passive |
| **11177348** | PVEA | | IP66 | Active |
| **11177345** | PVEA-NP[1)] | 1x6 DEU | IP67 | Passive |
| **11177357** | PVEA-DI[2)] | 2x4 DEU | IP67 | Active |

## PVE Electro-hydraulic Actuation

*Part numbers for PVEA variants (continued)*

| Part number | Type | Connector | IP rating | Fault Monitoring |
|---|---|---|---|---|
| **11177356** | PVEA-DI[2)] | 2x4 AMP | IP66 | Passive |
| **11177355** | PVEA-DI[2)] | | IP66 | Active |

[1)] Neutral Power-Off special features.


[2)] Direction Indication special features.

## PVE Electro-hydraulic Actuation

### PVEH

The PVEH actuator is a proportional control actuator with closed-loop spool control primarily used to control work functions with high performance requirements.

*PVEH*



- 9–32 $V_{DC}$ multi-voltage power supply
- Analog voltage control signal 25–75% of supply voltage
- Standard PVE pilot oil pressure of 13.5 bar [196 psi]
- DEUTSCH, AMP or DIN/Hirschman connectors
- LED indicating error state and active or passive fault monitoring
- Float (-F), Direction Indication output (-DI), Neutral Power-Off (-NP), Spool Position output (-SP) or 0-10 $V_{DC}$ control signal (-U) functionality

#### *PVEH functionality*

The PVE functionality includes an electric circuit with a closed-loop logic. An embedded micro-controller processes the signal voltage and the LVDT feedback signal and regulates the solenoid valves accordingly.

A continuous modulation of solenoid valves NC1 and NO4 together with a simultaneous energization of NO2 and de-energization of NC3 causes the main spool to move to the right direction and vice versa. When the main spool is stroked to the far right, a simultaneous energization of both NO2 and NO4 and de-energization of both NC1 and NC3 balances the main spool in its stroked position. An emergency stop activated when the spool is stroked will cause all solenoid valves to de-energize causing the main spool to move back to its neutral position by means of the main spool neutral spring and the hydraulic principle.

#### *PVEH Technical Data*

*Control Specification*

| Description | Type | Value |
|---|---|---|
| Supply Voltage ($U_{DC}$) | Rated Range | 11 to 32 $V_{DC}$ |
| | Max. ripple | 5% |
| Signal Voltage PWM ($U_S$) | Neutral | $U_S$ = 0.5 $U_{DC}$ = 50% DUT |
| | Q: P to A | $U_S$ = (0.5 to 0.25) $U_{DC}$ = 50% to 25% DUT |
| | Q: P to B | $U_S$ = (0.5 to 0.75) $U_{DC}$ = 50% to 75% DUT |

## PVE Electro-hydraulic Actuation

*Control Specification (continued)*

| Description | Type | Value |
|---|---|---|
| Input Impedance | Rated | 12 kΩ |
| Input Capacitance | Rated | 100 nF |

*Current consumption*

| Description | @ 12 $V_{DC}$ | @ 24 $V_{DC}$ |
|---|---|---|
| PWM Frequency ($U_S$) recommended | > 1000 Hz | > 1000 Hz |
| Current Consumption | 540 mA | 270 mA |
| Max. DI Current | 200 mA | 200 mA |

*Pilot pressure*

| Minimum | Nominal | Maximum |
|---|---|---|
| 10.0 bar [145 psi] | 13.5 bar [196 psi] | 15.0 bar [218 psi] |

*Fluid consumption*

| Neutral | Locked position | Actuating |
|---|---|---|
| 0.0 l/min | 0.0 l/min | 0.7 l/min<br>[0.18 US gal/min] |

*Technical specification*

| Parameter | Minimum | Recommended range | Maximum |
|---|---|---|---|
| **Fluid viscosity** | 4 $mm^2/s$ [39 SUS] | 12 to 75 $mm^2/s$ [65 to 347 SUS] | 460 $mm^2/s$ [2128 SUS] |
| **Fluid cleanliness** | 18/16/13 (according to ISO 4406) | | |
| **Storage temperature** | Ambient: -50 to 90°C [-58 to 194°F] | | |
| **Operating temperature** | Ambient: -30 to 60°C [-22 to 140°F] | | |


*LED Characteristic*

| Color | LED Characteristic | Description |
|---|---|---|
| Green constant | | No error – Actuating |
| Green flashing @ 1.5 Hz | | Neutral – Power save |
| Red constant | | Internal error |
| Red flashing @ 1.5 Hz | | External or Float error |
| Yellow | | Disable mode |

## PVE Electro-hydraulic Actuation

### *PVEH Reaction Times*

*Reaction times*




| Reaction | PVEH |
|---|---|
| T0 – Boot-up [ms] | 15 ms |
| T1 – Neutral to max. spool stroke @ Power ON [ms] | 125 ms |
| T2 – Max. spool stroke to neutral @ Power OFF [ms] | 110 ms |
| T1 – Neutral to max. spool stroke @ Constant $U_{DC}$ [ms] | 110 ms |
| T2 – Max. spool stroke to neutral @ Constant $U_{DC}$ [ms] | 90 ms |

The stated values are preliminary values and can be subject to change once an increased statistical basis is achieved.

### *PVE Hysteresis and Ripple*

*PVE hysteresis overview*

| PVE type | PVEP, PVES PVEH | PVEA | PVEM |
|---|---|---|---|
| Hysteresis (h) | <0.5 % | 2 % | 15 % |
| Steady state ripple @constant Us | 0.2 mm | 0.3 mm | 0.0 mm |

### *PVEH Part Numbers*

*Part numbers for PVEH variants*

| Part number | Type | Connector | IP class | Fault Monitoring | Functionality |
|---|---|---|---|---|---|
| 11166732 | PVEH | 1x4 DEUTSCH | IP67 | Passive | Standard |
| 11166775 | PVEH | 1x4 DEUTSCH | IP67 | Active | |
| 11166825 | PVEH | 1x4 AMP | IP66 | Passive | |
| 11166818 | PVEH | 1x4 AMP | IP66 | Active | |
| 11166824 | PVEH | 1x4 DIN | IP65 | Passive | |
| 11166817 | PVEH | 1x4 DIN | IP65 | Active | |

## PVE Electro-hydraulic Actuation

*Part numbers for PVEH variants (continued)*

| Part number | Type | Connector | IP class | Fault Monitoring | Functionality |
|---|---|---|---|---|---|
| 11166832[1)] | PVEH-U | 1x4 AMP | IP66 | Passive | Fixed $U_S$ 0-10 $V_{DC}$ |
| 11166821[1)] | PVEH-U | 1x4 AMP | IP66 | Active | |
| 11166770[1)] | PVEH-U | 1x4 DIN | IP65 | Passive | |
| 11166772[1)] | PVEH-U | 1x4 DIN | IP65 | Active | |
| 11166840 | PVEH-FLB | 1x4 DEUTSCH | IP67 | Passive | Float B-port |
| 11166742 | PVEH-FLB | 1x4 DEUTSCH | IP67 | Active | |
| 11166839 | PVEH-FLB | 1x4 DIN | IP65 | Active | |
| 11166841[2)] | PVEH-FLA | 1x6 DIN | IP67 | Active | Float A-port |
| 11168738[2)] | PVEH-FLA | 1x6 AMP | IP66 | Passive | |
| 11168739[2)] | PVEH-FLA | 1x6 AMP | IP66 | Active | |
| 11166773[3)] | PVEH-SP | 1x6 DEUTSCH | IP67 | Active | Standard |
| 11166750[4)] | PVEH-NP | 1x6 DEUTSCH | IP67 | Fast active | |
| 11166835[5)] | PVEH-DI | 2x4 DEUTSCH | IP67 | Active | |
| 11166820[5)] | PVEH-DI | 2x4 AMP | IP66 | Passive | |
| 11166819[5)] | PVEH-DI | 2x4 AMP | IP66 | Active | |

[1)] Includes **Disable Mode** special feature

[2)] Includes **Dedicated Float** Pin (UF) special feature

[3)] Includes **Spool Position** special feature

[4)] Includes **Neutral Power-OFF** special feature


[5)] Includes **Direction Indication** special feature

## PVE Electro-hydraulic Actuation

### PVES

The PVES actuator is a proportional control actuator with closed-loop spool control primarily used to control work functions with very high performance requirements.


*PVES*



- 9–32 $V_{DC}$ multi-voltage power supply
- Analog voltage control signal 25–75% of supply voltage
- Standard PVE pilot oil pressure of 13.5 bar [196 psi]
- DEUTSCH, AMP or DIN/Hirschman connectors
- LED indicating error state and active or passive fault monitoring
- Spool Position output (-SP) or 0-10 $V_{DC}$ control signal (-U) functionality

#### *PVES functionality*

*PVES functionality*




The PVE functionality includes an electric circuit with a closed-loop logic. An embedded micro-controller processes the signal voltage and the LVDT feedback signal and regulates the solenoid valves accordingly.

A continuous modulation of solenoid valves NC1 and NO4 together with a simultaneous energization of NO2 and de-energization of NC3 causes the main spool to move to the right direction and vice versa. When the main spool is stroked to the far right, a simultaneous energization of both NO2 and NO4 and de-energization of both NC1 and NC3 balances the main spool in its stroked position. An emergency stop

## PVE Electro-hydraulic Actuation

activated when the spool is stroked will cause all solenoid valves to de-energize causing the main spool to move back to its neutral position by means of the main spool neutral spring and the hydraulic principle.

### *PVES Technical Data*

*Control Specification*

| Description | Type | Value |
|---|---|---|
| Supply Voltage ($U_{DC}$) | Rated Range | 11 to 32 $V_{DC}$ |
| | Max. ripple | 5% |
| Signal Voltage PWM ($U_S$) | Neutral | $U_S$ = 0.5 $U_{DC}$ = 50% DUT |
| | Q: P to A | $U_S$ = (0.5 to 0.25) $U_{DC}$ = 50% to 25% DUT |
| | Q: P to B | $U_S$ = (0.5 to 0.75) $U_{DC}$ = 50% to 75% DUT |
| Input Impedance | Rated | 12 kΩ |
| Input Capacitance | Rated | 100 nF |

*Current consumption*

| Description | @ 12 $V_{DC}$ | @ 24 $V_{DC}$ |
|---|---|---|
| PWM Frequency ($U_S$) recommended | > 1000 Hz | > 1000 Hz |
| Current Consumption | 560 mA | 280 mA |

*Pilot pressure*

| Minimum | Nominal | Maximum |
|---|---|---|
| 10.0 bar [145 psi] | 13.5 bar [196 psi] | 15.0 bar [218 psi] |

*Fluid consumption*

| Neutral | Locked position | Actuating |
|---|---|---|
| 0.03 l/min<br>[0.106 US gal/min] | 0.01 l/min<br>[0.026 US gal/min] | 0.8 l/min<br>[0.21 US gal/min] |

*Technical specification*

| Parameter | Minimum | Recommended range | Maximum |
|---|---|---|---|
| **Fluid viscosity** | 4 $mm^2/s$ [39 SUS] | 12 to 75 $mm^2/s$ [65 to 347 SUS] | 460 $mm^2/s$ [2128 SUS] |
| **Fluid cleanliness** | 18/16/13 (according to ISO 4406) | | |
| **Storage temperature** | Ambient: -50 to 90°C [-58 to 194°F] | | |
| **Operating temperature** | Ambient: -30 to 60°C [-22 to 140°F] | | |


*LED Characteristic*

| Color | LED Characteristic | Description |
|---|---|---|
| Green constant | | No error – Actuating |
| Green flashing @ 1.5 Hz | | Neutral – Power save |
| Red constant | | Internal error |
| Red flashing @ 1.5 Hz | | External or Float error |
| Yellow | | Disable mode |

## PVE Electro-hydraulic Actuation

### *PVES Reaction Times*

*Reaction times*




| Reaction | PVES |
|---|---|
| T0 – Boot-up [ms] | 15 ms |
| T1 – Neutral to max. spool stroke @ Power ON | 125 ms |
| T2 – Max. spool stroke to neutral @ Power OFF | 110 ms |
| T1 – Neutral to max. spool stroke @ Constant $U_{DC}$ | 110 ms |
| T2 – Max. spool stroke to neutral @ Constant $U_{DC}$ | 90 ms |

The stated values are preliminary values and can be subject to change once an increased statistical basis is achieved.

### *PVE Hysteresis and Ripple*

*PVE hysteresis overview*

| PVE type | PVEP, PVES PVEH | PVEA | PVEM |
|---|---|---|---|
| Hysteresis (h) | <0.5 % | 2 % | 15 % |
| Steady state ripple @constant Us | 0.2 mm | 0.3 mm | 0.0 mm |

### *PVES Part Numbers*

*Part numbers for PVES variants*

| Part number | Type | Connector | IP | Fault Monitoring | Functionality |
|---|---|---|---|---|---|
| **11166748** | PVES | 1x4 DEUTSCH | IP67 | Passive | Standard |
| **11166864** | PVES | 1x4 DEUTSCH | IP67 | Active | |
| **11166859** | PVES | 1x4 AMP | IP66 | Passive | |
| **11166858** | PVES | 1x4 AMP | IP66 | Active | |
| **11166849** | PVES | 1x4 DIN | IP65 | Passive | |
| **11166857** | PVES | 1x4 DIN | IP65 | Active | |

## PVE Electro-hydraulic Actuation

*Part numbers for PVES variants (continued)*




| Part number | Type | Connector | IP | Fault Monitoring | Functionality |
|---|---|---|---|---|---|
| **11166745**[1)] | PVES-U | 1x4 DEUTSCH | IP67 | Passive | Fixed $U_S$ 0-10 $V_{DC}$ |
| **11166747**[1)] | PVES-U | 1x4 AMP | IP66 | Active | |
| **11166752**[2)] | PVES-SP | 1x6 DEUTSCH | IP67 | Passive | Standard |





[1)] Includes **Disable Mode** special feature

[2)] Includes **Spool Position** special feature

## PVE Electro-hydraulic Actuation

### Connector Overview

| 1 x 4 DEUTSCH | 2 x 4 DEUTSCH | 1 x 6 DEUTSCH |
|---|---|---|
|  |  |  |

| 1 x 4 AMP | 2 x 4 AMP | 1 x 6 AMP | 1 x 4 DIN |
|---|---|---|---|
|  |  |  |  |

*PVEO-DI 4-pin AMP Connector*

| Pinout | Pin 1 | Pin 2 | Pin 3 | Pin 4 |
|---|---|---|---|---|
| 2x4 AMP (A) | $U_{DC}$_A | $U_{DC}$_B | GND | GND |
| 2x4 AMP (B) | DI-B | DI-A | GND | $U_{DC2}$ |

*PVEM 4-pin DIN Connector*

| Pinout | Pin 1 | Pin 2 | Pin 3 | Pin 4 |
|---|---|---|---|---|
| 1x4 DIN | $U_{DC}$ | $U_S$ | Error | GND |

*PVEO, PVEO-R and PVEO-HP 4-pin Connector*

| Pinout | Pin 1 | Pin 2 | Pin 3 | Pin 4 |
|---|---|---|---|---|
| 1x4 AMP | $U_{DC}$_A | $U_{DC}$_B | GND | GND |
| 1x4 DEUTSCH | $U_{DC}$_A | GND | GND | $U_{DC}$_B |
| 1x4 DIN | $U_{DC}$_A | $U_{DC}$_B | - | GND |

*PVEA/PVEH/PVES*

| Pinout | Pin 1 | Pin 2 | Pin 3 | Pin 4 |
|---|---|---|---|---|
| 1x4 AMP | $U_S$ | $U_{DC}$ | GND | Error |
| 1x4 DEUTSCH | $U_S$ | Error | GND | $U_{DC}$ |
| 1x4 DIN | $U_{DC}$ | $U_S$ | Error | GND |

*PVEA-DI and PVEH-DI 4-pin Connector*

| Pinout | Pin 1 | Pin 2 | Pin 3 | Pin 4 |
|---|---|---|---|---|
| 2x4 AMP (A) | $U_S$ | $U_{DC}$ | GND | Error |
| 2x4 AMP (B) | DI-A | DI-B | GND | $U_{DC2}$ |

## PVE Electro-hydraulic Actuation

*PVEA-DI and PVEH-DI 4-pin Connector (continued)*

| Pinout | Pin 1 | Pin 2 | Pin 3 | Pin 4 |
|---|---|---|---|---|
| 2x4 DEUTSCH (A) | $U_S$ | Error | GND | $U_{DC}$ |
| 2x4 DEUTSCH (B) | $U_{DC2}$ | GND | DI-A | DI-B |

*PVEH-FLA 6-pin Connector*

| Pinout | Pin 1 | Pin 2 | Pin 3 | Pin 4 | Pin 5 | Pin 6 |
|---|---|---|---|---|---|---|
| 1x6 AMP | $U_S$ | $U_{DC}$ | GND | Error | Float | - |
| 1x6 DEUTSCH | $U_S$ | Error | - | SP | GND | $U_{DC}$ |

*PVEH-SP and PVES-SP 6-pin Connector*

| Pinout | Pin 1 | Pin 2 | Pin 3 | Pin 4 | Pin 5 | Pin 6 |
|---|---|---|---|---|---|---|
| 1x6 DEUTSCH | $U_S$ | Error | - | SP | GND | $U_{DC}$ |

## PVE Electro-hydraulic Actuation

### Extension plates for PVE Series 7


The PVE Series 7 Extension Plates are intended for use in case of conflict with external piping when replacing a PVE Series 4 with a PVE Series 7.

The Extension Plates are compatible with all versions of the PVE Series 7 and come in two different sizes with different purposes:

- A) 17 mm [0.67] – Moves the PVE series 7 further away from the PVB module so the total length of the plate and the PVE Series 7 is similar to the length of a PVE Series 4
- B) 44 mm [1.73] – Moves the PVE series 7 further away from the PVB module so the distance between the PVE Series 7 connector and the PVB module is similar to the distance between connector and PVB module when using a PVE Series 4

If you are using a PVE Series 7 with 2x4 DEUTSCH connector the distance will be 12,9 mm smaller between the PVB module and the connector, than in the case of using a PVE Series 4.

*PVE Series 7 extension plates*




| Part number | Description | Letter |
|---|---|---|
| 11188891 | 17 mm aluminum block | A |
| 11188902 | 44 mm aluminum block | B |

## Fault Monitoring and Reaction

All proportional control PVG 32 actuators feature:

- Integrated fault monitoring
- Detecting spool stroke inconsistencies
- Detecting internal hardware defects
- Detecting demand signal inconsistencies
- Fault reaction depending on the type of fault monitoring
  - Generic
  - Specific

### Passive fault monitoring

Passive fault monitoring does not disable the solenoid valves when an error is detected. It will continue to operate despite that an error was detected. When the error no longer is registered the passive fault monitoring will "forget" the error and continue as if the error was never there.

With a passive fault monitoring the following conditions will happen when an error is detected/occurs:

- The LED light will switch from green to red and the error pin output will go high
- The solenoid valves will continue operating at the set point given at the time of the error
  - Only exception is if the error is caused by the supply voltage ($U_{DC}$) being either above or below the allowed range or if the temperature measured on the internal electronics board is higher than allowed. In these cases, the solenoid valves will be disabled.

### Generic Fault Reaction

All PVE actuators with fault monitoring are triggered by the following main events:

| | |
|---|---|
| **Control Signal Monitoring** | The Control signal voltage ($U_S$) is continuously monitored.<br>The permissible range is between 15% and 85% of the supply voltage ($U_{DC}$). Outside this range the PVE will switch into an error state. A disconnected $U_S$ pin (floating) is recognized as a neutral set point. |
| **Transducer/LVDT Supervision** | The internal LVDT wires are monitored. If the signals are interrupted or short-circuited, the PVE will switch into an error state. |
| **Supervision of Spool Position** | The actual position must always correspond to the demanded position ($U_S$). If the actual spool position is further out from neutral than the demanded spool position or in opposite direction, the PVE will switch into an error state. Spool position closer to neutral and in same direction will not cause an error state – the situation is considered *in control*. |
| **Float Position Monitoring** | Float position must be entered or left within a time limit.<br>A too high delay on the 1x6 pin float PVE will cause an error state – this is relevant for the 1x6 pin PVEH-F actuators only. |
| **Temperature Monitoring** | When the temperature is too high the PVE LED will light constant red and solenoid valves will be disabled. |

## Fault Monitoring and Reaction

### Fault Reaction Overview

All entries have an Auto Recovery feature unless marked otherwise.

| Description | Monitoring | LED | Solenoid valves | Error pin output | Fault reaction time | |
|---|---|---|---|---|---|---|
| | | | | | PVEM/H/S | PVEA |
| Spool not at setpoint | Active* | | Disabled | High | 500 | 750 |
| | Passive | | - | High | 250 | 750 |
| Unable to reach float position | Active* | | Disabled | High | 1000 | 1000 |
| | Passive | | - | High | 1000 | 1000 |
| U dc > max. | Active | | Disabled | - | - | - |
| | Passive | | Disabled | - | - | - |
| U dc < min. | Active | ———— | Disabled | - | - | - |
| | Passive | ———— | Disabled | - | - | - |
| Us out of range | Active* | | Disabled | High | 500 | 750 |
| | Passive | | - | High | 250 | 750 |
| LVDT error | Active* | | Disabled | High | 500 | 750 |
| | Passive | | - | High | 250 | 750 |
| Temp > max. | Active* | | Disabled | High | 250 | 750 |
| | Passive | | Disabled | High | 250 | 750 |

* Does not have Auto Recovery


### Error Pin Specification

All proportional control PVE Series 7 actuators feature an error pin, indicating when an error is detected/ occurs, according to the Fault Reaction Overview table. The specifications of the error pin is shown below.

| Description | No error | Error |
|---|---|---|
| Output state | Low | High |
| Output voltage | <2 Vdc | ~Udc |
| Output current | Max. 100 mA | |

## Functionality Overview


*Progressive oil flow characteristics depending on spool type*




## PWM Voltage Control

The PVEM/PVEA/PVEH/PVES actuator variants can be controlled by a PWM controlled signal voltage (Us) proportional to the supply voltage (Udc).

The $V_1$ and $V_2$ must be symmetrical around Udc/2 and $V_1$ must be equal to or less than Udc.



## Functionality Overview

### Float A-Port (-FLA)

The Float A-Port functionality enables the proportional PVEH-FLA actuator variants to enter the main spool into a float position. The PVE actuators with Float A-Port functionality is compatible with the dedicated main spools with electronic float in A-port.


| PVE Type | PVBS Type | Standard Flow Control | Float Control |
|---|---|---|---|
| PVEH-FLA (1x6 pin) | Deadband 1.7 mm | Us = (0.25 → 0.75) · Udc | U dc to dedicated float pin (UF) |
| | Max. B-port flow 8.0 mm | | |

### Float B-Port (-FLB)

The Float B-Port functionality enables the proportional PVEM-FLB/PVEH-FLB actuator variants to enter the main spool into a float position. The PVE actuators with Float B-Port functionality is compatible with the dedicated main spools with electronic float in B-port.

| PVE Type | PVBS Type | Standard FC | Float Control |
|---|---|---|---|
| PVEM-FLB (1x4 pin) | Deadband 1.5 mm<br>Max. B-port flow 4.8 mm | Us = (0.35 → 0.65) · $U_{DC}$ | Us = 0.75 · $U_{DC}$ |
| PVEH-FLB (1x4 pin) | | | |

*Float in B-port functionality*




P109155

### PVE Power Save

All proportional actuator variants feature a Power Save mode, de-energizing the solenoid valve bridge. The Power Save mode is entered when the signal voltage (Us) and the LVDT spool position has been in

## Functionality Overview

neutral for 750 ms. As soon as the signal voltage (Us) or the LVDT spool position is out of neutral the PVE will leave its Power Save mode and re-energize the solenoid valve bridge as usual.


The Power Save mode results in increased power efficiency by reducing the current consumption of the PVE actuators in neutral position. The Power Save mode has no effect on the performance of the PVE actuator.

## Special Features


### Direction Indication (-DI)

The PVEO-DI/PVEA-DI/PVEH-DI actuator variants feature an integrated Direction Indication output derived from the LVDT spool position, indicating the state of the main spool (neutral, A-port or B-port).


*PVEO-DI functionality*




*PVEA-DI functionality*




*PVEH functionality*




## Special Features

The Direction Indication feature uses a dual power supply with the 2x4 pin AMP and DEUTSCH connectors as shown in the chapter *Connector Overview* on page 174.

When both DI_A and DI_B signals are High the main spool is in its neutral position.

When the DI_A signal goes Low and the DI_B signal stays High, the main spool is moving in the A-port direction, and vice versa. The relation between the direction indication feedback and the output signal is shown below.

*Direction indication feedback*





| | A-Port | B-Port |
|---|---|---|
| DI signals a1, a2 | –0.8 mm ± 0.4 mm | 0.8 mm ± 0.4 mm |
| Max. DI load | 200 mA | |
| DI High @ 20 mA | > $U_{DC}$ – 1.5 $V_{DC}$ | |
| DI High @ 100 mA | > $U_{DC}$ – 2.0 $V_{DC}$ | |
| DI Low | < 0.2 $V_{DC}$ | |

## Dedicated Float Pin (UF)

The Dedicated Float Pin (UF) feature is related to the PVEH-FLA actuator variant enabling the user to move the main spool into its float position by power. The PVEH-FLA uses 1x6 pin AMP orDEUTSCH connectors.

- Normal operation: Low or not connected
- High Float
- Input range: $U_{DC}$
- Max. voltage: 32 $V_{DC}$

*PVEH-FLA functionality diagram*




## Special Features


### Spool Position (SP)

The Spool Position (SP) feature available in the PVEH-SP/PVES-SP actuator variants enables the user to derive from the LVDT spool position of the main spool by means of an analog voltage signal on the dedicated spool position (SP) output pin.


*PVEH-SP functionality diagram*




*PVES-SP functionality diagram*




*Spool Position feedback*




SP feedback signal from 0.5 to 4.0 $V_{DC}$ inverted in direction relative to $U_S$ 2.5 $V_{DC}$ as the neutral value
SP from neutral to maximum stroke (mm)
SP maximum load is 0.5 mA
Output range for A-port: 2.5 – 1.25 $V_{DC}$ and for B-port: 2.5 – 3.75 $V_{DC}$


The PVEH-SP/PVES-SP uses a 1x6 DEUTSCH connector. For more information, please see *Connector Overview* on page 174.

## Special Features


### Neutral Power-OFF (NP)

The Neutral Power-OFF (NP) feature available in the PVEA-NP and PVEH-NP actuator variants enables the user to identify whether the solenoid valves in the actuator are energized or de-energized via a dedicated neutral power-OFF (NP) output pin.

*PVEA-NP functionality diagram*





*PVEH-NP functionality diagram*




The Neutral Power-OFF (NP) signal is defined as shown below:

*Solenoid disabling function (-NP) curves*




Normal operation from > $U_{DC}$ to 2 $V_{DC}$

Power Save < 1 $V_{DC}$ (solenoid valves de-energized)

NP maximum load is 50 mA

The PVEA-NP/PVEH-NP uses a 1x6 DEUTSCH connector. For more information, please see *Connector Overview* on page 174.

## Special Features

### Disable Mode

The PVEH-Uand PVES-U actuator variants controlled by a fixed 0-10 $V_{DC}$ signal voltage ($U_S$), feature the ability to enter a disable mode. This causes the counteracting force on the main spool created by the solenoid valve bridge to deactivate, when using Manual OverRide (MOR).

The disable mode is entered by sending a signal voltage (Us) of 16.2% of 10 $V_{DC}$ when in Power Save.

## PVS End Plates

The PVG 32 PVS end plates close off the valve stack section placed between them by placing them at the end. Furthermore, the end plate is ensuring Load Sense (LS) is relieved to tank pressure when the valve is not operated.

The PVS end plate variants are based on a generic platform with a wide selection of additional features, enabling you to tailor the PVS to suit the demands of any hydraulic system.

*The generic PVS end plates platform includes the following main variants:*

- **PVS/PVSI** – Either aluminum or cast iron
- **PVS/PVSI with LX-connection** – Either aluminum or cast iron
- **PVSI with P-, T-, LX- and M-connection** – Cast iron
- **PVSI start plate** – Cast iron
- **PVSD** – Cast iron
- **PVSI with PVE PPRV** – Cast iron
- **PVST with T-connection** – Steel
- **PVST with PVE PPRV and PP dump** – Steel

*PVS/PVSI*



*PVS/PVSI with LX-connection*



*PVSI with P-, T-, LX- and M-connection*




*PVST with T-connection*



## PVS End Plates


*PVSI start plate*




*PVSI with PVE PPRV*



*PVSD end plate*



*PVST with PVE PPRV and PP dump*




*Technical specification*

| Parameter | Minimum | Recommended range | Maximum |
|---|---|---|---|
| **Fluid temperature** | -30°C [-22°F] | 30 to 60°C [86 to 140°F] | 90° [194°F] |
| **Fluid viscosity** | 4 $mm^2/s$ [39 SUS] | 12 to 75 $mm^2/s$ [65 to 347 SUS] | 460 $mm^2/s$ [2128 SUS] |
| **Fluid cleanliness** | 23/19/16 (according to ISO 4406) | | |
| **Operating temperature** | Ambient: -30 to 60°C [-22 to 140°F] | | |

For more information about PVS End Plates, see:

*PVS/PVSI* on page 189
*PVS/PVSI with LX-connection* on page 191
*PVSI with P-, T-, LX- and M-connection* on page 193
*PVST with T-connection* on page 194
*PVSI Start Plate* on page 195
*PVSD End Plate* on page 196
*PVSI with PVE PPRV* on page 198
*PVST with PVE PPRV and PP dump* on page 200

## PVS End Plates

### PVS/PVSI

The PVS/PVSI are made of either aluminum or cast iron material and works as an end plate.


*The PVSI Start Plates features:*

- Integrated LS pressure relief valve to tank
- Optional integrated thermal orifice
- Optional version without seals

*PVS/PVSI*



*PVS/PVSI dimensions*




Weight: 0.47 kg [1.05 lb]

*PVS/PVSI schematic*



*Maximum pressure for P- and T-port*

| Max. P-port continuous | Max. P-port intermittent | Max. T-port static/dynamic |
|---|---|---|
| 300/350 bar [4351/5076 psi] | 400 bar [5800 psi] | 25/40 bar [365/580 psi] |

See part number table for details on maximum pressure capacity

*Technical specification*

| Parameter | Minimum | Recommended range | Maximum |
|---|---|---|---|
| **Fluid temperature** | -30°C [-22°F] | 30 to 60°C [86 to 140°F] | 90° [194°F] |
| **Fluid viscosity** | 4 $mm^2/s$ [39 SUS] | 12 to 75 $mm^2/s$ [65 to 347 SUS] | 460 $mm^2/s$ [2128 SUS] |
| **Fluid cleanliness** | 23/19/16 (according to ISO 4406) | | |
| **Operating temperature** | Ambient: -30 to 60°C [-22 to 140°F] | | |

*Part numbers for PVS end plates*

| Part number | Maximum pressure | Material | Weight kg [lb] | Seals | Mounting |
|---|---|---|---|---|---|
| **157B2000** | 300 bar [4351 psi] | Aluminum | 0.475 [1.05] | Yes | M8 |
| **157B2020** | 300 bar [4351 psi] | Aluminum | 0.475 [1.05] | Yes | 5/16-18 UNC |
| **157B2004** | 350 bar [5076 psi] | Cast iron | 1.745 [3.85] | Yes | 5/16-18 UNC |
| **157B2014** | 350 bar [5076 psi] | Cast iron | 1.745 [3.85] | Yes | M8 |
| **157B2017** | 350 bar [5076 psi] | Cast iron | 1.745 [3.85] | Yes | M10 |

## PVS End Plates

*Part numbers for PVS end plates (continued)*

| Part number | Maximum pressure | Material | Weight kg [lb] | Seals | Mounting |
|---|---|---|---|---|---|
| **157B2018** | 350 bar [5076 psi] | Cast iron | 1.745 [3.85] | No[1] | M8 |
| **157B2902**[2] | 350 bar [5076 psi] | Cast iron | 1.745 [3.85] | Yes | M8 |

[1] For use with priority modules.

[2] Thermal orifice 0.8 mm.

## PVS End Plates

### PVS/PVSI with LX-connection

The PVG 32 PVS end plates are placed at the end the valve stack section. Furthermore, the end plate is ensuring Load Sense (LS) is relieved to tank pressure when the valve is not operated. The LX port enables other remote valves to be connected onto the Load Sense shuttle network.

The PVS type end plates are made of aluminum while the PVSI types are made of cast iron thereby being able to withstand a higher pressure.


*The PVS/PVSI with LX-port connection features:*

- Integrated LS pressure relief valve to tank
- Threaded LX port for connecting another valve to LS network


*PVS/PVSI with LX-connection*



*PVS/PVSI with LX-connection dimensions*




*PVS/PVSI with LX-connection schematic*




*Maximum pressure for P- and T-port*

| Max. P-port continuous | Max. P-port intermittent | Max. T-port static/dynamic |
|---|---|---|
| 300/350 bar [4351/5076 psi] | 400 bar [5800 psi] | 25/40 bar [365/580 psi] |

See part number table for details on maximum pressure capacity

*Technical specification*

| Parameter | Minimum | Recommended range | Maximum |
|---|---|---|---|
| **Fluid temperature** | -30°C [-22°F] | 30 to 60°C [86 to 140°F] | 90° [194°F] |
| **Fluid viscosity** | 4 $mm^2/s$ [39 SUS] | 12 to 75 $mm^2/s$ [65 to 347 SUS] | 460 $mm^2/s$ [2128 SUS] |
| **Fluid cleanliness** | 23/19/16 (according to ISO 4406) | | |
| **Operating temperature** | Ambient: -30 to 60°C [-22 to 140°F] | | |

*Part numbers for PVS/PVSI with LX-port connection*

| Part number | Max. pressure | Material | Weight kg [lb] | LX port | Mounting |
|---|---|---|---|---|---|
| **157B2005** | 350 bar 5076 psi] | Cast iron | 1.695 [3.74] | 1/2-20 UNF | 5/16-18 UNC |
| **157B2015** | | | | G1/4" | M8 |
| **157B2910** | | | | M12x1.5 ISO 6149 | |

## PVS End Plates

*Part numbers for PVS/PVSI with LX-port connection (continued)*

| Part number | Max. pressure | Material | Weight kg [lb] | LX port | Mounting |
|---|---|---|---|---|---|
| **157B2011** | 300 bar [4351 psi] | Aluminum | 0.495 [1.09] | G1/8" | M8 |
| **157B2021** | | | | 3/8-24 UNF | 5/16-18 UNC |

## PVS End Plates

### PVSI with P-, T-, LX- and M-connection

PVSI is made of cast iron and works as an end plate. The PVSI with LX connection enables another valves LS pressure to be shuttled to the pump when needed. The additional P- and T-port connections enables an additional pump flow to a PVG 32 valve.


*The PVSI with P-, T-, LX- and M-connection features:*

- Integrated LS pressure relief valve to tank
- Threaded ports for P/T/LS/LX and M measuring gauge


*PVSI with P-, T-, LX- and M-connection*




*PVSI with P-, T-, LX- and M-connection dimensions*




*PVSI with P-, T-, LX- and M-connection schematic*




*Maximum pressure for P- and T-port*

| Max. P-port continuous | Max. P-port intermittent | Max. T-port static/dynamic |
|---|---|---|
| 300/350 bar [4351/5076 psi] | 400 bar [5800 psi] | 25/40 bar [365/580 psi] |

See part number table for details on maximum pressure capacity

*Technical specification*

| Parameter | Minimum | Recommended range | Maximum |
|---|---|---|---|
| **Fluid temperature** | -30°C [-22°F] | 30 to 60°C [86 to 140°F] | 90° [194°F] |
| **Fluid viscosity** | 4 $mm^2/s$ [39 SUS] | 12 to 75 $mm^2/s$ [65 to 347 SUS] | 460 $mm^2/s$ [2128 SUS] |
| **Fluid cleanliness** | 23/19/16 (according to ISO 4406) | | |
| **Operating temperature** | Ambient: -30 to 60°C [-22 to 140°F] | | |

*Part number for PVSI with P-, T-, LX-, M-ports*

| Part number | P-port | T-port | LX-port | M-port | Mounting feet | Weight |
|---|---|---|---|---|---|---|
| **157B2921** | G1/2 | G1/2 | G1/4 | G1/4 | M8 | 2.5 kg [5.51 lb] |

## PVS End Plates

### PVST with T-connection

The PVST end plate closes off the valve stack section placed between them by placing it at the end. Furthermore, the end plate is ensuring Load Sense (LS) is relieved to tank pressure when the valve is not operated.


*The PVSI Start Plates features:*

- Integrated LS pressure relief valve to tank
- Threaded T port
- Optional integrated thermal orifice


*PVST with T-connection*




*PVST with T-connection dimensions*




*PVST with T-connection schematic*




*Maximum pressure for P- and T-port*

| Max. P-port continuous | Max. P-port intermittent | Max. T-port static/dynamic |
|---|---|---|
| 300/350 bar [4351/5076 psi] | 400 bar [5800 psi] | 25/40 bar [365/580 psi] |

See part number table for details on maximum pressure capacity

*Technical specification*

| Parameter | Minimum | Recommended range | Maximum |
|---|---|---|---|
| **Fluid temperature** | -30°C [-22°F] | 30 to 60°C [86 to 140°F] | 90° [194°F] |
| **Fluid viscosity** | 4 $mm^2/s$ [39 SUS] | 12 to 75 $mm^2/s$ [65 to 347 SUS] | 460 $mm^2/s$ [2128 SUS] |
| **Fluid cleanliness** | 23/19/16 (according to ISO 4406) | | |
| **Operating temperature** | Ambient: -30 to 60°C [-22 to 140°F] | | |

When using a PVST with T-connection it is not possible to use the LS A/B fitting in the bottom of the PVG section next to the PVST.

*Part numbers for PVST with T-connection*

| Part number | Material | T-port | Mounting feet | Weight |
|---|---|---|---|---|
| **157B2500** | Steel | G1/2 | M8 | 0.47 kg [1.05 lb] |
| **157B2520** | | 7/8–14 | 5/16–18 | |

## PVS End Plates

*Part numbers for PVST with T-connection (continued)*

| Part number | Material | T-port | Mounting feet | Weight |
|---|---|---|---|---|
| **157B2913** | Iron | M22x1.5 DIN 3852-1 | M8 | 0.6 kg [1.32 lb] |
| **11004462** | | M22x1.5 ISO 6149 | | |

## PVSI Start Plate

The PVG 32 PVSI iron start plates is for use with PVPM in a closed center configuration for use with variable displacement pumps.


*The PVSI Start Plates features:*

- Integrated pilot pressure reducing valve (PPRV) for PVE
- Integrated sealing for groups with/without T0 port
- Threaded ports for LS and T0 port


*PVSI start plate*



*Dimensions*




*Schematic*




*Maximum pressure for P- and T-port*

| Max. P-port continuous | Max. P-port intermittent | Max. T-port static/dynamic |
|---|---|---|
| 300/350 bar [4351/5076 psi] | 400 bar [5800 psi] | 25/40 bar [365/580 psi] |

See part number table for details on maximum pressure capacity

*Part numbers for PVSI start plates*

| Part number | LS-, T0-port | Mounting | Weight |
|---|---|---|---|
| **11091772** | 9/16–18-UNF | 5/16-18 UNC | 1.6 kg [3.53 lb] |
| **11091773** | G1/4" | M8 | |


## PVS End Plates

### PVSD End Plate


The PVSD cast iron end plates are used for preventing T-line peaks and spillage and closing off the valve stack section at the end.

Furthermore, the end plate is ensuring Load Sense (LS) is relieved to tank pressure while the valve is not operated and features threaded P and V (spillage) ports.


*PVSD end plate*



*Schematic*





*Dimensions*



## PVS End Plates

*Pressure drop P to P characteristic*




*Maximum pressure, flow and leakage*

| Max. P-port continuous | Max. T-port static/ dynamic | Max. rated pump flow | V- port leakage |
|---|---|---|---|
| 210 bar [3046 psi] | 50 bar [725 psi] | 120 l/min [31.7 US gal/min] | 1 $cm^3$ [0.06 $in^3$] / hour |

See part number table for details on maximum pressure capacity

*Part number for PVSD end plate*

| Part number | P-, V-port | Weight | Mounting |
|---|---|---|---|
| **157B2904** | G1/4" | 3.01 kg [6.64 lb] | M8 |

## PVS End Plates

### PVSI with PVE PPRV

The PVG 32 PVS end plates close off the valve stack section placed between them by placing them at the end. Furthermore, the end plate is ensuring Load Sense (LS) is relieved to tank pressure when the valve is not operated.

The integrated pilot pressure reduction valve (PPRV) is intended a valve group with electro-hydraulic controlled work sections.


*The PVSI with PVE PPRV features:*

- Integrated pilot pressure reducing valve (PPRV) for PVE
- Threaded T0 port


*PVSI with PVE PPRV*




*Dimensions*




*Schematic*




*Pilot pressure reduction valve characteristics*



## PVS End Plates

*Maximum pressure for P- and T-port*

| Max. P-port continuous | Max. P-port intermittent | Max. T-port static/dynamic |
|---|---|---|
| 300/350 bar [4351/5076 psi] | 400 bar [5800 psi] | 25/40 bar [365/580 psi] |

See part number table for details on maximum pressure capacity

*Part number for PVSI with PVE PPRV plate*

| Part number | T0-port | Weight | Mounting |
|---|---|---|---|
| **157B2917** | M14x1.5 | 0.48 kg [1.05 lb] | M10 |

## PVS End Plates

### PVST with PVE PPRV and PP dump

The PVG 32 PVS end plates close off the valve stack section placed between them by placing them at the end. Furthermore, the end plate is ensuring Load Sense (LS) is relieved to tank pressure when the valve is not operated.


The integrated pilot pressure reduction valve (PPRV) is intended a valve group with electro-hydraulic controlled work sections. The pilot pressure can be dumped to tank thereby preventing any electrical activation of the work sections.

The selectable LX port enables other remote valves to be connected onto the Load Sense shuttle network.


*The PVST with PVE PPRV and PP dump features:*

- Integrated pilot pressure reducing valve (PPRV) for PVE
- Integrated pilot oil dump valve
- Threaded T and LX port
- Selector for LX or not LX modes

*PVST with PVE PPRV and PP dump*





*Schematic*




## PVS End Plates

*Dimensions*




*Pilot pressure reduction valve characteristics*




*Maximum pressure for P- and T-port*

| Max. P-port continuous | Max. P-port intermittent | Max. T-port static/dynamic |
|---|---|---|
| 300/350 bar [4351/5076 psi] | 400 bar [5800 psi] | 25/40 bar [365/580 psi] |

See part number table for details on maximum pressure capacity

*Part number for PVST with PPRV/PP dump*

| Part number | T0, LX-port | T- port | PP dump | Weight | Mounting |
|---|---|---|---|---|---|
| **11050065** | M14x1.5 | M22x1.5 | 12 $V_{DC}$ | 3.2 kg [7.05 lb] | M8 |

## PVSKM Full Flow Cut Off Modules

The PVG 32 PVSKM inline full flow cut-off module, also referred to as full flow cut-off modules, enables an integrated full flow cut-off and High Pressure Carry Over (HPCO) functionality by means of the integrated PVSKM spool, controlled either manually, hydraulically or electrohydraulically.

The PVG 32 PVSKM modules, also referred to as full flow cut-off modules, inline full flow cut-off of flow or as an HPCO, High Pressure Carry Over port.


The PVSKM module allows a position anywhere in the PVG 32 valve group, similar to a standard PVG 32 basic module. The freedom of position of the PVSKM module in the PVG 32 valve group enables a full flow cut-off, of the entire valve group, by placing the PVSKM right after the PVP inlet module, or only a part of the valve group, by placing the PVSKM elsewhere in the valve group.

The PVSKM module variants are based on a generic platform with a wide selection of additional features, enabling you to tailor the valve stack to comply with Category 2 or 3 safety systems according to ISO 13849.


*The PVSKM Full Flow Cut-Off Module features:*

- Threaded port for HPCO port
- Optional T0 facility and external T0 port
- Different PVSKM spool types depending on requested HPCO flow capacity

*PVSKM Full Flow Cut Off module*




*PVSKM schematic*




## PVSKM Full Flow Cut Off Modules

### PVSKM Functionality


*Neutral mode*



*PVG mode*




*HPCO mode*




*Maximum pressure for P- and T-port*

| Max. P-port continuous | Max. P-port intermittent | Max. T-port static/dynamic |
|---|---|---|
| 300/350 bar [4351/5076 psi] | 400 bar [5800 psi] | 25/40 bar [365/580 psi] |

*Technical specification*

| Parameter | Minimum | Recommended range | Maximum |
|---|---|---|---|
| **Fluid temperature** | -30°C [-22°F] | 30 to 60°C [86 to 140°F] | 90° [194°F] |
| **Fluid viscosity** | 4 $mm^2/s$ [39 SUS] | 12 to 75 $mm^2/s$ [65 to 347 SUS] | 460 $mm^2/s$ [2128 SUS] |
| **Fluid cleanliness** | 23/19/16 (according to ISO 4406) | | |
| **Operating temperature** | Ambient: -30 to 60°C [-22 to 140°F] | | |

## PVSKM Full Flow Cut Off Modules


*Part number for PVSKM module*

| Part number | P-port/HPCO-port | T0 Facility | Mounting |
|---|---|---|---|
| **11099469** | G3/4" | yes | M8 |
| **11107369** | 1 1/16-12 UN | yes | |
| **11117252** | G3/4" | - | |

## PVSKM Full Flow Cut Off Modules


### PVSKM Spool

*PVSKM Spool schematic*




#### Theoretical Performance

*Pressure drop P to P characteristic*




*Pressure drop from P to HPCO characteristics*



## PVSKM Full Flow Cut Off Modules

*Part number for PVSKM spool*

| Part number | HPCO flow | Actuation method |
|---|---|---|
| **11100036** | 150 l/min [39.6 US gal/min] | PVE |
| **11116733** | 40 l/min [10.6 US gal/min] | |
| **11116734** | 100 l/min [26.4 US gal/min] | |
| **11111293** | 150 l/min [39.6 US gal/min] | PVH/PVHC |

## PVAS Stay Bolts

PVAS Stay Bolts kit for various PVG combinations consist of three tie rods, six washers, six nuts and O-ring. Use the guide and reference tables how to choose PVAS kit.

The tie rods are inserted through the entire length of the PVG valve stack. The nuts are tightened at the pump side and at the end plate.

To find the PVAS kit that fits your PVG 16 valve stack, you need to go to the table *PVG 32 modules total length* on page 208 and find the length. Then go to the table *PVAS Part Numbers* on page 207 and find the matching part number.

For stay bolts for a PVG 32/16 combination, see this *PVG 32/16 Combinations* on page 208.

Stay bolts for PVG 256/128/32/16 combinations consist of two different kits. See *PVG 256/128/32/16 Combinations* on page 209 to find the right kits for your combination.

Combinations with PVG 100 and PVG 120 requires special PVAS kits. These are not included in the PVAS table.

## PVAS Part Numbers

PVAS part numbers according to accumulated length interval PVG 32.

*PVAS part numbers*

| Length, mm [in] | Part number | Length, mm [in] | Part number |
|---|---|---|---|
| 20 – 48 [0.79 – 1.89] | **11188219** | 361 – 372 [14.21 – 14.65] | **11188205** |
| 49 – 60 [1.93 – 2.36] | **11188218** | 373 – 384 [14.69 – 15.12] | **157B8026** |
| 61 – 72 [2.40 – 2.83] | **157B8000** | 385 – 396 [15.16 – 15.59] | **11188204** |
| 73 – 84 [2.87 – 3.31] | **11188217** | 397 – 408 [15.63 – 16.06] | **157B8007** |
| 85 – 96 [3.35 – 3.78] | **157B8031** | 409 – 420 [16.10 – 16.54] | **11188203** |
| 97 – 108 [3.82 – 4.25] | **11188216** | 421 – 432 [16.58 – 17.01] | **157B8027** |
| 109 – 120 [4.29 – 4.72] | **157B8001** | 433 – 444 [17.05 – 17.48] | **11188202** |
| 121 – 132 [4.76 – 5.20] | **11188215** | 445 – 456 [17.52 – 17.95] | **157B8008** |
| 133 – 144 [5.24 – 5.67] | **157B8021** | 457 – 468 [17.99 – 18.43] | **11188201** |
| 145 – 156 [5.71 – 6.14] | **11188214** | 469 – 480 [18.47 – 18.90] | **157B8028** |
| 157 – 168 [6.18 – 6.61] | **157B8002** | 481 - 492 [18.94 – 19.37] | **11188200** |
| 169 – 180 [6.65 – 7.09] | **11188213** | 493 – 504 [19.41 – 19.84] | **157B8009** |
| 181 – 192 [7.13 – 7.56] | **157B8022** | 505 – 516 [19.88 – 20.31] | **11188199** |
| 193 – 204 [7.60 – 8.03] | **11188212** | 517 – 528 [20.35 – 20.79] | **157B8029** |
| 205 – 216 [8.07 – 8.50] | **157B8003** | 529 – 540 [20.83 – 21.26] | **11188198** |
| 217 – 228 [8.54 – 8.98] | **11188211** | 541 – 552 [21.30 – 21.73] | **157B8010** |
| 229 – 240 [9.02 – 9.45] | **157B8023** | 553 – 564 [21.77 - 22.20] | **11188197** |
| 241 – 252 [9.49 – 9.92] | **11188210** | 565 – 576 [22.24 – 22.68] | **157B8030** |
| 253 – 264 [9.96 – 10.39] | **157B8004** | 577 – 588 [22.72 – 23.15] | **11188196** |
| 265 – 276 [10.43 – 10.87] | **11188209** | 589 – 600 [23.19 – 23.62] | **157B8061** |
| 277 – 288 [10.91 – 11.34] | **157B8024** | 601 – 612 [23.66 – 24.09] | **11188195** |
| 289 – 300 [11.38 – 11.81] | **11188208** | 613 – 624 [24.13 – 24.57] | **157B8081** |
| 301 – 312 [11.85 – 12.28] | **157B8005** | 625 – 636 [24.61 – 25.04] | **11188194** |
| 313 – 324 [12.32 – 12.76] | **11188207** | 637 – 648 [25.08 – 25.51] | **157B8062** |
| 325 – 336 [12.80 – 13.23] | **157B8025** | 649 – 660 [25.55 – 25.98] | **11188189** |
| 337 – 348 [13.27 – 13.70] | **11188206** | 661 - 672 [26.02 – 26.46] | **157B8082** |
| 349 – 360 [13.74 – 14.17] | **157B8006** | | |

## PVAS Stay Bolts

### PVG 32 modules total length

Table with total length of the PVG 32 depending on the number of PVB modules.

| No. of PVB 32 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| Length mm [in] | 119 [4.69] | 167 [6.57] | 215 [8.46] | 263 [10.35] | 311 [12.24] | 359 [14.13] | 407 [16.02] | 455 [17.91] | 503 [19.80] | 551 [21.69] | 599 [23.58] | 647 [25.47] |

### PVG 32/16 Combinations

The table of PVB 32 and PVB 16 modules combination, the total length depending on the amount of valve groups.

| | | PVB 16 | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| Modules in mm [in] | | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 |
| PVB 32 | 1 | 159 [6.26] | 199 [7.83] | 239 [9.41] | 279 [10.98] | 319 [12.56] | 359 [14.13] | 399 [15.71] | 439 [17.28] | 479 [18.86] | 519 [20.43] | 559 [22.01] |
| | 2 | 207 [8.15] | 247 [9.72] | 287 [11.30] | 327 [12.87] | 367 [14.45] | 407 [16.02] | 447 [17.60] | 487 [19.17] | 527 [20.74] | 567 [22.32] | 607 [23.90] |
| | 3 | 255 [10.04] | 295 [11.61] | 335 [13.19] | 375 [14.76] | 415 [16.34] | 455 [17.91] | 495 [19.49] | 535 [21.06] | 575 [22.64] | 615 [24.21] | 655 [25.79] |
| | 4 | 303 [11.93] | 343 [13.50] | 383 [15.08] | 423 [16.65] | 463 [18.23] | 503 [19.80] | 543 [21.38] | 583 [22.95] | 623 [24.53] | 663 [26.10] | - |
| | 5 | 351 [13.82] | 391 [15.39] | 431 [16.97] | 471 [18.54] | 511 [20.12] | 551 [21.69] | 591 [23.27] | 631 [24.84] | 671 [26.42] | - | - |
| | 6 | 399 [15.71] | 439 [17.28] | 479 [18.86] | 519 [20.43] | 559 [22.01] | 599 [23.58] | 639 [25.16] | - | - | - | - |
| | 7 | 447 [17.60] | 487 [19.17] | 527 [20.75] | 567 [22.32] | 607 [23.90] | 647 [25.47] | - | - | - | - | - |
| | 8 | 495 [19.49] | 535 [21.06] | 575 [22.64] | 615 [24.21] | 655 [25.79] | - | - | - | - | - | - |
| | 9 | 543 [21.38] | 583 [22.95] | 623 [24.53] | 663 [26.10] | - | - | - | - | - | - | - |
| | 10 | 591 [23.27] | 631 [24.84] | 671 [26.42] | - | - | - | - | - | - | - | - |
| | 11 | 639 [25.16] | - | - | - | - | - | - | - | - | - | - |

## PVAS Stay Bolts

### PVG 256/128/32/16 Combinations

The tables of PVB 256/128, 32/16 modules, total length depending on the amount of valve groups.

Stay bolts for PVG 128/256/32/16 combinations consist of 2 different kits:

1. For PVAS containing 2 stay bolts – please look in the *Table 1* below and use the part number before the + symbol.
2. For PVAS containing 3 stay bolts – please look in *Table 1* below and write down the length in millimeters which is the number after the + symbol. Next you add the number from *Table 2* below. Now find the part number for the needed stay bolts in the table *PVAS Part Numbers* on page 207.

O-rings are a part of the PVAS kits – no additional part number needed.

**Caution**

It is not possible to do combinations exceeding **672 mm**.

**Example**

For 2 PVB 256 and 1 PVB 128 and 1 PVB 32 and 2 PVB 16: PVAS 1 Part number = **11187681** from *Table 1*.

PVAS 2 = **278** mm from *Table 1* + **152** mm from *Table 2*= 278+152 =430 mm which equals **157B8027** in the PVAS table.

*Table 2 – PVG 256/128 combinations*

| | | PVB 256 | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|
| **Modules (mm)** | | **0** | **1** | **2** | **3** | **4** | **5** | **6** | **7** |
| **PVB 128** | 0 | 11187676+ 40 | 11187672+ 126 | 11187673+ 212 | 11187656+ 298 | 11187675+ 384 | 11187696+ 470 | 11187697+ 556 | 11187698+ 642 |
| | **1** | 11187320+ 106 | 11187677+ 192 | **11187681+ 278** | 11187658+ 364 | 11187685+ 450 | 11187687+ 536 | 11187690+ 622 | |
| | **2** | 11187617+ 172 | 11187678+ 258 | 11187682+ 344 | 11187686+ 430 | 11187691+ 516 | 11187704+ 602 | | |
| | **3** | 11187655+ 238 | 11187679+ 324 | 11187683+ 410 | 11187705+ 496 | 11187694+ 582 | 11187695+ 668 | | |
| | **4** | 11187684+ 304 | 11187680+ 390 | 11187696+ 476 | 11187697+ 562 | 11187689+ 648 | | | |
| | **5** | 11187658+ 370 | 11187699+ 456 | 11187688+ 542 | 11187710+ 628 | | | | |
| | **6** | 11187693+ 436 | 11187703+ 522 | 11187704+ 608 | | | | | |
| | **7** | 11187705+ 502 | 11187694+ 588 | | | | | | |
| | **8** | 11187692+ 568 | 11187709+ 654 | | | | | | |
| | **9** | 11187710+ 634 | | | | | | | |

## PVAS Stay Bolts


*Table 2 – PVG 32/16 combinations*

| | | PVB 16 | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| **Modules (mm)** | | **0** | **1** | **2** | **3** | **4** | **5** | **6** | **7** | **8** | **9** | **10** |
| **PVB 32** | **0** | - | 64 | 104 | 144 | 184 | 224 | 264 | 304 | 344 | 384 | 424 |
| | **1** | 72 | 112 | **152** | 192 | 232 | 272 | 312 | 352 | 392 | 432 | - |
| | **2** | 120 | 160 | 200 | 240 | 280 | 320 | 360 | 400 | 440 | - | - |
| | **3** | 168 | 208 | 248 | 288 | 328 | 368 | 408 | 448 | - | - | - |
| | **4** | 216 | 256 | 296 | 236 | 276 | 416 | 456 | - | - | - | - |
| | **5** | 264 | 304 | 344 | 384 | 424 | 464 | - | - | - | - | - |
| | **6** | 312 | 352 | 392 | 432 | 472 | - | - | - | - | - | - |
| | **7** | 360 | 400 | 440 | 480 | - | - | - | - | - | - | - |
| | **8** | 408 | 448 | 488 | - | - | - | - | - | - | - | - |
| | **9** | 456 | 496 | - | - | - | - | - | - | - | - | - |
| | **10** | 504 | - | - | - | - | - | - | - | - | - | - |


## PVG 32 Combinations Valve Stack Dimensions

### PVG 32 Dimensions


*PVG 32 with PVE actuator*




*PVG 32 with PVHC*



## PVG 32 Combinations Valve Stack Dimensions





| Number of PVB 32 | | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| L1 | mm [in] | 82 [3.23] | | 178 [7.01]130 [5.12] | 226 [8.90] | 274 [10.79] | 322 [12.68] | 370 [14.57] | 418 [16.46] | 466 [18.35] | 514 [20.24] | 562 [22.13] | 610 [24.02] |
| L2 | 130 [5.12mm [in] | 141 [5.55] | 190 [7.48] | 238 [9.37] | 287 [11.30] | 335 [13.19] | 384 [15.12] | 432 [17.01] | 481 [18.94] | 529 [20.83] | 578 [22.76] | 626 [24.65] | 675 [26.57] |
| Weight | kg [lb] | 8,33 [18.36] | 11,46 [25.26] | 14,53 [32.03] | 17,66 [38.93] | 20,74 [45.72] | 23,81 [52.49] | 26,94 [59.39] | 30,01 [66.16] | 33,09 [72.95] | 36,21 [79.83] | 39,29 [86.62] | 42,26 [93.17] |

Weight is for a PVG 32 with PVEO series 7 on each working section and is only approximate.

## PVG 32 Combinations Valve Stack Dimensions

### PVG 32/16 Dimensions

The table of PVB 32 and PVB 16 combination valve stack dimensions overview table with accompanying drawing.




*PVB 32/16 combination valve stack dimensions, mm [in]*

| Number of PVB 32 (down) | | Number of PVB 16 modules | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | **1** | **2** | **3** | **4** | **5** | **6** | **7** | **8** | **9** | **10** | **11** |
| **1** | L1 | 122 [4.80] | 162 [6.38] | 202 [7.95] | 242 [9.53] | 282 [11.10] | 322 [12.68] | 362 [14.25] | 402 [15.83] | 442 [17.40] | 482 [18.98] | 522 [20.55] |
| | L2 | 189 [7.44] | 238 [9.37] | 262 [10.31] | 311 [12.24] | 360 [14.17] | 385 [15.16] | 434 [17.09] | 483 [19.02] | 507 [19.96] | 551 [21.69] | 600 [23.62] |
| **2** | L1 | 170 [6.69] | 210 [8.27] | 250 [9.84] | 290 [11.42] | 330 [12.99] | 370 [14.57] | 410 [16.14] | 450 [17.72] | 490 [19.29] | 530 [20.87] | 570 [22.44] |
| | L2 | 238 [9.37] | 287 [11.30] | 311 [12.24] | 360 [14.17] | 409 [16.10] | 434 [17.09] | 483 [19.02] | 507 [19.96] | 551 [21.69] | 600 [23.62] | 646 [25.43] |
| **3** | L1 | 218 [8.58] | 258 [10.16] | 298 [11.73] | 338 [13.31] | 378 [14.88] | 418 [16.46] | 458 [18.03] | 498 [19.61] | 538 [21.18] | 578 [22.76] | - |
| | L2 | 287 [11.30] | 336 [13.23] | 360 [14.17] | 409 [16.10] | 458 [18.03] | 483 [19.02] | 527 [20.75] | 576 [22.68] | 600 [23.62] | 646 [25.43] | - |
| **4** | L1 | 266 [10.47] | 306 [12.05] | 346 [13.62] | 386 [15.20] | 426 [16.77] | 466 [18.35] | 506 [19.92] | 546 [21.50] | 586 [23.07] | - | - |
| | L2 | 336 [13.23] | 385 [15.16] | 409 [16.10] | 458 [18.03] | 483 [19.02] | 527 [20.75] | 576 [22.68] | 622 [24.49] | 646 [25.43] | - | - |
| **5** | L1 | 314 [12.36] | 354 [13.94] | 394 [15.51] | 434 [17.09] | 474 [18.66] | 514 [20.24] | 554 [21.81] | 594 [23.39] | - | - | - |
| | L2 | 385 [15.16] | 434 [17.09] | 458 [18.03] | 507 [19.96] | 551 [21.69] | 576 [22.68] | 622 [24.49] | 670 [26.38] | - | - | - |
| **6** | L1 | 362 [14.25] | 402 [15.83] | 442 [17.40] | 482 [18.98] | 522 [20.55] | 562 [22.13] | 602 [23.70] | - | - | - | - |
| | L2 | 434 [17.09] | 483 [19.02] | 507 [19.96] | 551 [21.69] | 600 [23.62] | 622 [24.49] | 670 [26.38] | - | - | - | - |
| **7** | L1 | 410 [16.14] | 450 [17.72] | 490 [19.29] | 530 [20.87] | 570 [22.44] | 610 [24.02] | - | - | - | - | - |
| | L2 | 483 [19.02] | 527 [20.75] | 551 [21.69] | 600 [23.62] | 646 [25.43] | 670 [26.38] | - | - | - | - | - |
| **8** | L1 | 458 [18.03] | 498 [19.61] | 538 [21.18] | 578 [22.76] | - | - | - | - | - | - | - |
| | L2 | 527 [20.75] | 576 [22.68] | 600 [23.62] | 646 [25.43] | - | - | - | - | - | - | - |

## PVG 32 Combinations Valve Stack Dimensions

*PVB 32/16 combination valve stack dimensions, mm [in] (continued)*

| Number of PVB 32 (down) | | Number of PVB 16 modules | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 |
| 9 | L1 | 506 [19.92] | 546 [21.50] | 586 [23.07] | - | - | - | - | - | - | - | - |
| | L2 | 576 [22.68] | 622 [24.49] | 646 [25.43] | - | - | - | - | - | - | - | - |
| 10 | L1 | 554 [21.81] | 594 [23.39] | - | - | - | - | - | - | - | - | - |
| | L2 | 622 [24.49] | 670 [26.38] | - | - | - | - | - | - | - | - | - |
| 11 | L1 | 602 [23.70] | - | - | - | - | - | - | - | - | - | - |
| | L2 | 670 [26.38] | - | - | - | - | - | - | - | - | - | - |

**Weight for a PVG 32/16 valve stack**

*The combined weight of a PVG 32/16 valve stack can be defined like this:*


**(Numbers of PVB 32 x 4,42) + (numbers of PVB 16 x 3,67) + 3,6 = Weight in kg**

**(Numbers of PVB 32 x 9.75) + (numbers of PVB 16 x 8.09) + 7.95 = Weight in lb**

## PVG 32 Combinations Valve Stack Dimensions

### PVG 100/32 Dimensions

The table of PVB 100 and PVB 32 combination valve stack dimensions overview table with accompanying drawing.




*PVB 100/32 combination valve stack dimensions, mm [in]*

| Number of PVB 100 (down) | | Number of PVB 32 modules | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | **1** | **2** | **3** | **4** | **5** | **6** | **7** | **8** | **9** | **10** | **11** |
| **1** | L1 | 168 | 216 | 264 | 312 | 360 | 408 | 456 | 504 | 552 | 600 | 648 |
| | | [6,61] | [8,50] | [10,39] | [12,28] | [14,17] | [16,06] | [17,95] | [19,84] | [21,73] | [23,62] | [25,51] |
| | L3 | 80 mm [3.15 in] | | | | | | | | | | |
| **2** | L1 | 216 | 264 | 312 | 360 | 408 | 456 | 504 | 552 | 600 | 648 | 696 |
| | | [8,50] | [10,39] | [12,28] | [14,17] | [16,06] | [17,95] | [19,84] | [21,73] | [23,62] | [25,51] | [27,40] |
| | L3 | 128 mm [5.04 in] | | | | | | | | | | |
| **3** | L1 | 264 | 312 | 360 | 408 | 456 | 504 | 552 | 600 | 648 | 696 | 744 |
| | | [10,39] | [12,28] | [14,17] | [16,06] | [17,95] | [19,84] | [21,73] | [23,62] | [25,51] | [27,40] | [29,29] |
| | L3 | 176 mm [6.93 in] | | | | | | | | | | |
| **4** | L1 | 312 | 360 | 408 | 456 | 504 | 552 | 600 | 648 | 696 | 744 | 792 |
| | | [12,28] | [14,17] | [16,06] | [17,95] | [19,84] | [21,73] | [23,62] | [25,51] | [27,40] | [29,29] | [31,18] |
| | L3 | 224 mm [8.82 in] | | | | | | | | | | |

## PVG 32 Combinations Valve Stack Dimensions

*PVB 100/32 combination valve stack dimensions, mm [in] (continued)*

| Number of PVB 100 (down) | | Number of PVB 32 modules | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | **1** | **2** | **3** | **4** | **5** | **6** | **7** | **8** | **9** | **10** | **11** |
| **5** | L1 | 360 | 408 | 456 | 504 | 552 | 600 | 648 | 696 | 744 | 792 | 840 |
| | | [14,17] | [16,06] | [17,95] | [19,84] | [21,73] | [23,62] | [25,51] | [27,40] | [29,29] | [31,18] | [33,07] |
| | L3 | 272 mm [10.71 in] | | | | | | | | | | |
| **6** | L1 | 408 | 456 | 504 | 552 | 600 | 648 | 696 | 744 | 792 | 840 | 888 |
| | | [16,06] | [17,95] | [19,84] | [21,73] | [23,62] | [25,51] | [27,40] | [29,29] | [31,18] | [33,07] | [34,96] |
| | L3 | 320 mm [12.60 in] | | | | | | | | | | |
| **7** | L1 | 456 | 504 | 552 | 600 | 648 | 696 | 744 | 792 | 840 | 888 | 936 |
| | | [17,95 | [19,84 | [21,73 | [23,62 | [25,51 | [27,40 | [29,29 | [31,18 | [33,07 | [34,96 | [36,85 |
| | L3 | 368 mm [14.49 in] | | | | | | | | | | |
| **8** | L1 | 504 | 552 | 600 | 648 | 696 | 744 | 792 | 840 | 888 | 936 | 984 |
| | | [19,84] | [21,73] | [23,62] | [25,51] | [27,40] | [29,29] | [31,18] | [33,07] | [34,96] | [36,85] | [38,74] |
| | L3 | 416 mm [16.38 in] | | | | | | | | | | |

**Weight for a PVG 100/32 valve stack**

*The combined weight of a PVG 100/32 valve stack can be defined like this:*


**(Numbers of PVB 100 x 7) + (numbers of PVB 32 x 4.42) + 10 = Weight (kg)**

**(Numbers of PVB 100 x 9.37) + (numbers of PVB 32 x 9.75) + 22 = Weight (lb)**

## PVG 32 Combinations Valve Stack Dimensions

### PVG 120/32 Dimensions

The table of PVB 120 and PVB 32 combination valve stack dimensions overview table with accompanying drawing.




There is a horizontal difference 62.5 mm [2.46 in] in the mounting plane of the PVG 120/PVG 16. Due to the large size of the PVG 120 interface-module it is necessary to have at least one PVG 32 module between the PVGI and the first PVG 32 slice.

*PVB 120/32 combination valve stack dimensions, mm [in]*

| Number of PVB 120 (down) | | Number of PVB 32 modules | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | **1** | **2** | **3** | **4** | **5** | **6** | **7** | **8** | **9** | **10** | **11** |
| **1** | L1 | 292 | 340 | 388 | 436 | 484 | 532 | 580 | 628 | 676 | 724 | 772 |
| | | [11.50] | [13.39] | [15.28] | [17.17] | [19.06] | [20.94] | [22.83] | [24.72] | [26.61] | [28.50] | [30.39] |
| | L3 | 170 mm [6.69 in] | | | | | | | | | | |
| **2** | L1 | 359 | 407 | 455 | 503 | 551 | 599 | 647 | 695 | 743 | 791 | 839 |
| | | [14.13] | [16.02] | [17.91] | [19.80] | [21.69] | [23.58] | [25.47] | [27.36] | [29.25] | [31.14] | [33.03] |
| | L3 | 237 mm [9.33 in] | | | | | | | | | | |
| **3** | L1 | 426 | 474 | 522 | 570 | 618 | 666 | 714 | 762 | 810 | 858 | 906 |
| | | [16.77] | [18.66] | [20.55] | [22.44] | [24.33] | [26.22] | [28.11] | [30.00] | [31.89] | [33.78] | [35.67] |
| | L3 | 304 mm [11.91 in] | | | | | | | | | | |

## PVG 32 Combinations Valve Stack Dimensions

*PVB 120/32 combination valve stack dimensions, mm [in] (continued)*

| Number of PVB 120 (down) | | Number of PVB 32 modules | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | **1** | **2** | **3** | **4** | **5** | **6** | **7** | **8** | **9** | **10** | **11** |
| **4** | L1 | 493 | 541 | 589 | 637 | 685 | 733 | 781 | 829 | 877 | 925 | 973 |
| | | [19.41] | [21.30] | [23.19] | [25.08] | [26.97] | [28.86] | [30.75] | [32.64] | [34.53] | [36.42] | [38.31] |
| | L3 | 371 mm [14.61 in] | | | | | | | | | | |
| **5** | L1 | 560 | 608 | 656 | 704 | 752 | 800 | 848 | 896 | 944 | 992 | 1040 |
| | | [22.05] | [23.94] | [25.83] | [27.72] | [29.61] | [31.50] | [33.39] | [35.28] | [37.17] | [39.06] | [40.94] |
| | L3 | 438 mm [17.24 in] | | | | | | | | | | |
| **6** | L1 | 627 | 675 | 723 | 771 | 819 | 867 | 915 | 963 | 1011 | 1059 | 1107 |
| | | [24.69] | [26.57] | [28.46] | [30.35] | [32.24] | [34.13] | [36.02] | [37.91] | [39.80] | [41.69] | [43.58] |
| | L3 | 505 mm [19.88 in] | | | | | | | | | | |
| **7** | L1 | 694 | 742 | 790 | 838 | 886 | 934 | 982 | 1030 | 1078 | 1126 | 1174 |
| | | [27.32] | [29.21] | [31.10] | [32.99] | [34.88] | [36.77] | [38.66] | [40.55] | [42.44] | [44.33] | [46.22] |
| | L3 | 572 mm [22.52 in] | | | | | | | | | | |
| **8** | L1 | 761 | 809 | 857 | 905 | 953 | 1001 | 1049 | 1097 | 1145 | 1193 | 1241 |
| | | [29.96] | [31.85] | [33.74] | [35.63] | [37.52] | [39.41] | [41.30] | [43.19] | [45.08] | [46.97] | [48.86] |
| | L3 | 639 mm [25.16 in] | | | | | | | | | | |

**Weight for a PVG 120/32 valve stack**

*The combined weight of a PVG 120/32 valve stack can be defined like this:*


**(Numbers of PVB 120 x 13.5) + (numbers of PVB 32 x 4.42) + 11.5 = Weight (kg)**

**(Numbers of PVB 120 x 29.76) + (numbers of PVB 32 x 9.75) + 25.4 = Weight (lb)**

## PVG 32 Combinations Valve Stack Dimensions

### PVG 128/32 Dimensions

The table of PVB 128 and PVB 32 combination valve stack dimensions overview table with accompanying drawing.




*PVB 128/32 combination valve stack dimensions, mm [in]*

| Number of PVB 128 (down) | | Number of PVB 32 modules | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | **1** | **2** | **3** | **4** | **5** | **6** | **7** | **8** | **9** | **10** | **11** |
| **1** | L1 | 181 [7.13] | 229 [9.02] | 277 [10.91] | 325 [12.80] | 373 [14.69] | 421 [16.57] | 469 [18.46] | 517 [20.35] | 565 [22.24] | 613 [24.13] | 661 [26.02] |
| | L2 | 249.5 [9.82] | 297,5 [11,71] | 346,5 [13,64] | 394,5 [15,53] | 417,5 [16,44] | 443,5 [17,46] | 540,5 [21,28] | 588,5 [23,17] | 637,5 [25,10] | 685,5 [26,99] | 734,5 [28,92] |
| | L3 | 98,5 mm [3.88 in] | | | | | | | | | | |
| **2** | L1 | 247,0 [9,72] | 295,0 [11,61] | 343,0 [13,50] | 391,0 [15,39] | 439,0 [17,28] | 487,0 [19,17] | 535,0 [21,06] | 583,0 [22,95] | 631,0 [24,84] | – | – |
| | L2 | 321,5 [12,66] | 370,5 [14,59] | 418,5 [16,48] | 467,5 [18,41] | 515,5 [20,30] | 564,5 [22,22] | 612,5 [24,11] | 661,5 [26,04] | 709,5 [27,93] | – | – |
| | L3 | 164,5 mm [6.48 in] | | | | | | | | | | |
| **3** | L1 | 313,0 [12,32] | 361,0 [14,21] | 409,0 [16,10] | 457,0 [17,99] | 505,0 [19,88] | 553,0 [21,77] | 601,0 [23,66] | 649,0 [25,55] | – | – | – |
| | L2 | 382,5 [15,06] | 431,5 [16,99] | 479,5 [18,88] | 528,5 [20,81] | 576,5 [22,70] | 625,5 [24,63] | 673,5 [26,52] | 722,5 [28,44] | – | – | – |
| | L3 | 230,5 mm [9.07 in] | | | | | | | | | | |
| **4** | L1 | 379,0 [14,92] | 427,0 [16,81] | 475,0 [18,70] | 523,0 [20,59] | 571,0 [22,48] | 619,0 [24,37] | 667,0 [26,26] | – | – | – | – |
| | L2 | 455,5 [17,93] | 503,5 [19,82] | 552,5 [21,75] | 600,5 [23,64] | 649,5 [25,57] | 697,5 [27,46] | 746,5 [29,39] | – | – | – | – |
| | L3 | 296,5 mm [11.67] | | | | | | | | | | |
| **5** | L1 | 445,0 17,52 | 493,0 19,41 | 541,0 21,30 | 589,0 23,19 | 637,0 25,08 | – | – | – | – | – | – |
| | L2 | 515,5 [20,30] | 564,5 [22,22] | 612,5 [24,11] | 661,5 [26,04] | 709,5 [27,93] | – | – | – | – | – | – |
| | L3 | 362,5 mm [14.27] | | | | | | | | | | |

## PVG 32 Combinations Valve Stack Dimensions

*PVB 128/32 combination valve stack dimensions, mm [in] (continued)*

| Number of PVB 128 (down) | | Number of PVB 32 modules | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | **1** | **2** | **3** | **4** | **5** | **6** | **7** | **8** | **9** | **10** | **11** |
| **6** | L1 | 511,0<br>20,12 | 559,0<br>22,01 | 607,0<br>23,90 | 655,0<br>25,79 | – | – | – | – | – | – | – |
| | L2 | 588,5<br>[23,17] | 637,5<br>[25,10] | 685,50<br>[26,99] | 734,50<br>[28,92] | – | – | – | – | – | – | – |
| | L3 | 428,5 mm [16.87] | | | | | | | | | | |
| **7** | L1 | 577,0<br>22,72 | 625,0<br>24,61 | 673,0<br>26,50 | – | – | – | – | – | – | – | – |
| | L2 | 649,5<br>[25,57] | 697,5<br>[27,46] | 746,5<br>[29,39] | – | – | – | – | – | – | – | – |
| | L3 | 494,5 mm [19.47] | | | | | | | | | | |
| **8** | L1 | 643,0<br>25,31 | – | – | – | – | – | – | – | – | – | – |
| | L2 | 722,50<br>[28,44] | – | – | – | – | – | – | – | – | – | – |
| | L3 | 560,5 mm [22.07] | | | | | | | | | | |

### Weight for a PVG 128/32 valve stack

*The weight is for a combined PVG 128/32 valve stack with a PVEO Series 7 on each working section and is only approximate, can be defined like this:*


**(Numbers of PVB 128 x 16.9) + (numbers of PVB 32 x 4,42) + 17.5 = Weight (kg)**

**(Numbers of PVB 128 x 37.26) + (numbers of PVB 32 x 9.75) + 38.6 = Weight (lb)**

## PVG 32 Combinations Valve Stack Dimensions

### PVG 256/32 Dimensions

The table of PVB 256 and PVB 32 combination valve stack dimensions overview table with accompanying drawing.




*PVB 256/32 combination valve stack dimensions, mm [in]*

| Number of PVB 256 (down) | | Number of PVB 32 modules | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| | | **1** | **2** | **3** | **4** | **5** | **6** | **7** | **8** | **9** | **10** |
| **1** | L1 | 201 [7.91] | 249 [9.80] | 297 [11.69] | 345 [13.58] | 393 [15.47] | 441 [1.36] | 489 [19.25] | 537 [21.14] | 585 [23.03] | 633 [24.92] |
| | L2 | 273,5 [10.77] | 321,5 [12.66] | 370,5 [14.59] | 418,5 [16.48] | 467,5 [18.41] | 515,5 [20.30] | 564,5 [22.22] | 612,5 [24.11] | 661,5 [26.04] | 709,5 [27.93] |
| | L3 | 118,5 mm [4.67 in] | | | | | | | | | |
| **2** | L1 | 287 [11.30] | 335 [13.19] | 383 [15.08] | 431 [16.97] | 479 [18.86] | 527 [20.75] | 575 [22.64] | 623 [24.53] | 671 [26.42] | – |
| | L2 | 358,5 [14.11] | 406,5 [16.0] | 455,5 [17.93] | 503,5 [19.82] | 552,5 [21.75] | 600,5 [23.64] | 649,5 [25.57] | 697,5 [27.46] | 746,5 [29.9] | – |
| | L3 | 204,5 mm [8.05 in] | | | | | | | | | |
| **3** | L1 | 373 [14.69] | 421 [16.57] | 469 [18.46] | 517 [20.35] | 565 [22.24] | 613 [24.13] | 661 [26.02] | – | – | – |
| | L2 | 443,5 [17,46] | 491,5 [19,35] | 540,5 [21,28] | 588,5 [23,17] | 637,5 [25,10] | 685,5 [26,99] | 734,5 [28,92] | – | – | – |
| | L3 | 290,5 mm [11.44 in] | | | | | | | | | |
| **4** | L1 | 459 [18,07] | 507 [19,96] | 555 [21,85] | 603 [23,74] | 651 [25,63] | – | – | – | – | – |
| | L2 | 528,5 [20,81] | 576,5 [22,70] | 625,5 [24,63] | 673,5 [26,52] | 722,5 [28,44] | – | – | – | – | – |
| | L3 | 376,5 mm [14.82 in] | | | | | | | | | |
| **5** | L1 | 545 [21,46] | 593 [23,35] | 641 [25,24] | – | – | – | – | – | – | – |
| | L2 | 625,5 [24,63] | 673,5 [26,52] | 722,5 [28,44] | – | – | – | – | – | – | – |
| | L3 | 462,5 mm [18.21 in] | | | | | | | | | |

## PVG 32 Combinations Valve Stack Dimensions

*PVB 256/32 combination valve stack dimensions, mm [in] (continued)*

| Number of PVB 256 (down) | | Number of PVB 32 modules | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| | | **1** | **2** | **3** | **4** | **5** | **6** | **7** | **8** | **9** | **10** |
| **6** | L1 | 631 [24,84] | – | – | – | – | – | – | – | – | – |
| | L2 | 709,5 [27,93] | – | – | – | – | – | – | – | – | – |
| | L3 | 548,5 mm [21.59 in] | | | | | | | | | |

**Weight for a PVG 256/32 valve stack**

*The weight is for a combined PVG 256/32 valve stack with a PVEO Series 7 on each working section and is only approximate, can be defined like this:*

**(Numbers of PVB 256 x 20,9) + (numbers of PVB 32 x 4,42) + 17.5 = Weight (kg)**

**(Numbers of PVB 256 x 46.08) + (numbers of PVB 32 x 9.75) + 38.6 = Weight (lb)**

ENGINEERING
TOMORROW

**Products we offer:**

- DCV directional control valves
- Electric converters
- Electric machines
- Electric motors
- Hydrostatic motors
- Hydrostatic pumps
- Orbital motors
- PLUS+1® controllers
- PLUS+1® displays
- PLUS+1® joysticks and pedals
- PLUS+1® operator interfaces
- PLUS+1® sensors
- PLUS+1® software
- PLUS+1® software services, support and training
- Position controls and sensors
- PVG proportional valves
- Steering components and systems
- Telematics

**Danfoss Power Solutions** is a global manufacturer and supplier of high-quality hydraulic and electric components. We specialize in providing state-of-the-art technology and solutions that excel in the harsh operating conditions of the mobile off-highway market as well as the marine sector. Building on our extensive applications expertise, we work closely with you to ensure exceptional performance for a broad range of applications. We help you and other customers around the world speed up system development, reduce costs and bring vehicles and vessels to market faster.

Danfoss Power Solutions – your strongest partner in mobile hydraulics and mobile electrification.

**Go to www.danfoss.com for further product information.**

We offer you expert worldwide support for ensuring the best possible solutions for outstanding performance. And with an extensive network of Global Service Partners, we also provide you with comprehensive global service for all of our components.

**Comatrol**
www.comatrol.com

**Turolla**
www.turollaocg.com

**Hydro-Gear**
www.hydro-gear.com

**Daikin-Sauer-Danfoss**
www.daikin-sauer-danfoss.com

Local address:

**Danfoss**
**Power Solutions (US) Company**
2800 East 13th Street
Ames, IA 50010, USA
Phone: +1 515 239 6000

**Danfoss**
**Power Solutions GmbH & Co. OHG**
Krokamp 35
D-24539 Neumünster, Germany
Phone: +49 4321 871 0

**Danfoss**
**Power Solutions ApS**
Nordborgvej 81
DK-6430 Nordborg, Denmark
Phone: +45 7488 2222

**Danfoss**
**Power Solutions Trading (Shanghai) Co., Ltd.**
Building #22, No. 1000 Jin Hai Rd
Jin Qiao, Pudong New District
Shanghai, China 201206
Phone: +86 21 3418 5200

Danfoss can accept no responsibility for possible errors in catalogues, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without subsequent changes being necessary in specifications already agreed.
All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

ENGINEERING
TOMORROW

Technical Information

# PVE Series 7
## Electro-hydraulic Actuators



www.danfoss.com

## Revision history

*Table of revisions*

| Date | Changed | Rev |
|---|---|---|
| July 2018 | Minor update. | 0202 |
| June 2018 | PVE actuation, connector image changes. | 0201 |
| May 2018 | Restored missing information. | 0105 |
| April 2018 | Minor updates. | 0104 |
| February 2017 | Added detailed Fault Monitoring description | 0103 |
| January 2017 | Minor updates | 0102 |
| November 2016 | First edition | 0101 |

## Contents

**PVE Electrical Actuator**

PVE Series 7 Electrical Actuator ..... 5
PVE Series 7 variants overview ..... 6

**PVEO**

PVEO Schematics and Dimensions ..... 9
PVEO Technical Data ..... 9
PVEO Reaction Times ..... 10
PVEO Variants for PVG ..... 11

**PVEO-HP**

PVEO-HP Schematics and Dimensions ..... 13
PVEO-HP Technical Data ..... 13
PVEO-HP Reaction Times ..... 14
PVEO-HP Variants for PVG ..... 15

**PVEM**

PVEM Schematics and Dimensions ..... 17
PVEM Technical Data ..... 17
PVEM Reaction Times ..... 19
PVEM Hysteresis and Ripple ..... 19
PVEM Variants for PVG ..... 20

**PVEA**

PVEA Schematics and Dimensions ..... 22
PVEA Technical Data ..... 22
PVEA Reaction Times ..... 24
PVEA Hysteresis and Ripple ..... 24
PVEA Variants for PVG ..... 25

**PVEH**

PVEH Schematics and Dimensions ..... 27
PVEH Technical Data ..... 27
PVEH Reaction Times ..... 29
PVEH Hysteresis and Ripple ..... 29
PVEH Variants for PVG ..... 30

**PVES**

PVES Schematics and Dimensions ..... 33
PVES Technical Data ..... 33
PVES Reaction Times ..... 35
PVES Hysteresis and Ripple ..... 35
PVES Variants for PVG ..... 36

**Connector Overview**

Connector Overview ..... 37

**Fault Monitoring and Fault Reaction**

Generic Fault Reaction ..... 39
Fault Reaction Overview ..... 40
Error Pin Specification ..... 40

**Functionality Overview**

Standard and Fixed US 0-10 Vdc ..... 41
PWM Voltage Control ..... 42
Ramp (-R) ..... 44
Quick Reaction (-Q) ..... 45
Float B-Port (-FLB) ..... 46
Float A-Port (-FLA) ..... 47
PVE Power Save ..... 47

**Special Features**

Direction Indication (-DI) ..... 48
Dedicated Float Pin (UF) ..... 50

## Contents

Spool Position (SP) ..... 51
Neutral Power-OFF (NP) ..... 52
Disable Mode ..... 53

**Performance Overview**

PVE S7 Reaction Times ..... 54
Hysteresis and Ripple ..... 54
Current Consumption ..... 55
Oil Consumption ..... 55

**Dimension Overview**

Dimension Overview for PVE Series 7 ..... 56

## PVE Electrical Actuator

### PVE Series 7 Electrical Actuator


The analog PVE Series 7 is an electro-hydraulic actuator used to control a single work section of a PVG proportional valve group. The PVE Series 7 actuator program includes variants with different performance levels and features for PVG 32/100/120/128/256.

The actuator positions the main spool in a PVG work section in order to control either the flow or the pressure of the oil distributed to/from the work function. The control signal to the actuator is an analog voltage signal, enabling the user to operate the work function remotely by means of a joystick, a controller or the similar.

The analog PVE Series 7 actuator program features five different main hydraulic principle variants (PVEO/PVEM/PVEA/PVEH/PVES). The different hydraulic principles combined with the different solenoid valve regulation principles determine whether the actuator controls the spool proportionally according to a demand signal or ON/OFF according to a voltage signal.


The electro-hydraulic solenoid valve bridge of the actuator is available in different designs utilizing different regulation principles, depending on performance variant. The actuator positions the main spool by distributing pilot oil pressure to either side of it, pressurizing one side by pilot pressure while relieving the opposite side to tank and vice versa, as illustrated below. All proportional actuators feature a closed-loop spool control and continuous fault monitoring.

*PVG 32 with PVEO/PVEM (PVEO without LVDT)*





## PVE Electrical Actuator

*PVG 32 with PVEH/PVES*








PVEA has the same housing as PVEO/PVEM and similar hydraulic principle as PVEH/PVES, but with fixed orifices instead of NO2 and NO4.

### PVE Series 7 variants overview

| Schematic | Description |
|---|---|
| *PVEO schematic*<br><br>P109195 | **PVEO** – ON/OFF voltage control for non-proportional functions, see *PVEO*<br>• Neutral position or max. spool stroke according to control signal<br>• 12 $V_{DC}$ or 24 $V_{DC}$ supply voltage<br>• DEUTSCH, AMP or DIN/Hirschman connectors<br>• Standard PVE pilot oil pressure of 13.5 bar [196 psi]<br>• LED only indicating Power ON or Power OFF<br>• Ramp (-R) or Direction Indication output (-DI) functionality |
| *PVEO-HP schematic*<br><br>P109195 | **PVEO-HP** – ON/OFF voltage control for non-proportional functions, see *PVEO-HP*<br>• Neutral position or max. spool stroke according to control signal<br>• 12 $V_{DC}$ or 24 $V_{DC}$ supply voltage<br>• DEUTSCH, AMP or DIN/Hirschman connectors<br>• To be used with PVH/PVHC pilot oil pressure of 25 bar<br>• LED only indicating Power ON or Power OFF |

## PVE Electrical Actuator


| Schematic | Description |
|---|---|
| *PVEM schematic*<br><br>P109196 | **PVEM** – proportional spool control for functions with medium performance demands, see *PVEM*<br>• 9–32 $V_{DC}$ multi-voltage power supply<br>• DIN or Hirschman connectors<br>• Standard PVE pilot oil pressure of 13.5 bar [196 psi]<br>• LED indicating error state and passive fault monitoring<br>• Float (-F), quick Ramp (-R) or Quick reaction functionality (-Q) |
| *PVEA schematic*<br><br>P109197 | **PVEA** – proportional spool control for functions with high performance demands, see *PVEA*<br>• 9–32 $V_{DC}$ multi-voltage power supply<br>• Variants available with DEUTSCH or AMP connectors<br>• Standard PVE pilot oil pressure of 13.5 bar [196 psi]<br>• LED indicating error state and active or passive fault monitoring<br>• Direction Indication output (-DI) or Neutral Power-Off (-NP) functionality |
| *PVEH schematic*<br><br>P109198 | **PVEH** – proportional spool control for functions with high performance demands, see *PVEH*<br>• 9–32 $V_{DC}$ multi-voltage power supply<br>• DEUTSCH, AMP or DIN/Hirschman connectors<br>• Standard PVE pilot oil pressure of 13.5 bar [196 psi]<br>• LED indicating error state and active or passive fault monitoring<br>• Float (-F), Direction Indication output (-DI), Neutral Power-Off (-NP), Spool Position output (-SP) or 0-10 $V_{DC}$ control signal (-U) functionality |
| *PVES Schematic*<br><br>P109199 | **PVES** – proportional spool control for functions with high performance and reaction demands, see *PVES*<br>• 9–32 $V_{DC}$ multi-voltage power supply<br>• Analog voltage control signal 25-75% of supply voltage<br>• DEUTSCH, AMP or DIN/Hirschman connectors<br>• Standard PVE pilot oil pressure of 13.5 bar [196 psi]<br>• LED indicating error state and active or passive fault monitoring<br>• Variants available with Spool Position output (-SP) or 0-10 $V_{DC}$ control signal (-U) functionality |

## PVEO


The PVEO actuator is a non-proportional ON/OFF control actuator with open-loop spool control primarily used to control simple ON/OFF work functions where a proportional control of speed or oil flow is not a requirement

The PVEO is available in two different performance variants, the standard PVEO and the PVEO-R with ramp.

*PVEO*



### PVEO functionality




The standard PVEO functionality includes the simplest electric circuit of the PVE Series 7 actuator program, using a fixed 12 Vdc or 24 Vdc supply voltage or signal voltage and a simple LED circuit to control the LED light indicating Power ON/OFF.



The PVEO-DI variant includes an LVDT spool position monitor and a more advanced electric circuit with an embedded micro-controller and separate power supply to handle the Direction Indication functionality.

An energization of solenoid valve SV1 and a simultaneous de-energization of SV2 will cause the main spool to move to the right direction and vice versa. If both SV1 and SV2 are energized or de-energized simultaneously, the main spool stays locked in its neutral position.


## PVEO

### PVEO Schematics and Dimensions

*Schematics*

| PVEO | PVEO-R |
|---|---|
|  P109195 |  P109200 |

*Dimensions*

| PVEO | Connector height |
|---|---|
|   P109231 | DEU = 30 mm [1.2 in]<br>DIN = 40 mm [1.6] |

### PVEO Technical Data

*Control Specification*

| Description | Type | Value | |
|---|---|---|---|
| Supply Voltage (Udc) | Rated | 12 Vdc | 24 Vdc |
| | Range | 11 to 15 Vdc | 22 to 30 Vdc |
| | Max. ripple | 5% | |
| *Current Consumption* | Typical | 480 mA | 250 mA |
| | Minimum | 430 mA | 220 mA |
| | Maximum | 950 mA | 480 mA |

## PVEO

*Operating Conditions*


| Description | Type | Value | |
|---|---|---|---|
| Pilot Pressure | Nominal | 13.5 bar | [196 psi] |
| | Minimum | 10.0 bar | [145 psi] |
| | Maximum | 15.0 bar | [218 psi] |
| *Oil Consumption* | Neutral | 0.0 l/min | [0.0 gal/min] |
| | Locked position | 0.0 l/min | [0.0 gal/min] |
| | Actuating | 0.9 l/min | [0.24 gal/min] |
| | Actuating (PVEO-R) | 0.3 l/min | [0.08 gal/min] |
| Storage Temperature | Ambient | -50 to +90°C | [-58 to +194°F] |
| Operating Temperature | Ambient | -40 to +90°C | [-40 to +194°F] |
| Oil Viscosity | Operating range | 12 to 75 cSt | [65 to 347 SUS] |
| | Minimum | 4 cSt | [39 SUS] |
| | Maximum | 460 cSt | [2128 SUS] |
| Oil Cleanliness | Maximum | 18/16/13 (according to ISO 4406) | |

*LED characteristic*

| Color | LED characteristic | Description |
|---|---|---|
| Green constant | | Power ON |

## PVEO Reaction Times

*Reaction times*




*Definition of Step Response*

| Reaction | PVEO<br>PVEO-DI | PVEO-R |
|---|---|---|
| T0 – Boot-up | 0 | 0 |
| T1 – Neutral to max. spool stroke @ Power ON/ @ Constant $U_{DC}$ | 110 ms | 300 ms |
| T2 – Max. spool stroke to neutral @ Power OFF/@ Constant $U_{DC}$ | 110 ms | 110 ms |

## PVEO

The stated values are preliminary values and can be subject to change once an increased statistical basis is achieved.

### PVEO Variants for PVG

*PVG 32/100 Variants*

| Part number | Type | *Connector* | IP | Udc | Functionality |
|---|---|---|---|---|---|
| 11166843 | PVEO | 1x4 DEU | 67 | 12 Vdc | Standard |
| 11166838 | PVEO | 1x4 DEU | 67 | 24 Vdc | Standard |
| 11166866 | PVEO | 1x4 AMP | 66 | 12 Vdc | Standard |
| 11166837 | PVEO | 1x4 AMP | 66 | 24 Vdc | Standard |
| 11166836 | PVEO | 1x4 DIN | 65 | 12 Vdc | Standard |
| 11166743 | PVEO | 1x4 DIN | 65 | 24 Vdc | Standard |
| 11166753 | PVEO-R | 1x4 DEU | 67 | 12 Vdc | Ramp |
| 11166754 | PVEO-R | 1x4 DEU | 67 | 24 Vdc | Ramp |
| 11166867 | PVEO-R | 1x4 AMP | 66 | 12 Vdc | Ramp |
| 11166776 | PVEO-R | 1x4 AMP | 66 | 24 Vdc | Ramp |
| 11166831 | PVEO-R | 1x4 DIN | 65 | 12 Vdc | Ramp |
| 11166908 | PVEO-R | 1x4 DIN | 65 | 24 Vdc | Ramp |
| 11168740[1] | PVEO-DI | 2x4 AMP | 66 | 12 Vdc | Standard |
| 11166869[1] | PVEO-DI | 2x4 AMP | 66 | 24 Vdc | Standard |

[1] Includes *Direction Indication* special feature

*PVG 120 Variants*

| Part number | Type | *Connector* | IP | Udc | Functionality |
|---|---|---|---|---|---|
| 11166755 | PVEO | 1x4 DEU | 67 | 12 Vdc | Standard |
| 11166757 | PVEO | 1x4 DEU | 67 | 24 Vdc | Standard |
| 11166815 | PVEO | 1x4 AMP | 66 | 12 Vdc | Standard |
| 11166816 | PVEO | 1x4 AMP | 66 | 24 Vdc | Standard |
| 11166822 | PVEO | 1x4 DIN | 65 | 12 Vdc | Standard |
| 11166744 | PVEO | 1x4 DIN | 65 | 24 Vdc | Standard |
| 11166882 | PVEO-R | 1x4 AMP | 66 | 24 Vdc | Ramp |
| 11166909 | PVEO-R | 1x4 DIN | 65 | 24 Vdc | Ramp |

*PVG 128/256 Variants*

| Part number | Type | *Connector* | IP | Udc | Functionality |
|---|---|---|---|---|---|
| 11186328 | PVEO | 1x4 DEU | 67 | 12 Vdc | Standard |
| 11186330 | PVEO | 1x4 DEU | 67 | 24 Vdc | Standard |
| 11186331 | PVEO | 1x4 DIN | 65 | 12 Vdc | Standard |
| 11186342 | PVEO | 1x4 DIN | 65 | 24 Vdc | Standard |


*PVG 60 Variants*

| Part number | Type | *Connector* | IP | Udc | Functionality |
|---|---|---|---|---|---|
| 11166939 | PVEO | 1x4 DIN | 65 | 12 Vdc | Standard |
| 11166940 | PVEO | 1x4 DIN | 65 | 24 Vdc | Standard |

## PVEO-HP

The PVEO-HP actuator is a non-proportional ON/OFF control actuator with open-loop spool control primarily used to control simple ON/OFF work functions where a proportional control of speed or oil flow is not a requirement.


*PVEO-HP*



All variants are available with following features:

- Neutral position or max. spool stroke according to control signal
- 12 $V_{DC}$ or 24 $V_{DC}$ supply voltage
- DEUTSCH, AMP or DIN/Hirschman connectors
- PVH/PVHC pilot oil pressure of 25 bar [362.6 psi]
- LED only indicating Power ON or Power OFF

*PVEO-HP functionality diagram*





The standard PVEO/PVEO-HP functionality includes the simplest electric circuit of the PVE actuator program, using a fixed 12 $V_{DC}$ or 24 $V_{DC}$ supply voltage or signal voltage and a simple LED circuit to control the LED light indicating Power ON/OFF.

An energization of solenoid valve SV1 and a simultaneous de-energization of SV2 will cause the main spool to move to the right direction and vice versa. If both SV1 and SV2 are energized or de-energized simultaneously, the main spool stays locked in its neutral position.


## PVEO-HP

### PVEO-HP Schematics and Dimensions

*Schematics*

| PVEO-HP |
|---|
|  |

*Dimensions*

| PVEO-HP | Connector height |
|---|---|
|  | DEU = 30 mm [1.2 in]<br>AMP = 38 mm [1.5 in]<br>DIN = 40 mm [1.6 in] |

For more information on dimensions, please see *Dimension Overview*.

### PVEO-HP Technical Data

*Control Specification*

| Description | Type | 12 $V_{DC}$ | 24 $V_{DC}$ |
|---|---|---|---|
| Supply Voltage ($U_{DC}$) | Range | 11 to 15 $V_{DC}$ | 22 to 30 $V_{DC}$ |
| | Max. ripple | 5% | |
| Current Consumption | Typical | 750 mA | 380 mA |
| | Minimum | 660 mA | 340 mA |
| | Maximum | 1460 mA | 740 mA |

## PVEO-HP

*Technical data*

| | | |
|---|---|---|
| **Pilot pressure** | Nominal | 25 bar [363 psi] |
| | Minimum | 21 bar [305 psi] |
| | Maximum | 25 bar [363 psi] |
| **Fluid consumption** | Neutral | 0 l/min [0 US gal/min] |
| | Locked position | 0 l/min [0 US gal/min] |
| | Actuating | 0.9 l/min [0.24 US gal/min] |

*Technical specification*


| Parameter | Minimum | Recommended range | Maximum |
|---|---|---|---|
| **Fluid viscosity** | 4 $mm^2/s$ [39 SUS] | 12 to 75 $mm^2/s$ [65 to 347 SUS] | 460 $mm^2/s$ [2128 SUS] |
| **Fluid cleanliness** | 18/16/13 (according to ISO 4406) | | |
| **Storage temperature** | Ambient: -50 to 90°C [-58 to 194°F] | | |
| **Operating temperature** | Ambient: -30 to 60°C [-22 to 140°F] | | |

*LED characteristic*

| Color | LED characteristic | Description |
|---|---|---|
| Green constant | | Power ON |

## PVEO-HP Reaction Times

*Reaction times*




*Definition of Step Response*

| Reaction | PVEO-HP |
|---|---|
| T0 – Boot-up | 0 |
| T1 – Neutral to max. spool stroke @ Power ON/@ Constant $U_{DC}$ | 90 ms |
| T2 – Max. spool stroke to neutral @ Power OFF/@ Constant $U_{DC}$ | 70 ms |

The stated values are preliminary values and can be subject to change once an increased statistical basis is achieved.

## PVEO-HP

### PVEO-HP Variants for PVG


*PVG 32/100 variants*

| Part number | Type | *Connector* | IP | Udc | Functionality |
|---|---|---|---|---|---|
| 11166765 | PVEO-HP | 1x4 DEU | 67 | 12 Vdc | Standard |
| 11166766 | PVEO-HP | 1x4 DEU | 67 | 24 Vdc | Standard |
| 11166763 | PVEO-HP | 1x4 AMP | 66 | 12 Vdc | Standard |
| 11187524 | PVEO-HP | 1x4 AMP | 66 | 24 Vdc | Standard |
| 11187551 | PVEO-HP | 1x4 DIN | 65 | 12 Vdc | Standard |
| 11187562 | PVEO-HP | 1x4 DIN | 65 | 24 Vdc | Standard |

## PVEM

The PVEM actuator is a proportional control actuator with closed-loop spool control primarily used to control work functions with medium performance requirements. The PVEM is available in three different performance variants, the standard PVEM, the PVEM-R with ramp and the PVEM-Q with quick reaction.


*PVEM*



Variants are available with following features:

- 9–32 $V_{DC}$ multi-voltage power supply
- Analog voltage control signal 25–75% of supply voltage
- DIN or Hirschman connectors
- Standard PVE pilot oil pressure of 13.5 bar [196 psi]
- LED indicating error state and passive fault monitoring
- Float (-F), quick Ramp (-R) or Quick reaction functionality (-Q)

### PVEM functionality






The PVE functionality includes an electric circuit with a closed-loop logic. An embedded micro-controller processes the signal voltage and the LVDT feedback signal and regulates the solenoid valves accordingly.

An energization of solenoid valve SV1 and a simultaneous de-energization of SV2 will cause the main spool to move to the right direction and vice versa. If both SV1 and SV2 are energized or de-energized simultaneously, the main spool stays locked in its neutral position.


## PVEM

### PVEM Schematics and Dimensions

*Schematics*

| PVEM/PVEM-FLB/PVEM-R | PVEM-Q |
|---|---|
|  P109196 |  P109201 |

*Dimensions*

| PVEM | Connector height |
|---|---|
|   P109232 | DEU = 30 mm [1.2 in]<br>AMP = 38 mm [1.5 in]<br>DIN = 40 mm [1.6 in] |

For more information on dimensions, please see *Dimension Overview*.

### PVEM Technical Data

*Control Specification*

| Description | Type | Value |
|---|---|---|
| Supply Voltage ($U_{DC}$) | Rated Range | 11 to 32 $V_{DC}$ |
| | Max. ripple | 5% |
| Signal Voltage PWM ($U_S$) | Neutral | $U_S$ = 0.5 $U_{DC}$ = 50% DUT |
| | Q: P to A | $U_S$ = (0.5 to 0.25) $U_{DC}$ = 50% to 25% DUT |
| | Q: P to B | $U_S$ = (0.5 to 0.75) $U_{DC}$ = 50% to 75% DUT |
| Input Impedance | Rated | 12 kΩ |
| Input Capacitance | Rated | 100 nF |

## PVEM

*Current consumption*

| Description | @ 12 $V_{DC}$ | @ 24 $V_{DC}$ |
|---|---|---|
| PWM Frequency ($U_S$) recommended | > 200 Hz | > 200 Hz |
| Current Consumption | 690 mA | 350 mA |

*Pilot pressure*

| Minimum | Nominal | Maximum |
|---|---|---|
| 10.0 bar [145 psi] | 13.5 bar [196 psi] | 15.0 bar [218 psi] |

*Fluid consumption*

| Neutral/Locked position | Actuating (PVEM-R) | Actuating (PVEM-Q) | Actuating |
|---|---|---|---|
| 0 l/min | 0.3 l/min | 1.0 l/min [0.26 US gal/min][0.08 US gal/min] | 0.5 l/min [0.13 US gal/min] |

*Technical specification*

| Parameter | Minimum | Recommended range | Maximum |
|---|---|---|---|
| **Fluid viscosity** | 4 $mm^2/s$ [39 SUS] | 12 to 75 $mm^2/s$ [65 to 347 SUS] | 460 $mm^2/s$ [2128 SUS] |
| **Fluid cleanliness** | 18/16/13 (according to ISO 4406) | | |
| **Storage temperature** | Ambient: -50 to 90°C [-58 to 194°F] | | |
| **Operating temperature** | Ambient: -30 to 60°C [-22 to 140°F] | | |


*LED characteristic*

| Color | LED characteristic | Description |
|---|---|---|
| Green constant | | No error – Actuating |
| Green flashing @ 1.5 Hz | | Neutral – Power save |
| Red constant | | Internal error |
| Red flashing @ 1.5 Hz | | External or Float error |

## PVEM

### PVEM Reaction Times

*Reaction times*





*Definition of Step Response*

| Reaction | PVEM-R | PVEM-FLB | PVEM-Q |
|---|---|---|---|
| T0 – Boot-up | 15 ms | 15 ms | 15 ms |
| T1 – Neutral to max. spool stroke @ Power ON | 325 ms | 225 ms | 125 ms |
| T2 – Max. spool stroke to neutral @ Power OFF | 110 ms | 110 ms | 110 ms |
| T1 – Neutral to max. spool stroke @ Constant $U_{DC}$ | 310 ms | 210 ms | 110 ms |
| T2 – Max. spool stroke to neutral @ Constant $U_{DC}$ | 90 ms | 90 ms | 90 ms |

The stated values are preliminary values and can be subject to change once an increased statistical basis is achieved.

### PVEM Hysteresis and Ripple



## PVEM

| Description | Type | PVEM |
|---|---|---|
| Hysteresis (h) | Rated [%] | 15 |
| Steady state ripple @ fixed US (v) | Rated [mm] | 0.0 |

The stated values are preliminary values and can be subject to change once an increased statistical basis is achieved.

For more information on hysteresis and ripple, see *Hysteresis and Ripple*.

## PVEM Variants for PVG


*PVG 32/100 Variants*

| Part number | Type | *Connector* | IP | *Fault Monitoring* | Functionality |
|---|---|---|---|---|---|
| 11166829 | PVEM | 1x4 DIN | 65 | Passive | Standard |
| 11166852 | PVEM-FLB | 1x4 DIN | 65 | Passive | Float B-port |
| 11166845 | PVEM-R | 1x4 DIN | 65 | Passive | Ramp |
| 11166853 | PVEM-Q | 1x4 DIN | 65 | Passive | Quick Reaction |

## PVEA

The PVEA actuator is a proportional control actuator with a closed-loop spool control primarily used to control work functions with above medium performance requirements.


*PVEA*



- 9–32 $V_{DC}$ multi-voltage power supply
- Analog voltage control signal 25–75% of supply voltage
- Standard PVE pilot oil pressure of 13.5 bar [196 psi]
- DEUTSCH, AMP or DIN/Hirschman connectors
- LED indicating error state and active or passive fault monitoring
- Direction Indication output (-DI) or Neutral Power-Off (-NP) functionality

### PVEA-DI functionality

*PVEA-DI functionality*





The PVE functionality includes an electric circuit with a closed-loop logic. An embedded micro-controller processes the signal voltage and the LVDT feedback signal and regulates the solenoid valves accordingly.

A continuous modulation of solenoid valve NC1 and a simultaneous de-energization of NC3 causes the main spool to move to the right direction and vice versa. When the main spool is stroked to the far right, a simultaneous modulation of both NC1 and NC3 balances the main spool in its stroked position. The main spool oscillates in its stroked position at a frequency corresponding to the modulation frequency. When both NC1 and NC3 are de-energized, the main spool moves back to its neutral position by means of the main spool neutral spring and the hydraulic principle.


## PVEA

### PVEA Schematics and Dimensions

*Schematics*

| PVEA |
|---|
|  P109197 |

*Dimensions*

| PVEA | Connector height |
|---|---|
|   P109232 | DEU = 30 mm [1.2 in]<br>AMP = 38 mm [1.5 in]<br>DIN = 40 mm [1.6 in] |

For more information on dimensions, see *Dimension Overview*.

### PVEA Technical Data

*Control Specification*

| Description | Type | Value |
|---|---|---|
| Supply Voltage ($U_{DC}$) | Rated Range | 11 to 32 $V_{DC}$ |
| | Max. ripple | 5% |
| Signal Voltage PWM ($U_S$) | Neutral | $U_S$ = 0.5 $U_{DC}$ = 50% DUT |
| | Q: P to A | $U_S$ = (0.5 to 0.25) $U_{DC}$ = 50% to 25% DUT |
| | Q: P to B | $U_S$ = (0.5 to 0.75) $U_{DC}$ = 50% to 75% DUT |
| Input Impedance | Rated | 12 kΩ |
| Input Capacitance | Rated | 100 nF |

## PVEA

*Current consumption*

| Description | @ 12 $V_{DC}$ | @ 24 $V_{DC}$ |
|---|---|---|
| PWM Frequency ($U_S$) recommended | > 1000 Hz | > 1000 Hz |
| Current Consumption | 290 mA | 150 mA |

*Pilot pressure*

| Minimum | Nominal | Maximum |
|---|---|---|
| 10.0 bar [145 psi] | 13.5 bar [196 psi] | 15.0 bar [218 psi] |

*Fluid consumption*

| Neutral | Locked position | Actuating |
|---|---|---|
| 0 l/min | 0 l/min | 1.0 l/min<br>[0.26 US gal/min] |

*Technical specification*

| Parameter | Minimum | Recommended range | Maximum |
|---|---|---|---|
| **Fluid viscosity** | 4 $mm^2/s$ [39 SUS] | 12 to 75 $mm^2/s$ [65 to 347 SUS] | 460 $mm^2/s$ [2128 SUS] |
| **Fluid cleanliness** | 18/16/13 (according to ISO 4406) | | |
| **Storage temperature** | Ambient: -50 to 90°C [-58 to 194°F] | | |
| **Operating temperature** | Ambient: -30 to 60°C [-22 to 140°F] | | |


*LED characteristic*

| Color | LED characteristic | Description |
|---|---|---|
| Green constant | | No error – Actuating |
| Green flashing @ 1.5 Hz | | Neutral – Power save |
| Red constant | | Internal error |
| Red flashing @ 1.5 Hz | | External or Float error |

## PVEA

### PVEA Reaction Times


*Reaction times*




| Reaction | PVEA |
|---|---|
| T0 – Boot-up [ms] | 15 ms |
| T1 – Neutral to max. spool stroke @ Power ON | 280 ms |
| T2 – Max. spool stroke to neutral @ Power OFF | 200 ms |
| T1 – Neutral to max. spool stroke @ Constant $U_{DC}$ | 265 ms |
| T2 – Max. spool stroke to neutral @ Constant $U_{DC}$ | 200 ms |

The stated values are preliminary values and can be subject to change once an increased statistical basis is achieved.

### PVEA Hysteresis and Ripple




| Description | Type | PVEA |
|---|---|---|
| Hysteresis (h) | Rated [%] | 2 |
| Steady state ripple @ fixed Us (v) | Rated [mm] | 0.3 |

## PVEA

The stated values are preliminary values and can be subject to change once an increased statistical basis is achieved.

For more information on hysteresis and ripple, see *Hysteresis and Ripple*.

## PVEA Variants for PVG

*PVG 32/100 Variants*

| Part number | Type | *Connector* | IP | *Fault monitoring* | Functionality |
|---|---|---|---|---|---|
| 11177346 | PVEA | 1x4 DEU | 67 | Passive | Standard |
| 11177347 | PVEA | 1x4 DEU | 67 | Active | Standard |
| 11177353 | PVEA | 1x4 AMP | 66 | Passive | Standard |
| 11177348 | PVEA | 1x4 AMP | 66 | Active | Standard |
| 11177345[1] | PVEA-NP | 1x6 DEU | 67 | Active | Standard |
| 11177357[2] | PVEA-DI | 2x4 DEU | 67 | Active | Standard |
| 11177356[2] | PVEA-DI | 2x4 AMP | 66 | Passive | Standard |
| 11177355[2] | PVEA-DI | 2x4 AMP | 66 | Active | Standard |


[1] Includes *Neutral Power-OFF* special feature

[2] Includes *Direction Indication* special feature

## PVEH

The PVEH actuator is a proportional control actuator with closed-loop spool control primarily used to control work functions with high performance requirements.


*PVEH*



- 9–32 $V_{DC}$ multi-voltage power supply
- Analog voltage control signal 25–75% of supply voltage
- Standard PVE pilot oil pressure of 13.5 bar [196 psi]
- DEUTSCH, AMP or DIN/Hirschman connectors
- LED indicating error state and active or passive fault monitoring
- Float (-F), Direction Indication output (-DI), Neutral Power-Off (-NP), Spool Position output (-SP) or 0-10 $V_{DC}$ control signal (-U) functionality

### PVEH functionality

*PVEH functionality*




The PVE functionality includes an electric circuit with a closed-loop logic. An embedded micro-controller processes the signal voltage and the LVDT feedback signal and regulates the solenoid valves accordingly.


A continuous modulation of solenoid valves NC1 and NO4 together with a simultaneous energization of NO2 and de-energization of NC3 causes the main spool to move to the right direction and vice versa. When the main spool is stroked to the far right, a simultaneous energization of both NO2 and NO4 and de-energization of both NC1 and NC3 balances the main spool in its stroked position. An emergency stop activated when the spool is stroked will cause all solenoid valves to de-energize causing the main spool

## PVEH


to move back to its neutral position by means of the main spool neutral spring and the hydraulic principle.

### PVEH Schematics and Dimensions

*Schematics*

| PVEH |
|---|
|  |

*Dimensions*

| PVEH | Connector height |
|---|---|
|  | DEU = 30 mm [1.2 in]<br>DIN = 40 mm [1.6 in] |

### PVEH Technical Data

*Control Specification*

| Description | Type | Value |
|---|---|---|
| Supply Voltage ($U_{DC}$) | Rated Range | 11 to 32 $V_{DC}$ |
| | Max. ripple | 5% |
| Signal Voltage PWM ($U_S$) | Neutral | $U_S$ = 0.5 $U_{DC}$ = 50% DUT |
| | Q: P to A | $U_S$ = (0.5 to 0.25) $U_{DC}$ = 50% to 25% DUT |
| | Q: P to B | $U_S$ = (0.5 to 0.75) $U_{DC}$ = 50% to 75% DUT |
| Input Impedance | Rated | 12 kΩ |
| Input Capacitance | Rated | 100 nF |

## PVEH

*Current consumption*

| Description | @ 12 $V_{DC}$ | @ 24 $V_{DC}$ |
|---|---|---|
| PWM Frequency ($U_S$) recommended | > 1000 Hz | > 1000 Hz |
| Current Consumption | 540 mA | 270 mA |
| Max. DI Current | 200 mA | 200 mA |

*Pilot pressure*

| Minimum | Nominal | Maximum |
|---|---|---|
| 10.0 bar [145 psi] | 13.5 bar [196 psi] | 15.0 bar [218 psi] |

*Fluid consumption*

| Neutral | Locked position | Actuating |
|---|---|---|
| 0.0 l/min | 0.0 l/min | 0.7 l/min<br>[0.18 US gal/min] |

*Technical specification*

| Parameter | Minimum | Recommended range | Maximum |
|---|---|---|---|
| **Fluid viscosity** | 4 $mm^2/s$ [39 SUS] | 12 to 75 $mm^2/s$ [65 to 347 SUS] | 460 $mm^2/s$ [2128 SUS] |
| **Fluid cleanliness** | 18/16/13 (according to ISO 4406) | | |
| **Storage temperature** | Ambient: -50 to 90°C [-58 to 194°F] | | |
| **Operating temperature** | Ambient: -30 to 60°C [-22 to 140°F] | | |


*LED Characteristic*

| Color | LED Characteristic | Description |
|---|---|---|
| Green constant |  | No error – Actuating |
| Green flashing @ 1.5 Hz |  | Neutral – Power save |
| Red constant |  | Internal error |
| Red flashing @ 1.5 Hz |  | External or Float error |
| Yellow |  | Disable mode |

## PVEH

### PVEH Reaction Times


*Reaction times*




| Reaction | PVEH |
|---|---|
| T0 – Boot-up [ms] | 15 ms |
| T1 – Neutral to max. spool stroke @ Power ON [ms] | 125 ms |
| T2 – Max. spool stroke to neutral @ Power OFF [ms] | 110 ms |
| T1 – Neutral to max. spool stroke @ Constant $U_{DC}$ [ms] | 110 ms |
| T2 – Max. spool stroke to neutral @ Constant $U_{DC}$ [ms] | 90 ms |

The stated values are preliminary values and can be subject to change once an increased statistical basis is achieved.

### PVEH Hysteresis and Ripple




| Description | Type | PVEH |
|---|---|---|
| Hysteresis (h) | Rated [%] | 4 |
| Steady state ripple @ fixed Us (v) | Rated [mm] | 0.0 |

For more information on hysteresis and ripple, see *Hysteresis and Ripple*.

## PVEH

### PVEH Variants for PVG

*PVG 32/100 variants*

| Part number | Type | Connector | IP | Fault monitoring | Functionality |
|---|---|---|---|---|---|
| 11166732 | PVEH | 1x4 DEU | 67 | Passive | Standard |
| 11166775 | PVEH | 1x4 DEU | 67 | Active | Standard |
| 11166825 | PVEH | 1x4 AMP | 66 | Passive | Standard |
| 11166818 | PVEH | 1x4 AMP | 66 | Active | Standard |
| 11166824 | PVEH | 1x4 DIN | 65 | Passive | Standard |
| 11166817 | PVEH | 1x4 DIN | 65 | Active | Standard |
| 11166832[1] | PVEH-U | 1x4 AMP | 66 | Passive | Fixed US 0-10 V dc |
| 11166821[1] | PVEH-U | 1x4 AMP | 66 | Active | Fixed US 0-10 V dc |
| 11166770[1] | PVEH-U | 1x4 DIN | 65 | Passive | Fixed US 0-10 V dc |
| 11166772[1] | PVEH-U | 1x4 DIN | 65 | Active | Fixed US 0-10 V dc |
| 11166840 | PVEH-FLB | 1x4 DEU | 67 | Passive | Float B-port |
| 11166742 | PVEH-FLB | 1x4 DEU | 67 | Active | Float B-port |
| 11166839 | PVEH-FLB | 1x4 DIN | 65 | Active | Float B-port |
| 11166841[2] | PVEH-FLA | 1x6 DEU | 67 | Active | Float A-port |
| 11168738[2] | PVEH-FLA | 1x6 AMP | 66 | Passive | Float A-port |
| 11168739[2] | PVEH-FLA | 1x6 AMP | 66 | Active | Float A-port |
| 11166773[3] | PVEH-SP | 1x6 DEU | 67 | Active | Standard |
| 11166750[4] | PVEH-NP | 1x6 DEU | 67 | Fast active | Standard |
| 11166835[5] | PVEH-DI | 2x4 DEU | 67 | Active | Standard |
| 11166820[5] | PVEH-DI | 2x4 AMP | 66 | Passive | Standard |
| 11166819[5] | PVEH-DI | 2x4 AMP | 66 | Active | Standard |

[1] Includes *Disable Mode* special feature

[2] Includes *Dedicated Float Pin (UF)* special feature

[3] Includes *Spool Position* special feature

[4] Includes *Neutral Power-Off* special feature

[5] Includes *Direction Indication* special feature

*PVG 120 variants*

| Part number | Type | Connector | IP | Fault monitoring | Functionality |
|---|---|---|---|---|---|
| 11166760 | PVEH | 1x4 DEU | 67 | Passive | Standard |
| 11166814 | PVEH | 1x4 AMP | 66 | Passive | Standard |
| 11166801 | PVEH | 1x4 AMP | 66 | Active | Standard |
| 11166813 | PVEH | 1x4 DIN | 65 | Passive | Standard |
| 11166777 | PVEH | 1x4 DIN | 65 | Active | Standard |
| 11166771[1] | PVEH-U | 1x4 DIN | 65 | Passive | Fixed US 0-10 V dc |
| 11166767[1] | PVEH-U | 1x4 DIN | 65 | Active | Fixed US 0-10 V dc |

[1] Includes *Disable Mode* special feature

## PVEH

*PVG 128/256 variants*

| Part number | Type | *Connector* | IP | *Fault monitoring* | Functionality |
|---|---|---|---|---|---|
| 11186325 | PVEH | 1x4 DEU | 67 | Passive | Standard |
| 11186326 | PVEH | 1x4 DEU | 67 | Active | Standard |
| 11186321 | PVEH | 1x4 DIN | 65 | Passive | Standard |
| 11186322 | PVEH | 1x4 DIN | 65 | Active | Standard |
| 11186323[1] | PVEH-U | 1x4 DIN | 65 | Passive | Fixed US 0-10 Vdc |
| 11186324[1] | PVEH-U | 1x4 DIN | 65 | Active | Fixed US 0-10 Vdc |

[1] Includes *Disable Mode* special feature


*PVG 60 variants*

| Part number | Type | *Connector* | IP | *Fault monitoring* | Functionality |
|---|---|---|---|---|---|
| 11166910 | PVEH | 1x4 DIN | 65 | Active | Float B-port |

## PVES

The PVES actuator is a proportional control actuator with closed-loop spool control primarily used to control work functions with very high performance requirements.


*PVES*



- 9–32 $V_{DC}$ multi-voltage power supply
- Analog voltage control signal 25–75% of supply voltage
- Standard PVE pilot oil pressure of 13.5 bar [196 psi]
- DEUTSCH, AMP or DIN/Hirschman connectors
- LED indicating error state and active or passive fault monitoring
- Spool Position output (-SP) or 0-10 $V_{DC}$ control signal (-U) functionality

### PVES functionality

*PVES functionality*




The PVE functionality includes an electric circuit with a closed-loop logic. An embedded micro-controller processes the signal voltage and the LVDT feedback signal and regulates the solenoid valves accordingly.


A continuous modulation of solenoid valves NC1 and NO4 together with a simultaneous energization of NO2 and de-energization of NC3 causes the main spool to move to the right direction and vice versa. When the main spool is stroked to the far right, a simultaneous energization of both NO2 and NO4 and de-energization of both NC1 and NC3 balances the main spool in its stroked position. An emergency stop activated when the spool is stroked will cause all solenoid valves to de-energize causing the main spool

## PVES


to move back to its neutral position by means of the main spool neutral spring and the hydraulic principle.

### PVES Schematics and Dimensions

*Schematic*

| PVES |
|---|
|  P109199 |

*Dimensions*

| PVES | Connector height |
|---|---|
|   P109235 | DEU = 30 mm [1.2 in]<br>AMP = 38 mm [1.5 in]<br>DIN = 40 mm [1.6 in] |

For information on dimensions, see *Dimension Overview*.

### PVES Technical Data

*Control Specification*

| Description | Type | Value |
|---|---|---|
| Supply Voltage ($U_{DC}$) | Rated Range | 11 to 32 $V_{DC}$ |
| | Max. ripple | 5% |
| Signal Voltage PWM ($U_S$) | Neutral | $U_S$ = 0.5 $U_{DC}$ = 50% DUT |
| | Q: P to A | $U_S$ = (0.5 to 0.25) $U_{DC}$ = 50% to 25% DUT |
| | Q: P to B | $U_S$ = (0.5 to 0.75) $U_{DC}$ = 50% to 75% DUT |

## PVES

*Control Specification (continued)*

| Description | Type | Value |
|---|---|---|
| Input Impedance | Rated | 12 kΩ |
| Input Capacitance | Rated | 100 nF |

*Current consumption*

| Description | @ 12 $V_{DC}$ | @ 24 $V_{DC}$ |
|---|---|---|
| PWM Frequency ($U_S$) recommended | > 1000 Hz | > 1000 Hz |
| Current Consumption | 560 mA | 280 mA |

*Pilot pressure*

| Minimum | Nominal | Maximum |
|---|---|---|
| 10.0 bar [145 psi] | 13.5 bar [196 psi] | 15.0 bar [218 psi] |

*Fluid consumption*

| Neutral | Locked position | Actuating |
|---|---|---|
| 0.03 l/min<br>[0.106 US gal/min] | 0.01 l/min<br>[0.026 US gal/min] | 0.8 l/min<br>[0.21 US gal/min] |

*Technical specification*

| Parameter | Minimum | Recommended range | Maximum |
|---|---|---|---|
| **Fluid viscosity** | 4 $mm^2/s$ [39 SUS] | 12 to 75 $mm^2/s$ [65 to 347 SUS] | 460 $mm^2/s$ [2128 SUS] |
| **Fluid cleanliness** | 18/16/13 (according to ISO 4406) | | |
| **Storage temperature** | Ambient: -50 to 90°C [-58 to 194°F] | | |
| **Operating temperature** | Ambient: -30 to 60°C [-22 to 140°F] | | |


*LED Characteristic*

| Color | LED Characteristic | Description |
|---|---|---|
| Green constant | | No error – Actuating |
| Green flashing @ 1.5 Hz | | Neutral – Power save |
| Red constant | | Internal error |
| Red flashing @ 1.5 Hz | | External or Float error |
| Yellow | | Disable mode |

## PVES

### PVES Reaction Times


*Reaction times*




| Reaction | PVES |
|---|---|
| T0 – Boot-up [ms] | 15 ms |
| T1 – Neutral to max. spool stroke @ Power ON | 125 ms |
| T2 – Max. spool stroke to neutral @ Power OFF | 110 ms |
| T1 – Neutral to max. spool stroke @ Constant $U_{DC}$ | 110 ms |
| T2 – Max. spool stroke to neutral @ Constant $U_{DC}$ | 90 ms |

The stated values are preliminary values and can be subject to change once an increased statistical basis is achieved.

### PVES Hysteresis and Ripple




| Description | Type | PVES |
|---|---|---|
| Hysteresis (h) | Rated [%] | <0.5 |
| Steady state ripple @ fixed US (v) | Rated [mm] | 0.2 |

## PVES

The stated values are preliminary values and can be subject to change once an increased statistical basis is achieved.

For more information on hysteresis and ripple, see *Hysteresis and Ripple*.

### PVES Variants for PVG

*PVG 32/100 variants*

| Part number | Type | *Connector* | IP | *Fault monitoring* | Functionality |
|---|---|---|---|---|---|
| 11166748 | PVES | 1x4 DEU | 67 | Passive | Standard |
| 11166864 | PVES | 1x4 DEU | 67 | Active | Standard |
| 11166859 | PVES | 1x4 AMP | 66 | Passive | Standard |
| 11166858 | PVES | 1x4 AMP | 66 | Active | Standard |
| 11166849 | PVES | 1x4 DIN | 65 | Passive | Standard |
| 11166857 | PVES | 1x4 DIN | 65 | Active | Standard |
| 11166745[1] | PVES-U | 1x4 DEU | 67 | Passive | Fixed Us 0-10 Vdc |
| 11166747[1] | PVES-U | 1x4 AMP | 66 | Active | Fixed Us 0-10 Vdc |
| 11166752[2] | PVES-SP | 1x6 DEU | 67 | Passive | Standard |

[1] Includes *Disable Mode* special feature




[2] Includes *Spool Position* special feature





*PVG 120 variants*

| Part number | Type | *Connector* | IP | *Fault monitoring* | Functionality |
|---|---|---|---|---|---|
| 11166761 | PVES | 1x4 DEU | 67 | Passive | Standard |
| 11166762 | PVES | 1x4 DIN | 65 | Passive | Standard |

## Connector Overview

### Connector Overview

| 1 x 4 DEUTSCH | 2 x 4 DEUTSCH | 1 x 6 DEUTSCH |
|---|---|---|
|  |  |  |

| 1 x 4 AMP | 2 x 4 AMP | 1 x 6 AMP | 1 x 4 DIN |
|---|---|---|---|
|  |  |  |  |

*PVEO-DI 4-pin AMP Connector*

| Pinout | Pin 1 | Pin 2 | Pin 3 | Pin 4 |
|---|---|---|---|---|
| 2x4 AMP (A) | $U_{DC}$_A | $U_{DC}$_B | GND | GND |
| 2x4 AMP (B) | DI-B | DI-A | GND | $U_{DC2}$ |

*PVEM 4-pin DIN Connector*

| Pinout | Pin 1 | Pin 2 | Pin 3 | Pin 4 |
|---|---|---|---|---|
| 1x4 DIN | $U_{DC}$ | $U_S$ | Error | GND |

*PVEO, PVEO-R and PVEO-HP 4-pin Connector*

| Pinout | Pin 1 | Pin 2 | Pin 3 | Pin 4 |
|---|---|---|---|---|
| 1x4 AMP | $U_{DC}$_A | $U_{DC}$_B | GND | GND |
| 1x4 DEUTSCH | $U_{DC}$_A | GND | GND | $U_{DC}$_B |
| 1x4 DIN | $U_{DC}$_A | $U_{DC}$_B | - | GND |

*PVEA/PVEH/PVES*

| Pinout | Pin 1 | Pin 2 | Pin 3 | Pin 4 |
|---|---|---|---|---|
| 1x4 AMP | $U_S$ | $U_{DC}$ | GND | Error |
| 1x4 DEUTSCH | $U_S$ | Error | GND | $U_{DC}$ |
| 1x4 DIN | $U_{DC}$ | $U_S$ | Error | GND |

*PVEA-DI and PVEH-DI 4-pin Connector*

| Pinout | Pin 1 | Pin 2 | Pin 3 | Pin 4 |
|---|---|---|---|---|
| 2x4 AMP (A) | $U_S$ | $U_{DC}$ | GND | Error |
| 2x4 AMP (B) | DI-A | DI-B | GND | $U_{DC2}$ |

## Connector Overview

*PVEA-DI and PVEH-DI 4-pin Connector (continued)*

| Pinout | Pin 1 | Pin 2 | Pin 3 | Pin 4 |
|---|---|---|---|---|
| 2x4 DEUTSCH (A) | $U_S$ | Error | GND | $U_{DC}$ |
| 2x4 DEUTSCH (B) | $U_{DC2}$ | GND | DI-A | DI-B |

*PVEH-FLA 6-pin Connector*

| Pinout | Pin 1 | Pin 2 | Pin 3 | Pin 4 | Pin 5 | Pin 6 |
|---|---|---|---|---|---|---|
| 1x6 AMP | $U_S$ | $U_{DC}$ | GND | Error | Float | - |

*PVEH-SP and PVES-SP 6-pin Connector*

| Pinout | Pin 1 | Pin 2 | Pin 3 | Pin 4 | Pin 5 | Pin 6 |
|---|---|---|---|---|---|---|
| 1x6 DEUTSCH | $U_S$ | Error | - | SP | GND | $U_{DC}$ |

## Fault Monitoring and Fault Reaction

All proportional control PVE Series 7 actuators feature:

- Integrated fault monitoring
- Detecting spool stroke inconsistencies
- Detecting internal hardware defects
- Detecting demand signal inconsistencies
- Fault reaction depending on the type of fault monitoring
  - Generic
  - Specific

Passive and active fault monitoring refers to whether or not the actuator is reacting on the error when it is detected.

### Active fault monitoring

No matter what kind of error is detected, the solenoid valves will be disabled and the operation that the valves/spool controls will stop immediately. Active fault monitoring keeps a “memory” of the error, even if it is no longer registered. The active fault monitoring does not have Auto Recovery because of this “memory” and a reboot/restart will therefore be required to reactivate the solenoid valves.

With an active fault monitoring the following scenarios will take place when an error is detected/occurs:

- The LED light will switch from green to red and the error pin output will go high
- The solenoid valves will be disabled and the operation that the valves/spool controls will stop immediately
- The active fault monitoring does not have Auto Recovery, so when the error is fixed/no longer is registered a reboot/restart of the PVE is required to reactivate it.

### Passive fault monitoring

Passive fault monitoring does not disable the solenoid valves when an error is detected. It will continue to operate despite that an error was detected. When the error no longer is registered the passive fault monitoring will “forget” the error and continue as if the error was never there.

With a passive fault monitoring the following conditions will happen when an error is detected/occurs:

- The LED light will switch from green to red and the error pin output will go high
- The solenoid valves will continue operating at the set point given at the time of the error
  - Only exception is if the error is caused by the supply voltage ($U_{DC}$) being either above or below the allowed range or if the temperature measured on the internal electronics board is higher than allowed. In these cases, the solenoid valves will be disabled.

An overview of the error states and the reaction to the errors can be seen in the table *Fault Reaction Overview*.

## Generic Fault Reaction

All PVE actuators with fault monitoring are triggered by the following main events:

| | |
|---|---|
| **Control Signal Monitoring** | The Control signal voltage ($U_S$) is continuously monitored. The permissible range is between 15% and 85% of the supply voltage ($U_{DC}$). Outside this range the PVE will switch into an error state. A disconnected $U_S$ pin (floating) is recognized as a neutral set point. |
| **Transducer/LVDT Supervision** | The internal LVDT wires are monitored. If the signals are interrupted or short-circuited, the PVE will switch into an error state. |

## Fault Monitoring and Fault Reaction

| | |
|---|---|
| **Supervision of Spool Position** | The actual position must always correspond to the demanded position ($U_S$). If the actual spool position is further out from neutral than the demanded spool position or in opposite direction, the PVE will switch into an error state. Spool position closer to neutral and in same direction will not cause an error state – the situation is considered *in control.* |
| **Float Position Monitoring** | Float position must be entered or left within a time limit.<br>A too high delay on the 1x6 pin float PVE will cause an error state – this is relevant for the 1x6 pin PVEH-F actuators only. |
| **Temperature Monitoring** | When the temperature is too high the PVE LED will light constant red and solenoid valves will be disabled. |

## Fault Reaction Overview

All entries have an Auto Recovery feature unless marked otherwise.

| Description | Monitoring | LED | Solenoid valves | Error pin output | Fault reaction time | |
|---|---|---|---|---|---|---|
| | | | | | PVEM/H/S | PVEA |
| Spool not at setpoint | Active* |  | Disabled | High | 500 | 750 |
| | Passive |  | - | High | 250 | 750 |
| Unable to reach float position | Active* |  | Disabled | High | 1000 | 1000 |
| | Passive |  | - | High | 1000 | 1000 |
| U dc > max. | Active |  | Disabled | - | - | - |
| | Passive |  | Disabled | - | - | - |
| U dc < min. | Active | ———— | Disabled | - | - | - |
| | Passive | ———— | Disabled | - | - | - |
| Us out of range | Active* |  | Disabled | High | 500 | 750 |
| | Passive |  | - | High | 250 | 750 |
| LVDT error | Active* |  | Disabled | High | 500 | 750 |
| | Passive |  | - | High | 250 | 750 |
| Temp > max. | Active* |  | Disabled | High | 250 | 750 |
| | Passive |  | Disabled | High | 250 | 750 |

* Does not have Auto Recovery

## Error Pin Specification

All proportional control PVE Series 7 actuators feature an error pin, indicating when an error is detected/ occurs, according to the Fault Reaction Overview table. The specifications of the error pin is shown below.

| Description | No error | Error |
|---|---|---|
| Output state | Low | High |
| Output voltage | <2 Vdc | ~Udc |
| Output current | Max. 100 mA | |

## Functionality Overview

### Standard and Fixed US 0-10 Vdc

All standard proportional actuator variants (PVEM/PVEA/PVEH/PVES) can be controlled by an analog signal voltage (Us) or a PWM controlled signal voltage (Us) proportional to the supply voltage (Udc).

*PVEO*

| Description | Type | Value | |
|---|---|---|---|
| Supply voltage (Udc) | Rated | 12 Vdc | 24 Vdc |
| | Range | 11 to 15 Vdc | 22 to 30 Vdc |
| | Max. ripple | 5% | |

*PVEM/PVEA/PVEH/PVES*

| Description | Type | Value |
|---|---|---|
| Supply voltage (Udc) | Rated | 11 to 32 Vdc |
| | Range | 11 to 32 Vdc |
| | Max. ripple | 5% |
| Signal voltage (Us) | Neutral | Us = 0.5 · Udc |
| | Q: P to A | US = (0.5 to 0.25) · Udc |
| | Q: P to B | US = (0.5 to 0.75) · Udc |


The PVEH-U and PVES-U variants are controlled by a fixed 0-10 Vdc signal voltage (Us), directly compatible with standard PLC control.

*PVEH-U*

| Description | Type | Value |
|---|---|---|
| Supply voltage (Udc) | Rated | 11 to 32 Vdc |
| | Range | 11 to 32 Vdc |
| | Max. ripple | 5% |
| Signal voltage (Us) | Neutral | Us = 5 V |
| | Q: P to A | 5 V to 2.5 V |
| | Q: P to B | 5 V to 7.5 V |

## Functionality Overview


**Performance**




### PWM Voltage Control

The PVEM/PVEA/PVEH/PVES actuator variants can be controlled by a PWM controlled signal voltage (Us) proportional to the supply voltage (Udc).

The $V_1$ and $V_2$ must be symmetrical around Udc/2 and $V_1$ must be equal to or less than Udc.




*PVEM Control Specification*

| Description | Type | Value |
|---|---|---|
| Supply Voltage (Udc) | Rated | 11 to 32 Vdc |
| | Range | 11 to 32 Vdc |
| | Max. ripple | 5% |

## Functionality Overview

*PVEM Control Specification (continued)*

| Description | Type | Value |
|---|---|---|
| Signal Voltage PWM (Us) | Neutral | Us = 50% DUT |
| | Q: P to A | Us = 50% to 25% DUT |
| | Q: P to B | Us = 50% to 75% DUT |
| PWM Frequency (Us) | Recommended | > 200 Hz |

*PVEA/PVEH/PVES Control specification*


| Description | Type | Value |
|---|---|---|
| Supply Voltage (Udc) | Rated | 11 to 32 Vdc |
| | Range | 11 to 32 Vdc |
| | Max. ripple | 5% |
| Signal Voltage PWM (Us) | Neutral | Us = 50% DUT |
| | Q: P to A | Us = 50% to 25% DUT |
| | Q: P to B | Us = 50% to 75% DUT |
| PWM Frequency (Us) | Recommended | > 1000 Hz |

## Functionality Overview


### Ramp (-R)

The Ramp functionality is a rate limitation of the spool stroke, resulting in extended reaction times and in some cases a smoother control of the main spool compared to the standard PVEO variant. The Ramp functionality of a *PVEO-R* variant is achieved purely hydraulically by implementing two orifices working on both sides of the main spool (integrated in the actuator). The Ramp functionality of a *PVEM-R* variant is achieved in the regulation principle.

*PVEO with ramp functionality (PVEO-R)*




*PVEM with ramp functionality (PVEM-R)*





For reaction times, see *PVE S7 Reaction Times* on page 54

## Functionality Overview

### Quick Reaction (-Q)

The Quick Reaction functionality of the *PVEM-Q* variant results in shorter reaction times and a more rapid or aggressive control of the main spool compared to the standard PVEM variant. The Quick Reaction functionality of a PVEM-Q is achieved by replacing the combined orifice and check valve with a check valve in the connection to tank and changing the regulation principle.

*PVEM with quick reaction functionality (PVEM-Q)*




For reaction times, see *PVE S7 Reaction Times* on page 54.


## Functionality Overview

### Float B-Port (-FLB)

The Float B-Port functionality enables the proportional PVEM-FLB/PVEH-FLB actuator variants to enter the main spool into a float position. The PVE actuators with Float B-Port functionality is compatible with the dedicated main spools with electronic float in B-port.

| PVE Type | PVBS Type | Standard FC | Float Control |
|---|---|---|---|
| PVEM-FLB (1x4 pin) | Deadband 1.5 mm<br>Max. B-port flow 4.8 mm | Us = (0.35 → 0.65) · $U_{DC}$ | Us = 0.75 · $U_{DC}$ |
| PVEH-FLB (1x4 pin) | | | |

*Float in B-port functionality*




## Functionality Overview

### Float A-Port (-FLA)

The Float A-Port functionality enables the proportional PVEH-FLA actuator variants to enter the main spool into a float position. The PVE actuators with Float A-Port functionality is compatible with the dedicated main spools with electronic float in A-port.

| PVE Type | PVBS Type | Standard Flow Control | Float Control |
|---|---|---|---|
| PVEH-FLA (1x6 pin) | Deadband 1.7 mm | Us = (0.25 → 0.75) · Udc | U dc to dedicated float pin (UF) |
| | Max. B-port flow 8.0 mm | | |




### PVE Power Save

All proportional actuator variants feature a Power Save mode, de-energizing the solenoid valve bridge. The Power Save mode is entered when the signal voltage (Us) and the LVDT spool position has been in neutral for 750 ms. As soon as the signal voltage (Us) or the LVDT spool position is out of neutral the PVE will leave its Power Save mode and re-energize the solenoid valve bridge as usual.

The Power Save mode results in increased power efficiency by reducing the current consumption of the PVE actuators in neutral position. The Power Save mode has no effect on the performance of the PVE actuator.


For current consumption values, please see chapter *Current Consumption*.

## Special Features


### Direction Indication (-DI)

The PVEO-DI/PVEA-DI/PVEH-DI actuator variants feature an integrated Direction Indication output derived from the LVDT spool position, indicating the state of the main spool (neutral, A-port or B-port).


*PVEO-DI functionality*




*PVEA-DI functionality*




*PVEH functionality*





The Direction Indication feature uses a dual power supply with the 2x4 pin AMP and DEUTSCH connectors as shown in the chapter *Connector Overview* on page 37.

## Special Features

When both DI_A and DI_B signals are High the main spool is in its neutral position.

When the DI_A signal goes Low and the DI_B signal stays High, the main spool is moving in the A-port direction, and vice versa. The relation between the direction indication feedback and the output signal is shown below.

*Direction indication feedback*




157-435.10

| | **A-Port** | **B-Port** |
|---|---|---|
| DI signals a1, a2 | –0.8 mm ± 0.4 mm | 0.8 mm ± 0.4 mm |
| Max. DI load | 200 mA | |
| DI High @ 20 mA | > $U_{DC}$ – 1.5 $V_{DC}$ | |
| DI High @ 100 mA | > $U_{DC}$ – 2.0 $V_{DC}$ | |
| DI Low | < 0.2 $V_{DC}$ | |


## Special Features

### Dedicated Float Pin (UF)

The Dedicated Float Pin (UF) feature is related to the PVEH-FLA actuator variant enabling the user to move the main spool into its float position by power. The PVEH-FLA uses 1x6 pin AMP orDEUTSCH connectors.

- Normal operation: Low or not connected
- High Float
- Input range: $U_{DC}$
- Max. voltage: 32 $V_{DC}$

*PVEH-FLA functionality diagram*




## Special Features


### Spool Position (SP)

The Spool Position (SP) feature available in the PVEH-SP/PVES-SP actuator variants enables the user to derive from the LVDT spool position of the main spool by means of an analog voltage signal on the dedicated spool position (SP) output pin.


*PVEH-SP functionality diagram*




*PVES-SP functionality diagram*




*Spool Position feedback*




SP feedback signal from 0.5 to 4.0 $V_{DC}$ inverted in direction relative to $U_S$ 2.5 $V_{DC}$ as the neutral value
SP from neutral to maximum stroke (mm)
SP maximum load is 0.5 mA
Output range for A-port: 2.5 – 1.25 $V_{DC}$ and for B-port: 2.5 – 3.75 $V_{DC}$


The PVEH-SP/PVES-SP uses a 1x6 DEUTSCH connector. For more information, please see *Connector Overview* on page 37.

## Special Features


### Neutral Power-OFF (NP)

The Neutral Power-OFF (NP) feature available in the PVEA-NP and PVEH-NP actuator variants enables the user to identify whether the solenoid valves in the actuator are energized or de-energized via a dedicated neutral power-OFF (NP) output pin.

*PVEA-NP functionality diagram*





*PVEH-NP functionality diagram*




The Neutral Power-OFF (NP) signal is defined as shown below:

*Solenoid disabling function (-NP) curves*




Normal operation from > $U_{DC}$ to 2 $V_{DC}$
Power Save < 1 $V_{DC}$ (solenoid valves de-energized)
NP maximum load is 50 mA

The PVEA-NP/PVEH-NP uses a 1x6 DEUTSCH connector. For more information, please see *Connector Overview* on page 37.

## Special Features


### Disable Mode

The PVEH-Uand PVES-U actuator variants controlled by a fixed 0-10 $V_{DC}$ signal voltage ($U_S$), feature the ability to enter a disable mode. This causes the counteracting force on the main spool created by the solenoid valve bridge to deactivate, when using Manual OverRide (MOR).

The disable mode is entered by sending a signal voltage (Us) of 16.2% of 10 $V_{DC}$ when in Power Save.

## Performance Overview

### PVE S7 Reaction Times




| Reaction |
|---|
| T0 – Boot-up [ms] |
| T1 – Neutral to max. spool stroke |
| T2 – Max. spool stroke to neutral |
| T1 – Neutral to max. spool stroke |
| T2 – Max. spool stroke to neutral |


*PVG 32/100 PVEO—PVEM-R reaction times*

| Reaction | PVEO | PVEO-R | PVEO-HP | PVEM | PVEM-R |
|---|---|---|---|---|---|
| T0 [ms] | 0 | 0 | 0 | 15 | 15 |
| T1 @ Power ON [ms] | 110 | 300 | 90 | 225 | 325 |
| T2 @ Power OFF [ms] | 110 | 110 | 70 | 110 | 110 |
| T1 @ Constant U dc [ms] | 110 | 300 | 90 | 210 | 310 |
| T2 @ Constant U dc [ms] | 110 | 110 | 70 | 90 | 90 |

*PVG 32/100 PVEM-Q—PVES reaction times*

| Reaction | PVEM-Q | PVEA | PVEH | PVES |
|---|---|---|---|---|
| T0 [ms] | 15 | 15 | 15 | 15 |
| T1 @ Power ON [ms] | 125 | 280 | 125 | 125 |
| T2 @ Power OFF [ms] | 110 | 200 | 110 | 110 |
| T1 @ Constant U dc [ms] | 110 | 265 | 110 | 110 |
| T2 @ Constant U dc [ms] | 90 | 200 | 90 | 90 |

### Hysteresis and Ripple



## Performance Overview

| Type | Hysteresis (h) | Steady state ripple @ fixed Us (v) |
|---|---|---|
| | Rated [%] | Rated [mm] |
| *PVEM* | 15 | 0.0 |
| *PVEM-R* | 15 | 0.0 |
| *PVEM-Q* | 15 | 0.0 |
| *PVEA* | 2 | 0.3 |
| *PVEH* | 4 | 0.0 |
| *PVEH 256* | 1.5 | 0.0 |
| *PVES* | 0 | 0.2 |

The stated values are preliminary values and can be subject to change once an increased statistical basis is achieved.

## Current Consumption

| Type | Typical | Minimum | Maximum |
|---|---|---|---|
| | [mA] | | |
| *PVEO @ 12 Vdc* | 480 | 430 | 950 |
| *PVEO @ 24 Vdc* | 250 | 220 | 480 |
| *PVEO-HP @ 12 Vdc* | 750 | 660 | 1460 |
| *PVEO-HP @ 24 Vdc* | 380 | 340 | 740 |

| Type | @ 12 Vdc | @ 24 Vdc |
|---|---|---|
| | [mA] | |
| *PVEM* | 690 | 350 |
| *PVEA* | 290 | 150 |
| *PVEH* | 540 | 270 |
| *PVES* | 560 | 280 |

The stated values are preliminary values and can be subject to change once an increased statistical basis is achieved.



## Oil Consumption

| Type | Neutral | Locked position | Actuating |
|---|---|---|---|
| | [l/min] | | |
| *PVEO* | 0.0 | 0.0 | 0.9 |
| *PVEO-R* | 0.0 | 0.0 | 0.3 |
| *PVEO-HP* | 0.0 | 0.0 | 0.9 |
| *PVEM* | 0.0 | 0.0 | 0.5 |
| *PVEM-R* | 0.0 | 0.0 | 0.3 |
| *PVEM-Q* | 0.0 | 0.0 | 0.3 |
| *PVEA* | 0.0 | 0.4 | 1.0 |
| *PVEH* | 0.0 | 0.0 | 0.7 |
| *PVES* | 0.3 | 0.1 | 0.8 |



## Dimension Overview

### Dimension Overview for PVE Series 7

*PVG 32/100 variants*



| PVEO/PVEM/PVEA | PVEH/PVES | Connector Height |
|---|---|---|
|  |  | DEU = 30 mm [1.2 in]<br>AMP = 38 mm [1.5 in]<br>DIN = 40 mm [1.6 in] |

*PVG 120 variants*

| PVEO | PVEH/PVES | Connector Height |
|---|---|---|
|  |  | DEU = 30 mm [1.2 in]<br>AMP = 38 mm [1.5 in]<br>DIN = 40 mm [1.6 in] |

## Dimension Overview

*PVG 128/256 variants*

| PVEO | PVEH | Connector Height |
|---|---|---|
|  |  | DEU = 30 mm [1.2 in]<br>AMP = 38 mm [1.5 in]<br>DIN = 40 mm [1.6 in] |

ENGINEERING
TOMORROW

**Products we offer:**

- Bent Axis Motors
- Closed Circuit Axial Piston Pumps and Motors
- Displays
- Electrohydraulic Power Steering
- Electrohydraulics
- Hydraulic Power Steering
- Integrated Systems
- Joysticks and Control Handles
- Microcontrollers and Software
- Open Circuit Axial Piston Pumps
- Orbital Motors
- PLUS+1® GUIDE
- Proportional Valves
- Sensors
- Steering
- Transit Mixer Drives

**Danfoss Power Solutions** is a global manufacturer and supplier of high-quality hydraulic and electronic components. We specialize in providing state-of-the-art technology and solutions that excel in the harsh operating conditions of the mobile off-highway market. Building on our extensive applications expertise, we work closely with our customers to ensure exceptional performance for a broad range of off-highway vehicles.

We help OEMs around the world speed up system development, reduce costs and bring vehicles to market faster.

Danfoss – Your Strongest Partner in Mobile Hydraulics.

**Go to www.powersolutions.danfoss.com for further product information.**

Wherever off-highway vehicles are at work, so is Danfoss. We offer expert worldwide support for our customers, ensuring the best possible solutions for outstanding performance. And with an extensive network of Global Service Partners, we also provide comprehensive global service for all of our components.

Please contact the Danfoss Power Solution representative nearest you.

**Comatrol**
www.comatrol.com

**Turolla**
www.turollaocg.com

**Hydro-Gear**
www.hydro-gear.com

**Daikin-Sauer-Danfoss**
www.daikin-sauer-danfoss.com

Local address:

**Danfoss**
**Power Solutions (US) Company**
2800 East 13th Street
Ames, IA 50010, USA
Phone: +1 515 239 6000

**Danfoss**
**Power Solutions GmbH & Co. OHG**
Krokamp 35
D-24539 Neumünster, Germany
Phone: +49 4321 871 0

**Danfoss**
**Power Solutions ApS**
Nordborgvej 81
DK-6430 Nordborg, Denmark
Phone: +45 7488 2222

**Danfoss**
**Power Solutions Trading (Shanghai) Co., Ltd.**
Building #22, No. 1000 Jin Hai Rd
Jin Qiao, Pudong New District
Shanghai, China 201206
Phone: +86 21 3418 5200

Danfoss can accept no responsibility for possible errors in catalogues, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without changes being necessary in specifications already agreed.
All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

TMA s.r.l. Via S.Vito, 221
41057 SPILAMBERTO (MO)
Tel. ++39.059.78.17.11
Fax. ++39.059.78.16.06
info@tmawinches.com



ARGANI ° WINCHES ° CABRESTANTES ° TREUILS DE LEVAGE ° HUBWINDE


**MANUALE D'USO E MANUTENZIONE**
Pag.1 (I)

**OPERATING SERVICE MAINTENANCE MANUAL**
Pag.6 (GB)

**MANUAL DE USO Y MANUTENCION**
Pag.11 (E)

**MANUEL D'UTILISATION ET ENTRETIEN**
Pag.16 (F)

**BETRIEB UND WARTUNGSANLEITUNGEN**
Seite 21 (D)

## IT GARANZIA

**1. Proprietà intellettuale**
I modelli, disegni, schemi e progetti rimangono di nostra proprietà e non è permesso riprodurli, utilizzarli o cederli a terzi senza nostra espressa autorizzazione scritta.

**2. Indicazioni tecniche**
Le caratteristiche tecniche dei prodotti si devono intendere sempre come valore medio e non impegnative. Ci riserviamo la facoltà di apportare modifiche, in qualsiasi momento e senza preavviso.

**3. Garanzia**
L'esame della richiesta di garanzia ha come premessa che il Committente abbia soddisfatto tutti gli obblighi contrattuali. Ci assumiamo la garanzia per difetti di materiale e di lavorazione per un periodo di dodici mesi dalla data di consegna. L'obbligo che ci deriva dalla garanzia comporta la riparazione o la sostituzione dell'intera unità, o parte di essa, a nostro insindacabile giudizio. Per esaminare la richiesta di garanzia dobbiamo poter disporre dell'unità integra, così come consegnata. Ogni intervento o manomissione del Committente o di terzi su unità contestate, ed in particolare, la mancanza della targhetta, comporta la decadenza della garanzia. La garanzia non viene prestata nel caso di danni dovuti a negligenza o incompetenza dell'utilizzatore e comunque per uso non conforme alle caratteristiche o alle prescrizioni. Il termine di garanzia, per le unità riparate o sostituite in garanzia, viene prorogato oltre la scadenza originaria per un massimo di tre mesi dalla data dell'intervento o della restituzione. Tutte le spese di qualsiasi natura derivanti dallo smontaggio dell'unità e dal suo trasporto al nostro domicilio, come pure quelle derivanti dal trasporto dell'unità riparata o sostituita al domicilio dell'Utente, e del suo rimontaggio, sono a carico del Committente. Non sono a nostro carico per nessuna ragione addebiti per danni di qualsiasi natura, quali fermo macchina, mancato guadagno e spese di manodopera, salvo diversi accordi che devono essere concordati esclusivamente per iscritto.

## GB WARRANTY

**1. Intellectual property**
Winch models, drawings and engineering are of our exclusive property. It is expressly forbidden to copy use or hand over to third parties such informations without a specific written permission.

**2. Technical data**
Technical data of products shall always be considered as medium and not binding. We do reserve the right to carry out modifications at any moment and without advance notice.

**3. Warranty**
The examination of a warranty claim is subject to the fulfilment by of all Customer contractual obligations. We do undertake the warranty for material and fabrication faults for a period of 12 months from delivery date. Our warranty obligations will cover the repair or the partial or complete renewal of claimed unit at our final decision. The examination of a warranty claim needs the availability of the complete unit as previously delivered. Any action carried out by the Customer or third parties to claimed units and specially the absence of the data plate will imply the warranty discontinuance. The warranty will not apply to damages or defects due to negligence, incompetence or use not conforming to features or instructions. The warranty period of units repaired or renewed under the warranty clause is extended for a maximum of 3 months starting from repair or redelivery date of the unit. All expenses of any kind to dismount and transport the unit to our residence as well as the ones to transport repaired unit to Customer residence and to refit such a unit are at Customer's charge.
Unless differently agreed in written we will not bear charges or expenses of any kind like machine stop, profit losses or manpower costs.

## E GARANTIA

**1. Propiedad intelectual**
Los modelos, dibujos, esquemas y proyectos permanecen de nuestra propiedad y no pueden ser reproducidos, utilizados o cedidos a terceros sin nuestra autorización escrita.

**2. Indicaciones técnicas**
Las características técnicas de los productos se entienden siempre de valor medio y no vinculantes. Nos reservamos el derecho de efectuar modificaciones en cualquier momento y sin previo aviso.

**3. Garantía**
El examen de la petición de garantía presupone que el comprador haya cumplido con todos los compromisos contractuales. Acordamos la garantía por los defectos de material y de fabricación por un plazo de doce meses desde la entrega. Esto compromiso comporta la reparación o el reemplazo de toda o parte de la unidad según nuestra intachable opinión. Para poder examinar la petición de garantía, el comprador tiene que ponernos a disposición la unidad integra, así como entregada. En el caso de que el comprador o terceros intervengan sobre las unidades contestadas y, en particular, en falta de la placa de fábrica, la garantía decae automáticamente. La garantía no se acuerda en caso de averías debidas a negligencia o incompetencia del usuario y de todas maneras en caso de uso no conforme a las características detalladas o a las prescripciones. El plazo de garantía para las unidades reparadas o reemplazadas puede ser aplazado del vencimiento originario de máximo tres meses desde la fecha de intervención o de devolución. Todos los gastos de cualquier tipo debidos al desmontaje de la unidad y a su transporte a nuestro domicilio así como los debidos al transporte de la unidad reparada o reemplazada al domicilio del usuario y a su remontaje son en cargo al comprador. No nos hacemos cargo, por ningun motivo, de los adeudos por daños de cualquier tipo como paro máquina falta de beneficio y gastos de mano de obra, salvo otros acuerdos escritos.

## F GARANTIE

**1. Propriété intellectuelle**
Les modèles, les dessins, les plans et les projets restent de notre propriété et ne peuvent pas être reproduits, utilisés ou cédés à tiers sans notre autorisation écrite.

**2. Indications techniques**
Les caractéristiques techniques des produits doivent s'entendre toujours de valeur moyenne et non compromettantes. Nous nous reservons le droit d'effectuer des modifications sans préavis et dans n'importe quel moment.

**3. Garantie**
La demande de garantie sera prise en considération à condition que le Commettant ait satisfait tous les engagements contractuels. Nous accordons la garantie pour défauts de matériel et de travail pour une période de douze mois à compter de la date de livraison. L'engagement que nous assumons au sujet de la garantie comporte le dépannage ou le remplacement de toute ou d'une partie de l'unité et ceci à notre jugement sans appel. Pour prendre en considération la demande de garantie, nous devons pouvoir disposer de l'unité complète, ainsi comme elle a été livrée. Chaque intervention du Commettant ou de tiers sur les unités contestées, et en particulier le manque de la plaquette, comporte la déchéance de la garantie. La garantie n'est pas prêtée en cas d'inconvénients ou de dommages dûs à négligence ou à incompétence ou, de toute façon, à l'emploi de matériaux non conformes aux instructions. Pour les pièces et les unitées dépannées ou remplacées en garantie, le délai de garantie s'entend prolongé au-delà de l'échéance originaire jusqu'à un maximum de trois mois à compter de leur date d'intervention ou de retour. Tous les frais de n'importe quelle nature, dûs au démontage de l'unité ou à son transport auprès de notre siège ainsi que ceux dûs au transport de l'unité dépannée ou remplacée chez l'utilisateur et à son remontage sont à la charge du Commettant. Les dommages de n'importe quelle nature, soit arrêt machine, gain manqué et frais de main-d'oeuvre, ne pourront en aucun cas nous être débités à moins que d'autres accords, qui devront cependant être confirmés par écrit, n'aient été pris.

## D GEWÄHRLEISTUNG

**1. Geistiges Eigentum**
Die Modelle, Zeichnungen, Pläne und Projekte bleiben von unserem Eigentum; ohne unsere, ausdrücklische schriftliche Zustimmung können diese nicht nachgedruckt, verwendet oder Dritten abgetreten werden.

**2. Technische Eigenschaften**
Die technischen Eigenschaften der Produkte sind immer von Mittelwert und unverbindlich zu verstehen. Wir behalten uns vor, Änderungen jederzeit und ohne vorherige Benachrichtigung auszuführen.

**3. Gewährleistung**
Eine Gewähr wird nur übernommen, wenn der Auftraggeber seinen vertraglichen Verpflichtungen nachgekommen ist. Für Material- und Bearbeitungsfehler sind wir nur für einen Zeitraum von 12 Monaten ab Lieferungsdatum verantwortlich. Unsere Gewährleistungspflicht ist auf die Reparatur bzw. Ersetzung der Gesamt- oder Teileinheit nach unserem unanfechtbaren Dafürhalten beschränkt. Um den Gewährleistungsantrag in Erwänung zu ziehen, muß uns die Gesamteinheit - wie im Lieferzustand - beigestellt werden. Jede Arbeit oder Handhabung seitens des Auftraggebers oder Dritter an beanstandeter Einheit, insbesondere das Fehlen des Typschilds, läßt den Gewährleistungsanspruch verfallen. Für Schäden, die der Nachlässigkeit oder Unfähigkeit des Bedieners zuzuschreiben oder bei unerlaubtem Einsatz entstanden sind, übernimmt TMA keine Verantwortung. Die Gewährleistungsfrist für die reparierten oder ersetzten Einheiten wird höchstens drei Monate ab dem Nachbesserungs- oder Rückgabedatum verlängert. Alle Demontage-, Tranport-, Rücktranport- und Wiedereinbaukosten hinsichtlich der reparierten oder ersetzten Einheiten gehen zu den Lasten des Auftraggebers. Soweit nicht ausdrücklich schriftlich etwas anderes vereinbart ist, sind alle weiteren Ansprüche des Auftraggebers für unmittelbaren und mittelbaren Schaden wie z.B. Wagenstand, Verdienstausfall und Arbeitskosten, ausgeschlossen.

## PREMESSA

**In questo manuale sono utilizzati tre tipi di avvertimenti per la sicurezza, che evidenziano altrettanti livelli di rischio.**

**"PERICOLO"**
È usato per evidenziare situazioni pericolose per l'operatore, e quindi, per prevenire gravi infortuni anche mortali.

**"ATTENZIONE"**
È usato per evidenziare situazioni pericolose per l'integrità e l'efficienza dell'argano e, quindi,possono riguardare anche la sicurezza e l'incolumità delle persone.

**"IMPORTANTE"**
È usato per richiamare l'attenzione su importanti informazioni che l'operatore deve conoscere e tener presente.

**ATTENZIONE**
**NON USARE L'ARGANO PRIMA DI AVER LETTO CON ATTENZIONE QUESTO MANUALE.**

**PERICOLO**
**IL PRESENTE APPARECCHIO NON È DESTINATO AD IMPIANTI PER IL SOLLEVAMENTO O LO SPOSTAMENTO DI PERSONE.**

**ATTENZIONE**
Leggere attentamente questo manuale prima di procedere alle operazioni di avviamento, di lavoro, di manutenzione, o prima di effettuare qualsiasi intervento sull'argano. La maggior parte degli incidenti che avvengono durante il lavoro sono dovuti alla inosservanza delle semplici norme di sicurezza o delle più elementari precauzioni. Per tale motivo, molti incidenti possono essere evitati conoscendo le cause e procedendo con opportuna attenzione.

**ATTENZIONE**
Questo manuale intende essere una guida per l'impiego corretto e sicuro dell'argano, e per la sua razionale manutenzione.
La costante osservanza delle norme in esso contenute garantisce le migliori prestazioni,l'economia di esercizio ed una lunga durata dell'argano e consente di evitare le più comuni cause di incidenti che possono verificarsi durante il lavoro o la manutenzione.
Una volta letto, questo manuale va conservato integro in tutte le sue parti, in prossimità dell'argano, in modo che sia sempre disponibile.
Nel caso si presentassero problemi di comprensione di questo manuale o di parti di esso,raccomandiamo di contattare la ditta *TMA*.
Per qualsiasi tipo di assistenza tecnica rivolgersi alla ditta *TMA*.

**IMPORTANTE**
La ditta *TMA* si riserva il diritto di apportare modifiche e miglioramenti ai propri argani in qualsiasi momento senza alcun obbligo di preavviso e non risponde per qualsiasi differenza che possa intercorrere fra le caratteristiche dell'argano e le descrizioni del presente libro uso e manutenzione.

## INDICE GENERALE


PREMESSA..... 3
INDICE GENERALE..... 3
1. CAPITOLO PRIMO. INFORMAZIONI
1.1 Dati di identificazione: peso e dimensioni..... 4
1.2 Descrizione generale argano e dei dispositivi di sicurezza..... 4
1.3 Avvertenze generali. Norme di sicurezza..... 4
1.4 Trasporto e consegna. Condizioni di fornitura..... 4
2. CAPITOLO SECONDO. FUNZIONAMENTO E INSTALLAZIONE
2.1 Installazione..... 4
2.2 Lubrificazione..... 5
2.3 Montaggio del cavo..... 5
2.4 Impianto idraulico: suggerimenti e prescrizioni..... 6
2.5 Condizioni d'utilizzo..... 6
2.6 Messa in funzione..... 6
3. CAPITOLO TERZO. MANUTENZIONE
3.1 Operazioni di manutenzione..... 7
3.2 Eventuali problemi: cause e soluzioni..... 7
4. CAPITOLO QUARTO. LISTA RICAMBI E COMPLESSIVO
4.1 Complessivo..... 7
4.2 Lista ricambi..... 7


# CAPITOLO PRIMO

**ATTENZIONE**
Per un corretto utilizzo dell'argano al fine di ottenere un buon funzionamento nel tempo, si consiglia di leggere con attenzione le seguenti note che permettono di ottenere una buona conoscenza del prodotto.

## 1. INFORMAZIONI

### 1.1 Dati di identificazione, peso e dimensioni

Per i dati di identificazione e peso vedere la targhetta rivettata sull'argano.
Per caratteristiche e dimensioni vedere allegato n.1 (Pag.28).




### 1.2 Descrizione generale argano e dei dispositivi di sicurezza

Gli elementi principali che costituiscono gli argani *TMA* sono:
Motore: L'organo che fornisce la coppia utile per movimentare il carico.
Freno di stazionamento: È il dispositivo di sicurezza che, creando una coppia resistente, contrasta il movimento del carico. Interviene quando si toglie energia al motore. Agisce sulla coppia di ingresso ed ha normalmente un valore pari a due volte la coppia motrice. È possibile, a richiesta, prevedere un ulteriore freno di sicurezza che agisce direttamente sul tamburo.
Riduttore: Dispositivo che moltiplica la coppia erogata dal motore per ottenere la coppia necessaria alla movimentazione del carico.
Tamburo: È l'elemento destinato alla raccolta del cavo ed è delimitato da due flange. Come elemento di sicurezza, il diametro esterno delle flange laterali è maggiore di una quantità pari a tre volte il diametro del cavo rispetto al diametro esterno dell'ultimo strato utile.
Supporto: Struttura che sostiene il tamburo e gli altri elementi costitutivi dell'argano.
Dispositivi di finecorsa
(RES 4.1.2.3 della Direttiva 2006/42/CE): Possono essere a contagiri o a sensore e servono per mantenere l'ampiezza dei movimenti del carico entro i limiti previsti.
Vengono forniti in base alla specifica esigenza del cliente e al tipo di applicazione.
Pressacavo: È il dispositivo che evita che il cavo, senza tensione, si allenti o si srotoli sul tamburo.
Limitatore di tiro (EN 12077-2)
È il dispositivo di sicurezza che impedisce che l'argano possa sollevare un carico superiore al massimo consentito o che venga sollecitato con un carico anomalo. Il dispositivo viene preventivamente tarato dalla *TMA* per il valore del carico massimo ammissibile così come è stato specificato in fase di ordine.
Valvola di controllo del carico (per argani idraulici)
Ha la funzione di impedire che la velocità di rilascio del carico sia superiore a quella ottenibile dall'impianto e di bloccare il movimento in caso di rottura dei tubi.
È flangiata normalmente sul motore.

### 1.3 Avvertenze generali per la sicurezza

1)Verificare che l'argano sia conforme alle vostre necessità e che rispetti le normative in vigore.
2) Realizzare sulla macchina un sistema di fissaggio sicuro e rigido.
3) Posizionare l'argano in modo corretto utilizzando tutti i fori di fissaggio ed assicurarsi che le viti di fissaggio siano idonee e correttamente serrate.
4) Nel caso l'argano sia di facile accesso per terzi realizzare le opportune protezioni come richiesto dalla Direttiva 2006/42/CE
5) Inserire nel tamburo la quantità di olio necessaria per una corretta lubrificazione e verificarne il livello.
6) Non maneggiare il cavo senza indossare guanti antinfortunistici e non tentare mai di modificare la posizione del cavo sotto carico.
7) Accertarsi che il cavo sia correttamente ancorato al tamburo e abbia caratteristiche e dimensioni compatibili con le caratteristiche dell'argano.
8) Verificare che il senso di avvolgimento del cavo sia corretto e conforme a quello indicato sull'argano.
Un corretto montaggio del cavo contribuisce ad aumentarne la vita.
9) Verificare che il cavo sia integro e non presenti fili rotti o pieghe che ne possono provocare la rottura.
10) Verificare che i dispositivi di sicurezza siano funzionanti ed efficaci.
11) Accertarsi che le condizioni di funzionamento siano coerenti con le caratteristiche dell'argano.
12) Non realizzare tiri con carichi superiori a quelli massimi consentiti.

### 1.4 Trasporto e consegna - condizioni di fornitura

Ogni argano viene consegnato montato, collaudato ed adeguatamente imballato su pallet.
Al momento della consegna controllare l'integrità del prodotto; in caso di danni comunicare immediatamente i fatti al trasportatore.
Per la movimentazione dell'argano vedere allegato n.7 (Pag.28).

# CAPITOLO SECONDO

## 2. INSTALLAZIONE E FUNZIONAMENTO

### 2.1 Installazione

- Gli argani *TMA*, se utilizzati con asse orizzontale possono essere montati in qualsiasi posizione rispettando le forature esistenti.
For use in different configurations, contact the service TMA.
- Per evitare che nell'argano si creino delle tensioni anomale che potrebbero provocare una rapida usura degli organi interni è necessario che il supporto sul quale verrà fissato l'argano sia rigido e piano.
- Posizionare l'argano sulla piastra e verificare che i punti di appoggio aderiscano perfettamente al piano della piastra del supporto.
Qualora rimanesse della luce fra i piani di appoggio, spessorare opportunamente e, solo successivamente, serrare le viti di fissaggio.
Suggeriamo di utilizzare sempre tutti i fori di fissaggio previsti e di usare viti con caratteristiche non inferiori alla classe 8.8 serrandole con la dovuta coppia.
- La posizione dell'argano sulla piastra di ancoraggio deve essere tale da realizzare una perfetta perpendicolarità tra l'asse del tamburo e la linea congiungente la mezzeria del tamburo e la prima puleggia.
Piccole deviazioni possono provocare un cattivo avvolgimento della fune sul tamburo.
- La distanza tra l'argano e la prima puleggia deve esseretale da rispettare l'angolo di funzionamento caratteristico del cavo.

**ATTENZIONE**
Se l'argano è installato in posizione tale da essere facilmente accessibile, è necessario che il tamburo e le parti in movimento siano opportunamente protette con relative protezioni (2006/42/CE). E' necessario concordare con TMA l'eventuale fornitura di detti accessori sulle effettive esigenze del cliente.

## 2.2 Lubrificazione

- Lubrificazione interna.
Poiché gli organi interni dell'argano quali riduttori cuscinetti e freni lavorano in bagno d'olio, per ottenere un buon funzionamento è necessario garantirne una idonea lubrificazione mantenendo sempre il giusto livello di lubrificante.
- Per condizioni di uso leggero è ammesso l'utilizzo di olio idraulico di ottime caratteristiche con viscosità compatibile con le condizioni di utilizzo e ambientali (secondo ISO 3448 in ambienti temperati -5 °C ÷ 40 °C viscosità VG32 - VG46, in ambienti caldi 40 °C ÷ 65 °C viscosità VG64).
Per condizioni di uso gravoso usare un olio specifico per ingranaggi con viscosità compatibile alle condizioni ambientali (secondo ISO 3448 in ambienti temperati -5 °C ÷ 40 °C viscosità VG100 - VG150, in ambienti caldi 40 °C ÷ 65 °C viscosità VG150-220).
Per altre condizioni ambientali contattare la *TMA*.

**ATTENZIONE**
Gli argani *TMA* vengono spediti senza olio di lubrificazione. Se l'argano viene consegnato con la fune già montata, l'olio di lubrificazione è già inserito nel tamburo nella giusta quantità e del tipo ISO VG 46.
Prima di mettere in servizio l'argano effettuare il riempimento del tamburo inserendone la quantità di olio indicata dall'allegato n.2 (Pag.28). Tale quantità è idonea per riempire metà tamburo. Verificare il livello e, se necessario, effettuare le opportune correzioni.
La temperatura dell'olio di lubrificazione non deve superare il valore di 100°C.

## 2.3 Montaggio del cavo


**ATTENZIONE**
Nell'avvolgere il cavo, verificare che il senso di rotazione del tamburo sia uguale a quella indicata dalla freccia dell'adesivo applicato sul tamburo dell'argano.

**PERICOLO**
Qualora il cavo fosse avvolto sul tamburo senza rispettare il giusto senso di rotazione si potrebbe perdere il controllo del carico con gravi rischi per persone e cose.

**ATTENZIONE**
Per invertire il senso di rotazione del tamburo non è normalmente sufficiente invertire la posizione di attacco del cavo. Si consiglia pertanto di contattare l'ufficio assistenza *TMA* prima di procedere a modifiche o manomissioni.

**PERICOLO**
Non montare un cavo di lunghezza superiore al massimo ammissibile in quanto si otterrebbero strati non conformi alle normative di sicurezza.


Inserire il capo del cavo nell'apposita asola posta ad un lato del tamburo dall'interno verso l'esterno (fig.1).



(fig.1)


### 2.3.1 Montaggio con tasca e radancia

Il cavo va inserito nella tasca, realizzando un occhiello nel quale va inserito il cuneo (fig.2).




(fig.2)

Tirare il cavo dal lato opposto in modo da costringere il tutto nella tasca (fig.3 ).



(fig.3)

### 2.3.2 Montaggio con morsetti



(fig.4)

Serrare le viti dei morsetti (fig.4) in modo da bloccare il cavo dopo averlo inserito come in fig.1.

**PERICOLO**
Verificare che le viti di fissaggio dei morsetti non oltrepassino la lamiera dell'aletta. Nel caso in cui ciò accada, accorciare le viti opportunamente onde evitare che la fune si danneggi seriamente.

**PERICOLO**
È necessario lasciare un minimo di 4 spire di cavo sempre avvolte sul tamburo per garantire la trattenuta del carico.
Il sistema di fissaggio del cavo presente sull'argano non è ritenuto una sufficiente garanzia per la tenuta del carico.

**ATTENZIONE**
Nel primo montaggio occorre realizzare una perfetta compattazione del cavo sul tamburo senza lasciare vuoti tra le spire. Avvolgere il cavo sottoponendolo ad un'opportuna tensione. Il cavo che non è stato ben compattato si può facilmente danneggiare potendosi incuneare fra le spire sottostanti, quando si applica il carico .

## 2.4 Impianto idraulico: suggerimenti e prescrizioni

**ATTENZIONE**
Il corretto funzionamento dell'argano è condizionato dall'impianto idraulico nel quale tale apparecchio è inserito.
Verificare che i valori caratteristici dell'impianto idraulico relativamente a pressione e flusso massimi siano compatibili con le caratteristiche di funzionamento dell'argano.

Gli argani idraulici *TMA* sono dotati di un freno a dischi multipli ad azione negativa e di valvola per il controllo del carico flangiata sul motore.
- Freno
La coppia frenante si ottiene dall'attrito che si genera tra una serie di dischi statici (collegati alla struttura fissa) alternati ad una serie di dischi mobili (collegati all'albero di entrata) pressati tra loro dalla forza esercitata da una serie di molle. L'azione delle molle può essere contrastata da un opportuno pistone azionato idraulicamente.
Per aprire il freno, una piccola quantità di olio viene prelevata dalla linea in pressione del circuito del motore ed inviata al pistone posto all'interno del corpo freno (pressione minima di apertura 2.6 - 2.8 MPa, pressione massima ammissibile 28 - 30 MPa).
In tal modo si equilibra l'azione delle molle e si liberano i dischi mobili del freno. È così possibile la libera rotazione dell'albero del motore.
Quando si arresta l'argano si pone la leva della valvola di distribuzione in posizione centrale. Affinché il freno possa richiudersi, bloccando il movimento, occorre che l'olio defluisca dal pistone, permettendo alle molle di esercitare la loro spinta sui dischi. È fondamentale che la spola della valvola di distribuzione che comanda il motore abbia una configurazione che permetta al pistone di scaricare l'olio interno. Una configurazione della spola con centro ad "H" è pertanto necessaria.
Riferirsi allo schema idraulico in allegato n.6 (Pag.28).

**PERICOLO**
L'uso di una spola a centro chiuso, impedisce il deflusso dell'olio del pistone, e rende inefficace sia il freno di stazionamento che la valvola di controllo del carico. In tal caso si potrebbe avere la caduta incontrollata del carico a causa dello svuotamento, per cavitazione, del motore idraulico .

- Valvola di controllo del carico.
La valvola di controllo del carico, normalmente flangiata sul motore, ha la funzione principale di effettuare una frenatura dinamica del carico. Impedisce che la velocità del motore possa essere superiore a quella permessa dal flusso dell'olio. Ha anche la funzione di bloccare il movimento del carico, tramite l'azione del freno, nel caso della rottura della tubazione di alimentazione del motore.

**PERICOLO**
Non modificare la taratura della valvola di controllo del carico.
La valvola viene tarata dalla *TMA* durante il collaudo dinamico al banco. Normalmente il collaudo viene effettuato dalla *TMA* con carichi superiori al tiro massimo nominale.
Modificare la taratura della valvola potrebbe provocare la perdita del controllo del carico.

- Tubazione.
La corretta realizzazione dell'impianto idraulico è determinante per il buon funzionamento dell'argano. Occorre pertanto dimensionare la sezione utile delle tubazioni proporzionandola al flusso di olio e alla lunghezza dell'impianto. Un'insufficiente sezione dei tubi determina cadute di pressione di linea con conseguente aumento della pressione di funzionamento di tutto l'impianto e contropressione sulla linea di ritorno. In tal modo si corre il rischio di avere un cattivo funzionamento dell'argano od anche un suo possibile danneggiamento.

**ATTENZIONE**
Per evitare inconvenienti al buon funzionamento dell'argano, la pressione necessaria a far fluire l'olio nelle tubazioni, non deve mai essere superiore a 0.5-1.0 MPa.

Per collegare l'argano all'impianto di alimentazione idraulico fare riferimento allo schema idraulico e al foglio tecnico fornito, con le corrette dimensioni e posizioni delle bocche di mandata, ritorno e per il drenaggio. Il diametro interno di tale tubo non deve essere inferiore a 1/4".

**ATTENZIONE**
Nel caso si verificasse una strozzatura o un'occlusione nella linea di drenaggio si creerebbero sicuramente danni al motore e all'argano con probabili perdite di olio.

- Valvola di sicurezza.
Prevedere sempre una valvola di sicurezza di massima pressione, tarata ad un valore superiore del 10-20% rispetto al valore della pressione di lavoro indicata in allegato 2 (Pag.28).
Normalmente tale valvola è parte integrante della valvola di distribuzione, ma, qualora non fosse presente, occorre prevederla nella linea di alimentazione dell'argano.

**ATTENZIONE**
I valori di pressione di funzionamento, riportati sui diagrammi di carico *TMA*, si riferiscono ad utilizzo con pressione di ritorno pari alla pressione atmosferica.

- Filtro
Per ottenere una corretta durata dell'argano utilizzare sempre sull'impianto idraulico un filtro di idonea capacità filtrante.
Per motori a pistoni 10 micron
Per motori orbitali 25 micron
Una periodica sostituzione del filtro allunga la vita di tutti i componenti dell'impianto.
- Olio
Per l'impianto idraulico utilizzare olio di buona qualità e con caratteristiche compatibili con i componenti utilizzati e con le condizioni ambientali.

**ATTENZIONE**
La temperatura dell'olio idraulico dell'impianto non deve superare la temperatura di 60 °C.

## 2.5 Condizioni d'utilizzo

**ATTENZIONE**
L'argano è stato costruito per un impiego in un campo di temperature ambientali compreso tra -20 °C e +50°C. Utilizzare l'argano al di fuori di questo campo di temperature costituisce uso improprio e non autorizzato dal costruttore.
Per altre condizioni vedi allegato n.2 (Pag.28).

## 2.6 Messa in funzione
- Verificare il riempimento dell'olio di lubrificazione.
- Prima di montare il cavo, effettuare alcune manovre a vuoto per verificare la correttezza dell'impianto.
- Montare il cavo secondo le indicazioni precedenti
- Con un carico ridotto effettuare alcuni sollevamenti e verificare il corretto funzionamento dei dispositivi di fine corsa.
- Con il carico nominale effettuare alcune prove e verificare la corrispondenza tra il valore della pressione di lavoro e quello indicato dalla scheda di collaudo *TMA*.
Verificare il corretto intervento del limitatore di tiro.

# CAPITOLO TERZO

## 3. MANUTENZIONE

### 3.1 Operazioni di manutenzione

Gli argani *TMA* sono stati progettati in modo da ridurre al minimo gli interventi di manutenzione.Prima di ogni intervento di manutenzione è necessario accertarsi che l'argano non possa essere accidentalmente azionato durante le operazioni. E' inoltre obbligatorio indossare tutti i dispositivi di protezione individuale idonei per la specifica operazione e valutando le condizioni ambientali di intervento.

**ATTENZIONE**
Ogni cinque anni l'argano deve essere sottoposto ad una revisione completa da effettuarsi presso un'officina specializzata.

- Verifica dell'olio di lubrificazione
Sia il freno che gli ingranaggi lavorano a bagno d'olio. Verificare che non vi siano perdite di olio di lubrificazione e controllare periodicamente una volta al mese il livello. Procedere eventualmente al ripristino. Si raccomanda la sostituzione dell'olio dopo 250 ore di funzionamento o almeno una volta all'anno.

**ATTENZIONE**
L'olio che viene sostituito deve essere smaltito secondo le normative vigenti nella località di utilizzo.

- Verifica del cavo
Tenere ben lubrificato il cavo con oli molto viscosi o grassi leggeri contenenti additivi adesivi con grafite, bisolfuro di molibdeno o trifosfato di sodio.

**PERICOLO**
Prima di operare con l'argano, verificare sempre che il cavo sia integro. Se presenta schiacciature o fili rotti, sostituirlo con un cavo nuovo idoneo.

- Verifica del serraggio viti
Verificare periodicamente il serraggio delle viti che fissano l'argano alla struttura.

### 3.2 Eventuali problemi: cause e soluzioni

| PROBLEMA | CAUSA | SOLUZIONE |
|---|---|---|
| **Il carico cade velocemente** | Cavo montato in senso contrario<br>Valvola di controllo carico starata<br>Posizione errata della valvola controllo carico<br>Flusso d'olio in direzione errata | Montare la fune nel senso corretto<br>Contattare l'assistenza tecnica<br>Montare la valvola nella posizione corretta<br>Invertire la posizione dei tubi di mandata e ritorno |
| **Il carico scende lentamente in continuo** | Freno inefficiente<br>Contropressione nel freno<br>Distribuzione centro chiuso | Contattare l'assistenza tecnica<br>Eliminare le contropressioni nell'impianto<br>Sostituire la spola |
| **L'argano non solleva il carico** | Taratura bassa<br>Motore danneggiato<br>Freno bloccato | Modificare la taratura<br>Verifica drenaggio. Sostituire il motore<br>Contattare l'assistenza tecnica |
| **L'argano solleva lentamente il carico** | Taratura bassa<br>Motore danneggiato<br>Flusso insufficiente<br>Freno non aperto | Modificare la taratura<br>Verifica drenaggio. Sostituire il motore<br>Controllare il flusso della pompa<br>Contattare l'assistenza tecnica |
| **Perdita di olio** | Tenute danneggiate<br>Tappi lenti<br>Trafilatura freno | Contattare l'assistenza tecnica<br>Serrare i tappi dell'olio<br>Contattare l'assistenza tecnica |
| **L'argano a vuoto non ruota** | Ingranaggi danneggiati<br>Assenza di flusso<br>Pressione impianto inesistente | Contattare l'assistenza tecnica<br>Controllare il flusso della pompa<br>Controllare la pompa |
| **Eccessiva rumorosità** | Ingranaggi rumorosi<br>Cuscinetti di banco danneggiati<br>Assenza olio di lubrificazione<br>Flusso di olio superiore all'ammissibile<br>Motore rumoroso | Contattare l'assistenza tecnica<br>Contattare l'assistenza tecnica<br>Controllare il livello dell'olio nel tamburo<br>Controllare il flusso della pompa<br>Contattare l'assistenza tecnica |
| **Il cavo non si avvolge correttamente sul tamburo** | Angolo di deviazione tra puleggia (o rinvio) e tamburo troppo elevato<br>La fune non è in tensione durante l'avvolgimento | Riportare l'angolo di deviazione entro limiti accettabili (2°)<br>Mettere la fune in tensione durante l'avvolgimento |
| **Perdita di olio dal tappo di sfiato** | Tenuta del motore danneggiate<br>Tenute del freno inefficienti | Sostituire le tenute |
| **L'argano tende a vibrare** | Viti di fissaggio lente | Serrare le viti di fissaggio con la coppia adeguata |

# CAPITOLO QUARTO

## 4. LISTA RICAMBI E COMPLESSIVO

### 4.1 Complessivo

Vedere allegato n.4 (Pag.28).

### 4.2 Lista ricambi

Vedere allegato n.5 (Pag.28).

# INTRODUCTION

**Below mentioned three types of safety warning, each one related to a different level of operational risk are used throughout present manual.**

**"DANGER"**
Used to emphasize situations which do involve a danger for the operator, thus to prevent possible accidents involving serious and mortal injuries.

**"WARNING"**
Used to emphasize situations involving danger for the entirety and the efficiency of the winch, also in connection with people's safety.

**"IMPORTANT"**
Used to draw the operator's attention to primary informations he shall be aware and bear in mind.

**WARNING**
**DO NOT USE THE WINCH BEFORE A CAREFUL READ OF PRESENT MANUAL.**

**DANGER**
**THE WINCH DESCRIBED ON PRESENT MANUAL SHALL NOT BE USED TO LIFT OR MOVE PEOPLE.**

**WARNING**
Read carefully present manual before start, use or carry out any maintenance operation on the winch. As the major part of industrial accidents are the consequence of failures to comply with simplest safety rules or most elementary precautions, the awareness of possible causes and the due attention to running operations can avoid a lot of accidents.

**WARNING**
Present manual is issued with the scope to be a guide for the correct and safe use of the winch and for its rational maintenance.
After careful reading keep present manual in unabridged condition and near the winch in order to be always available.
In case of non understanding of present manual or parts of such, we recommend to contact Messrs *TMA*.
For any kind of technical assistance please contact Messrs *TMA*.

**IMPORTANT**
Messrs *TMA* do reserve the right to modify and upgrade the winches they fabricate at any moment and without advance notice and will not be liable for any difference between winch features and the specifications of present use and maintenance manual.

## GENERAL INDEX


| | |
|---|---|
| 8..... | INTRODUCTION |
| 8..... | GENERAL INDEX |
| | SECTION 1. INFORMATIONS |
| 9..... | 1.1 Identification data, weights and dimensions |
| 9..... | 1.2 General description of winch and safety devices |
| 9..... | 1.3 General warnings, safety instructions |
| 9..... | 1.4 Transport, delivery, supply conditions |
| | SECTION 2. OPERATION AND INSTALLATION |
| 9..... | 2.1 Installation |
| 10..... | 2.2 Lubrication |
| 10..... | 2.3 Fitting of the wire |
| 11..... | 2.4 Hydraulic system, recommendations and instructions |
| 11..... | 2.5 Service conditions |
| 11..... | 2.6 Start up service |
| | SECTION 3. MAINTENANCE |
| 12..... | 3.1 Maintenance operations |
| 12..... | 3.2 Trouble shooting |
| | SECTION 4. GENERAL ASSEMBLY AND SPARE PARTS LIST |
| 12..... | 4.1 Drawing assembly |
| 12..... | 4.2 Spare part list |

# SECTION 1


**WARNING**

We do recommend to carefully read at following notes for a good knowledge of the product, a correct use and a long lasting good performance of the winch.

## 1. INFORMATIONS

### 1.1 Identification data, weight and dimensions

Identification data and weight are listed on the data plate riveted to the winch.
Winch features and dimensions are shown on attachment n.1(Pag.28)




### 1.2 General description of winch and safety devices

Principal components of *TMA* winches are the following:
Motor: The part delivering the torque driving the load.
Brake: The safety device delivering the torque opposing to the load when the motor is not feeded. The brake acts on the input torque and normally features twice the driving torque. A further safety brake, directly acting on the drum, can be delivered on request.
Reduction gear: The part which do multiply the torque delivered by the motor to obtain the one necessary to drive the load.
Drum: The part which winds the wire. Drum boundaries are the flanges. For safety reasons the diameter of the flanges is equal to the outer diameter of the upper allowed wire layer increased by three wire diameters. Frame: The structure which supports drum and other winch parts.
End stroke devices
(RES 4.1.2.3 of Directive 2006/42 / EC): The safety devices engineered to keep the range of load movements within stated limits. They may be made by revolution counter or sensors.They are provided according to the specific needs of the customer and the type of application.
Wire pressing device: The device engineered to avoid the loosening and the self unwinding from the drum of a slack wire.
Load limiting device: (EN 12077-2)
The safety device engineered to prevent the winch from lifting loads exceeding the allowed maximum or from being subject to abnormal loads. The load limiting device is in house rated by *TMA* before delivery to the maximum allowed load stated on order.
Load control valve (hydraulic winches):
The valve preventing the load lowering speed to exceed the one allowed by the system and to stop winch movements in case of hydraulic pipe breaking. The load control valve is normally directly flanged to the motor.

### 1.3 General safety instructions

1) Check winch conformity to your needs and applicable rules in force.
2) Make sure that winch fastening system is safe and stiff.
3) Place the winch in a proper position and secure all fixing points with right size bolts correctly tightened.
4) Should the winch be easily accessible by third parties, realize the protections stated by CE rules (Directive 2006/42 / EC).
5) Fill up the drum with the oil quantity needed for a correct lubrication and check oil level.
6) Do not handle wires without accident prevention gloves and never try to move wires under tension.
7) Make sure that wire size and features are compatible with winch ones and check the correct fastening of the wire to the drum.
8) Check the wire winding sense on winch drum for correctness and conformity to the one stated on winch data sheet. The correct winding contributes to extend wire's operational life.
9) Check wire integrity and absence of broken strands or kinks which may cause wire breaking.
10) Check safety device operation and efficacy.
11) Make sure that working conditions do conform to winch features.
12) Never lift loads exceeding maximum stated ones.

### 1.4 Transport, delivery, supply conditions

Every winch is delivered completely assembled, tested and packed on pallet.
Check product integrity on delivery and immediately notify found damages to the transport company.
For winch handling see attachment n.7 (Pag.28).

# SECTION 2

## 2. INSTALLATION AND OPERATION

### 2.1 Installation

- *TMA* winches can be installed in any position provided that winch shaft is horizontal and winch fastening is made with existing foundation holes.
For use in different configurations, contact the service TMA.
- Winch foundation shall be flat and stiff to avoid anomalous tensions which could cause the quick wear of internal parts
- Position the winch onto the foundation and check winch foundation feet for perfect sticking to.
Fit opportune shim plates before foundation bolt tightening should any gap be found between foundation and winch feet.
Use grade 8.8 or higher foundation bolts through all existing foundation holes and tighten all bolts with due torque.
- Winch installation shall be such to warrant that the line connecting the middle of the drum to the first wire pulley is perfectly perpendicular to drum shaft.
Small deviations may cause the bad winding of the wire on the drum.
- The distance between winch and first pulley shall be such to warrant the correct fleet angle of installed wire.

**WARNING**

If the winch is installed in an easily accessible position, it is necessary that the drum and the moving parts are properly protected with relevant protections (2006/42 / EC).It is necessary to agree with TMA upon the supply of such accessories according to the actual needs of the customer.

## 2.2 Lubrication

- Internal lubrication

As winch internal parts like reduction gears, brakes and bearings are engineered to work in oil bath it is necessary to warrant the correct lubrication of such parts, always keeping the correct lubricating oil level.

-For light working conditions it is allowed the use of good quality hydraulic oils with viscosity able to withstand ambient temperature (in according to ISO 3448 for temperatures between -5 °C ÷ 40 °C viscosity VG32 - VG46, between 40 °C ÷ 65 °C viscosity VG64).

-For heavy working conditions use a specific gear oil having a viscosity able to withstand ambient temperature (in according to ISO 3448 for temperatures between -5 °C ÷ 40 °C viscosity VG100 - VG150, between 40 °C ÷ 65 °C viscosity VG150-220).

-For other ambient conditions consult *TMA*.

**WARNING**

*TMA* winches are usually delivered without lubricating oil. Should the winch be delivered with pre fitted wire, the drum will be already filled up with the right quantity of lubrication oil of ISO VG 46 type.

Before running the winch fill up the drum with the lub oil quantity stated on attachment 2 (Pag.28). Such quantity shall fill up half of the drum. Check oil level and fill up an additional oil quantity if necessary.

Lubricating oil temperature shall never exceed 100 °C.

## 2.3 Fitting of the wire

**WARNING**

Check drum rotation sense for conformity to the adhesive arrow placed to winch drum.

**DANGER**

The misrespect of drum rotation sense when fitting the wire may cause load control losses involving danger to people or goods.

**WARNING**


Winch rotation sense cannot normally be changed by the simple reversion of wire dead end connection position.

We do recommend to call *TMA* technical assistance before carrying out any modification or tampering with the winch.

**DANGER**

Never fit a wire longer than the maximum allowed to avoid excess wire layers non conforming to safety rules.


Fit wire dead end from inside to outside the drum through the slotted hole made on one drum flange (see pict. 1)



(pict.1)


### 2.3.1 Fastening with pocket and wedge

The wire dead end shall be fitted in the pocked as to make an eye around the wire wedge with free end fitted backwards through the pocket (see pict.2).




(pict.2)

Pull the wire from the opposite side to press wire and wedge into the pocket (see pict. 3).



(pict.3)

### 2.3.2 Fitting with wire clamp



(pict.4)

Fit the wire as shown on pict. 1 and through the wire clamp of drum flange. Tighten wire clamp bolts (see pict. 4).

**DANGER**

Always keep a minimum of 4 wire coils winded around the drum to warrant a safe winch load holding.

The lone wire dead end fastening is not sufficient to hold the winch load.

**DANGER**

Make sure that wire clamp bolts don't pass over the flange plate. If it happens, shorten the bolts to avoid rope damage.

**WARNING**

The first winding of the wire to the drum shall be such to obtain a perfect compactness of the wire coils and leave no space between the coils.

Keep the wire under tension during the first winding operation.

The wire can be easily damaged should it be wedged under load between non compacted under laying coils.

## 2.4 Hydraulic system: suggestions and instructions

**WARNING**
Correct function of the winch will depend on the type of hydraulic system it is used with. Make sure that the maximum pressure and flow values of the hydraulic system are compatible with the winch's function characteristics.

TMA hydraulic winches are equipped with a negative multiple disc brake and a load control valve, which is flanged onto the engine.

- Brake
Braking torque is achieved through friction between a series of static discs (connected to the fixed structure) alternated with a series of moving discs (connected to the input shaft) which are pushed against one another due to pressure exerted by a series of springs. The action of the springs may be impeded by a special hydraulically-operated piston. To release the brake a small quantity of oil is taken from the pressure line of the engine circuit and sent to the piston inside the brake assembly (minimum opening pressure 2.6 - 2.8 MPa, maximum tolerable pressure 28 - 30 MPa).
This balances the action of the springs, thereby disengaging the moving brake discs and thus allowing for the free rotation of the engine shaft. When the winch stops the distribution valve lever should be returned to the central position. To engage the brake again, and thus prevent movement, the oil must flow out of the piston, allowing the springs to exert their pressure on the discs. It is vital that the distribution valve spool that controls the engine be shaped in a way that allows the piston to discharge the oil inside, and therefore a spool with an "H" type centre should always be used.
Please refer to the hydraulic drawing (enclosure 6 Pag.28).

**DANGER**
The use of a closed-centre spool will prevent the oil from flowing out of the piston and will render both the parking brake and load control valve ineffective. This could result in the fall of the load due to emptying of the hydraulic engine through cavitation.

- Load control valve
The load control valve which is normally flanged to the motor does realise the dinamic braking of the load.
It avoids that motor speed will exceed the maximum one allowed by the oil flow. A further scope is to stop load movements should the hydraulic piping be broken.

**DANGER**
Never reset the load control valve rating.
The load control valve is rated by *TMA* during the factory dynamic bench test which is normally carried out with loads exceeding the maximum nominal one.
The modification of the control valve rating may cause the loss of control of the load.

-Piping
Winch good operation is strictly connected to system correct realisation.
Pipe section shall be dimensioned in function of oil flow and system length. An insufficient pipe section will create pressure drops on the line, consequent working pressure increases in the all system and back pressures on the return line. Such situation may put the winch at risk for poor working condition and possible damage.

**WARNING**
To avoid winch brake poor working, the pressure necessary to flow the oil through distributor valve and filter (tank line) shall never exceed 0.5 MPa.
In order to obtain a correct operation, the pressure necessary to flow the oil through the winch piping system with by passed winch shall never exceed 1 Mpa.

To connect the winch to the hydraulic supply system refer to the hydraulic diagram and the data sheet provided with the correct dimensionsand positions of the ports of delivery, return and drainage.The internal diameter of the drain pipe shall never be less than¼".

**WARNING**
Winch and hydraulic motor will suffer sure damages should the drain line be chocked or clogged.

Safety valve
Always fit a system safety valve rated to a pressure exceeding 10 to 20% of the working pressure value stated on attachment 2 (Pag.28).
The safety valve is normally an integrant component of the distribution valve; should such safety valve be missing than a dedicated one shall be fitted on winch pressure line.

**WARNING**
Working pressure values stated on *TMA* load diagrams are based on atmospheric return line pressure.

-Filter
Always fit a filter of correct filtering gauge on the hydraulic system to obtain the correct winch working life.
Filtering gauges shall be the following:
10 microns for piston motors 25 microns for orbital motors
The periodical renewal of the filter will give a longer life to all system components.

-Hydraulic oil
Always fill up the hydraulic system with good quality hydraulic oil compatible with system components and ambient temperature.

**WARNING**
Hydraulic oil working temperature shall never exceed 60° C

## 2.5 Service conditions

**WARNING**
*TMA* winches are built to work in ambient temperatures from -20 °C to +50 °C.
The use of the winch outside above temperature range will be considered unsuitable and not authorized by the maker.
For other conditions see attachment n.2 (Pag 28).

## 2.6 Start up sequence
- Check lubricating oil fill up.
- Make a few trials without load before fitting the wire to check system correct operation.
- Fit the wire as described above.
- Make a few lifting trials with reduced load to check the correct operation of the end stroke devices
- Make a few lifting trials with winch nominal load and check the correspondance between found pressure values and the ones stated on the *TMA* test sheet.
-Check the correct working of the load limiting device.

# SECTION 3

## 3. MAINTENANCE

### 3.1 Maintenance operations

*TMA* winches are engineered to reduce to the bare minimum the maintenance operations. Before any maintenance it is necessary to ensure that the winch can not be accidentally activated during the operations.
It's also compulsory to wear all the suitable personal protective equipment for the relevant operation by evaluating the environmental conditions of the intervention.

**WARNING**
A complete revision shall be carried out by a *TMA* authorized workshop every 5 years.

Lubricating oil check
Both brake and reduction gear do work in oil bath. Check the winch for possible oil leaks and monthly check oil levels.
Lubrication oil renewal is recommmended every 250 working hours or at least once a year.

**WARNING**
Old lubricating oils shall be disposed according to applicable rules.

-Wire check
Keep the wire well lubrified by mean of heavy viscosity oils or light greases containing adhesive additives together with graphite, molybdenum bisulfide or sodium triphosphate

**DANGER**
Always check wire integrity before winch operation.
Fit a suitable new wire should hould the existing one have been squeezed or have broken strands.

- Bolt tightening check
Check periodically the tightening of winch foundation bolts.

### 3.2 Trouble shooting

| PROBLEM | POSSIBLE REASON | SOLUTIONS |
|---|---|---|
| **Quick load fall** | Reverse wire fitting<br>Derated load control valve<br>Erroneous load control valve position<br>Erroneous flow direction | Fit the wire the other way around<br>Contact the technical assistance<br>Fit the valve in the correct position<br>Reverse pipe connection |
| **The load slowly falls continuously** | Brake out of order<br>Back pressure to the brake<br>Closed center distributor | Contact the technical assistance<br>Eliminate system back pressure<br>Change distributor spool |
| **The winch does not lift the weight at all** | Low pressure<br>Motor failure<br>Locked brake | Change pressure rating<br>Check the drain. Renew the motor<br>Contact the technical assistance |
| **The winch does slowly lift the weighto** | Low pressure rating<br>Motor failure<br>Insufficient oil flow<br>Closed brake | Change pressure rating<br>Check the drain. Renew the motor<br>Check pump delivery flow<br>Contact the technical assistance |
| **Generical oil leaks** | Damage seals<br>Loose oil plugs | Contact the technical assistance<br>Tighten oil plugs |
| **The winch does not turn without load** | Damaged gears<br>Lack of oil flow<br>Lack of system pressure | Contact the technical assistance<br>Check pump delivery flow<br>Check the pump |
| **Excessive noise** | Noisy gears<br>Damaged foundation bearings<br>Lack of lubrication oil<br>Oil flow over the admissible<br>Noisy motor | Contact the technical assistance<br>Contact the technical assistance<br>Check oil level in the drum<br>Check pump delivery flow<br>Contact the technical assistance |
| **The wire does not correctly wind on the drum** | Excess fleet angle between drum and first pulley<br>Winding of slack wire | Set the fleet angle within acceptable limits (2°)<br>Keep the wire under tension during the |
| **Oil leak from relief plug** | Damaged motor seals<br>Damaged brake seals | Change the seals |
| **Winch vibration tendence** | Loose foundation bolts | Tighten foundation bolts with due torque |

# SECTION 4

## 4. GENERAL ASSEMBLY AND SPARE PARTS LIST

### 4.1 Drawing assembly

See attachment n.4 (Pag.28).

### 4.2 Spare part list

See attachment n.5 (Pag.28).

# PREAMBULO

**En este manual se mencionan tres tipos de instrucciones para la seguridad y otros tantos niveles de riesgo.**

**"PELIGRO"**
Se usa para poner en evidencia situaciones peligrosas para el usuario y, por lo tanto, para prevenir accidentes graves, incluso mortales.

**"CUIDADO"**
Se usa para poner en evidencia situaciones peligrosas para la integridad y el rendimiento del cabrestante y, por lo tanto, también para la seguridad y la incolumidad de las personas.

**"IMPORTANTE"**
Se usa para llamar la atención sobre informaciones importantes que el usuario debe conocer y tomar en nota.

**CUIDADO**
**NO UTILIZAR EL CABRESTANTE ANTES DE HABER LEIDO CON CUIDADO ESTE MANUAL.**

**PELIGRO**
**ESTE DISPOSITIVO NO ES DESTINADO PARA INSTALACIONES DE LEVANTAMIENTO O DE DESPLAZAMIENTO DE PERSONAS.**

**CUIDADO**
Leer con cuidado este manual antes de efectuar operaciones de puesta en marcha, de trabajo, de mantenimiento o cualquiera intervención sobre el cabrestante. El mayor número de accidentes de trabajo son debidos a inobservancia de las normas de seguridad y de las precauciones primarias. Por este motivo, muchos accidentes pueden ser evitados conociendo sus causas e interveniendo con cuidado.

**CUIDADO**
Este manual es una guía para el uso correcto y seguro del cabrestante y para su mantenimiento racional.
La constante observancia de las normas allá contenidas asegura un mejor rendimiento, una buena rentabilidad de trabajo y una larga duración del cabrestante; permite además evitar las comunes causas de accidentes durante el trabajo y el mantenimiento.
Una vez leido, este manual debe ser conservado, íntegro en todas sus partes, cerca del cabrestante, para que sea siempre disponible.
En caso de problemas de comprensión del manual o de algunas de sus partes, recomandamos
ponerse en contacto con *TMA*. Para cualquier tipo de asistencia téncica, ponerse en contacto con *TMA*.

**IMPORTANTE**
La empresa *TMA* se reserva el derecho de efectuar modificaciones y mejoramientos a sus cabrestantes en cualquier momento y sin previo aviso y no se hace cargo de alguna responsabilidad por cualquier diferencia que pueda encontrarse entre las características del cabrestante y las descripciones del presente manual de empleo y de mantenimiento.

## INDICE GENERAL


PREAMBULO ..... 13
INDICE GENERAL ..... 13
1. CAPITULO PRIMERO. INFORMACIONES
1.1 Datos de identificación: peso y dimensiones ..... 14
1.2 Descripción general cabrestante y dispositivos de seguridad ..... 14
1.3 Instrucciones generales. Normas de seguridad ..... 14
1.4 Transporte y entrega. Condiciones de entrega ..... 14
2. CAPITULO SEGUNDO. FUNCIONAMIENTO E INSTALACION
2.1 Instalación ..... 14
2.2 Lubrificación ..... 15
2.3 Montaggio del cavo ..... 15
2.4 Instalación hidráulica: consejos y prescripciones ..... 16
2.5 Condiciones de empleo ..... 16
2.6 Puesta en marcha ..... 16
3. CAPITULO TERCERO. ENTRETENIMIENTO
3.1 Operaciones de entretenimiento ..... 17
3.2 Posibles problemas: causas y soluciones ..... 17
4. CAPITULO CUARTO. LISTA REPUESTOS Y PLANO DE CONJUNTO
4.1 Plano de conjunto ..... 17
4.2 Lista repuestos ..... 17

# CAPITULO PRIMERO


**CUIDADO**

Para el uso correcto del cabrestante y un buen funcionamiento duradero, se aconseja leer con cuidado las siguientes notas que permiten conseguir un buen conocimiento del producto.

## 1. INFORMACIONES

### 1.1 Datos de identificación, peso y dimensiones

Para los datos de identificación yel peso, ver la placa remachada sobre el cabrestante.
Para las características y las dimensiones, ver el anexo n.1 (Pag.28).




### 1.2 Descripción general cabrestante y dispositivos de seguridad

Los elementos principales que constituyen los cabrestantes *TMA* son los siguientes:
Motor: es el órgano que ditribuye el par útil para desplazar la carga.
Freno de estacionamiento: dispositivo de seguridad que, creando un par resistente, contrasta el movimiento de la carga. Interviene cuando se corta energía al motor. Actúa sobre el par de entrada y normalmente tiene un valor igual a dos veces el par motor. A pedido, se puede haber un freno de seguridad suplementario que actúa directamente sobre el tambor.
Reductor: dispositivo que multiplica el par suministrado por el motor para conseguir el par necesario al desplazamiento de la carga.
Tambor: elemento que recoge el cable, delimitado por dos bridas. Como elemento de seguridad, el diámetro exterior de las bridas laterales es tres veces superior al diámetro del cable con respecto al diámetro exterior de la última capa útil.
Soporte: estructura que soporta el tambor y los otros elementos constructivos del cabrestante.
Dispositivos de tope
(RES 4.1.2.3 de la Directiva 2006/42/CE): pueden ser de cuentagiros o de detector y sirven para mantener la amplitud de los movimientos de la carga dentro de los limites previstos.
Son obligatorios, pero se montan bajo pedido.
Sujeta-cables: dispositivo que impide que el cable bajo tensión se afloje o se desenrolle sobre el tambor.
Limitador de tracción (EN 12077-2) Dispositivo de seguridad que impide que el cabrestante pueda levantar una carga superior a la máxima admitida o que sea sometido a una carga irregular. *TMA* ajusta previamente el dispositivo sobre el valor de carga máximo admisible mencionado al momento del pedido.

Válvula de control de la carga
(para cabrestanteshidráulicos)
Tiene la función de impedir que la velocidad de desenganche de la carga sea superior a la que puede ser alcanzada por la instalación y de bloquear el movimiento en caso de ruptura de los tubos.
Normalmente está conectada al motor por medio de una brida.

### 1.3 Instrucciones generales para la seguridad

1) Averiguar que el cabrestante sea conforme a sus necesidades y a las normas en vigor.
2) Realizar sobre la máquina un sistema de fijación seguro y rigido.
3) Posicionar correctamente el cabrestante utilizando todos los orificios de fijacion y averiguar que los tornillos de fijación sean idóneos y correctamente apretados.
4) En el caso de que el cabrestante sea facilmente accesible por terceros, realizar las oportunas protecciones según la Directiva máquinas Directiva 2006/42/CE.
5) Introducir en el tambor la cantidad de aceite necesaria para una correcta lubricación y averiguar su nivel.
6) No manejar el cable sin ponerse los guantes protectores y nunca intentar modificar la posición del cable bajo carga.
7) Averiguar que el cable sea correctamente fijado al tambor y que tenga unas características y dimensiones compatibles con las del cabrestante.
8) Averiguar que el sentido de arrollamiento del cable sea correcto y conforrme a lo indicado sobre el cabrestante. Un correcto montaje del cable contribuye acrecer su vida.
9) Averiguar que el cable sea integro y no tenga hilos rotos o pliegues que puedan provocar su ruptura.
10) Averiguar que los dispositivos de seguridad sean funcionantes y eficaces.
11) Averiguar que las condiciones de funcionamiento sean conformes a las características del cabrestante.
12) No efectuar tracciones con cargas superiores a las máximas admitidas.

### 1.4 Transporte y entrega - Condiciones de entrega

Cada cabrestante se entrega montado, ensayado y adecuadamente embalado sobre pallet.
Al momento de la entrega, controlar que el producto sea integro; en caso de daños, comunicarlo de inmediato al transportista.
Para la movilización del cabrestante vease anexo n.7 (Pag.28).

# CAPITULO SEGUNDO

## 2. INSTALACION Y FUNCIONAMIENTO

### 2.1 Instalación

- Los cabrestantes *TMA*, si utilizados con eje horizontal, pueden ser montados en cualquier posición, respetando los orificions existentes.
Para su uso en diferentes configuraciones, póngase en contacto con el servicio de TMA.
- Para evitar que en el cabrestante se formen tensiones irregulares que podrían provocar un rápido desgaste de los órganos internos, el soporte sobre el cual será fijado el cabrestante tiene que ser rigido y plano.
- Posicionar el cabrestante sobre la placa y averiguar que los puntos de apoyo estén perfectamente pegados al plano de la placa de soporte.
Si se queda un espacio libre entre los planos de apoyo, introducir arandelas y luego apretar los tornillos de fijación.
Aconsejamos utilizar siempre todos los orificios de fijación previstos y aplicar tornillos con características no inferiores a la clase 8.8 apretandolos con el par correspondiente.
- La posición del cabrestante sobre la placa de fijación debe alcanzar una perpendicularidad perfecta entre el eje del tambor y la línea que une la línea de centro del tambor y la primera polea.
Unas pequeñas desviaciones pueden provocar un arrolliamento irregular del cable sobre el tambor.
- La distancia entre el cabrestante y la primera polea debe permitir el respeto del ángulo de funcionamiento característico del cable

**CUIDADO**
Si el cabrestante está instalado en una posición tal que sea fácilmente accesible,es necesario que el tambor y las piezas móviles están debidamente protegida con protección relacionada (2006/42/CE). Es necesario ponerse de acuerdo con TMA para la disposición de este tipo de accesorios adjuntos las necesidades reales del cliente.

## 2.2 Lubricación

- Lubricación interior.Ya que los órganos internos del cabrestante, es decir reductores, cojinetes y frenos, trabajan en baño de aceite, para conseguir un buen funcionamiento se necesita una buena lubricación y el mantenimiento constante del nivel de lubricante correcto.

-En caso de condiciones de funcionamiento ligeras se puede utilizar aceite hidráulico de características buenas con viscosidad compatible con las condiciones ambientales (segun ISO 3448 con temperaturas comprendidas entre -5°C y 40°C viscosidad VG32 - VG46, en ambientes calientes entre 40°C y 65°C viscosidad VG64).
-En caso de condiciones de funcionamiento intensas utilizar un aceite especifico para engranajes con viscosidad adecuada a las condiciones ambientales (segun ISO 3448 con temperaturas comprendidas entre -5°C y 40°C viscosidad VG100 - VG150, en ambientes calientes 40°C y 65°C viscosidad VG150-220).

**CUIDADO**
Los cabrestantes *TMA* se entregan sin aceite de lubricación. En caso de entrega del cabrestante con cable montado, el tambor ya posee la correcta cantidad de aceite de lubricación del tipo ISO VG 46.
Antes de la puesta en marcha del cabrestante, llenar el tambor introduciendo la cantidad de aceite indicada en el anexo 2 (Pag.28). Esta cantidad es la adecuada para llenar la mitad del tambor. Averiguar el nivel y eventualmente efectuar las correcciones necesarias.
La temperatura del aceite de lubricación no debe superar el valor de 100°C.

## 2.3 Montaje del cable


**CUIDADO**
Arrollando el cable, averiguar que el sentido de rotación del tambor sea igual a lo indicado por la flecha de la etiqueta autoadhesivo aplicada sobre el tambor del cabrestante.

**PELIGRO**
En el caso de que el cable fuese enrollado sobre el tambor en el sentido de rotación incorrecto, esto podría provocar la pérdida de control de la carga con riesgos graves para las personas y las cosas.

**CUIDADO**
Para invertir el sentido de rotación del tambor, se necesita invertir la posición de fijación del cable. Antes de efectuar modificaciones o intervenciones, se aconseja ponerse en contacto con el servicio posventa *TMA*.

**PELIGRO**
No montar un cable de longitud superior a la máxima admisible, ya que se formarían capas no conformes a las normas de seguridad.


Introducir el cabo del cable en su ojal, puesto al lado del tambor, desde el interior hacia el exterior (fig.1).



(fig.1)


### 2.3.1 Montaje con caja de cono y cono

Introducir el cable en la caja de cono realizando un ojal a introducir en el cono (fig.2).




(fig.2)

Tirar el cable desde el lado opuesto para empujar todo en la caja de cono (fig.3 ).



(fig.3)

### 2.3.2 Montaje con bridas de fijación



(fig.4)

Introducir el cable como indicado en la fig.1 y luego apretar los tornillos de las bridas (fig.4) para bloquearlo.

**PELIGRO**
Averiguar que los tornillos de fijación de las bridas del cable no pasen a la chapa. En caso de que eso occurra, cortar los tornillos para que el cable no se dañe

**PELIGRO**
Para asegurar que la carga esté detenida, dejar siempre por lo menos 4 espiras de cable en el tambor. El sistema de fijación del cable sobre el cabrestante no puede ser considerado una garantía suficiente para la detención de la carga.

**CUIDADO**
El cable que no haya sido bien compactado puede ser facilmente dañado durante la aplicación de la carga que podría romper las espiras que están debajo

## 2.4 Instalación hidráulica: sugerencias y prescripciones

**CUIDADO**
El uso correcto del cabrestante es condicionado a la instalación hidráulica en la que el aparato se encuentra.
Averiguar que los valores característicos de la instalación hidráulica con respecto a la presión y al flujo máximos sean compatibles con las características de funcionamiento del cabrestante.

Los cabrestantes hidráulicos TMA están equipados de un freno multidiscos negativo y de una válvula para el control de la carga, embridada sobre el motor.
- Freno
El par de frenado se obtiene por el rozamiento engendrado entre una serie de discos estáticos (conectados a la estructura fija) y otra de discos móviles (conectados al eje de entrada), comprimidos entre ellos por la fuerza ejercida por un juego de resortes.
La acción de los resortes puede ser contrastada por un pistón accionado de manera hidráulica. Para abrir el freno, se saca una pequeña cantidad de aceite de la línea bajo presión del circuito del motor y se envía al pistón puesto en el interior del cuerpo freno (presión de abertura admisible: mínima 2.6 - 2.8 MPa, máxima 28-30 MPa).
De esta manera se balancea la acción de los resortes y se desbloquean los discos móviles del freno. Así es posible la rotación libre del eje del del motor.
Cuando se para el cabrestante, la palanca de la válvula distribuidora se pone en posición central. Para que el freno pueda volver a cerrarse, bloqueando el movimiento, se necesita que el aceite salga del piston permitiendo a los resortes de ejercer su presión sobre los discos. Es esencial que la bobina de la válvula distribuidora que manda el motor tenga una configuración que permita al pistón de descargar el aceite interior. Se necesita por lo tanto una configuración de la bobina con núcleo en "H". Ver esquema hidráulico en anexo 6 (Pag.28).

**PELIGRO**
El uso de una bobina con núcleo cerrado impide la salida del aceite del pistón y vuelve ineficaz tanto el freno de aparcamiento como la válvula de control de la carga.
En este caso se podría producir la caída incontrolada de la carga por vaciado del motor hidráulico por cavitación.

- Válvula de control de la carga.
La válvula de control de la carga, normalmente conectada al motor por una brida, tiene la función principal de efectuar un frenado dinámico de la carga. Impide además que la velocidad del motor sea superior a la permitida por el flujo de aceite.Tiene también la función de bloquear el movimiento de la carga, mediante el freno, en caso de ruptura de la tubería de alimentación del motor.

**PELIGRO**
No modificar el ajuste de la válvula de control de la carga.
*TMA* ajusta la válvula durante la prueba dinámica al banco.
Normalmente, *TMA* efectúa esta prueba con cargas superiores a la tracción máxima nominal.
Modificar el ajuste de la válvula podría provocar la pérdida de control de la carga.

- Tubería.
La correcta realización de la instalación hidráulica es muy imporante para el buen funcionamiento del cabrestante. Se necesita por lo tanto dimensionar la sección útil de las tuberías según el flujo de aceite y la longitud de la instalación. Una insuficiente sección de los tubos provoca caídas de presión de línea con conseguente aumento de la presión de funcionamiento de toda la instalación y contrapresión en la línea de regreso. Esto puede llevar a un funcionamiento irregular del cabrestante o también a una avería.

**CUIDADO**
Para evitar problemas de funcionamiento del cabrestante, la presión necesaria para el flujo de aceite en las tuberías no debe exceder 0.5-1.0 MPa.

Para conectar el cabrestante al sistema hidráulico, consulte la hoja de datos tecnicos y el esquema hidráulico con las dimensiones correctas y las posiciones de las bocas de entrada, devolución y drenaje.
El diámetro interior de este tubo non debe ser inferior de 1/4”.

**CUIDADO**
En caso de estrechamiento u oclusión en la línea del aceite de retorno el motor y el cabrestante serían seguramente dañados (probables pérdidas de aceite).

- Válvula de seguridad.
Preveer siempre una válvula de seguridad de máxima presión, ajustada con un valor superior de 10-20% con respecto al valor de la presión de trabajo indicada en el anexo 2 (Pag.28).
Normalmente esta válvula es parte integrante de la válvula distribuidora, pero, si no existe, es necesario preveerla en la línea di alimentación del cabrestante..

**CUIDADO**
Los valores de la presión de funcionamiento indicados en los diagramas de carga *TMA* se refieren al uso con presión de retorno igual a la atmosférica.

- Filtro
Para conseguir una correcta duración del cabrestante, utilizar siempre, en la instalación hidráulica, un filtro de capacidad filtrante adecuada.
Para motores de pistón: 10 micron
Para motores orbitales: 25 micron
Un reemplazo periódico del filtro prolonga la vida de todos los componentes de la instalación.
- Aceite
Para la instalación hidráulica utilizar aceite de buena calidad con características compatibles con los componentes utilizados y las condiciones atmosféricas locales.

**CUIDADO**
La temperatura del aceite hidráulico de la instalación no debe superar la temperatura de 60 °C.

## 2.5 Condiciones de empleo

**CUIDADO**
El cabrestante ha sido construido para un empleo en un campo de temperaturas atmosféricas locales comprendidas entre -20 °C y +50°C. El uso del cabrestante fuera de este campo de temperaturas representa un uso indebido y no autorizado por el constructor.
Para las otras condiciones, ver anexo n.2 (Pag.28).

## 2.6 Puesta en marcha
- Controlar el nivel del aceite de lubricación.
- Antes de montar el cable, efectuar algunas maniobras en vacío para averiguar el buen funcionamiento de la instalación.
- Montar el cable según las indicaciones anteriores.
- Con carga reducida, efectuar algunos levantamientos y averiguar el correcto funcionamiento de los dispositivos de tope.
- Con carga nominal, efectuar algunas pruebas y averiguar si el valor de la presión de trabajo corresponde a lo indicado en el certificado de prueba *TMA*.
Controlar el limitador de tracción interviene de manera correcta.

# CAPITULO TERCERO

## 3. ENTRETENIMIENTO

### 3.1 Operaciones de entretenimiento

Los cabrestantes *TMA* han sido proyectados para reducir lo mas posible las intervenciones de entretenimiento.Antes de cualquier operación de mantenimiento es necesario asegurar que el cabrestante no se puede activar accidentalmente durante la operación. Es también necesario utilizar todo el equipo de protección adecuado para la operación relevante y la evaluación de las condiciones ambientales de intervención.

**CUIDADO**
Cada cinco años el cabrestante debe ser sumetido a una revisión completa en un taller especializado.

- Control del aceite de lubricación
Tanto el freno como los engranajes trabajan en baño de aceite. Averiguar que no se encuentran pérdidas de aceite de lubricación y controlar el nivel una vez por mes. Si necesario, rellenar. Se recomenda el reemplazo del aceite cada 250 horas de funcionamiento o por lo menos una vez por año.

**CUIDADO**
El aceite reemplazado debe ser eliminado según las normas en vigor.

- Control del cable
Mantener el cable bien lubricado con aceites viscosos o grasas ligeras que contienen aditivos adhesivos con grafito, bisulfuro de molibdeno o trifosfato de sodio.

**PELIGRO**
Antes de poner en marcha el cabrestante, averiguar siempre que el cable sea integro. Si tiene aplastamientos o hilos rotos, reemplazarlo con un cable nuevo idóneo.

- Control del apretamiento tornillos
Controlar periódicamente el apretamiento de los tornillos que fijan el cabrestante a la estructura.

### 3.2 Eventuali problemi: cause e soluzioni

| PROBLEMA | CAUSA | SOLUCIONES |
|---|---|---|
| **La carga cae rápidamente.** | Cable montado en el sentido contrario.<br>Válvula de control carga desajustada.<br>Posición errónea de la válvula de control carga.<br>Flujo de aceite en dirección errónea | Montar el cable en el sentido correcto.<br>Ponerse en contacto con el servicio post-venta.<br>Montar la válvula en posición correcta.<br>Invertir la posición de los tubos de alimentación y de retorno. |
| **La carga baja despacio y continuamente** | Freno ineficaz.<br>Contrapresión en el freno.<br>Válvula distribuidora de centro cerrado. | Ponerse en contacto con el servicio post-venta.<br>Eliminar las contrapresiones en la instalación.<br>Reemplazar la bobina |
| **El cabrestante levanta la carga despacio** | Motor dañado.<br>Flujo insuficiente.<br>Freno no abierto. | Control aceite de retorno. Reemplazar el motor.<br>Controlar el flujo de la bomba.<br>Ponerse en contacto con el servicio post-venta. |
| **El cabrestante levanta la carga despacio** | Motor dañado.<br>Flujo insuficiente.<br>Freno no abierto. | Modificar el ajuste.<br>Control aceite de retorno. Reemplazar el motor.<br>Controlar el flujo de la bomba.<br>Ponerse en contacto con el servicio post-venta. |
| **Pérdida de aceite genérico** | Juntas estropeadas.<br>Tapones aflojados. | Ponerse en contacto con el servicio post-venta.<br>Cerrar los tapones de llenado de aceite.. |
| **El cabrestante en vacío no gira** | Engranajes estropeados.<br>Falta de flujo.<br>Presión instalación inexistente. | Ponerse en contacto con el servicio post-venta.<br>Controlar el flujo de la bomba.<br>Controlar la bomba. |
| **Ruidos demasiado elevados.** | Engranajes ruidosos.<br>Cojinetes de cigüeñal estropeados.<br>Falta de aceite de lubricación.<br>Flujo de aceite superior a lo admitido.<br>Motor ruidoso. | Ponerse en contacto con el servicio post-venta.<br>Ponerse en contacto con el servicio post-venta.<br>Controlar el nivel de aceite en el tambor.<br>Controlar el flujo de la bomba.<br>Ponerse en contacto con el servicio post-venta |
| **El cable no se arrolla correctamene sobre el tambor** | Angulo de desviación entre polea (o tranmisión) y tambor demasiado elevado.<br>El cable no está bajo tensión durante el arrollamiento | Volver a poner el ángulo de desviación entre los límites aceptables (2°).<br>Poner el cable bajo tensión durante el arrollamiento. |
| **Pèrdida de aceite tapon respiradero** | Juntas del motor estropeadas.<br>Juntas del freno ineficaz | Cambiar las juntas |
| **El cabrestante tiende a vibrar** | Tornillos de fijación aflojados. | Apretar los tornillos de fijación con el par adecuado |

# CAPITULO CUARTO

## 4. LISTA REPUESTOS Y PLANO DE CONJUNTO

### 4.1 Plano de conjunto

Ver anexo n.4 (Pag.28).

### 4.2 Lista repuestos

Ver anexo n.5 (Pag.28).

## PREFACE

**Dans cette notice, on utilise trois types d'avertissements pour la sécurité qui mettent en évidence différents niveaux de risque.**

**"DANGER"**
Il est utilisé pour mettre en évidence des situations dangereuses pour l'opérateur et, par conséquent, pour prévenir des accidents graves ou mortels.

**"ATTENTION"**
Il est utilisé pour mettre en évidence des situations dangereuses pour l'intégrité et le rendement du treuil pouvant également concerner la sécurité des personnes

**"IMPORTANT"**
Il est utilisé pour attirer l'attention sur des informations importantes que l'opérateur doit connaître et dont il doit tenir compte.

**ATTENTION**
**AVANT D'UTILISER LE TREUIL, LIRE ATTENTIVEMENT CETTE NOTICE.**

**DANGER**
**ICET APPAREIL N'EST PAS DESTINE A INSTALLATIONS DE LEVAGE OU DE DEPLACEMENT DE PERSONNES.**

**ATTENTION**
Avant de procéder aux opérations de démarrage, de travail, d'entretien ou avant d'effectuer n'importe quelle intervention sur le treuil, veuillez lire attentivement cette notice. La plupart des accidents qui se produisent pendant le travail sont dûs à l'inobservance des normes de sécurité et des précautions les plus simples. Pour ce motif, plusieurs accidents peuvent être évités en connaissant les causes et en procédant avec beaucoup d'attention.

**ATTENTION**
Cette notice est une introduction à l'emploi correct et sûr du treuil et à son entretien rationelle. Le respect constant des normes y contenues assure de bonnes performances, une bonne rentabilité et une longue vie du treuil, en évitant les accidents les plus communs pouvant se produire pendant le travail ou l'entretien.Une fois lue, cette notice doit être maintenue intacte dans toutes ses parties, à proximité du treuil, pour qu'elle soit toujours disponible. Au cas où cette notice ou quelques parties de celle-ci ne soit pas compréhensible, veuillez contacter la société TMA. Pour tout genre d'assistance technique, veuillez vous adresser à la société TMA

**IMPORTANT**
TMA se réserve le droit d'effectuer, sans préavis, des modifications et des améliorations à ses treuils et ne répond pas de différences existantes entre les caractéristiques du treuil et les descriptions de cette notice.

## INDEX GENERAL


| | |
|---|---|
| 18..... | PREFACE |
| 18..... | INDEX GENERAL |
| | 1. PREMIER CHAPITRE. INFORMATIONS |
| 19..... | 1.1 Données d'identification: poids et dimensions |
| 19..... | 1.2 Description général treuil et dispositifs de sécurité |
| 19..... | 1.3 Instructions générales. Normes de sécurité |
| 19..... | 1.4 Transport et livraison. Conditions de livraison |
| | 2. DEUXIEME CHAPITRE. FONCTIONNEMENT ET INSTALLATION |
| 19..... | 2.1 Installation |
| 20..... | 2.2 Lubrification |
| 20..... | 2.3 Montage du câble |
| 21..... | 2.4 Installations hydrauliques: conseils et prescriptions |
| 21..... | 2.5 Conditions d'emploi |
| 21..... | 2.6 Mise en service |
| | 3. TROISIEME CHAPITRE. ENTRETIEN |
| 22..... | 3.1 Opérations d'entretien |
| 22..... | 3.2 Problèmes éventuels: causes et solution |
| | 4. QUATRIEME CHAPITRE. LISTE PIECES DETACHEES ET VUE D'ENSEMBLE |
| 22..... | 4.1 Vue d'ensemble |
| 22..... | 4.2 Liste pièces détachées |

# PREMIER CHAPITRE


**ATTENTION**

Pour un emploi correct du treuil et pour le bon fonctionnement dans le temps, on conseille de lire attentivement les notes suivantes pour acquérir une bonne connaissance du produit.

## 1. INFORMATIONS

### 1.1 Données d'identification, poids et dimensions

Pour les données d'identification et le poids, voir la plaquette fixée, à l'aide de rivets, sur le treuil.
Pour les caractéristiques et les dimensions, voir annexe n.1 (Pag.28).




### 1.2 Description générale treuil et dispositifs de sécurité

Les éléments principaux qui constituent les treuils TMA sont:
Moteur: organe qui donne le couple nécessaire à déplacer la charge.
Frein de stationnement: il s'agît du dispositif de sécurité qui, en créant un couple resistant, s'oppose au mouvement de la charge. Il intervient lorsqu'on coupe l'énergie du moteur. Il agit sur le couple à l'entrée et, normalement, il a une valeur deux fois supérieure au couple-moteur. Sur demande, on peut livrer un frein de sûreté supplementaire agissant directement sur le tambour.
Réducteur: dispositif qui multiplie le couple distribué par le moteur pour obtenir le couple nécessaire au déplacement de la charge.
Tambour: il s'agît de l'élément d'enroulement du câble. Il est délimité par deux brides. En qualité d'élément de sécurité, le diamètre extérieur des brides latérales dépasse de trois fois le diamètre du câble par rapport au diamètre extérieur de la dernière couche utile.
Support: structure qui supporte le tambour et les autres éléments constituant le treuil.
Dispositifs de fin de course
(RES 4.1.2.3 de la Directiva 2006/42/CE):
Ils peuvent être à compte-tours ou à capteur et ils servent à maintenir l'amplitude des mouvements de la charge dans les limites prévues.
Están provistos de acuerdo a las necesidades específicas del cliente y el tipo de aplicación.
Presse-câble: il s'agît du dispositif qui empêche que le câble sans tension se détend ou se déroule sur le tambour.
Limiteur de traction (EN 12077-2)
Il s'agît d'un dispositif de sûreté qui empêche que le treuil puisse soulever une charge supérieure à la valeur maxi. admise ou qu'il soit soumis à une charge anomale. Le dispositif est préalablement reglé par TMA pour la valeur de la charge maxi. admise, indiquée dans la commande.
Soupape de côntrole de la charge (pour treuils hydrauliques)
Ella a la fonction d'empêcher que la vitesse de relâchement de la charge soit supérieure à celle qui peut être obtenue par l'installation et de bloquer le mouvement en cas de rupture des tuyaux. Elle connectée au moteur d'une façon normale.

### 1.3 Indications générales pour la sécurité

1) Vérifier que le treuil soit conforme à vos besoins et aux normes en vigueur.
2) Réaliser sur la machine un système de fixation sûr et rigide.
3) Positionner le treuil d'une façon correcte, en utilisant tous les trous de fixation et en s'assurant que les vis de fixation soient appropriées et correctement serrées.
4) Au cas où le treuil soit facilement accessible à tiers, réaliser des protections comme d'après le Directiva 2006/42/CE
5) Introduire dans le tambour la quantité d'huile nécessaire à une lubrification correcte et en vérifier le niveau.
6) Ne pas manier le câble sans les gants de protection et ne pas essayer de modifier la position du câble sous charge.
7) Vérifier que le câble soit correctement ancré au tambour et qu'il ait les caractéristiques et les dimensions compatibles à celles du treuil.
8) Vérifier que le sens d'enroulement du câble soit correct et conforme à celui indiqué sur le treuil.
Un montage correct du câble contribue à en augmenter la vie.
9) Vérifier que le câble soit intact et qu'il ne présente pas de fils cassés ou de plis pouvant en provoquer la rupture.
10) Vérifier que les dispositifs de sûreté fonctionnent bien et soient efficaces.
11) Vérifier que les conditions de fonctionnement correspondent aux caractéristiques du treuil.
12) N'effectuer pas de tractions avec charges supérieures à celles maximales admises.

### 1.4 Transport et livraison - conditions de livraison

Chaque treuil est livré monté, essayé et adéquatement emballé sur pallette.
Lors de la livraison, côntroler que le produit soit intact; en cas de dommages, le communiquer immédiatement au transporteur.
Voir l'annexe 7 (Pag.28) pour la manutention du treuil.

# DEUXIEME CHAPITRE

## 2. INSTALLATION ET FONCTIONNEMENT

### 2.1 Installation

- Les treuils TMA utilisés l'axe horizontal peuvent être montés dans n'importe quelle position, à condition que les percements existants soient respectés.
Pour l'emploi avec axe vertical, contacter le service après-vente TMA.
- Pour éviter que des tensions anomales se produisent dans le treuil, tensions qui pourraient provoquer une usure rapide des organes internes, il est nécessaire que le support, sur lequel le treuil est fixé, soit rigide et plat.
- Positionner le treuil sur la plaque et vérifier que les points d'appui adhèrent parfaitement au plan de la plaque du support.
Au cas où une lumière reste entre les plans d'appui, insérer des cales et, ensuite, serrer les vis de fixation.
Nous conseillons d'utiliser tous les trous de fixation prévus et des vis ayant des caractéristiques non inférieures à la classe 8.8, en les serrant avec un couple approprié.
- La position du treuil sur la plaque d'ancrage doit permettre d'obtenir une perpendicularité parfaite entre l'axe du tambour et la ligne reliant la ligne médiane du tambour et la première poulie.
De petites déviations peuvent provoquer l'enroulement erroné du câble sur le tambour.
- La distance entre le treuil et la première poulie doit être telle que l'angle de fonctionnement caractéristique du câble soit respecté

**ATTENTION**
Si le treuil est installé dans une position telle qu'il soit facilement accessible, il est nécessaire que le tambour et les parties mobiles sont bien protégé avec les protections connexes (2006/42/CE). Se doit convenir avec TMA toute disposition de ces pièces jointes les besoins réels du client.

## 2.2 Lubrification

- Lubrification interne.
Etant donné que les organes intérieurs du treuil - soit réducteurs, roulements et freins - travaillent en bain d'huile, pour un bon fonctionnement, il est nécessaire d'en assurer une lubrification appropriée, en maintenant toujours le juste niveau de lubrifiant.
- Pour des conditions d'emploi legères, utiliser une huile hydraulique ayant des caractéristiques optimales et une viscosité compatible avec les conditions d'emploi et les conditions ambiantes (ISO 3448 en ambiants tempérés -5 °C - 40 °C viscosité VG32 - VG46, en ambiants chauds 40 °C - 65 °C viscosité VG64).
- Pour des conditions d'emploi difficiles utiliser une huile spécifique pour engrenages ayant une viscosité conforme à la température et aux conditions de travail ambiantes (ISO 3448 en ambiants tempérés -5 °C - 40 °C viscosité VG100 - VG150, en ambiants chauds 40 °C - 65 °C viscosité VG150-220).
Pour températures inferieures à -20 °C contacter TMA.

**ATTENTION**
Les treuils TMA sont livrés sans huile de lubrification.
Avant de mettre le treuil en service, remplir le tambour en introduisant la quantité d'huile indiquée dans l'annexe n.2 (Pag.28).
Cette quantité remplit la moitié du tambour. Vérifier le niveau et, le cas écheant, effectuer les corrections nécessaires.
La température de l'huile de lubrification ne doit pas dépasser la valeur de 100°C.
Si le treuil est livré le câble monté, le tambour contient déjà la quantité d'huile de lubrification (type ISO VG 46) appropriée

## 2.3 Montage du câble


**ATTENTION**
En enroulant le câble, vérifier que le sens de rotation soit celui indiqué par la flèche de l'étiquette autocollante appliquée sur le tambour du treuil.

**DANGER**
Au cas où le câble soit enroulé sur le tambour sans respecter le sens de rotation correct, on pourrait perdre le côntrole de la charge, ce qui provoquerait de gros risques pour les personnes et les choses.

**ATTENTION**
Pour inverser les sens de rotation du tambour, il ne suffit pas d'inverser la position d'attelage du câble. Avant de procéder à modifications ou à interventions, on conseille donc de contacter le service après-vente TMA.

**DANGER**
Ne pas monter un câble de longueur supérieure à la valeur maximale admise, car on obtiendrait des couches non conformes aux normes de sécurité.


Introduire l'extrémité du câble dans la fente correspondante, placée sur un côté du tambour, de l'intérieur vers l'extérieur (fig.1).



(fig.1)


### 2.3.1 Montage avec boîte à cône et cône

Le câble doit être mis dans la boîte à cône, en formant un oeillet où le coin doit être introduit (fig.2).




(fig.2)

Tirer le câble du côté opposé pour introduire l'ensemble dans la boîte à cône (fig.3 ).



(fig.3)

### 2.3.2 Montage avec brides de blocage



(fig.4)

Serrer les vis des brides de blocage (fig.4) de telle sorte que le câble, une fois introduit comme d'après la figure 1, soit bloqué

**DANGER**
Verifier que le vis de fixation ne passent pas, au dehors de l'epaisseurde la flasque; en ce cas, il faut reduire les vis pour eviter que le cable se casse.

**DANGER**
Sur le tambour, il faut toujours laisser au moins 4 spires de câble enroulées, pour que la charge soit retenue.
Le système de fixation du câble présent sur le treuil n'est pas considéré une garantie suffisante pour la retenue de la charge.

**ATTENTION**
Lors du premier montage, il faut compacter parfaitement le câble sur le tambour sans laisser des éspaces entre les spires. Enrouler le câble en le soumettant à une tension appropriée.
Le câble qui n'a pas été bien compacté risque d'être facilement abîmé, car, sous l'effet de la charge, les spires pourraient s'endommager.

## 2.4 Installation hydraulique: conseils et prescriptions

**ATTENTION**

Le fonctionnement correct du treuil est lié à l'installation hydraulique dans laquelle l'appareil est introduit.
Vérifier que les valeurs caractéristiques de l'installation hydraulique concernant la pression et le flux maxi. soient compatibles avec les caractéristiques de fonctionnement du treuil.

Les treuils hydrauliques TMA sont doués d'un frein multidisques négatif et d'une soupape pour le côntrole de la charge, bridée au moteur.

- Frein

Le couple de freinage s'obtient du frottement qui se produit entre une série de disques statiques (connectés à la structure fixe) et une autre de disque mobiles (connectés à l'arbre d'entrée) pressés entre eux par la force excercée d'un jeu de ressorts. Un piston actionné hydrauliquement peut s'opposer à l'action des ressorts. Pour ouvrir le frein, une petite quantité d'huile est prélevée de la ligne sous pression du circuit du moteur et envoyée au piston placé à l'intérieur du corps de frein
(pression d'ouverture admise: mini. 2.6 - 2.8 MPa, maxi. 28 - 30 MPa).
De cette façon, l'action des ressort s'équilibre et les disques mobiles du frein se désengagent. Il est ainsi possible la libre rotation de l'arbre du moteur.
Lorsque le treuil s'arrête, le levier de la valve distributrice passe en position centrale. Pour que le frein puisse se renfermer en arrêtant le mouvement, il faut que l'huile sorte du piston, en permettant aux ressorts d'exercer une pression sur les disques.
Il est essentiel que la bobine de la valve distributrice qui commande le moteur ait une configuration permettant au piston de décharger l'huile interne. Une configuration de la bobine à noyau en "H" est donc nécessaire. Voir schéma hydraulique dans l'annexe 6 (Pag.28).

**DANGER**

L'emploi d'une bobine à centre fermé empêche l'ecoulement de l'huile du piston et rend inefficace tant le frein de parking que la soupape de contrôle de la charge. En ce cas, une chute incôntrolée de la charge suite à la vidange du moteur hydraulique par cavitation pourrait se produire.

- Soupape de côntrole de la charge.

La soupape de côntrole de la charge, normalement connectée au moteur, a la fonction principale d'effectuer un freinage dynamique de la charge. Elle empêche que la vitesse du moteur soit supérieure à celle admise par le flux de l'huile. Elle a également la fonction de bloquer le mouvement de la charge, par l'action du frein, en cas de rupture de la canalisation d'alimentation du moteur.

**DANGER**

Ne pas modifier le réglage de la soupape de côntrole de la charge. La soupape est réglée par TMA lors de l'essai dynamique efectué sur le banc d'essai.L'essai est normalement effectué par TMA avec des charges supérieures à la traction nominale maximale.Le fait de modifier le réglage de la soupape pourrait provoquer la perte de côntrole de la charge.

- Canalisation

La réalisation correcte de l'installation hydraulique est fondamentale pour le bon fonctionnement de l'installation. Il faut donc dimensionner la section utile des canalisations, en la proportionnant au flux d'huile et à la longueur de l'installation. Une section insuffisante des tuyaux cause des chutes de pression de ligne ainsi que l'augmentation conséquente de la pression de fonctionnement de l'installation complète et une contrepression sur la ligne de retour, ce qui pourrait provoquer un fonctionnement mauvais du treuil ou même son endommagement.

**ATTENTION**

Pour éviter des problèmes de fonctionnement du treuil, la pression nécessaire à l'écoulement de l'huile dans les canalisations ne doit pas dépasser 0.5-1.0 MPa.

Pour connecter le treuil au système hydraulique, il faut faire réfèrent le schéma hydraulique et la feuille de données fourni avec les dimensions correctes et les positions de la bouche de la entrée, le retour et le drainage.
Le diamètre interne de ce tuyau ne doit pas être inférieur à 1/4".

**ATTENTION**

En cas de rétrécissement ou d'occlusion dans la ligne de l'huile en retour, des dommages au moteur ou au treuil avec probables pertes d'huile se produiraient.

- Soupape de sûreté.

Prévoir toujours une soupape de sûreté, réglée sur une valeur supérieure à 10-20% par rapport à la valeur de la pression d'exercice indiquée dans l'annexe 2 (Pag.28). Cette soupape fait normalement partie de la valve distributrice mais, au cas où elle ne soit pas présente, il faut la prévoir dans la ligne d'alimentation du treuil.

**ATTENTION**

Les valeurs de pression de fonctionnement indiquées sur les diagrammes de charge TMA se rapportent à l'emploi avec une pression de retour pareille à celle atmosphérique.

- Filtre

Pour que le treuil ait une durée correcte, utiliser toujours, sur l'installation hydraulique, un filtre ayant une capacité de filtrage approprié.
Pour moteurs à pistons: 10 micron.
Pour moteurs orbitaux: 25 micron.
Un remplacement périodique du filtre prolonge la vie de tous les composants de l'installation.

- Huile

Pour l'installation hydraulique, utiliser une huile de bonne qualité, ayant des caractéristiques compatibles avec les composants utilisés et les conditions ambiantes.

**ATTENTION**

La température de l'huile hydraulique de l'installation ne doit pas dépasser la température de 60 °C.

## 2.5 Conditions d'emploi

**ATTENTION**

Le treuil a été conçu pour un emploi dans un champ de températures ambiantes compris entre -20 °C et +50°C.
Le fait d'utiliser le treuil au dehors de ce champ de températures représente un emploi impropre et non autorisé par le constructeur. Pour les autres conditions, voir annexe n.2 (Pag.28).

## 2.6 Mise en service

- Vérifier le remplissage de l'huile de lubrification.
- Avant de monter le câble, effectuer quelques mouvements à vide pour vérifier le bon fonctionnement de l'installation.
- Monter le câble selon les indications précédentes.
- La charge réduite, effectuer quelques levages et vérifier le bon fonctionnement des dispositifs de fin de course.
- La charge nominale, effectuer quelques essais et vérifier la correspondance entre la valeur de la pression d'exercise et celle indiquée dans la fiche d'essai TMA.

Vérifier si le limiteur de traction intervient correctement.

# TROISIEME CHAPITRE

## 3. ENTRETIEN

### 3.1 Opération d'entretien

Les treuils TMA ont été projetés de telle sorte à réduire au minimum les opérations d'entretien.Vor jeder Wartung ist es notwendig sicherzustellen, dass die Winde während der Operationen nicht versehentlich aktiviert werden. Es ist auch erforderlich, alle geeignete persönliche Schutzausrüstung für das jeweilige Geschäft laut der Bewertung der Umweltbedingungen der Intervention zu tragen.

**ATTENTION**
Tous les cinq ans, le treuil doit être soumis à une révision complète auprès d'une usine spécialisée.

- Côntrole de l'huile de lubrification
Tant le frein que les engrenages travaillent en bain d'huile. Vérifier qu'aucune perte d'huile de lubrification soit présente et en côntroler, une fois par mois, le niveau. Procéder éventuellement au rétablissement. On recommande de remplacer l'huile après 250 heures de fonctionnement ou, au moins, une fois par an.

**ATTENTION**
L'huile remplacée doit être évacuée selon les normes en vigueur.

- Côntrole du câble
Maintenir le câble bien lubrifié à l'aide d'huiles très visqueuses ou de graisses légères contenant des additifs adhésifs avec graphite, bisulfure de molybdène ou triphosphate de sodium.

**DANGER**
Avant de mettre en service le treuil, vérifier toujours que le câble soit intact. S'il ya des aplatissements ou des fils cassés, le remplacer par un câble nouveau approprié.

- Côntrole du serrage vis
Vérifier périodiquement le serrage des vis qui fixent le treuil à la structure.

### 3.2 Problèmes éventuelles: causes et solutions

| PROBLEME | CAUSE | SOLUTION |
|---|---|---|
| **La charge tombe vite** | Câble monté dans le sens contraire<br>Valvola di controllo carico starata<br>Soupape de côntrole charge non réglée<br>Flux d'huile en direction erronée | Monter le câble dans le sens correct<br>Contacter le service après-vente<br>Monter la soupape en position correcte<br>Inverser la position des tuyaux d'alimentation et de retour |
| **La charge descend lentement d'une façon continuelentamente in continuo** | Frein insuffisant<br>Contrepression dans le frein<br>Valve distributrice à centre fermé | Contacter le service après-vente<br>Eliminer les contrepressions présentes dans l'installation<br>Remplacer la bobine |
| **Le treuil ne lève pas la charge** | Réglage bas<br>Moteur endommagé<br>Frein bloqué | Modifier le réglage<br>Côntroler l'huile en retour. Remplacer le moteur<br>Contacter le service après-vente |
| **Le treuil lève lentement la charge** | Réglage bas<br>Moteur endommagé<br>Flux insuffisant<br>Frein non ouvert | Modifier le réglage<br>Côntroler l'huile en retour. Remplacer le moteur<br>Côntroler le flux de la pompe.<br>Contacter le service après-vente |
| **Perte d'huile générique** | Joints abîmés<br>Bouchons desesserés | Contacter le service après-vente<br>Serrer les buchons de remplissage d'huile |
| **Le treuil à vide ne tourne pa** | Engrenages abîmés<br>Manque de flux<br>Pression installation inexistante | Contacter le service après-vente.<br>Côntroler le flux de la pompe<br>Côntroler la pompe |
| **Bruit trop élevé** | Engrenages bruyants<br>Paliers principaux endommagés<br>Manque d'huile de lubrification<br>Flux d'huile de quantité supérieure à celle admise<br>Moteur bruyant | Contacter le service après-vente<br>Contacter le service après-vente<br>Côntroler le niveau d'huile dans le tambour<br>Côntroler le flux de la pompe<br>Contacter le service après-vente |
| **Le câble ne s'enroule pas correctement autour du tambour** | Angle de déviation entre poulie (ou transmission) et tambour trop élevé<br>Le câble n'est pas sous tension lors de l'enroulement | Ramener l'angle de déviation entre des limites acceptables (2°)<br>Pendant l'enroulement, mettre le câble sous tension |
| **Perte d'huile de le bouchon de sécurité** | Joints du moteur abîmés<br>Joints du frein abîmés | Changer les joints |
| **Le treuil tend à vibrer** | Vis de fixation desesserées | Serrer les vis de fixation avec le couple approprié |

# QUATRIEME CHAPITRE

## 4. LISTE PIECES DETACHEES ET VUE D'ENSEMBLE

### 4.1 Vue d'ensemble

Voir annexe n°4 (Pag.28).

### 4.2 Liste pièces détachées

Voir annexe n°5 (Pag.28).

# VORWORT

**In diesem Handbuch sind drei Warnungszeichen für die Sicherheit erwähnt, die ebensoviele Gefahrniveaus darstellen.**

**"GEFAHR"**
Wird verwendet, um gefährliche Situationen dem Bediener zu melden und daher schwere -auch lebensgefährliche -Unfälle zu verhindern.

**"ACHTUNG"**
Wird verwendet, um schädliche Situationen, die zur Beschädigung der Winde und demzufolgen zu Verletzungen der Personen führen können, hervorzuheben

**"WICHTIG"**
Wird verwendet, um die Aufmerksamkeit auf wichtige Hinweise, die der Bediener zu kennen und zu berücksichtigen hat, zu lenken.

**ACHTUNG**
**WINDE NICHT IN BETRIEB SETZEN, BEVOR SIE DIESES HANDBUCH SORGFÄLTIG GELESEN HABEN.**

**GEFAHR**
**DIESE VORRICHTUNG IST NICHT FÜR HEBE- UND FÖRDERZEUGE FÜR PERSONEN GEEIGNET.**

**ACHTUNG**
Vor den Inbetriebnahme-, Wartungs- und Reparaturarbeiten an der Winde ist dieses Handbuch sorgfältig zu lesen. Die meisten Arbeitsunfälle sind der Nichteinhaltung der einfachsten Sicherheitsvorschriften und Vorsichtsmaßnahmen zuzuschreiben. Aus diesem Grund können viele Unfälle durch die Erkennung der Ursachen und ein vorsichtiges Vorgehen vehindert werden.

**ACHTUNG**
Dieses Handbuch ist ein Wegweiser für eine bestimmungsgemäße und sichere Verwendung der Winde sowie für seine rationelle Wartung. Die beständige Einhaltung der hier erwähnten Normen versichert den besten Wirkungsgrad, einen ökonomischen Betrieb sowie eine lange Lebensdauer der Winde und verhütet die bei der Arbeit und Wartung gewöhnlichsten Unfallursachen.Nach der Lesung des Handbuches, ist dieses in der Nähe der Winde in seiner vollständiger Ausgabe so zu bewahren, daß es stets verfügbar ist. Sollten Verständnisprobleme aus diesem Handbuch oder dessen Teilen entstehen, so bitten wir Sie mit TMA Kontakt aufzunehmen.
Für jede technische Beratung steht Ihnen TMA gerne zur Verfügung..

**WICHTIG**
TMA behält sich vor, Änderungen und Verbesserungen an ihren Winden jederzeit ohne vorherige Benachrichtung auszuführen, und übernimmt keine Verantwortung für irgendwelchen Unterschied zwischen den Eigenschaften der Winde und den Beschreibungen dieser Betriebs- und Wartungsanweisungen .

## INHALTSVERZEICHNIS


VORWORT ..... 23
INHALTSVERZEICHNIS ..... 23
1. ABSCHNITT. INFORMATIONEN
1.1 Kenndaten: Gewicht und Abmessungen ..... 24
1.2 Allgemeine Beschreibung Winde und Sicherheitsvorrichtungen ..... 24
1.3 Allgemeine Anweisungen Sicherheitsvorschriften ..... 24
1.4 Transport und Lieferung. Lieferbedingungen ..... 24
2. ABSCHNITT. BETRIEB UND ANBAU
2.1 Anbau ..... 24
2.2 Schmierung ..... 25
2.3 Montage des Seils ..... 25
2.4 Hydraulik: Tips und Vorschriften ..... 26
2.5 Betriebsbedingungen ..... 26
2.6 Inbetriebnahme ..... 26
3. ABSCHNITT. WARTUNG
3.1 Wartungsarbeitene ..... 27
3.2 Mögliche Probleme: Ursachen und Abhilfen ..... 27
4. ABSCHNITT. ERSATZTEILLISTE UND GESAMTZEICHNUNG
4.1 Gesamtzeichnung ..... 27
4.2 Ersatzteilliste ..... 27


# 1. ABSCHNITT

**ACHTUNG**
Für einen einwandfreien Einsatz der Winde empfiehlt es sich nachstehende Hinweise, die eine gute Kenntnis des Produkts ermöglichen, sorgfältig zu lesen.

## 1. HINWEISE

### 1.1 Kenndaten, Gewichtt und Abmessungen

Für die Kenndaten und das Gewicht siehe Typschild an der Winde.
Für die Eigenschaften und Abmessungen sehen Anlage n.1(Seite 28).




### 1.2 Allgemeine Beschreibung der Winde und Sicherheitsvorrichtungen

Die Bestandteile der TMA-Winden sind folgende:
Motor: Organ, das das Nutzmoment zum Lasttransport abgibt.
Feststellbremse: Es handelt sich um die Sicherheitsvorrichtung, die durch ein Gegenmoment den Lasttrasnport verhindert. Sie schaltet ein, wenn Energie am Motor abgenommen wird. Sie wirkt auf das Eingangsdrehmoment und hat in der Regel einen Wert, der zweilmal das Antriebsdrehmoment ist. Auf Wunsch kann eine zusätzliche Sicherheitsbremse montiert werden, die unmittelbar auf den Trommel wirkt.
Getriebe: Vorrichtung, die das vom Motor abgegebene Moment übersetzt, um das für den Lasttransport notwendige Moment zu erzielen.
Trommel: Es handelt sich um einen Bestandteil, der zur Aufnahme des Seils dient und von zwei Flanschen abgegrenzt ist. Als Sicherheitsteil ist der Aussendurchmesser der Seitenflansche dreimal höher als der Seildurchmesser im Vergleich zum Aussendurchmesser der letzten Nutzlage.
Halterung: Struktur, die den Trommel und die Bestandteile der Winde abstützt.
Endschalter (RES 4.1.2.3 der Richtlinie 2006/42 / EG):
Sie können mit Drehzahlmesser oder Sensor versehen sein und dienen, die Weite der Lastbewegungen innerhalb den vorgeschriebenen Grenzen zu halten. Sie werden je nach den spezifischen Bedürfnissen des Kunden und der Art der Anwendung zur Verfügung gestellt.
Seilandrückrolle: Es handelt sich um eine Vorrrichtung, die die Entspannung bzw. das Aufrollen des spannungslosen Seils auf den Trommel verhindert.
Zugbegrenzer (EN 12077-2)
Es handelt sich um die Sicherheitsvorrichtung, die verhindert, daß die Winde eine unzulässige Last aufhebt oder mit einer ungeeigneten Belastung beansprucht wird. Die Vorrichtung wird von TMA auf den höchsten,zulässigen Lastwert, der bei Auftrag erwähnt wurde,voreingestellt.
Lastüberwachungsventil (für Hydraulikwinden) Es verhindert, daß die Lastabgabegeschwindigkeit höher als die von der Anlage erhältliche Geschwindigkeit ist und stoppt die Bewegung bei Rohrbruch. In der Regel ist es am Motor mit einem Flansch angebracht.

### 1.3 Grundlegende Sicherheitshinweise

1) Überprüfen, daß die Winde Ihren Erfordernissen und den gültigen Vorschriften entspricht.
2) An der Maschine ein sicheres und festes Befestigungssystem vorsehen.
3) Winde durch die Befestigungsbohrungen richtig positionieren und sich vergewissern, daß die Befestigungsschrauben geeignet und sachgemäß angezogen sind.
4) Sollte die Winde Dritten leicht zugänglich sein, so sind Schutzeinrichtungen nach der Maschinenrichtlinie Richtlinie 2006/42 / EG vorzusehen.
5) Trommel mit der für eine korrekte Schmierung erforderlichen Ölmenge füllen und Ölstand überprüfen.
6) Seil ohne Schutzhandschuhen nicht handhaben und niemals versuchen, die Stellung des unter Last befindlichen Seils zu verändern.
7) Sich vergewissern, daß der Seil am Trommel einwandfrei befestigt ist und Eigenschaften und Abmessungen aufweist, die sich den Eigenschaften der Winde anpassen.
8) Überprüfen, daß die Bewicklungsrichtung des Seils richtig ist und der an der Winde aufgeführten Richtung entspricht.
Eine einwandfreie Montage des Seils verlängert seine Lebensdauer.
9) Überprüfen, daß der Seil vollkommen ist und keine abgerissenen Drahten bzw. keine Falten, die seinen Bruch verursachen könnten, aufweist.
10) Überprüfen, daß die Sicherheitseinrichtungen funktionsfähig und wirksam sind.
11) Sich vergewissern, daß die Betriebsbedingungen den Windeneigenschaften übereinstimmen.
12) Keine Zuge mit unzulässigen Lasten ausführen.

### 1.4 Transport und Lieferung - Lieferbedingungen

Jede Winde wird zusammengebaut, geprüft und auf Palette sachgerecht verpackt geliefert.
Bei der Lieferung ist das Produkt auf seine Vollständigkeit zu prüfen; die eventuellen Schäden sind der Spedition unverzüglich mitzuteilen.

# 2. ABSCHNITT

## 2. INSTALLATION UND BETRIEB

### 2.1 Installation

- Beim Einsatz mit waagerechter Achese können die TMA-Wellen unter Berücksichtigung der bestehenden Bohrungen in irgenwelcher Stellung montiert werden.
Für den Einsatz in verschiedenen Konfigurationen, Kundendienst mit TMA.
- Um unregelmäßige Spannungen an der Winde zu verhindern, die zu einer schnellen Abnutzung der Innenteile führen könnten, muß die Halterung, auf der die Winde befestigt wird, starr und flach sein.
- Welle auf der Platte positionieren und überprüfen, daß die Stützpunkte der Auflageplatte der Halterung genau aufeinanderpassen.
Sollte einen Zwischeraum zwischen den Auflageplatten bleiben, so sind geeignete Unterlegscheiben anzubringen und nur danach die Befestigungsschrauben anzuziehen.
Es empfiehlt sich, alle vorgesehene Befestigungsbohrungen zu verwenden; die Schrauben, die nicht unter der Klasse 8.8 sein müssen, sind mit einem geeigneten Anzugsmoment anzuziehen.
- Die Lage der Winde auf der Ankerplatte muß eine genaue, senkrechte Stellung zwischen der Trommelachse und der Linie, die die Mittellinie des Trommels mit der ersten Riemenscheibe verbindet, gewährleisten.
Kleine Abweichungen können eine unregelmäßige Bewicklung des Seils am Trommel verursachen.
- Der Abstand zwischen der Winde und der ersten Riemenscheibe muß den charakteristichen Betriebswinkel des Seils berücksichtigen.

**ACHTUNG**
Wenn die Winde in einer leicht zugänglichen Position angebracht ist, ist es notwendig, dass die Trommel und die beweglichen Teile ordentlich mit entsprechenden Sicherungsschutze geschützt werden (2006/42 / EG).Es ist notwendig, mit TMA auf die eventuelle Lieferung solcher Zubehör eine Bestimmung nach der tatsächlichen Bedürfnisse des Kunden zu zustimmen.

**2.2 Schmierung**

- Innenschmierung.
In Anbetracht dessen, daß die inneren Bestandteile der Winde, wie Getrieben, Lager und Bremsen, in Ölbad arbeiten, sind diese für einen einwandfreien Betrieb sachgerecht zu schmieren, indem den richtigen Ölstand stets gehalten wird.
- Für leichte Einsatzfälle ist ein Hydrauliköl mit optimalen Eigenschaften und einer mit den Betriebszuständen kompatiblen Viskosität zwischen 32 und 46 °E bei 40°C (z.B. AGIP OSO 32/46, BP ENERGOL HLP 32/46, ELF ELFOLINA 32/46, SHELL TELLUS OIL 32/46, SHELL HYDRAULIC OIL 32/46) zugelassen.
- Für harte Einsatzfälle ist dagegen ein spezifisches Getriebeöl zu verwenden, das eine der Temperatur und den Arbeitsbedingungen entsprechende Viskosität (z.B. ISO VG 150 EP) aufweist.

**ACHTUNG**
Die TMA-Winden werden ohne Schmieröl geliefert. Wird die Winde mit integriertem Seil geliefert, so ist die notwendige Ölmenge von Typ ISO VG 46 bereits im Trommel beinhaltet.
Vor der Inbetriebnahme der Winde, Trommel mit der in der Anlage 2 (Seite 28) aufgeführten Ölmenge füllen. Diese Menge ist für die Füllung der Trommelhälfte geeignet. Ölstand überprüfen und, wenn nötig, nachfüllen.
Die Temperatur des Schmieröls muß 100°C nicht überschreiten.

**2.3 Montage des Seils**


**ACHTUNG**
Beim Aufwickeln des Kabels ist es zu überprüfen, daß die Drehrichtung des Trommels der Richtung des Pfeiles am Trommelklebzettel entspricht

**GEFAHR**
Ist der Seil in falscher Drehrichtug am Trommel aufgewickelt, so könnte dies zur Lastkontrollverlust mit schweren Personen- und Sachschäden führen.

**ACHTUNG**
Um die Drehrichtung des Trommels zu verkehren, reicht es in der Regel aus, die Stellung der Seilbefestigung zu verkehren. Es empfiehlt sich, vor jeder Änderung bzw. Handhabung mit dem TMA-Kundendienst Kontakt aufzunehmen. Seilende in das entsprechende Langloch auf einer Seite des Trommels von innen nach aussen (Fig. 1) einführen.


**GEFAHR**
Keinen Seil mit unzulässiger Länge montieren, um den Sicherheitsvorschriften nicht entsprechenden Lagen zu vermeiden.

Seilende in das entsprechende Langloch auf einer Seite desTrommels voninnen nach aussen (Fig. 1) einführen.




(fig.1)

**2.3.1 Montage mit Keilkasten und Keil**
Seil in den Keilkasten durch Ausführung einer Öse, in die der Keil (Fig. 2) einzustecken ist, einzuführen




(fig.2)

Seil aus der entgegengesetzten Seite so ziehen, daß alles in denKeilkasten eintritt (Fig.3 ).



(fig.3)

**2.3.2 Montage mit Seilklemmung**



(fig.4)

Schrauben (Fig.4) so anziehen, daß der wie in der Fig. 1 eingeführte Seil blockiert wird.

**GEFAHR**
Prüfen Sie, daß die Befestigungsschrauben der Klemmen den Flügelblech nicht überschreiten. Bejahendenfalls sind die Schrauben angemessen zu verkürzen, um einen schweren Seilschaden zu vermeiden.

**GEFAHR**
Um das Halten der Last zu gewährleisten, ist es nötig, mindestens 4 Seilwindungen um den Trommel zu lassen. Das Befestigungssystem des an der Winde bestehenden Seils stellt keine ausreichende Gewährleistung dafür dar.

**ACHTUNG**
Bei erster Montage ist der Seil auf dem Trommel sachgemäß zu kompaktieren, d.h. es müssen keine Freiräume unter den Windungen bleiben. Seil mit der geeigneten Spannung aufwickeln. Bei Lastanwendung kann der nicht gut kompaktierte Seil zu Beschädigungen führen, wenn er in die darunterliegenden Windungen eindringt.

## 2.4 Hydraulik: Tips und Vorschriften

**ACHTUNG**
Die einwandfreie Funktion der Winde hängt von der Hydraulik ab, mit der die Vorrichtung verbunden ist.
Vergewissern Sie sich, daß die Kennwerte der Hydraulik hinsichtlich Höchstdruck und -durchfluss mit den Betriebseigenschaften der der Winde kompatibel sind.

Die TMA-Hydraulikwinden sind mit einer Negativ-Lamellenbremse und einem am Motor geflanschten Ventil zur Lastüberwachung ausgestattet.
- Bremse
Das Bremsdrehmoment wird durch die Reibung erreicht, die zwischen einer Serie von statischen Lamellen (mit der festen Struktur verbunden) und einer von beweglichen Lamellen (mit Antriebswelle verbunden) entsteht. Die Lamellen werden von der Kraft eines Federpakets untereinander gepresst.Die Wirkung der Feder kann von einem hydraulisch betätigten Kolben entgegengesetzt werden.Zum Öffnen der Bremse wird eine kleine Menge Öl aus der unter Druck stehenden Linie des Motorkreises abgenommen und zum im Bremskörper integrierten Kolben weitergeführt (zul. Öffnungsdruck: min. 2.6 - 2.8 MPa, max.28 - 30 MPa).
Somit wird die Wirkung der Feder ausgeglichen und die beweglichen Lamellen der Bremse freigemacht, was die freie Umdrehung der Motorwelle ermöglicht. Beim Abschalten der Winde wird der Hebel des Verteilungsventils auf die mittige Stellung gestellt. Um die Bremse wieder zu schließen und die Bewegung anzuhalten hat das Öl aus dem Kolben herauszufliessen, indem die Feder ihren Druck auf die Lamellen bewirken. Dabei ist es unbedingt notwendig, daß die Spule des Verteilungsventils, das den Motor steuert, so gestaltet ist, daß das Öl im Kolben ablaufen kann.Die Spule muß daher mit H-Kern sein.
Siehe Hydraulikplan in der Anlage 6 (Seite 28).

**GEFAHR**
Die Verwendung einer Spule mit geschlossenem Kern verhindert den Ölablauf aus dem Kolben und macht sowohl die Feststellbremse als auch das Ventil zur Lastüberwachung unwirksam. Dies könnte einen unerwarteten Abfall der Last infolge der Entleerung des Hydraulikmotors aus Kavitationsgründen zur Folge haben.

- Lastüberwachungsventil.
Das Lastüberwachungsventil, das in der Regel am Motor durch einen Flansch angebracht ist, hat die Funktion eine dynamische Abbremsung der Last auszuführen. Es vehindert, daß die Motorgeschwindigkeit höher als die vom Öldurchfluss erlaubte Geschwindigkeit sein kann. Dazu unterbricht es die Lastbewegung durch die Bremswirkung im Falle einer Beschädigung an der Förderleitung des Motors.

**GEFAHR**
Einstellung des Lastüberwachungsventils nicht verändern..
Das Ventil wird von TMA beim dynamischen Prüfstandversuch geregelt. In der Regel wird die Prüfung von TMA mit Lasten über den Höchstnennzug durchgeführt.
Die unerlaubte Einstellung des Ventils könnte zur Lastkontrollverlust führen.

- Rohrleitung.
Die sachgerechte Ausführung der Hydraulik ist wichtig für eine einwandfreie Funktion der Winde. Es ist daher notwendig, den Nutzschnitt der Rohrleitungen je nach dem Öldurchfluss und der Länge der Anlage zu bemessen. Ein unzureichender Rohrschnitt führt zu Leitungsdruckgefällen mit der daraus entstehenden Betriebsdruckerhöhung der Gesamtanlage und Gegendruck in der Rücklaufleitung, was eine unregelmäßige Funktion oder Beschädigung der Winde verursachen kann.

**ACHTUNG**
Um eine einwandfreie Funktion der Winde zu erreichen, hat der für den Öldurchfluss erforderlichen Druck 0.5-1.0 Mpa nicht zu überschreiten.

Um die Seilwinde an der Hydraulikversorgung anzuschließen, beziehen Sie sich auf die bereitsgestellten Hydraulikschema und Datenblatt mit den richtigen Abmessungen und Positionen der Anschlüsse der Lieferung, Rücklauf und Ablauf. Der Innendurchmesser von letztem Rohr muß nicht kleiner als 1/4” sein.

**ACHTUNG**
Im Falle einer Drosselstelle bzw. einer Einschliesseung in der Rücklaufleitung würden ohne weiteres Schäden am Motor und an der Winde mit möglichen Ölverlusten auftreten.

- Sicherheitsventil.
Ein Sicherheits-Druckregelventil immer vorsehen; dieses Ventil ist auf einen Wert einzustellen, der 10-20% der in der Anlage 2 (Seite 28) aufgeführten Arbeitsdruck höher ist. In der Regel ist dieses Ventil wesentlicher Bestandteil des Abschaltventils; solltes dieses aber nicht vorhanden sein, so ist es in der Förderleitung der Winde vorzusehen.

**ACHTUNG**
Die in den TMA-Lastdiagrammen aufgeführten Betriebsdruckwerte beziehen sich auf den Einsatz mit einem Rücklaufdruck, der gleich hoch wie der Luftdruck ist.

- Filter
Um die richtige Lebensdauer der Winde zu erreichen, ist an der Hydraulik ein geeigneter Filter zu verwenden.
Für Kolbenmotoren: 10 micron
Für Umlaufmotoren: 25 micron
Die periodische Erneurung des Filters verlängert die Lebensdauer von allen Anlagenbestandteilen.
- Öl
Für die Hydraulik ist ein hochwertiges Öl zu verwenden, dessen Eigenschaften sich den gebrauchten Bestandteilen und den Umweltbedingungen anpassen.

**ACHTUNG**
Die Temperatur des Hydrauliköls muß 60 °C nicht überschreiten.

## 2.5 Einsatzbedingungen

**ACHTUNG**
Die Winde ist für den Einsatz in einem Temperaturraum von -20 °C bis +50°C ausgelegt worden. Der Einsatz der Winder außerhalb diesem Temperaturraum stellt eine unerlaubte und vom Hersteller nicht zugelassene Verwendung dar.
Für weitere Bedingungen siehe Anlage 2 (Seite 28).

## 2.6 Inbetriebnahme

- Schmierölstand überprüfen.
- Vor der Seilmontage, Anlage durch einige Betätigungen im Leerzustand auf ihre Funktion prüfen.
- Seil gemäß den vorherigen Anweisungen montieren.
- Bei reduzierter Last einige Heben durchführen und Endschalter auf ihre Funktion prüfen.
- Bei Nennlast einige Prüfugen ausführen und die Übereinstimmung zwischen dem Arbeitsdruckwert und dem in der TMA-Abnahmekarte aufgeführten Wert überprüfen.
Zugbegrenzer auf seine Funktion prüfen.

Bilag 3

# 3. ABSCHNITT

## 3. WARTUNG

### 3.1 Wartungsarbeiten

Die TMA-Winden sind wartungsfreundlich.

**ACHTUNG**
Alle fünf Jahre ist die Winde von einer Fachwerkstatt komplett überholen zu lassen.

- Kontrolle des Schmieröls
Sowohl die Bremse als auch die Zahnräder arbeiten in Ölbad. Sich vergewissern, daß keine Schmierölverluste vorhanden sind und einmal im Monat den Ölstand nachprüfen und bei Bedarf nachfüllen. Ölwechsel nach 250 Betriebsstunden oder mindenstens einmal im Jahr empfohlen.

**ACHTUNG**
Das gewechselte Öl ist gemäß den gültigen Normen zu entsorgen.

- Seilkontrolle
Seil mit schwerflüssigen Ölen oder leichten Fetten, die Klebwirkstoffe mit Graphit, Molybdändisulfid oder Natriumtriphosphat enthalten, schmieren.

**GEFAHR**
Vor der Betätigung der Winde, sich vergewissern, daß der Seil vollständig ist. Sollte er Quetschungen oder beschädigte Drahte aufweisen, so ist er durch einen neuen geeigneten Seil zu ersetzen.

- Kontrolle des Schraubenanzugs
Anzug der Schrauben, die die Winde an der Struktur befestigen, von Zeit zu Zeit kontrollieren.

### 3.2 Mögliche Probleme: Ursachen und Abhilfen

| PROBLEM | URSACHE | ABHILFE |
|---|---|---|
| **Die Last fällt schnell.** | Seil in entgegengesetzter Richtung montiert.<br>Lastüberwachungsventil ungeeicht.<br>Unregelmäßige Stellung des Lastüberwachungsventils.<br>Ölfluss in falscher Richtung. | Kabel in der richtigen Richtung montieren.<br>Mit dem Kundendienst Kontakt aufnehmen.<br>Ventil in der richtigen Stellung montieren.<br>Stellung der Vorlauf- und Rücklaufrohrs vertauschen. |
| **Die Last sinkt langsam und kontinuerlich** | Unwirksame Bremse<br>Gegendruck an der Bremse.<br>Steuerventil mit geschlossenem Wirkungsweg | Mit dem Kundendienst Kontakt aufnehmen.<br>Gegendrücke an der Anlage beseitigen.<br>Spule ersetzen. |
| **Die Winde hebt die Last nicht auf** | Niedrige Einstellung.<br>Motor ausgefallen.<br>Bremse blockiert | Einstellung verändern.<br>Rücklaufölkontrolle. Motor ersetzen.<br>Mit dem Kundendienst Kontakt aufnehmen |
| **Die Welle hebt die Last langsam auf.** | Niedrige Einstellung.<br>Motor ausgefallen.<br>Durchfluss unzureichend.<br>Bremse nicht offen. | Einstellung verändern.<br>Rücklaufölkontrolle. Motor ersetzen.<br>Durchfluss der Pumpe prüfen.<br>Mit dem Kundendienst Kontakt aufnehmen |
| **Generisch ölverlust** | Dichtungen beschädigt.<br>Stopfen locker. | Mit dem Kundendienst Kontakt aufnehmen<br>Ölstopfen verschließen. |
| **Die Winde in Leerzustand dreht nich** | Zahnräder beschädigt.<br>Kein Durchfluss.<br>Kein Druck an der Anlage. | Mit dem Kundendienst Kontakt aufnehmen<br>Durchfluss der Pumpe prüfen.<br>Pumpe kontrollieren |
| **Zu geräuschvoll** | Zahnrädergeräuschvoll.<br>Hauptlager beschädigt.<br>Kein Schmieröl.<br>Öldurchfluss höher als der zulässige.<br>Motor geräuschvoll. | Mit dem Kundendienst Kontakt aufnehmen<br>Mit dem Kundendienst Kontakt aufnehmen<br>Ölstand in der Trommel kontrollieren.<br>Durchfluss der Pumpe kontrollieren.<br>Mit dem Kundendienst Kontakt aufnehmen |
| **Der Seil wickelt sich um die Trommel unregelmäßig herum** | Ablenkwinkel zwischen Riemenscheibe (oder Vorgelege) und Trommel zu hoch.<br>Bei Bewicklung ist der Seil nicht gespannt | Ablenkwinkel in den zulässigen Grenzen (2°) wieder bringen.<br>Bei Bewicklung ist der Seil zu spannen. |
| **ölverlust aus der entluftungsstopfen** | Motor dichtungen beschädigt<br>Bremse dichtungen beschädigt | wechseln die dichtungen |
| **Die Winde schwingt.** | Lose Befestigungsschrauben. | Befestigungsschrauben mit entsprechendem Anzugsmoment festziehen. |

# 4. ABSCHNITT

## 4. ERSATZTEILLISTE UND GESAMTZEICHNUNG

### 4.1 Gesamtzeichnung

Siehe in der Anlage 4 (Seite 28).

### 4.2 Ersatzteilliste

Siehe in der Anlage 5 (Seite 28).

ARGANI VERRICELLI
HYDRAULIC
ELECTRIC WINCHES
41057 SPILAMBERTO – (MO) – ITALY
Via S.Vito 221 Tel. +39.059.78.17.11
www.tmawinches.com

CE

**IT** **ALLEGATO N°**

1. PESO E DIMENSIONI
2. CONDIZIONI DI UTILIZZO
3. GRAFICO PRESTAZIONI
4. COMPLESSIVO
5. LISTA RICAMBI
6. SCHEMA IDRAULICO GENERALE
7. TRASPORTO E MOVIMENTAZIONE

**GB** **ATTACHMENT N°**

1. WEIGHT AND SIZES
2. OPERATING CONDITIONS
3. PERFORMANCES GRAHPS
4. DRAWING ASSAMBLY
5. SPARE PART LIST
6. BASIC HYDRAULIC DIAGRAM
7. LOADING AND TRANSPORT

**E** **ANEXO N°**


1. PESO Y DIMENSIONES
2. CONDICIONES DE EMPLEO
3. GRÀFICO DE LAS PRESTACIONES
4. PLANO DE CONJUNTO
5. LISTA REPUESTOS
6. ESQUEMA HIDRAULICO
7. TRANSPORT Y MOVILIZACIÓN

**F** **ANNEXE N°**

1. POIDS ET DIMENSION
2. CONDITIONS D'EMPLOI
3. GRAPHIQUE DES PRESTATIONS
4. VUE D'ENSEMBLE
5. LISTE PIECES DETACHEES
6. SCHEMA HYDRAULIQUE
7. TRANSPORT ET MOUVEMENT


**D** **ANLAGE N°**

1. GEWICHT UND ABMESSUNGEN
2. BETRIEBSBEDINGUNGEN
3. GRAPHIK DER LEISTUNGEN
4. GESAMTZEICH
5. ERSATZTEILLISTE
6. HYDRAULIKPLAN
7. TRANSPORT UND VERSCHIEBUNG




MASSA - WEIGHT - MASA - MASS - GEWICHT: kg 41

ANGOLI DI UTILIZZO - OPERATING ANGLES - ANGULOS DE EMPLEO - ANGLES D'EMPLOI - EINSATZWINKEL



*Tiro nominale: 10 kN al 1° strato
* Motore idraulico con cilindrata: 100 cc
* Pressione nominale di lavoro: 17,5 MPa (175 bar) - Pressione massima di funzionamento allo spunto: 18,5 MPa (185 bar)
* Velocità massima di sollevamento : 49 m/min al 4° strato
* Flusso massimo di funzionamento: 40 L/min - Flusso minimo di funzionamento: 10 L/min
* Riduttore epicicloidale con rapporto di riduzione di 1:4,875
* Freno negativo multidisco con coppia statica di: 48 daNm
* Pressione minima di apertura freno: 2,7 MPa (27 bar) - Pressione massima ammissibile nel freno: 30 MPa (300 bar)
* Quantità di fune avvolgibile: 50 m di fune Ø8 su 4 strati (DIN 15020)
* Quantità di fune avvolgibile a tamburo pieno: 66 m di fune Ø8 su 5 strati (DIN 15020)
* Pressione massima ad argano fermo, misurata allo scarico del distributore: 0,5 MPa (5 bar)
* Lubrificazione parti interne con olio - quantità 0,4 Kg.
* Fissaggio dell'argano con n°4 viti M14 classe minima 8,8 serrate con coppia di135 Nm

* Nominal hoisting pull: 10 kN on 1th layer
* Hydraulic motor displacement: 100 cc
* Working pressure: 17,5 MPa (175 bar) - Maximum starting pressure: 18,5 MPa (185 bar)
* Maximum line speed: 49 m/min on 4th layer
* Maximum working flow: 40 L/min - Minimum working flow: 10 L/min
* Planetary gear reduction ratio: 1:4,875
* Multidisc negative brake, braking static torque: 48 daNm
* Minimum opening brake pressure: 2,7 MPa (27 bar) - Maximum allowable brake pressure: 30 MPa (300 bar)
* Rope storage quantity: 50 m of cable Ø 8 on 4 layers (DIN 15020)
* Maximum storage rope quantity with full drum: 66 m of cable Ø 8 on 5 layers
* Maximum pressure with stopped winch, measured at the distributor exhaust manifold: 0,5 MPa (5 bar)
* Internal lubrication - quantity 0,4 Kg.
* Fixing the winch with n°4 screw M14 minimum class 8,8 tightened with a torque of 135 Nm

* Tiro nominal: 10 kN al 1 estrato
* Motor hidráulico con cilindrada: 100 cc
* Presión nominal de trabajo: 17,5 MPa (175 bar) - Presión máxima de funcionamiento alo arranque: 18,5 MPa (185 bar)
* Velocidad máxima de levantamiento: 49 m/min al 4 estrato
* Flujo máximo de funcionamiento: 40 L/min - Flujo mínimo de funcionamiento: 10 L/min
* Reductor planetario con relación de transmisión 1:4,875
* Freno negativo multidisco con par estatico di: 48 daNm
* Presión mínima de apertura freno: 2,7 MPa (27 bar) - Presión máxima admisible en el freno: 30 MPa (300 bar)
* Cantidad de cable enrollable: 50 m de cable Ø 8 en 4 estratos (DIN 15020)
* Cantitad de cable enrollable con tambor lleno: 66 m de cable Ø 8 en 5 estratos
* Presión máxima a cabrestante parado, medido alo descargue del distribuidor: 0,5 MPa (5 bar)
* Lubricación partes internas con aceite - cantidad 0,4 Kg.
* Fijar el cabrestante con n°4 tornillos M14 clase mínima 8,8 y apretarlos con par de 135 Nm

* Trait nominal : 10 kN au 1 couche
* Moteur hydraulique avec cylindrée 100 cc
* Pression nominal de travail :17,5 MPa (175 bar) - Pression maxime de functionnement au décollage : 18,5 MPa (185 bar)
* Vitesse maxime de levage : 49 m/min au 1 couche
* Flux maxime de functiooement: 40 L/min - Flux minimum de functiooement: 10 L/min
* Réducteur épicycloidal avec rapport de réduction de 1:4,875
* Frein négatif multidisque avec couple statique de : 48 daNm
* Pression minimum ouverture frein : 2,7 MPa (27 bar) - Pression maxime admissible dans le frein: 30 MPa (300 bar)
* Quantité de cable enroulable: 50 m Ø 8 su 4 couches (DIN 15020)
* Quantité de cable enroulable a tambour plein: 66 m Ø 8 su 5 couches
* Pression maxime a treuil ferme, mesurè au décharge du distributeur: 0,5 MPa (5 bar)
* Lubrification parties internes avec huile - quantité 0,4 Kg.
* Fixer le treuil avec n°4 vis M 14 classe minime 8,8 et serré le vis avec couple de 135 Nm

* Nennzugkraft: 10 kN bei 1 seillage
* Hydraulimotor mit hubraum: 100 cc
* Nennarbeitsdruck: 17,5 MPa (175 bar) - Hochstbetriebsdruck bei anlass: 18,5 MPa (185 bar)
* Max. hebegeschwindigkeit: 49 m/min bei 4 seillage
* Max. betriebsdurchfluss: 40 L/min - Min. betriebsdurchfluss: 10 L/min
* Planetenuntersetzungsgetriebe mit untersetzungsverhaltnis von 1:4,875
* Negative lamellenbremse mit stutzmoment von 48 daNm
* Mindestdruck zur bremsenoffnung: 2,7 MPa (27 bar) - In der bremse zulassiger hochstdruck: 30 MPa (300 bar)
* Trommelbare Seilmenge: 50 m Durchm. 8 auf 4 seillage (DIN 15020)
* Trommelbare seilmenge bei vollem trommel: 66 m Durchm. 8 auf 5 seillage
* Hochstdruck bei stehender winde, am auslauf des wegeventils gemessen: 0,5 MPa (5 bar)
* Olschmierung der innenteile - menge: 0,4 Kg.
* Befestigung der winde durch 4 schrauben M14 min. klasse 8,8, mit drehmoment von 135 Nm angezogen

DIAGRAMMA PRESSIONE-TIRO PULL-PRESSURE DIAGRAM DIAGRAMA PRESION-TIRO
DIAGRAM PRESSION-TIR DIAGRAMM DRUCK-ZUG







DIAGRAMMA PORTATA-VELOCITA' SPEED-FLOW DIAGRAM DIAGRAMA FLUJO-VELOCIDAD
DIAGRAM DEBIT-VITESSE DIAGRAMM DURCHFLUSSMENGE-GESCHWINDIGKEIT






4

COMPLESSIVO
DRAWING ASSAMBLY
PLANO DE CONJUNTO
VUE D'ENSEMBLE
GESAMTZEICH

ARGANI VERRICELLI

**9.01.50.58**

**9.01.50.58**

ARGANI VERRICELLI

LISTA RICAMBI
SPARE PART LIST
LISTA REPUESTOS
LISTE PIECES DETACHEES
ERSATZTEILLISTE

5

| POS. | Q. | | ITALIANO | ENGLISH | ESPAÑOL | FRANÇAIS | DEUTSCH | POS. |
|---|---|---|---|---|---|---|---|---|
| 1 | 8 | | VITE T.E. 10.9 UNI 5739 | SCREW T.E. 10.9 UNI 5739 | TORNILLO UNI 5739 | VIS UNI 5739 | SCHRAUBE UNI 5739 | 1 |
| 2 | 1 | | VALVOLA DI BLOCCO | COUNTERBLANCE VALVE | VALVULA DE BLOQUEO | VANNE D'ARRET | SPERRVENTIL | 2 |
| 3 | 1 | | RACCORDO CONICO | PIPE FITTING | TUBERIA | RACCORD | VERBINDUNG | 3 |
| 4 | 1 | | GUARNIZIONE O-RING | O-RING | O-RING | O-RING | O-RING | 4 |
| 5 | 1 | | TUBO DI COLLEGAMENTO | BRAKE PIPE | TUBO DE CONEXION | TUYAU DE CONNEXION | ANSCHLUSSROHR | 5 |
| 6 | 1 | | ANELLO SUPPORTO TAMBURO | DRUM RING | ANILLO SUPORTE TAMBOR | BAGUE SUPPORT TAMBOUR | TROMMELRING | 6 |
| 7 | 2 | | MOLLA A TAZZA | BELLEVILLE SPRING | MUELLE PLANO | RESSORT A DISQUES | TELLERFEDER | 7 |
| 8 | 6 | | VITE TCEI 12.9 UNI 5931 | SCREW UNI 5931 | TORNILLO UNI 5931 | VIS UNI 5931 | SCHRAUBE UNI 5931 | 8 |
| 9 | 1 | | MOTORE IDRAULICO | HYDRAULIC MOTOR | MOTOR HIDRAULICO | MOTEUR HYDRAULIQUE | HYDRAULIKMOTOR | 9 |
| 10 | 1 | | ANELLO ELASTICO PER FORO DIN 472 | RETAINING RING DIN 472 | ANILLO ELASTICO DIN 471 | JOINT D'ARRET POUR AXE DIN 471 | WELLENBORDRING DIN 471 | 10 |
| 11 | 1 | | RACCORDO CONICO | PIPE FITTING | TUBERIA | RACCORD | VERBINDUNG | 11 |
| 12 | 1 | | GUARNIZIONE O-RING | O-RING | O-RING | O-RING | O-RING | 12 |
| 12 | 1 | | GUARNIZIONE O-RING | O-RING | O-RING | O-RING | O-RING | 12 |
| 13 | 1 | | SUPPORTO LATO MOTORE | MOTOR SIDE BRACKET | SOPORTE LADO MOTOR | SUPPORT COTE MOTEUR | HALTER MOTORSEITIG | 13 |
| 14 | 1 | | ANELLO DI TENUTA | OIL SEAL | EMPAQUETADO | BAGUE D'ETANCHEITE | DICHTRING | 14 |
| 15 | 1 | | ANELLO | RING | ANILLO | BAGUE | RING | 15 |
| 16 | 1 | | ANELLO ANTIESTRUSIONE | PARBAK RING | ANILLO ANTIEXTRUSION | BAGUE ANTIEXTRUSION | VERSTEIFUNGSRING | 16 |
| 17 | 1 | | GUARNIZIONE O-RING | O-RING | O-RING | O-RING | O-RING | 17 |
| 18 | 5 | | DISCO | BRAKE PLATE | DISCO | DISQUE DE FREIN | BREMSSCHEIBE | 18 |
| 19 | 6 | | CONTRODISCO | DIVIDER PLATE | CONTRADISCO | CONTRE-DISQUE | GEGENSCHEIBE | 19 |
| 20 | 1 | | DISTANZIALE SUPPORTI | SPACER | ANILLO RIOSTRA RIDUCTOR | BAGUE D'ECARTEMENT REDUCTEUR | GETRIEBE-ABSTANDRING | 20 |
| 21 | 1 | | ANELLO CHIUSURA FRENO | BRAKE CLOSER RING | ANILLO DE CIERRE FRENO | BAGUE DE FERMETURE FREIN | BREMSVERSCHLUSSRING | 21 |
| 22 | 1 | | RONDELLA | WASHER | ARANDELA | BRIDE | FLANSCH | 22 |
| 23 | 1 | | TAPPO | PLUG | TAPON RESPIRADERO | BOUCHON DE VIDANGE | ENTLÜFTUNGSSTOPFEN | 23 |
| 24 | 1 | | ANELLO ELASTICO PER ALBERO DIN 471 | RETAINING RING DIN 472 | ANILLO ELASTICO DIN 471 | JOINT D'ARRET POUR AXE DIN 471 | WELLENBORDRING DIN 471 | 24 |
| 25 | 6 | | VITE TCEI 12.9 UNI 5931 | SCREW UNI 5931 | TORNILLO UNI 5931 | VIS UNI 5931 | SCHRAUBE UNI 5931 | 25 |
| 26 | 108 | | RULLINO | ROLLER | RODILLO | ROULEAU | ROLLE | 26 |
| 27 | 1 | | GUARNIZIONE O-RING | O-RING | O-RING | O-RING | O-RING | 27 |
| 28 | 4 | | VITE T.E. 10.9 UNI 5739 | SCREW T.E. 10.9 UNI 5739 | TORNILLO UNI 5739 | VIS UNI 5739 | SCHRAUBE UNI 5739 | 28 |
| 29 | 1 | | SUPPORTO LATO RIDUTTORE | GEAR SIDE BRACKET | SOPORTE LADO REDUCTOR | SUPPORT COTE REDUCTEUR | HALTER GETRIEBENSEITIG | 29 |
| 30 | 1 | | RADANCIA A GOCCIA | THIMBLE | GUARDACABO | CONE | KEIL | 30 |
| 31 | 2 | | TASCA PORTA RADANCIA | THIMBLE POCKET | SEDE DEL GUARDACABO | BOITE A CONE | KEILKASTEN | 31 |
| 32 | 2 | | VITE TSPEI 10.9 UNI 5933 | SCREW TSPEI 10.9 UNI 5933 | TORNILLO UNI 5933 | VIS UNI 5933 | SCHRAUBE UNI 5933 | 32 |
| 33 | 3 | | RALLA | THRUST RACE | RANGUA | CRAPAUDINE | DREHTEIL | 33 |
| 34 | 3 | | RONDELLA | WASHER | ARANDELA | BRIDE | FLANSCH | 34 |
| 35 | 1 | | FLANGIA FISSAGGIO CUSCINETTO | BEARING FIXING FLANGE | ARANDELA DE FIJACION COJINETE | BRIDE DE FIXATION ROULEMENT | LAGERBEFESTIGUNGSFLANSCH | 35 |
| 36 | 1 | | ANELLO ELASTICO PER FORO DIN 472 | RETAINING RING DIN 472 | ANILLO ELASTICO DIN 471 | JOINT D'ARRET POUR AXE DIN 471 | WELLENBORDRING DIN 471 | 36 |
| 37 | 1 | | ANELLO ELASTICO PER ALBERO DIN 471 | RETAINING RING DIN 472 | ANILLO ELASTICO DIN 471 | JOINT D'ARRET POUR AXE DIN 471 | WELLENBORDRING DIN 471 | 37 |
| 38 | 3 | | VITE TSPEI 10.9 UNI 5933 | SCREW TSPEI 10.9 UNI 5933 | TORNILLO UNI 5933 | VIS UNI 5933 | SCHRAUBE UNI 5933 | 38 |
| 39 | 3 | | PERNO SATELLITE | PLANET PIN | PIVOTE SATELITE | PIVOT ENGRENAGE PLANETAIRE | PLANETENRADZAPFEN | 39 |
| 40 | 3 | | SATELLITE | PLANET | SATELITE | SATELLITE | PLANETENRAD | 40 |
| 41 | 1 | | PASTIGLIA DI RASAMENTO | TEFLON SHIM | PASTILLA | CALE D'EPAISSEUR | ZWISCHENLEGSCHEIBE | 41 |
| 42 | 1 | | CUSCINETTO A SFERE | BALL BEARING | COJINETE A BOLAS | ROULEMENT A BILLES | KUGELLAGER | 42 |
| 43 | 4 | | VITE T.E. 10.9 UNI 5739 | SCREW T.E. 10.9 UNI 5739 | TORNILLO UNI 5739 | VIS UNI 5739 | SCHRAUBE UNI 5739 | 43 |
| 44 | 4 | | SPINA ELASTICA UNI 6873 | ELASTIC PIN UNI 6873 | VASTAGO ELASTICO UNI 6873 | GOUPILLE ELASTIQUE UNI 6873 | KERBSTIFT UNI 6873 | 44 |
| 45 | 4 | | VITE T.E. 10.9 UNI 5739 | SCREW T.E. 10.9 UNI 5739 | TORNILLO UNI 5739 | VIS UNI 5739 | SCHRAUBE UNI 5739 | 45 |
| 46 | 1 | | FIANCATA LATO RIDUTTORE | GEAR SIDE FLANGE | FLANCO LADO REDUCTOR | FLANC COTE REDUCTEUR | SEITENWAND GETRIEBENSEITIG | 46 |
| 47 | 1 | | SOLARE | SUN GEAR | EJE SOLAR | AXE PLANETAIRE | SONNENWELLE | 47 |
| 48 | 1 | | CORONA RIDUTTORE | INTERNAL GEAR | CORONA GUIDACABLE | COURONNE GUIDE DE CABLE | SEILFÜHRUNGSKRANZ | 48 |
| 49 | 6 | | VITE TCEI 12.9 UNI 5931 | SCREW UNI 5931 | TORNILLO UNI 5931 | VIS UNI 5931 | SCHRAUBE UNI 5931 | 49 |
| 50 | 1 | | CORPO FRENO | BRAKE HOUSING | CUERPO FRENO | CORPS FREIN | BREMSKÖRPER | 50 |
| 51 | 2 | | PIATTO DI FISSAGGIO | FIXING PLATE | PLATO DE FIJACION | PLATEAU DE FIXATION | BEFESTIGUNGSPLATTE | 51 |
| 52 | 1 | | INGRANAGGIO PORTA DISCHI | BRAKE PLATE GEAR | ENGRANAJE PORTADISCOS | ENGRENAGE PORTE-DISQUES | BREMSSCHEIBEN-MITNEHMER | 52 |
| 53 | 1 | | ANELLO ANTIESTRUSIONE | PARBAK RING | ANILLO ANTIEXTRUSION | BAGUE ANTIEXTRUSION | VERSTEIFUNGSRING | 53 |
| 54 | 1 | | GUARNIZIONE O-RING | O-RING | O-RING | O-RING | O-RING | 54 |
| 55 | 1 | | PISTONE FRENO | BRAKE PISTON | PISTON FRENO | PISTON DE FREIN | BREMSKOLBEN | 55 |
| 56 | 1 | | TAMBURO | DRUM | TAMBOR | TAMBOUR | TROMMEL | 56 |
| 57 | 1 | | ANELLO DI TENUTA | OIL SEAL | EMPAQUETADO | BAGUE D'ETANCHEITE | DICHTRING | 57 |
| 58 | 1 | | GUARNIZIONE O-RING | O-RING | O-RING | O-RING | O-RING | 58 |
| 59 | 1 | | COPERCHIO CUSCINETTO | COVER BEARING | TAPA POR COJINETE DE BOLAS | COUVERCLE ROULEMENT | LAGERDECKEL | 59 |

1 ARGANO
2 MOTORE IDRAULICO
3 VALVOLA DI BILANCIAMENTO
4 VALVOLA DI MESSA A SCARICO

A - SOLLEVAMENTO
B - DISCESA

1 WINCH
2 HYDRAULIC MOTOR
3 COUNTERBALANCE VALVE
4 EXAUST VALVE

A - LIFTING
B - LOWERING

1 CABRESTANTE
2 MOTOR HIDRAULICO
3 VALVULA DE BLOQUEO
4 VALVULA DE DESCARGA


A - LEVANTAMIENTO
B - DESCENSA

1 TREUIL
2 MOTEUR HYDRAULIQUE
3 SOUPAPE DE CONTROLE DESCENTE
4 VALVE DÉCHARGE DE MASSE

A - LEVAGE
B - DESCENTE


1 WINDE
2 HYDRAULIKMOTOR
3 AUSGLEICHVENTIL
4 VALVE ENTLASTUNG MASS

A - HEBEN
B - SENKEN



MOVIMENTAZIONE SENZA PALLET
HANDLING WITHOUT PALLET
MOVILIZACION SIN PALLET
MANUTENTION SANS PALETTE
BEWEGUNG OHNE PALETTE

PRESA PER SOLLEVAMENTO
HOISTING POINT
AGARRE POR LEVANTAMIENTO
PRISE DE LEVAGE
ABTRIEB ZUM HEBEN



MOVIMENTAZIONE CON PALLET
HANDLING WITH PALLET
MOVILIZACION CON PALLET
MANUTENTION AVEC PALETTE
BEWEGUNG MIT PALETT

Bilag 3


ARGANI VERRICELLI

MW 14

PESO E DIMENSIONI
WEIGHT AND SIZES
PESO Y DIMENSIONES
POIDS ET DIMENSION
GEWICHT UND ABMESSUNGEN


ALLEGATO N.
ATTACHMENT N.
ANEXO N.
ANNEXE N.
ANLAGE N.

1




MASSA - WEIGHT - MASA - MASS - GEWICHT: kg 71

ANGOLI DI UTILIZZO - OPERATING ANGLES - ANGULOS DE EMPLEO - ANGLES D'EMPLOI - EINSATZWINKEL




**ARGANI VERRICELLI**

**MW 18**

PESO E DIMENSIONI
WEIGHT AND SIZES
PESO Y DIMENSIONES
POIDS ET DIMENSION
GEWICHT UND ABMESSUNGEN


ALLEGATO N.
ATTACHMENT N.
ANEXO N.
ANNEXE N.
ANLAGE N.

1




MASSA - WEIGHT - MASA - MASS - GEWICHT: kg 72

ANGOLI DI UTILIZZO - OPERATING ANGLES - ANGULOS DE EMPLEO - ANGLES D'EMPLOI - EINSATZWINKEL



**ARGANI VERRICELLI**

**MW 14**

CONDIZIONI DI UTILIZZO
OPERATING CONDITIONS
CONDICIONES DE EMPLEO
CONDITIONS D'EMPLOI
BETRIEBSBEDINGUNGEN

ALLEGATO N.
ATTACHMENT N.
ANEXO N.
ANNEXE N.
ANLAGE N.

2

DIAGRAMMA PRESSIONE-TIRO — PULL-PRESSURE DIAGRAM — DIAGRAMA PRESION-TIRO
DIAGRAM PRESSION-TIR — DIAGRAMM DRUCK-ZUG






DIAGRAMMA PORTATA-VELOCITA' — SPEED-FLOW DIAGRAM — DIAGRAMA FLUJO-VELOCIDAD
DIAGRAM DEBIT-VITESSE — DIAGRAMM DURCHFLUSSMENGE-GESCHWINDIGKEIT



**ARGANI VERRICELLI**

**MW 18**

CONDIZIONI DI UTILIZZO / OPERATING CONDITIONS / CONDICIONES DE EMPLEO / CONDITIONS D'EMPLOI / BETRIEBSBEDINGUNGEN

ALLEGATO N. / ATTACHMENT N. / ANEXO N. / ANNEXE N. / ANLAGE N.

2

DIAGRAMMA PRESSIONE-TIRO / PULL-PRESSURE DIAGRAM / DIAGRAMA PRESION-TIRO / DIAGRAM PRESSION-TIR / DIAGRAMM DRUCK-ZUG






DIAGRAMMA PORTATA-VELOCITA' / SPEED-FLOW DIAGRAM / DIAGRAMA FLUJO-VELOCIDAD / DIAGRAM DEBIT-VITESSE / DIAGRAMM DURCHFLUSSMENGE-GESCHWINDIGKEIT



**ARGANI VERRICELLI**

**MW 14**

CONDIZIONI DI UTILIZZO
OPERATING CONDITIONS
CONDICIONES DE EMPLEO
CONDITIONS D'EMPLOI
BETRIEBSBEDINGUNGEN

ALLEGATO N.
ATTACHMENT N.
ANEXO N.
ANNEXE N.
ANLAGE N.

2



***Tiro nominale: 13 kN al 3° strato**
*** Motore idraulico con cilindrata: 125 cc**
*** Pressione nominale di lavoro: 19 MPa (190 bar) - Pressione massima di funzionamento allo spunto: 20,9 MPa (209 bar)**
*** Velocità massima di sollevamento : 54 m/min al 4° strato**
*** Flusso massimo di funzionamento: 50 L/min- Flusso minimo di funzionamento: 10 L/min**
*** Riduttore epicicloidale con rapporto di riduzione di 1:5,6**
*** Freno negativo multidisco con coppia statica di: 90 daNm**
*** Pressione minima di apertura freno: 2,7 MPa (27 bar)- Pressione massima ammissibile nel freno: 30 MPa (300 bar)**
*** Quantità di fune avvolgibile: 59m Ø 9su 4 strati (DIN 15020)**
*** Quantità di fune avvolgibile a tamburo pieno: 76 m di fune Ø 9su 5 strati**
*** Pressione massima ad argano fermo, misurata allo scarico del distributore: 0,5 MPa (5 bar)**
*** Lubrificazione parti interne con olio - quantità 0,8 kg.**
*** Fissaggio dell'argano con n°4 viti M14 classe minima 8,8 serrate con coppia di 135 Nm**

*** Nominal hoisting pull: 13 kN on 3th layer**
*** Hydraulic motor displacement: 125 cc**
*** Working pressure: 19 MPa (190 bar) - Maximum starting pressure: 20,9 MPa (209 bar)**
*** Maximum line speed: 54 m/min on 4th layer**
*** Maximum working flow: 50 L/min - Minimum working flow: 10 L/min**
*** Planetary gear reduction ratio: 1:5,6**
*** Multidisc negative brake, braking static torque: 90 daNm**
*** Minimum opening brake pressure: 2,7 MPa (27 bar) - Maximum allowable brake pressure: 30 MPa (300 bar)**
*** Rope storage quantity: 59 m of cable Ø 9 on 4 layers (DIN 15020)**
*** Maximum storage rope quantity with full drum: 76 m of cable Ø 9 on 5 layers**
*** Maximum pressure with stopped winch, measured at the distributor exhaust manifold: 0,5 MPa (5 bar)**
*** Internal lubrication - quantity 0,8 kg.**
*** Fixing the winch with n°4 screw M14 minimum class 8,8 tightened with a torque of 135 Nm**

*** Tiro nominal: 13 kN al 3 estrato**
*** Motor hidráulico con cilindrada: 125 cc**
*** Presión nominal de trabajo: 19 MPa (190 bar) - Presión máxima de funcionamiento alo arranque: 20,9 MPa (209 bar)**
*** Velocidad máxima de levantamiento: 54 m/min al 4 estrato**
*** Flujo máximo de funcionamiento: 50 L/min - Flujo mínimo de funcionamiento: 10 L/min**
*** Reductor planetario con relación de transmisión 1:5,6**
*** Freno negativo multidisco con par estatico di: 90 daNm**
*** Presión mínima de apertura freno: 2,7 MPa (27 bar) - Presión máxima admisible en el freno: 30 MPa (300 bar)**
*** Cantidad de cable enrollable: 59 m de cable Ø 9 en 4 estratos (DIN 15020)**
*** Cantitad de cable enrollable con tambor lleno: 76 m de cable Ø 9 en 5 estratos**
*** Presión máxima a cabrestante parado, medido alo descargue del distribuidor: 0,5 MPa (5 bar)**
*** Lubricación partes internas con aceite - cantidad 0,8 kg.**
*** Fijar el cabrestante con n°4 tornillos M14 clase mínima 8,8 y apretarlos con par de 135 Nm**

*** Trait nominal : 13 kN au 3 couche**
*** Moteur hydraulique avec cylindrée 125 cc**
*** Pression nominal de travail :19 MPa (190 bar) - Pression maxime de functionnement au décollage : 20,9 MPa (209 bar)**
*** Vitesse maxime de levage : 54 m/min au 4 couche**
*** Flux maxime de functiooement: 50 L/min - Flux minimum de functiooement: 10 L/min**
*** Réducteur épicycloidal avec rapport de réduction de 1:5,6**
*** Frein négatif multidisque avec couple statique de : 90 daNm**
*** Pression minimum ouverture frein : 2,7 MPa (27 bar) - Pression maxime admissible dans le frein: 30 MPa (300 bar)**
*** Quantité de cable enroulable: 59 m Ø 9 su 4 couches (DIN 15020)**
*** Quantité de cable enroulable a tambour plein: 76 m Ø 9 su 5 couches**
*** Pression maxime a treuil ferme, mesurè au décharge du distributeur: 0,5 MPa (5 bar)**
*** Lubrification parties internes avec huile - quantité 0,8 kg.**
*** Fixer le treuil avec n.4 vis M 14 classe minime 8,8 et serré le vis avec couple de 135 Nm**

*** Nennzugkraft: 13 kNbei 3 seillage**
*** Hydraulimotor mit hubraum: 125 cc**
*** Nennarbeitsdruck: 19 MPa (190 bar) - Hochstbetriebsdruck bei anlass: 20,9 MPa (209 bar)**
*** Max. hebegeschwindigkeit: 54 m/min bei 4 seillage**
*** Max. betriebsdurchfluss: 50 L/min - Min. betriebsdurchfluss: 10 L/min**
*** Planetenuntersetzungsgetriebe mit untersetzungsverhaltnis von 1:5,6**
*** Negative lamellenbremse mit stutzmoment von 90 daNm**
*** Mindestdruck zur bremsenoffnung: 2,7 MPa (27 bar) - In der bremse zulassiger hochstdruck: 30 MPa (300 bar)**
*** Trommelbare Seilmenge: 59 m Durchm. 9 auf 4 seillage (DIN 15020)**
*** Trommelbare seilmenge bei vollem trommel: 76 m Durchm. 9 auf 5 seillage**
*** Hochstdruck bei stehender winde, am auslauf des wegeventils gemessen: 0,5 MPa (5 bar)**
*** Olschmierung der innenteile - menge: 0,8 kg.**
*** Befestigung der winde durch 4 schrauben M14 min. klasse 8,8, mit drehmoment von 135 Nm angezogen**

| ARGANI VERRICELLI<br>MW 18 | CONDIZIONI DI UTILIZZO<br>OPERATING CONDITIONS<br>CONDICIONES DE EMPLEO<br>CONDITIONS D'EMPLOI<br>BETRIEBSBEDINGUNGEN | ALLEGATO N.<br>ATTACHMENT N.<br>ANEXO N.<br>ANNEXE N.<br>ANLAGE N. | 2 |
|---|---|---|---|

***Tiro nominale: 18 kN al 2° strato**
*** Motore idraulico con cilindrata: 160 cc**
*** Pressione nominale di lavoro: 19 MPa (190 bar) - Pressione massima di funzionamento allo spunto: 23 MPa (230 bar)**
*** Velocità massima di sollevamento : 43 m/min al 4° strato**
*** Flusso massimo di funzionamento: 50 L/min- Flusso minimo di funzionamento: 10 L/min**
*** Riduttore epicicloidale con rapporto di riduzione di 1:5,6**
*** Freno negativo multidisco con coppia statica di: 90 daNm**
*** Pressione minima di apertura freno: 2,7 MPa (27 bar)- Pressione massima ammissibile nel freno: 30 MPa (300 bar)**
*** Quantità di fune avvolgibile: 53m Ø 10su 4 strati (DIN 15020)**
*** Quantità di fune avvolgibile a tamburo pieno: 68 m di fune Ø 10su 5 strati**
*** Pressione massima ad argano fermo, misurata allo scarico del distributore: 0,5 MPa (5 bar)**
*** Lubrificazione parti interne con olio - quantità 0,8 kg.**
*** Fissaggio dell'argano con n°4 viti M14 classe minima 8,8 serrate con coppia di 135 Nm**

*** Nominal hoisting pull: 18 kN on 2th layer**
*** Hydraulic motor displacement: 160 cc**
*** Working pressure: 19 MPa (190 bar) - Maximum starting pressure: 23 MPa (230 bar)**
*** Maximum line speed: 43 m/min on 4th layer**
*** Maximum working flow: 50 L/min - Minimum working flow: 10 L/min**
*** Planetary gear reduction ratio: 1:5,6**
*** Multidisc negative brake, braking static torque: 90 daNm**
*** Minimum opening brake pressure: 2,7 MPa (27 bar) - Maximum allowable brake pressure: 30 MPa (300 bar)**
*** Rope storage quantity: 53 m of cable Ø 10 on 4 layers (DIN 15020)**
*** Maximum storage rope quantity with full drum: 68 m of cable Ø 10 on 5 layers**
*** Maximum pressure with stopped winch, measured at the distributor exhaust manifold: 0,5 MPa (5 bar)**
*** Internal lubrication - quantity 0,8 kg.**
*** Fixing the winch with n°4 screw M14 minimum class 8,8 tightened with a torque of 135 Nm**

*** Tiro nominal: 18 kN al 2 estrato**
*** Motor hidráulico con cilindrada: 160 cc**
*** Presión nominal de trabajo: 19 MPa (190 bar) - Presión máxima de funcionamiento alo arranque: 23 MPa (230 bar)**
*** Velocidad máxima de levantamiento: 43 m/min al 4 estrato**
*** Flujo máximo de funcionamiento: 50 L/min - Flujo mínimo de funcionamiento: 10 L/min**
*** Reductor planetario con relación de transmisión 1:5,6**
*** Freno negativo multidisco con par estatico di: 90 daNm**
*** Presión mínima de apertura freno: 2,7 MPa (27 bar) - Presión máxima admisible en el freno: 30 MPa (300 bar)**
*** Cantidad de cable enrollable: 53 m de cable Ø 10 en 4 estratos (DIN 15020)**
*** Cantitad de cable enrollable con tambor lleno: 68 m de cable Ø 10 en 5 estratos**
*** Presión máxima a cabrestante parado, medido alo descargue del distribuidor: 0,5 MPa (5 bar)**
*** Lubricación partes internas con aceite - cantidad 0,8 kg.**
*** Fijar el cabrestante con n°4 tornillos M14 clase mínima 8,8 y apretarlos con par de 135 Nm**

*** Trait nominal : 18 kN au 2 couche**
*** Moteur hydraulique avec cylindrée 160 cc**
*** Pression nominal de travail :19 MPa (190 bar) - Pression maxime de functionnement au décollage : 23 MPa (230 bar)**
*** Vitesse maxime de levage : 43 m/min au 4 couche**
*** Flux maxime de functiooement: 50 L/min - Flux minimum de functiooement: 10 L/min**
*** Réducteur épicycloidal avec rapport de réduction de 1:5,6**
*** Frein négatif multidisque avec couple statique de : 90 daNm**
*** Pression minimum ouverture frein : 2,7 MPa (27 bar) - Pression maxime admissible dans le frein: 30 MPa (300 bar)**
*** Quantité de cable enroulable: 53 m Ø 10 su 4 couches (DIN 15020)**
*** Quantité de cable enroulable a tambour plein: 68 m Ø 10 su 5 couches**
*** Pression maxime a treuil ferme, mesurè au décharge du distributeur: 0,5 MPa (5 bar)**
*** Lubrification parties internes avec huile - quantité 0,8 kg.**
*** Fixer le treuil avec n.4 vis M 14 classe minime 8,8 et serré le vis avec couple de 135 Nm**

*** Nennzugkraft: 18 kNbei 2 seillage**
*** Hydraulimotor mit hubraum: 160 cc**
*** Nennarbeitsdruck: 19 MPa (190 bar) - Hochstbetriebsdruck bei anlass: 23 MPa (230 bar)**
*** Max. hebegeschwindigkeit: 43 m/min bei 4 seillage**
*** Max. betriebsdurchfluss: 50 L/min - Min. betriebsdurchfluss: 10 L/min**
*** Planetenuntersetzungsgetriebe mit untersetzungsverhaltnis von 1:5,6**
*** Negative lamellenbremse mit stutzmoment von 90 daNm**
*** Mindestdruck zur bremsenoffnung: 2,7 MPa (27 bar) - In der bremse zulassiger hochstdruck: 30 MPa (300 bar)**
*** Trommelbare Seilmenge: 53 m Durchm. 10 auf 4 seillage (DIN 15020)**
*** Trommelbare seilmenge bei vollem trommel: 68 m Durchm. 10 auf 5 seillage**
*** Hochstdruck bei stehender winde, am auslauf des wegeventils gemessen: 0,5 MPa (5 bar)**
*** Olschmierung der innenteile - menge: 0,8 kg.**
*** Befestigung der winde durch 4 schrauben M14 min. klasse 8,8, mit drehmoment von 135 Nm angezogen**

**ARGANI VERRICELLI**

**MW 14 - 18**

SCHEMA IDRAULICO GENERALE
BASIC HYDRAULIC DIAGRAM
ESQUEMA HIDRAULICO
SCHEMA HYDRAULIQUE
HYDRAULIKPLAN

ALLEGATO N.
ATTACHMENT N.
ANEXO N.
ANNEXE N.
ANLAGE N.

3

1 ARGANO
2 MOTORE IDRAULICO
3 VALVOLA DI BILANCIAMENTO
4 DISTRIBUTORE DIREZIONALE A CENTRO APERTO

A - SOLLEVAMENTO
B - DISCESA

1 WINCH
2 HYDRAULIC MOTOR
3 COUNTERBALANCE VALVE
4 DIRECTIONAL MAIN VALVE MOTOR SPOOL

A - LIFTING
B - LOWERING

1 CABRESTANTE
2 MOTOR HIDRAULICO
3 VALVULA DE BLOQUEO
4 VALVULA DISTRIBUIDORA DE CENTRO ABIERTO


A - LEVANTAMIENTO
B - DESCENSA


1 TREUIL
2 MOTEUR HYDRAULIQUE
3 SOUPAPE DE CONTROLE DESCENTE
4 DISTRIBUTEUR DIRECTIONNEL EN CIRCUIT OUVERT

A - LEVAGE
B - DESCENTE

1 WINDE
2 HYDRAULIKMOTOR
3 AUSGLEICHVENTIL
4 WEGEVENTIL MIT OFFENER MITTELSTELLUNG

A - HEBEN
B - SENKEN






| DATA | MODIFICA | DATA | MODIFICA |
|---|---|---|---|
| | | | |

| | | | |
|---|---|---|---|
| TRATTAMENTO TERMICO | MATERIALE: ALLEGATO - ATTACHMENT - ANEXO - ANNEXE - ANLANGE N°4 | | |
| | PARTICOLARE: COMPLESSIVO - DRAWING ASSEMBLY | GREZZO — MASSA (kg) — FINITO | |
| PROFOND. / HRC | PLANO DE CONJUNTO - GASAMTZEICH - VUE D'ENSEMBLE | CONTROLL. / DATA | |
| TECNOLOGIE MECCANICHE AVANZATE s.r.l. SPILAMBERTO-MODENA ITALY | COMPLESSIVO: MW 14 - MW 18 | INDICI DI MODIFICA | |
| | DISEGN.: D.Serugeri | SCALA: | DATA: 21/10/2005 |
| | | | CODICE: 9015259-62 |

La TMA s.r.l. si riserva a termini di legge la proprieta' del presente disegno con divieto di riprodurlo o di renderlo noto a terzi

| TMA ARGANI VERRICELLI | | | LISTA RICAMBI ARGANO: 9.01.52.59 - 62 | SPARE PART LIST WINCH: 9.01.52.59 - 62 | LISTA REPUESTOS CABRESTANTE: 9.01.52.59 - 62 | LISTE PIECES DETACHEES TREUIL: 9.01.52.59 - 62 | ERSATZTEILLISTE WINDE: 9.01.52.59 - 62 n°5 |
|---|---|---|---|---|---|---|---|
| POS. | COD. | NR. | DESCRIZIONE | DESCRIPTION | DESCRIPCTION | DESCRIPTION | BESCHREIBUNG POS. |
| 1 | 60105007 | 2 | VITE TSPEI 10.9 UNI 5933 | SCREW TSPEI 10.9 UNI 5933 | TORNILLO UNI 5933 | VIS UNI 5933 | SCHRAUBE UNI 5933 1 |
| 2 | 61901019 | 1 | VALVOLA DI BILANCIAMENTO | BALANCE VALVE | VALVULA | VANNE | SPERRVENTIL 2 |
| 3 | 10410156 | 1 | FLANGIA DI FISSAGGIO | FIXING FLANGE | ARANDELA DE FIJACION | BRIDE DE FIXATION | BEFESTIGUNGSFLANSCH 3 |
| 4 | * (MW14-62101061) (MW18-62101062) | | MOTORE IDRAULICO | HYDRAULIC MOTOR | MOTOR HIDRAULICO | MOTEUR HYDRAULIQUE | HYDRAULIKMOTOR 4 |
| 5 | 60102008 | 6 | VITE T.E 10.9 UNI 5739 | SCREW T.E 10.9 UNI 5739 | TORNILLO UNI 5739 | VIS UNI 5739 | SCHRAUBE UNI 5739 5 |
| 6 | 11510041 | 1 | INGRANAGGIO PORTA DISCHI | BRAKE PLATE GEAR | ENGRANAJE PORTADISCOS | ENGRENAGE PORTE-DISQUES | BREMSSCHEIBEN-MITNEHMER 6 |
| 7 | 60601007 | 2 | SPINA ELASTICA UNI 6873 | ELASTIC PIN UNI 6873 | VASTAGO ELASTICO UNI 6873 | GOUPILLE ELASTIQUE UNI 6873 | KERBSTIFT UNI 6873 7 |
| 8 | 60305001 | 1 | GUARNIZIONE QUADRING | QUADRING | QUADRING | QUADRING | QUADRING 8 |
| 9 | 60201005 | 1 | CUSCINETTO A SFERE | BALL BEARING | COJINETE A BOLAS | ROULEMENT A BILLES | KUGELLAGER 9 |
| 10 | 62001003 | 1 | RACCORDO CONICO | PIPE FITTING | TUBERIA | RACCORD CONIQUE | KEGELSTUTZEN 10 |
| 11 | 61601015 | 2 | MOLLA A TAZZA | BELLEVILLE SPRING | MUELLE PLANO | RESSORT A DISQUES | TELLERFEDER 11 |
| 12 | 60304005 | 1 | O-RING PER MOTORE | MOTOR O-RING | GUARNICION DEL MOTOR | O-RING POUR MOTEUR | MOTOR O-RING 12 |
| 13 | 60302003 | 1 | GUARNIZIONE O-RING | O-RING | O-RING | O-RING | O-RING 13 |
| 14 | 62003009 | 1 | COLONNETTA CORTA | REDUCTION CONNECTION | RACOR | PETIT RACCORD | KURZE VERBINDUNG 14 |
| 15 | 61001004 | 1 | RONDELLA | WASHER | ARANDELA | RONDELLE | UNTERLEGSCHEIBE 15 |
| 16 | 60902009 | 1 | ANELLO DI TENUTA | OIL SEAL | EMPAQUETADO | BAGUE D'ETANCHEITE | DICHTRING 16 |
| 17 | 60307002 | 1 | ANELLO | RING | ANILLO | BAGUE | RING 17 |
| 18 | 60301013 | 3 | GUARNIZIONE O-RING | O-RING | O-RING | O-RING | O-RING 18 |
| 19 | 61803001 | 1 | TAPPO ESPANSIONE | PLUG | TAPON KOENING EXPANDER | BOUCHON EXPANSIBLE KOENING | SPREIZDECKEL KOENING 19 |
| 20 | 11610047 | 1 | PISTONE FRENO | BRAKE PISTON | PISTON FRENO | PISTON DE FREIN | BREMSKOLBEN 20 |
| 21 | 61001003 | 1 | RONDELLA | WASHER | ARANDELA | RONDELLE | UNTERLEGSCHEIBE 21 |
| 22 | 61801004 | 1 | TAPPO | PLUG | TAPON | BOUCHON | DECKEL 22 |
| 23 | 60302010 | 1 | GUARNIZIONE O-RING | O-RING | O-RING | O-RING | O-RING 23 |
| 24 | 61701003 | 1 | ANELLO ANTIESTRUSIONE | PARBAK RING | ANILLO ANTIEXTRUSION | BAGUE ANTIEXTRUSION | VERSTEIFUNGSRING 24 |
| 25 | 10310064 | 1 | DISTANZIALE SUPPORTI | BRAKET SPACER | RIOSTRA SOPORTES | ENTRETOISE SUPPORTS | HALTER-ABSTANDSTÜCK 25 |
| 26 | 12210005 | 1 | RONDELLA DI RASAMENTO | WASHER | PASTILLA | CALE D'EPAISSEUR | ZWISCHENLEGSCHEIBE 26 |
| 27 | 60401004 | 1 | ANELLO ELASTICO PER FORO DIN 472 | RETAINING RING DIN 472 | ANILLO ELASTICO DIN 472 | JOINT D'ARRET POUR TROU DIN 472 | SPRENGRING F. BOHRUNG DIN 472 27 |
| 28 | 60201004 | 1 | CUSCINETTO A SFERE | BALL BEARING | COJINETE A BOLAS | ROULEMENT A BILLES | KUGELLAGER 28 |
| 29 | 60104033 | 8 | VITE TCEI 12.9 UNI 5931 | SCREW UNI 5931 | TORNILLO UNI 5931 | VIS UNI 5931 | SCHRAUBE UNI 5931 29 |
| 30 | 60402031 | 3 | ANELLO ELASTICO PER ALBERO DIN 471 | RETAINING RING DIN 472 | ANILLO ELASTICO DIN 471 | JOINT D'ARRET POUR AXE DIN 471 | WELLENBORDRING DIN 471 30 |
| 31 | 10610004 | 1 | RADANCIA A GOCCIA | THIMBLE | GUARDACABO | CONE | KEIL 31 |
| 32 | 60102008 | 4 | VITE T.E. 10.9 UNI 5739 | SCREW T.E. 10.9 UNI 5739 | TORNILLO UNI 5739 | VIS UNI 5739 | SCHRAUBE UNI 5739 32 |
| 33 | 60104050 | 6 | VITE TCEI 12.9 UNI 5931 | SCREW UNI 5931 | TORNILLO UNI 5931 | VIS UNI 5931 | SCHRAUBE UNI 5931 33 |
| 34 | 13310062 | 6 | RONDELLA SATELLITI | WASHER | RONDANA SATELITE | RONDELLE PIVOT SATELLITE | UNTERLEGSCHEIBE BOLZEN PLANETENRAD 34 |
| 35 | 12710357 | 3 | PERNO SATELLITE | PLANET PIN | PIVOTE SATELITE | PIVOT ENGRENAGE PLANETAIRE | PLANETENRADZAPFEN 35 |
| 36 | 13310012 | 3 | RONDELLA | WASHER | ARANDELA | RONDELLE | UNTERLEGSCHEIBE 36 |
| 37 | 60105006 | 3 | VITE TSPEI 10.9 UNI 5933 | SCREW TSPEI 10.9 UNI 5933 | TORNILLO UNI 5933 | VIS UNI 5933 | SCHRAUBE UNI 5933 37 |
| 38 | 60401001 | 1 | ANELLO ELASTICO PER FORO DIN 472 | RETAINING RING DIN 472 | ANILLO ELASTICO DIN 472 | JOINT D'ARRET POUR TROU DIN 472 | SPRENGRING F. BOHRUNG DIN 472 38 |
| 39 | 60402002 | 1 | ANELLO ELASTICO PER ALBERO DIN 471 | RETAINING RING DIN 472 | ANILLO ELASTICO DIN 471 | JOINT D'ARRET POUR AXE DIN 471 | WELLENBORDRING DIN 471 39 |
| 40 | 60208013 | 114 | RULLO CILINDRICO TESTA PIANA | ROLLER | RODILLO | ROULEAU CYLINDRIQUE TETE PLATE | ZYLINDERROLLE MIT FLACHKOPF 40 |
| 41 | 13210024 | 3 | SATELLITE | PLANET | SATELITE | SATELLITE | PLANETENRAD 41 |
| 42 | 30702006 | 1 | PASTIGLIA DI RASAMENTO | TEFLON SHIM | PASTILLA | CALE D'EPAISSEUR | ZWISCHENLEGSCHEIBE 42 |
| 43 | 19811281 | 1 | FIANCATA LATO RIDUTTORE | GEAR SIDE FLANGE | FLANCO LADO REDUCTOR | FLANC COTE REDUCTEUR | SEITENWAND GETRIEBENSEITIG 43 |
| 44 | 12110081 | 1 | ALBERO SOLARE | SUN GEAR | EJE SOLAR | AXE PLANETAIRE | SONNENWELLE 44 |
| 45 | 60202018 | 1 | CUSCINETTO A SFERE | BALL BEARING | COJINETE A BOLAS | ROULEMENT A BILLES | KUGELLAGER 45 |
| 46 | 60102035 | 6 | VITE T.E. 10.9 UNI 5739 | SCREW T.E. 10.9 UNI 5739 | TORNILLO UNI 5739 | VIS UNI 5739 | SCHRAUBE UNI 5739 46 |
| 47 | 12510052 | 1 | FLANGIA FISSAGGIO CUSCINETTO | BEARING FIXING FLANGE | ARANDELA DE FIJACION COJINETE | BRIDE DE FIXATION ROULEMENT | LAGERBEFESTIGUNGSFLANSCH 47 |
| 48 | 13610057 | 1 | SUPPORTO LATO RIDUTTORE | GEAR SIDE BRACKET | SOPORTE LADO REDUCTOR | SUPPORT COTE REDUCTEUR | HALTER GETRIEBENSEITIG 48 |
| 49 | 60601009 | 4 | SPINA ELASTICA UNI 6873 | ELASTIC PIN UNI 6873 | VASTAGO ELASTICO UNI 6873 | GOUPILLE ELASTIQUE UNI 6873 | KERBSTIFT UNI 6873 49 |
| 50 | 60302032 | 1 | GUARNIZIONE O-RING | O-RING | O-RING | O-RING | O-RING 50 |
| 51 | 11810025 | 1 | CORONA RIDUTTORE | INTERNAL GEAR | RUEDA REDUCTOR | COURONNE REDUCTEUR | GETRIEBENKRANZ 51 |
| 52 | 13710106 | 2 | PIATTO DI FISSAGGIO | FIXING PLATE | PLATO DE FIJACION | PLATEAU DE FIXATION | BEFESTIGUNGSPLATTE 52 |
| 53 | 60104101 | 8 | VITE TCEI 12.9 UNI 5931 | SCREW UNI 5931 | TORNILLO UNI 5931 | VIS UNI 5931 | SCHRAUBE UNI 5931 53 |
| 54 | 11010372 | 1 | ANELLO CHIUSURA FRENO | BRAKE CLOSER RING | ANILLO DE CIERRE FRENO | BAGUE DE FERMETURE FREIN | BREMSVERSCHLUSSRING 54 |
| 55 | 60801011 | 7 | DISCO | BRAKE PLATE | DISCO | DISQUE DE FREIN | BREMSSCHEIBE 55 |
| 56 | 60801004 | 8 | CONTRODISCO | DIVIDER PLATE | CONTRADISCO | CONTRE-DISQUE | GEGENSCHEIBE 56 |
| 57 | 60302009 | 1 | GUARNIZIONE O-RING | O-RING | O-RING | O-RING | O-RING 57 |
| 58 | 19820021 | 1 | GRUPPO CORPO FRENO | BRAKE HOUSING | GRUPO CUERPO FRENO | GROUPE CORPS FREIN | BREMSAGGREGAT 58 |
| 59 | 60502015 | 2 | ANELLO DI SPALLAMENTO PER FORO | RETAINING RING | ANILLO ELASTICO | BAGUE D'EPAULEMENT POUR TROU | BORDRING F. BOHRUNG 59 |
| 60 | 60302003 | 1 | GUARNIZIONE O-RING | O-RING | O-RING | O-RING | O-RING 60 |
| 61 | 61701001 | 1 | ANELLO ANTIESTRUSIONE | PARBAK RING | ANILLO ANTIEXTRUSION | BAGUE ANTIEXTRUSION | VERSTEIFUNGSRING 61 |
| 62 | 19812195 | 1 | TAMBURO | DRUM | TAMBOR | TAMBOUR | TROMMEL 62 |
| 63 | 11010217 | 1 | ANELLO SUPPORTO TAMBURO | DRUM RING | ANILLO SUPORTE TAMBOR | BAGUE SUPPORT TAMBOUR | TROMMELRING 63 |
| 64 | 13610058 | 1 | SUPPORTO LATO MOTORE | MOTOR SIDE BRACKET | SOPORTE LADO MOTOR | SUPPORT COTE MOTEUR | HALTER MOTORSEITIG 64 |
| 65 | 60102001 | 8 | VITE T.E. 10.9 UNI 5739 | SCREW T.E. 10.9 UNI 5739 | TORNILLO UNI 5739 | VIS UNI 5739 | SCHRAUBE UNI 5739 65 |
| 66 | 60104045 | 2 | VITE TCEI 12.9 UNI 5931 | SCREW UNI 5931 | TORNILLO UNI 5931 | VIS UNI 5931 | SCHRAUBE UNI 5931 66 |
| 67 | 62001001 | 1 | RACCORDO CONICO | PIPE FITTING | TUBERIA | RACCORD CONIQUE | KEGELSTUTZEN 67 |
| 68 | 12910054 | 1 | TUBO DI COLLEGAMENTO | BRAKE PIPE | TUBO DE CONEXION | TUYAU DE CONNEXION | ANSCHLUSSROHR 68 |
| 69 | 60902025 | 1 | ANELLO DI TENUTA | OIL SEAL | EMPAQUETADO | BAGUE D'ETANCHEITE | DICHTRING 69 |
| 70 | 60301008 | 1 | GUARNIZIONE O-RING | O-RING | O-RING | O-RING | O-RING 70 |
| 71 | 11010215 | 1 | COPERCHIO CUSCINETTO | COVER BEARING | TAPA POR COJINETE DE BOLAS | COUVERCLE ROULEMENT | LAGERDECKEL 71 |

**ARGANI VERRICELLI**

**MW 14-18**


MOVIMENTAZIONE ARGANO
WINCH HANDLING
MOVILIZACION DEL CABRESTANTE
MANUTENTION TREUIL
BETRIEBSBEDINGUNGEN

ALLEGATO N.
ATTACHMENT N.
ANEXO N.
ANNEXE N.
ANLAGE N.

6

MOVIMENTAZIONE SENZA PALLET
HANDLING WITHOUT PALLET
MOVILIZACION SIN PALLET
MANUTENTION SANS PALETTE
BEWEGUNG OHNE PALETTE

PRESA PER SOLLEVAMENTO
HOISTING POINT
AGARRE POR LEVANTAMIENTO
PRISE DE LEVAGE
ABTRIEB ZUM HEBEN





MOVIMENTAZIONE CON PALLET
HANDLING WITH PALLET
MOVILIZACION CON PALLET
MANUTENTION AVEC PALETTE
BEWEGUNG MIT PALETTE


**ARGANI VERRICELLI**

**MW 22**

PESO E DIMENSIONI
WEIGHT AND SIZES
PESO Y DIMENSIONES
POIDS ET DIMENSION
GEWICHT UND ABMESSUNGEN


ALLEGATO N.
ATTACHMENT N.
ANEXO N.
ANNEXE N.
ANLAGE N.

1




MASSA - WEIGHT - MASA - MASS - GEWICHT: kg 95

ANGOLI DI UTILIZZO - OPERATING ANGLES - ANGULOS DE EMPLEO - ANGLES D'EMPLOI - EINSATZWINKEL



**ARGANI VERRICELLI**

**MW 22**

CONDIZIONI DI UTILIZZO
OPERATING CONDITIONS
CONDICIONES DE EMPLEO
CONDITIONS D'EMPLOI
BETRIEBSBEDINGUNGEN

ALLEGATO N.
ATTACHMENT N.
ANEXO N.
ANNEXE N.
ANLAGE N.

2

DIAGRAMMA PRESSIONE-TIRO — PULL-PRESSURE DIAGRAM — DIAGRAMA PRESION-TIRO
DIAGRAM PRESSION-TIR — DIAGRAMM DRUCK-ZUG






DIAGRAMMA PORTATA-VELOCITA' — SPEED-FLOW DIAGRAM — DIAGRAMA FLUJO-VELOCIDAD
DIAGRAM DEBIT-VITESSE — DIAGRAMM DURCHFLUSSMENGE-GESCHWINDIGKEIT



| ARGANI VERRICELLI<br>MW 22 | CONDIZIONI DI UTILIZZO<br>OPERATING CONDITIONS<br>CONDICIONES DE EMPLEO<br>CONDITIONS D'EMPLOI<br>BETRIEBSBEDINGUNGEN | ALLEGATO N.<br>ATTACHMENT N.<br>ANEXO N.<br>ANNEXE N.<br>ANLAGE N. | 2 |
|---|---|---|---|


***Tiro nominale: 22 kN al 2° strato**
*** Motore idraulico con cilindrata: 200 cc**
*** Pressione nominale di lavoro: 20,5 MPa (205 bar) - Pressione massima di funzionamento allo spunto: 21,5 MPa (215 bar)**
*** Velocità massima di sollevamento : 38 m/min al 4° strato**
*** Flusso massimo di funzionamento: 50 L/min- Flusso minimo di funzionamento: 10 L/min**
*** Riduttore epicicloidale con rapporto di riduzione di 1:6,25**
*** Freno negativo multidisco con coppia statica di: 90 daNm**
*** Pressione minima di apertura freno: 2,7 MPa (27 bar)- Pressione massima ammissibile nel freno: 30 MPa (300 bar)**
*** Quantità di fune avvolgibile: 54m Ø 12su 4 strati (DIN 15020)**
*** Quantità di fune avvolgibile a tamburo pieno: 69 m di fune Ø 12su 5 strati**
*** Pressione massima ad argano fermo, misurata allo scarico del distributore: 0,5 MPa (5 bar)**
*** Lubrificazione parti interne con olio - quantità 2 kg.**
*** Fissaggio dell'argano con n°4 viti M16 classe minima 8,8 serrate con coppia di 210 Nm**

*** Nominal hoisting pull: 22 kN on 2th layer**
*** Hydraulic motor displacement: 200 cc**
*** Working pressure: 20,5 MPa (205 bar) - Maximum starting pressure: 21,5 MPa (215 bar)**
*** Maximum line speed: 38 m/min on 4th layer**
*** Maximum working flow: 50 L/min - Minimum working flow: 10 L/min**
*** Planetary gear reduction ratio: 1:6,25**
*** Multidisc negative brake, braking static torque: 90 daNm**
*** Minimum opening brake pressure: 2,7 MPa (27 bar) - Maximum allowable brake pressure: 30 MPa (300 bar)**
*** Rope storage quantity: 54 m of cable Ø 12 on 4 layers (DIN 15020)**
*** Maximum storage rope quantity with full drum: 69 m of cable Ø 12 on 5 layers**
*** Maximum pressure with stopped winch, measured at the distributor exhaust manifold: 0,5 MPa (5 bar)**
*** Internal lubrication - quantity 2 kg.**
*** Fixing the winch with n°4 screw M16 minimum class 8,8 tightened with a torque of 210 Nm**

*** Tiro nominal: 22 kN al 2 estrato**
*** Motor hidráulico con cilindrada: 200 cc**
*** Presión nominal de trabajo: 20,5 MPa (205 bar) - Presión máxima de funcionamiento alo arranque: 21,5 MPa (215 bar)**
*** Velocidad máxima de levantamiento: 38 m/min al 4 estrato**
*** Flujo máximo de funcionamiento: 50 L/min - Flujo mínimo de funcionamiento: 10 L/min**
*** Reductor planetario con relación de transmisión 1:6,25**
*** Freno negativo multidisco con par estatico di: 90 daNm**
*** Presión mínima de apertura freno: 2,7 MPa (27 bar) - Presión máxima admisible en el freno: 30 MPa (300 bar)**
*** Cantidad de cable enrollable: 54 m de cable Ø 12 en 4 estratos (DIN 15020)**
*** Cantitad de cable enrollable con tambor lleno: 69 m de cable Ø 12 en 5 estratos**
*** Presión máxima a cabrestante parado, medido alo descargue del distribuidor: 0,5 MPa (5 bar)**
*** Lubricación partes internas con aceite - cantidad 2 kg.**
*** Fijar el cabrestante con n°4 tornillos M16 clase mínima 8,8 y apretarlos con par de 210 Nm**

*** Trait nominal : 22 kN au 2 couche**
*** Moteur hydraulique avec cylindrée 200 cc**
*** Pression nominal de travail :20,5 MPa (205 bar) - Pression maxime de functionnement au décollage : 21,5 MPa (215 bar)**
*** Vitesse maxime de levage : 38 m/min au 4 couche**
*** Flux maxime de functiooement: 50 L/min - Flux minimum de functiooement: 10 L/min**
*** Réducteur épicycloidal avec rapport de réduction de 1:6,25**
*** Frein négatif multidisque avec couple statique de : 90 daNm**
*** Pression minimum ouverture frein : 2,7 MPa (27 bar) - Pression maxime admissible dans le frein: 30 MPa (300 bar)**
*** Quantité de cable enroulable: 54 m Ø 12 su 4 couches (DIN 15020)**
*** Quantité de cable enroulable a tambour plein: 69 m Ø 12 su 5 couches**
*** Pression maxime a treuil ferme, mesurè au décharge du distributeur: 0,5 MPa (5 bar)**
*** Lubrification parties internes avec huile - quantité 2 kg.**
*** Fixer le treuil avec n.4 vis M 16 classe minime 8,8 et serré le vis avec couple de 210 Nm**

*** Nennzugkraft: 22 kNbei 2 seillage**
*** Hydraulimotor mit hubraum: 200 cc**
*** Nennarbeitsdruck: 20,5 MPa (205 bar) - Hochstbetriebsdruck bei anlass: 21,5 MPa (215 bar)**
*** Max. hebegeschwindigkeit: 38 m/min bei 4 seillage**
*** Max. betriebsdurchfluss: 50 L/min - Min. betriebsdurchfluss: 10 L/min**
*** Planetenuntersetzungsgetriebe mit untersetzungsverhaltnis von 1:6,25**
*** Negative lamellenbremse mit stutzmoment von 90 daNm**
*** Mindestdruck zur bremsenoffnung: 2,7 MPa (27 bar) - In der bremse zulassiger hochstdruck: 30 MPa (300 bar)**
*** Trommelbare Seilmenge: 54 m Durchm. 12 auf 4 seillage (DIN 15020)**
*** Trommelbare seilmenge bei vollem trommel: 69 m Durchm. 12 auf 5 seillage**
*** Hochstdruck bei stehender winde, am auslauf des wegeventils gemessen: 0,5 MPa (5 bar)**
*** Olschmierung der innenteile - menge: 2 kg.**
*** Befestigung der winde durch 4 schrauben M16 min. klasse 8,8, mit drehmoment von 210 Nm angezogen**




| DATA | MODIFICA | DATA | MODIFICA |
|---|---|---|---|
| TRATTAMENTO TERMICO | | MATERIALE: ALLEGATO - ATTACHMENT - ANEXO - ANNEXE - ANLAGE N°4 | |
| | | PARTICOLARE: COMPLESSIVO - DRAWING ASSEMBLY<br>PIANO DE CONJUNTO - GESAMTZEICH - VUE D'ENSEMBLE | GREZZO — MASSA (kg) — FINITO<br>CONTROLL.<br>DATA |
| PROFOND. | HRC | COMPLESSIVO: MW 22 | INDICI DI MODIFICA |
| TMA TECNOLOGIE MECCANICHE AVANZATE s.r.l. SPILAMBERTO-MODENA ITALY | | DISEGN.: Serugeri / SCALA: 1:1.6 / DATA: 06.12.2005 | CODICE: 9.01.53.70 |

La TMA s.r.l. si riserva a termini di legge la proprieta' del presente disegno con divieto di riprodurlo o di renderlo noto a terzi

| TMA ARGANI VERRICELLI | | | LISTA RICAMBI ARGANO: 9.01.53.70 | SPARE PART LIST WINCH: 9.01.53.70 | LISTA REPUESTOS CABRESTANTE: 9.01.53.70 | LISTE PIECES DETACHEES TREUIL: 9.01.53.70 | ERSATZTEILLISTE WINDE: 9.01.53.70 n°5 | |
|---|---|---|---|---|---|---|---|---|
| POS. | COD. | NR. | DESCRIZIONE | DESCRIPTION | DESCRIPCTION | DESCRIPTION | BESCHREIBUNG | POS. |
| 1 | 61901019 | 1 | VALVOLA DI BILANCIAMENTO | BALANCE VALVE | VALVULA | VANNE | SPERRVENTIL | 1 |
| 2 | 60502015 | 2 | ANELLO DI SPALLAMENTO PER FORO | RETAINING RING | ANILLO ELASTICO | BAGUE D'EPAULEMENT POUR TROU | BORDRING F. BOHRUNG | 2 |
| 3 | 10410156 | 1 | FLANGIA DI FISSAGGIO | FIXING FLANGE | ARANDELA DE FIJACION | BRIDE DE FIXATION | BEFESTIGUNGSFLANSCH | 3 |
| 4 | 60102026 | 6 | VITE T.E. 10.9 UNI 5739 | SCREW T.E. 10.9 UNI 5739 | TORNILLO UNI 5739 | VIS UNI 5739 | SCHRAUBE UNI 5739 | 4 |
| 5 | 11510041 | 1 | INGRANAGGIO PORTA DISCHI | BRAKE PLATE GEAR | ENGRANAJE PORTADISCOS | ENGRENAGE PORTE-DISQUES | BREMSSCHEIBEN-MITNEHMER | 5 |
| 6 | 62101063 | 1 | MOTORE IDRAULICO | HYDRAULIC MOTOR | MOTOR HIDRAULICO | MOTEUR HYDRAULIQUE | HYDRAULIKMOTOR | 6 |
| 7 | 60601009 | 2 | SPINA ELASTICA UNI 6873 | ELASTIC PIN UNI 6873 | VASTAGO ELASTICO UNI 6873 | GOUPILLE ELASTIQUE UNI 6873 | KERBSTIFT UNI 6873 | 7 |
| 8 | 12210005 | 1 | RONDELLA DI RASAMENTO | WASHER | PASTILLA | CALE D'EPAISSEUR | ZWISCHENLEGSCHEIBE | 8 |
| 9 | 62001003 | 1 | RACCORDO CONICO | PIPE FITTING | TUBERIA | RACCORD CONIQUE | KEGELSTUTZEN | 9 |
| 10 | 60305001 | 1 | GUARNIZIONE QUADRING | QUADRING | QUADRING | QUADRING | QUADRING | 10 |
| 11 | 60201005 | 1 | CUSCINETTO A SFERE | BALL BEARING | COJINETE A BOLAS | ROULEMENT A BILLES | KUGELLAGER | 11 |
| 12 | 60304005 | 1 | O-RING PER MOTORE | MOTOR O-RING | GUARNICION DEL MOTOR | O-RING POUR MOTEUR | MOTOR O-RING | 12 |
| 13 | 61601015 | 2 | MOLLA A TAZZA | BELLEVILLE SPRING | MUELLE PLANO | RESSORT A DISQUES | TELLERFEDER | 13 |
| 14 | 61802002 | 1 | TAPPO | PLUG | TAPON | BOUCHON | DECKEL | 14 |
| 15 | 60302003 | 1 | GUARNIZIONE O-RING | O-RING | O-RING | O-RING | O-RING | 15 |
| 16 | 11010219 | 1 | ANELLO PER TENUTA | OIL SEAL RING | EMPAQUETADO | BAGUE D'ETANCHEITE | DICHTRING | 16 |
| 17 | 11010218 | 1 | ANELLO SUPPORTO TAMBURO | DRUM RING | ANILLO SUPORTE TAMBOR | BAGUE SUPPORT TAMBOUR | TROMMELRING | 17 |
| 18 | 13610059 | 1 | SUPPORTO LATO MOTORE | MOTOR SIDE BRACKET | SOPORTE LADO MOTOR | SUPPORT COTE MOTEUR | HALTER MOTORSEITIG | 18 |
| 19 | 11010220 | 1 | PISTA ROTOLAMENTO RULLI | BEARING EXTERNAL RING | PISTA RODILLOS | SURFACE DE ROULEMENT ROULEAUX | ROLLENLAUFRING | 19 |
| 20 | 60301013 | 3 | GUARNIZIONE O-RING | O-RING | O-RING | O-RING | O-RING | 20 |
| 21 | 61803001 | 1 | TAPPO ESPANSIONE | PLUG | TAPON KOENING EXPANDER | BOUCHON EXPANSIBLE KOENING | SPREIZDECKEL KOENING | 21 |
| 22 | 11610047 | 1 | PISTONE FRENO | BRAKE PISTON | PISTON FRENO | PISTON DE FREIN | BREMSKOLBEN | 22 |
| 23 | 19820021 | 1 | GRUPPO CORPO FRENO | BRAKE HOUSING | GRUPO CUERPO FRENO | GROUPE CORPS FREIN | BREMSAGGREGAT | 23 |
| 24 | 10310065 | 1 | DISTANZIALE SUPPORTI | BRAKET SPACER | RIOSTRA SOPORTES | ENTRETOISE SUPPORTS | HALTER-ABSTANDSTÜCK | 24 |
| 25 | 60302010 | 1 | GUARNIZIONE O-RING | O-RING | O-RING | O-RING | O-RING | 25 |
| 26 | 61701003 | 1 | ANELLO ANTIESTRUSIONE | PARBAK RING | ANILLO ANTIEXTRUSION | BAGUE ANTIEXTRUSION | VERSTEIFUNGSRING | 26 |
| 27 | 60401004 | 1 | ANELLO ELASTICO PER FORO DIN 472 | RETAINING RING DIN 472 | ANILLO ELASTICO DIN 472 | JOINT D'ARRET POUR TROU DIN 472 | SPRENGRING F. BOHRUNG DIN 472 | 27 |
| 28 | 19812197 | 1 | TAMBURO | DRUM | TAMBOR | TAMBOUR | TROMMEL | 28 |
| 29 | 60201004 | 1 | CUSCINETTO A SFERE | BALL BEARING | COJINETE A BOLAS | ROULEMENT A BILLES | KUGELLAGER | 29 |
| 30 | 12110069 | 1 | ALBERO SOLARE | SUN GEAR | EJE SOLAR | AXE PLANETAIRE | SONNENWELLE | 30 |
| 31 | 61402030 | 1 | GRUPPO RIDUZIONE | PLANET HUB | GRUPO REDUCCION | GROUPE REDUCTEUR | PLANETENGETRIEBE | 31 |
| 32 | 11810013 | 1 | CORONA RIDUTTORE | INTERNAL GEAR | RUEDA REDUCTOR | COURONNE REDUCTEUR | GETRIEBENKRANZ | 32 |
| 33 | 60302036 | 1 | GUARNIZIONE O-RING | O-RING | O-RING | O-RING | O-RING | 33 |
| 34 | 60102023 | 4 | VITE T.E. 10.9 UNI 5739 | SCREW T.E. 10.9 UNI 5739 | TORNILLO UNI 5739 | VIS UNI 5739 | SCHRAUBE UNI 5739 | 34 |
| 35 | 13610060 | 1 | SUPPORTO LATO RIDUTTORE | GEAR SIDE BRACKET | SOPORTE LADO REDUCTOR | SUPPORT COTE REDUCTEUR | HALTER GETRIEBENSEITIG | 35 |
| 36 | 10504001 | 2 | TASCA PORTA RADANCIA | THIMBLE POCKET | SEDE DEL GUARDACABO | BOITE A CONE | KEILKASTEN | 36 |
| 37 | 10610005 | 1 | RADANCIA A GOCCIA | THIMBLE | GUARDACABO | CONE | KEIL | 37 |
| 38 | 60102001 | 8 | VITE T.E. 10.9 UNI 5739 | SCREW T.E. 10.9 UNI 5739 | TORNILLO UNI 5739 | VIS UNI 5739 | SCHRAUBE UNI 5739 | 38 |
| 39 | 19811178 | 1 | FIANCATA LATO RIDUTTORE | GEAR SIDE FLANGE | FLANCO LADO REDUCTOR | FLANC COTE REDUCTEUR | SEITENWAND GETRIEBENSEITIG | 39 |
| 40 | 60502003 | 1 | ANELLO DI SPALLAMENTO PER FORO | RETAINING RING | ANILLO ELASTICO | BAGUE D'EPAULEMENT POUR TROU | BORDRING F. BOHRUNG | 40 |
| 41 | 60902020 | 1 | ANELLO DI TENUTA | OIL SEAL | EMPAQUETADO | BAGUE D'ETANCHEITE | DICHTRING | 41 |
| 42 | 60402007 | 1 | ANELLO ELASTICO PER ALBERO DIN 471 | RETAINING RING DIN 472 | ANILLO ELASTICO DIN 471 | JOINT D'ARRET POUR AXE DIN 471 | WELLENBORDRING DIN 471 | 42 |
| 43 | 30702007 | 1 | PASTIGLIA DI RASAMENTO | TEFLON SHIM | PASTILLA | CALE D'EPAISSEUR | ZWISCHENLEGSCHEIBE | 43 |
| 44 | 12010029 | 1 | FLANGIA ANTIROTAZIONE | GEAR FIXING FLANGE | ARANDELA ANTIROTACION | BRIDE ANTIROTATION | VERDREHSICHERUNGSFLANSCH | 44 |
| 45 | 60201002 | 1 | CUSCINETTO A SFERE | BALL BEARING | COJINETE A BOLAS | ROULEMENT A BILLES | KUGELLAGER | 45 |
| 46 | 60102009 | 11 | VITE T.E. 10.9 UNI 5739 | SCREW T.E. 10.9 UNI 5739 | TORNILLO UNI 5739 | VIS UNI 5739 | SCHRAUBE UNI 5739 | 46 |
| 47 | 60601009 | 4 | SPINA ELASTICA UNI 6873 | ELASTIC PIN UNI 6873 | VASTAGO ELASTICO UNI 6873 | GOUPILLE ELASTIQUE UNI 6873 | KERBSTIFT UNI 6873 | 47 |
| 48 | 60102023 | 8 | VITE T.E. 10.9 UNI 5739 | SCREW T.E. 10.9 UNI 5739 | TORNILLO UNI 5739 | VIS UNI 5739 | SCHRAUBE UNI 5739 | 48 |
| 49 | 60302032 | 1 | GUARNIZIONE O-RING | O-RING | O-RING | O-RING | O-RING | 49 |
| 50 | 11010373 | 1 | ANELLO CHIUSURA FRENO | BRAKE CLOSER RING | ANILLO DE CIERRE FRENO | BAGUE DE FERMETURE FREIN | BREMSVERSCHLUSSRING | 50 |
| 51 | 60104005 | 8 | VITE TCEI 12.9 UNI 5931 | SCREW UNI 5931 | TORNILLO UNI 5931 | VIS UNI 5931 | SCHRAUBE UNI 5931 | 51 |
| 52 | 60302009 | 1 | GUARNIZIONE O-RING | O-RING | O-RING | O-RING | O-RING | 52 |
| 53 | 60801011 | 7 | DISCO | BRAKE PLATE | DISCO | DISQUE DE FREIN | BREMSSCHEIBE | 53 |
| 54 | 60801004 | 8 | CONTRODISCO | DIVIDER PLATE | CONTRADISCO | CONTRE-DISQUE | GEGENSCHEIBE | 54 |
| 55 | 61001002 | 1 | RONDELLA | WASHER | ARANDELA | RONDELLE | UNTERLEGSCHEIBE | 55 |
| 56 | 61801005 | 1 | TAPPO | PLUG | TAPON | BOUCHON | DECKEL | 56 |
| 57 | 60302003 | 1 | GUARNIZIONE O-RING | O-RING | O-RING | O-RING | O-RING | 57 |
| 58 | 61701001 | 1 | ANELLO ANTIESTRUSIONE | PARBAK RING | ANILLO ANTIEXTRUSION | BAGUE ANTIEXTRUSION | VERSTEIFUNGSRING | 58 |
| 59 | 13710107 | 2 | PIATTO DI FISSAGGIO | FIXING PLATE | PLATO DE FIJACION | PLATEAU DE FIXATION | BEFESTIGUNGSPLATTE | 59 |
| 60 | 60208005 | 53 | RULLO CILINDRICO TESTA PIANA | ROLLER | RODILLO | ROULEAU CYLINDRIQUE TETE PLATE | ZYLINDERROLLE MIT FLACHKOPF | 60 |
| 61 | 30810001 | 2 | SEMIGABBIA IN PLASTICA PER RULLI | ROLLER HOUSING | CAJA DE RODILLOS | CAGE A ROULEAUX EN PLASTIQUE | ROLLENKASTEN AUS KUNSTSTOFF | 61 |
| 62 | 60902010 | 1 | ANELLO DI TENUTA | OIL SEAL | EMPAQUETADO | BAGUE D'ETANCHEITE | DICHTRING | 62 |
| 63 | 60102001 | 8 | VITE T.E. 10.9 UNI 5739 | SCREW T.E. 10.9 UNI 5739 | TORNILLO UNI 5739 | VIS UNI 5739 | SCHRAUBE UNI 5739 | 63 |
| 64 | 60105005 | 2 | VITE TSPEI 10.9 UNI 5933 | SCREW TSPEI 10.9 UNI 5933 | TORNILLO UNI 5933 | VIS UNI 5933 | SCHRAUBE UNI 5933 | 64 |
| 65 | 60104045 | 2 | VITE TCEI 12.9 UNI 5931 | SCREW UNI 5931 | TORNILLO UNI 5931 | VIS UNI 5931 | SCHRAUBE UNI 5931 | 65 |
| 66 | 62001001 | 1 | RACCORDO CONICO | PIPE FITTING | TUBERIA | RACCORD CONIQUE | KEGELSTUTZEN | 66 |
| 67 | 12910043 | 1 | TUBO DI COLLEGAMENTO | BRAKE PIPE | TUBO DE CONEXION | TUYAU DE CONNEXION | ANSCHLUSSROHR | 67 |
| 68 | 11010103 | 1 | ANELLO PER FLANGIA ANTIROTAZIONE | GEAR FIXING FLANGE RING | ANILLO ANTIROTACION | BAGUE POUR BRIDE ANTIROTATION | RING F. VERDREHSICHERUNGSFLANSCH | 68 |

**ARGANI VERRICELLI**

**MW 22**

SCHEMA IDRAULICO GENERALE
BASIC HYDRAULIC DIAGRAM
ESQUEMA HIDRAULICO
SCHEMA HYDRAULIQUE
HYDRAULIKPLAN

ALLEGATO N.
ATTACHMENT N.
ANEXO N.
ANNEXE N.
ANLAGE N.

3

1 ARGANO
2 MOTORE IDRAULICO
3 VALVOLA DI BILANCIAMENTO
4 DISTRIBUTORE DIREZIONALE A CENTRO APERTO

A - SOLLEVAMENTO
B - DISCESA

1 WINCH
2 HYDRAULIC MOTOR
3 COUNTERBALANCE VALVE
4 DIRECTIONAL MAIN VALVE MOTOR SPOOL

A - LIFTING
B - LOWERING

1 CABRESTANTE
2 MOTOR HIDRAULICO
3 VALVULA DE BLOQUEO
4 VALVULA DISTRIBUIDORA DE CENTRO ABIERTO


A - LEVANTAMIENTO
B - DESCENSA

1 TREUIL
2 MOTEUR HYDRAULIQUE
3 SOUPAPE DE CONTROLE DESCENTE
4 DISTRIBUTEUR DIRECTIONNEL EN CIRCUIT OUVERT

A - LEVAGE
B - DESCENTE

1 WINDE
2 HYDRAULIKMOTOR
3 AUSGLEICHVENTIL
4 WEGEVENTIL MIT OFFENER MITTELSTELLUNG

A - HEBEN
B - SENKEN



ARGANI VERRICELLI

MW 22


MOVIMENTAZIONE ARGANO
WINCH HANDLING
MOVILIZACION DEL CABRESTANTE
MANUTENTION TREUIL
BETRIEBSBEDINGUNGEN


ALLEGATO N.
ATTACHMENT N.
ANEXO N.
ANNEXE N.
ANLAGE N.

6

MOVIMENTAZIONE SENZA PALLET
HANDLING WITHOUT PALLET
MOVILIZACION SIN PALLET
MANUTENTION SANS PALETTE
BEWEGUNG OHNE PALETTE

PRESA PER SOLLEVAMENTO
HOISTING POINT
AGARRE POR LEVANTAMIENTO
PRISE DE LEVAGE
ABTRIEB ZUM HEBEN





MOVIMENTAZIONE CON PALLET
HANDLING WITH PALLET
MOVILIZACION CON PALLET
MANUTENTION AVEC PALETTE
BEWEGUNG MIT PALETTE

# Spare parts catalogue

HMF: 58281

## Winch

## S25


| | |
|---|---|
| Spare parts catalogue No. | **L211** |
| Logbook code | **922500167G** |
| Edition | **08/01/2014** |
| Revision | **0** |

**DINAMIC OIL S.p.A.**
Via Togliatti, 15
41030 Bomporto (MO)
tel +39.059.812611
fax +39.059.812603
dinamicoil@dinamicoil.it

| Table index | *Winch* | **S25** |
|---|---|---|
| | *Logbook code* | **922500167G** |



| Page | Table code | Table heading |
|---|---|---|
| 3 | **922500167G-1** | WINCH S25 SX LIS.12 INTERNAL DRAINAGE CABLE PRESS |
| 4 | **922500167G-2** | WINCH S25 SX LIS.12 INTERNAL DRAINAGE CABLE PRESS |
| 5 | **02981008** | BRAKE GROUP S20-->S45 WITH TRUST BEARING |
| 6 | **02981105** | DRAINAGE CONNECTION KIT S20-->S45 SX |
| 7 | **905146800-1** | CABLE TENSIONER ELECTRIC END STROKE S20-27 FS |
| 8 | **905146800-2** | CABLE TENSIONER ELECTRIC END STROKE S20-27 FS |
| 9 | **905000102** | ELECTRICAL END STROKE KIT (PIZZATO) |

| 922500167G-1 | *Winch* | **S25** |
|---|---|---|
| | *Logbook code* | **922500167G** |





| Pos | Code | Qty | Description |
|---|---|---|---|
| 1 | 425020300 | 1 | MOTOR OMTS 250 151B3038 |
| 2 | 02981008 | 1 | BRAKE GROUP S20-->S45 WITH TRUST BEARING |
| 3 | 410000800 | 8 | HEX SOCKET HEAD CAP SCREW M8X30 8.8 UNI 5931 |
| 4 | 02611004 | 1 | SUN GEAR S20-SW27 RE 500 1:7,5 |
| 5 | 02981204 | 1 | SMOOTH DRUM GROUP S20 |
| 6 | 410410200 | 12 | HEX SOCKET HEAD CAP SCREW M10X55 12.9 UNI 5931 |
| 7 | 427008500 | 1 | THICKNESS SHIM ADJUSTMENT 60X75X1 DIN988 |
| 8 | 421102000 | 1 | HOLE SEEGER Ø110 |
| 9 | 406026900 | 1 | O-RING 2-270 NBR 70SH |
| 10 | 400001900 | 1 | BALL BEARING 6212 |
| 11 | 02321001 | 1 | GEARBOX SIDE FLANGE S-SE20 |
| 12 | 02410204 | 1 | WEDGE S20-SW27 DIA 12-S45 DIA 18 |
| 13 | 410407000 | 12 | HEX SOCKET HEAD CAP SCREW M10X25 12.9 UNI 5931 |
| 14 | 419000700 | 1 | HEX SOCKET HEAD CAP PLUG DIN 908 R 3/8"GAS |
| 15 | 423000600 | 2 | SOFT WASHER COPPER 3/8" UNI 6953 |
| 16 | 406060500 | 1 | V-RING NBR VA 120 |
| 17 | 410030500 | 10 | HEX HEAD CAP SCREW M12X25 10.9 UNI 5739 |
| 18 | 1000027200 | 1 | PAD ERTACETAL 16X4,5 |
| 19 | 02371003 | 1 | ANTIROTATION FLANGE S20-SE27 |
| 20 | 415004800 | 1 | SEAL RING 70X90X10 BASL |
| 21 | 02971646 | 1 | GEARBOX SIDE SUPPORT S20 |
| 22 | 419020600 | 1 | LEVEL OIL PLUG 3/8"(METAL) |
| 23 | 99124500 | 1 | REDUCTION GROUP RE 510 7,5 '00 X S20 |
| 24 | 434003300 | 4 | ELASTIC PIN SPIROL Ø10X24 UNI6875 |
| 25 | 2030030600 | 1 | RING GEAR RE500 |
| 26 | 02451004 | 2 | FIXING PLATE S20-S27 |
| 27 | 02751001 | 1 | DRUM SUPPORT RING S20-SW27 |
| 28 | 402005900 | 1 | ROLLER CAGE KKRK 200-03 L=682 |
| 29 | 415090100 | 1 | SEAL RING 220X250X15 BASL |
| 30 | 423203900 | 1 | RUBBER WASHER 1/8"GAS |
| 31 | 442025600 | 1 | SHORT STUD MF 1/8 L=17 |
| 32 | 02971643 | 1 | MOTOR SIDE SUPPORT S20 |
| 33 | 440001000 | 1 | STRAIGHT CONNECTOR 1/8"G CONICAL Ø6 PIPE |
| 34 | 440000100 | 1 | CONNECTOR 90° 1/8"G CONICAL Ø6 PIPE |
| 35 | 02671017 | 1 | BRAKE PIPE S20 S25 DX |

| 922500167G-2 | *Winch* | **S25** |
|---|---|---|
| | *Logbook code* | **922500167G** |





| Pos | Code | Qty | Description |
|---|---|---|---|
| 13 | 410407000 | 12 | HEX SOCKET HEAD CAP SCREW M10X25 12.9 UNI 5931 |
| 24 | 434003300 | 4 | ELASTIC PIN SPIROL Ø10X24 UNI6875 |
| 36 | 02451008 | 2 | CROSS MEMBER S-SE20-27 2°SERIES |
| 37 | 410260100 | 12 | HEX SOCKET HEAD CAP SCREW M10X25 10.9 UNI 5739 |
| 38 | 410101200 | 2 | HEX SOCKET COUNTERSUNK HEAD CAP SCREW M10X25 10.9 |
| 39 | 410003400 | 4 | HEX SOCKET HEAD CAP SCREW M12X30 8.8 UNI 5931 |
| 40 | 438014600 | 1 | VALVE VOC120 F.MD.S.SE.CH/10 OMT |
| 41 | 410002100 | 2 | HEX SOCKET HEAD CAP SCREW M10X80 8.8 |
| 42 | 410409500 | 8 | HEX SOCKET HEAD CAP SCREW M14X30 12.9 UNI 5931 |

| 02981008 | *Winch* | **S25** |
|---|---|---|
| | *Logbook code* | **922500167G** |





| Pos | Code | Qty | Description |
|---|---|---|---|
| 1 | 414001200 | 2 | PLUG SK 550-060 |
| 2 | 406006000 | 2 | O-RING 2-011 |
| 3 | 406001100 | 1 | O-RING 2-008 |
| 4 | 415068700 | 1 | ANTIEXTRUSION FLUORTEN T-2306/A |
| 5 | 406016800 | 1 | O-RING 2-163 N 674-70 (PARKER) |
| 6 | 02461045 | 1 | MOTOR FIXING FLANGE OMTS |
| 7 | 415006300 | 1 | SEAL ROTO-GLYD TF2105-1-0500-600 |
| 8 | 02631002 | 1 | FLANGED COUPLING S20--->S45 |
| 9 | 400004100 | 1 | BALL BEARING 16010 TYPE B |
| 10 | 415025900 | 1 | SHOULDER RING BR112 FOR HOLE |
| 11 | 406016700 | 2 | O-RING 2-159 N 674-70 (PARKER) |
| 12 | 02271002 | 1 | BRAKE PISTON S20--->S100 |
| 13 | 406013100 | 1 | O-RING 2-167 |
| 14 | 410406100 | 8 | HEX SOCKET HEAD CAP SCREW M10X70 12.9 |
| 15 | 415068600 | 1 | ANTIEXTRISION RING FLUORTEN T-2307/A |
| 16 | 416203700 | 2 | DISC SPRING 112X57X4 |
| 17 | 410419000 | 3 | HEX SOCKET HEAD CAP SCREW M10X16 10.9 DIN7984 |
| 18 | 403002600 | 1 | THRUST BEARING AXK 4565 + 2AS 4565 |
| 19 | 402005500 | 1 | ROLLER BEARING HK 4512 |
| 20 | 02741002 | 1 | BRAKE PAD 'S' WINCHES |
| 21 | 406014400 | 1 | O-RING 2-129 |
| 22 | 02241003 | 1 | BRAKE DISK GEAR S20--->S100 |
| 23 | 434017100 | 3 | ELASTIC PIN Ø10X24 UNI6873 |
| 24 | 415040400 | 5 | SINTERED DISK MIBA 7351104 C SP.1,6 |
| 25 | 415030800 | 6 | STEEL DISK EST. 5" SHIM 1 |
| 26 | 02461018 | 1 | BRAKE CLOSING FLANGE FOR TRUST BEARING |
| 27 | 02981003 | 1 | BRAKE BODY GROUP WINCH "S" |
| 28 | 434017200 | 3 | ELASTIC PIN Ø6X24 UNI6873 |

| 02981105 | *Winch* | **S25** |
|---|---|---|
| | *Logbook code* | **922500167G** |





| Pos | Code | Qty | Description |
|---|---|---|---|
| 1 | 440000200 | 1 | CONICAL CONNECTOR 90° 1/4"G Ø6 PIPE |
| 2 | 423204500 | 1 | RUBBER WASHER Ø12 |
| 3 | 438011100 | 1 | UNIDIRECTIONAL VALVE VU-20-X-A |
| 4 | 02671023 | 1 | DRAINAGE PIPE S20-S25-S27 SX |
| 5 | 440001000 | 1 | STRAIGHT CONNECTOR 1/8"G CONICAL Ø6 PIPE |

| 905146800-1 | *Winch* | **S25** |
|---|---|---|
| | *Logbook code* | **922500167G** |




| Pos | Code | Qty | Description |
|---|---|---|---|
| 1 | 02981308 | 1 | SCREWS+BOLT KIT M6 |
| 2 | 024902121 | 2 | CABLE PRESS SUPPORT PLATE |
| 3 | 410025800 | 4 | HEX HEAD CAP SCREW M10X35 10.9 GEOMET 500B |
| 4 | 01020002 | 1 | END STROKE LEVER (SHORT) NYLON 6 |
| 5 | 410019400 | 1 | HEX HEAD CAP SCREW M8X30 INOX A2-70 |
| 6 | 413002900 | 3 | NUT M8 UNI 5588 INOX A2-70 |
| 7 | 410150600 | 2 | HEX SOCKET HEAD CAP SCREW M8X20 A2-70 (INOX) |
| 8 | 01020003 | 1 | MICROSWITCH SUPPORT PLATE |
| 14 | 029917178 | 1 | CABLE PRESS ARM TYPE 09 INOX |
| 15 | 029813102 | 2 | NYLON CLAMP GROUP Ø20 |
| 16 | 02490285 | 4 | SPRING PLATE I=8 |
| 17 | 418201400 | 4 | TRACTION SPRING DIM T42710 INOX |


| 905146800-2 | *Winch* | **S25** |
|---|---|---|
| | *Logbook code* | **922500167G** |




| Pos | Code | Qty | Description |
|---|---|---|---|
| 6 | 413002900 | 3 | NUT M8 UNI 5588 INOX A2-70 |
| 9 | 423109700 | 2 | FLAT WASHER Ø8.4X17X1.6 INOX |
| 10 | 434010900 | 3 | ELASTIC PIN Ø 5X30 UNI6873 INOX |
| 11 | 423203800 | 2 | WASHER Ø21 UNI6592 INOX SHIM 3 |
| 12 | 423010500 | 4 | NYLON WASHER Ø20.2X31.5X1 |
| 13 | 02601602 | 1 | LIMIT SWITCH CABLE PRESS PIN INOX SE20 |
| 18 | 410083800 | 2 | HEX SOCKET HEAD CAP SCREW M8X30 INOX UNI 5931 |
| 19 | 02601600 | 1 | SPRING PIN Ø20X355 |
| 20 | 423010600 | 4 | NYLON WASHER Ø21X41.5X1 |
| 21 | 400011600 | 4 | BALL BEARING 6004 2RS |
| 22 | 02601601 | 1 | CABLE PRESS Ø20X224 ROLL PIN STANDARD |
| 23 | 01010534 | 1 | DISCHARGED ROLLER L50 Ø68X112 PLA6 |
| 24 | 01010533 | 1 | CABLE PRESS ROLLER Ø68X112 ERTALON 6 PLA |
| 25 | 421005700 | 2 | SHAFT SEEGER Ø20 INOX |

| 905000102 | *Winch* | **S25** |
|---|---|---|
| | *Logbook code* | **922500167G** |

| Pos | Code | Qty | Description |
|---|---|---|---|
| 1 | 409801 | 1 | MICROSWITCH PIZZATO FR501-V9 |
| 2 | 460100900 | 1 | REDUCTION MF PG13,5-PG7 RTG 86782 |
| 3 | 460100400 | 1 | FIXED MALE CONNECTOR PG7 RTG84310 |
| 4 | 410085000 | 2 | HEX SOCKET HEAD CAP SCREW M4X40 INOX A2-70 |
| 5 | 423106700 | 2 | CHAMFERED WASHER Ø4 UNI 1750 INOX |




STV15

dinamic oil

# ARGANO OLEODINAMICO
# HYDRAULIC WINCH

Cod.92 25 00 16 7G
28/05/2013

S25




| Strato di fune – Rope layer | n° | 1 | 2 | 3 | 4 |
|---|---|---|---|---|---|
| Tiro diretto<br>Line pull | daN | 3130 | 2890 | 2680 | 2500 |
| Velocita' fune con 60 l/1'<br>Rope speed with | m/1' | 31 | 34 | 36.5 | 39 |
| Q.ta' fune tamburo liscio<br>Rope capacity smooth drum | m | 17 | 35 | 55 | 76 |
| Q.ta' fune tamburo filettato<br>Rope capacity grooved drum | | | | | |

| | |
|---|---|
| Pressione di sollev.<br>Hoisting pressure | 220 bar |
| Max–min portata alim.<br>Max–min pump delivery | 100/15 l/1' |
| Cilindrata motore<br>Motor displacement | 250 $cm^3$ |
| Rapporto di riduz.<br>Gear ratio | 1:6.5 |

| | | | | | |
|---|---|---|---|---|---|
| A = Ramo di sollevamento<br>Hoisting port | 3/4" | D= Ramo di drenaggio<br>Drain port | –– | Diametro fune consig.<br>Adviced rope size | 12 mm |
| B = Ramo di discesa<br>Lowering port | | P= Tappo olio lubrificazione<br>Lubrication oil plug | 3/8" | Massa<br>Weight | 154 Kg |

IL PRESENTE ARGANO NON PUO' ESSERE UTILIZZATO PER IL SOLLEVAMENTO DI PERSONE.

- Sollevamento con rotazione antioraria del tamburo.(Contraria a richiesta).
- Freno negativo multidisco con coppia statica di 120 daN.m.
- Lubrificazione ingranaggi in bagno d'olio
- Contropressione massima sulla linea di ritorno 5 bar.
- Per sicurezza lasciare sul tamburo 4 spire di fune sempre avvolte.
- L'apparecchio e' classificato secondo la **UNI ISO 4301/1.**
- Per fissare l'argano utilizzare viti **M14 classe 10.9.**
- Le caratteristiche tecniche possono variare senza preavviso.


THE PRESENT EQUIPMENT CAN'T BE USED TO LIFT PEOPLE.


- Hoisting with counter clockwise rotation of the drum (or clockwise if required)
- Negative multi–disc brake,with 120 daN.m of static torque.
- Gear lubrication oil bath.
- Maximum back pressure on return line : 5 bar.
- Always keep at least 4 twists of rope on the drum,for safety reasons.
- The equipment is classified under **UNI ISO 4301/1.**
- To fix the winch use screws **M14 10.9 class.**
- Technical features may change with no previous notice from manufacturer.

DINAMIC OIL S.p.A–Via Togliatti, 15 – 41030 Bomporto (MO)–Italy Tel. 059 812611– Fax 059 812606

ROLLIX®

# INSTALLATION OG VEDLIGEHOLDELSE AF DREJEKRANSE OG SPECIALLEJER





o u t r e m e r : 0 2 4 0 0 1 9 7 0 0 - Photos : Pascal Beltrami

IT ETR 946 - INDICE 2 - JANVIER 1997

ROLLIX®

DEFONTAINE S.A.
3, Rue Louis Renault B.P. 329
F - 44803 SAINT-HERBLAIN Cedex
Tél. (33) 2 40 67 89 89
Fax (33) 2 40 67 89 03

DEFONTAINE GROUP

DK

*Vi gratulerer Dem hermed med Deres valg af en ROLLIX-drekekrans. Vi er overbevist om, at de vil blive yderst tilfreds med dette produkt, såfremt De anvender nedenstående anvisning, anbefalet af ROLLIX DEFONTAINE.*

ADVARSEL

Garantien, som ROLLIX yder, er kun gældende så længe instruktionen overholdes, hvad angår samling, anvendelse og vedligeholdelse af drejekranse, som beskrevet i ROLLIX's tekniske litteratur og katalog.

Specielt nominelle eller exceptionelle belastninger bør ikke overskride kapaciteten for leje, tænder og befæstelsesdele. Kun bolte anbefalet af ROLLIX må anvendes i fastgøringshullerne.

MONTAGE

Foruden at sikre at drejekransen opererer under de bedste forhold og holder den forventede levetid, kræver anvendelsen af en drejekrans i enhver sammenhæng, at der tsærlige forholdsregler eller anvendes særlige fremgangsmåder.

For korrekt udførelse af monteringen vil det følgende være til hjælp for operatøren.

INFORMATION

Denne manual og instruktionsbog kan fås i flere fremmedsprog, og De vil kunne rekvirere disse hos os ved normal henvendelse. Vi gør Dem opmærksom på, at De bør overholde vore forslag til vedligeholdelse af kransen i Deres maskine - eller i givet fald videregive informationerne til operatøren.

# TILSLUTNINGSKONSTRUKTION


## MONTAGEFLANGE

Drejekransen har en moderat aksial bøjningstivhed, idet dens diameter er stor i forhold til tværsnittet. Drejekransen skal installeres på bearbejdede tilslutningsflanger, der sikrer en tilstrækkelig stivhed i forhold til de belastninger, der skal overføres. På denne måde kan man sikre en jævn fordeling af belastningerne og undgå deformation under drift, hvilket ville skade drejekransens driftssikkerhed.Det er således nødvendigt at bruge montageflanger, hvis minimale tykkelse ikke må ligge under de værdier, som er angivet i ovenstående skema.

Bærefladens bredde skal mindst være lig med drejekransens.

Vi anbefaler ringformede forstærkninger af konstruktionenplaceret lige over løbebanen. For at opnå en bedre fordeling af belastningen, foretrækkes kraftig forstærkninger frem for tynde forstærkninger med ribber.

| Drejekran.gennem-snitlige diam.(mm) | 500 | 750 | 1000 | 1250 | 1500 | 2000 | 2500 | 3000 |
|---|---|---|---|---|---|---|---|---|
| Minimal tykkelse (mm) | 25 | 30 | 35 | 40 | 50 | 60 | 70 | 80 |







# TILSLUTNINGSKONSTRUKTION

MONTAGEFLANGERNES PLANHED

Skævheder i flangen medfører deformationer på løbebanen, forårsager indre modstand eller eventuelle blokeringer, som kan ændre lejets levetid.

De maksimale ujævnheder må ikke overstige værdierne i modstående skema.


| Drejekran.gennem-snitlige diam.(mm) | 500 | 750 | 1000 | 1250 | 1500 | 2000 | 2500 | 3000 |
|---|---|---|---|---|---|---|---|---|
| Maksimal tolerance med rulleleje (mm) | 0,10 | 0,12 | 0,15 | 0,18 | 0,20 | 0,25 | 0,29 | 0,32 |
| Maksimal tolerance med kugleleje (mm) | 0,12 | 0,18 | 0,21 | 0,25 | 0,28 | 0,33 | 0,38 | 0,42 |

## MONTAGEFLANGE


Disse maksimale værdier er tilladelige for "lange fejl" i omkredsens retning.

De "korte fejl" f.eks. mellem to fastspændingshuller, må ikke overstige 1/4 af modstående værdier. De fejl, som forekommer i den radiale retning (konicitet) skal forblive under 0,05 mm / m af den gennemsnitlige Ø.

LANGE FEJL




KORTE FEJL




TOLERANCER FOR PLANHED

Planheden på hele drejekransens montageflanger skal være således, at afvigelsen af planheden under maksimal belastning ikk e overstiger de i skemaet angivne værdier.

| Drejekran.gennem-snitlige diam.(mm) | 500 | 750 | 1000 | 1250 | 1500 | 2000 | 2500 | 3000 |
|---|---|---|---|---|---|---|---|---|
| Maksimal afvigelse (mm) | 0,25 | 0,30 | 0,35 | 0,45 | 0,55 | 0,65 | 0,80 | 1,00 |

PLASTIK-CEMENT

I de tilfælde hvor ovenstående tolerancer ikke kan overholdes, kan man bruge Epoxy-harpiks til udglatning af anlægsfladerne.Flere produkter kan benyttes afhæng igt af hvilken type fejl, der skal kompenseres for. En detaljeret vejledning kan fås ved henvendelse tilvor salgsafdeling.

# INSTALLATION

## TRANSPORT-GODSHÅNDTERING

Vore drejekranse bliver omhyggeligt indpakket for at undgå skader under transport.
Transport og opbevaring skal foregå udelukkende i vandret stilling. Hvis drejekransen skal transporteres i andre stillinger, kræves der specielt tilpassede transportkasser.
Som alle maskindele skal drejekransene håndteres forsigtigt idet der skal undgås stød, specielt i radial retning. Intern transport skal foregå ved hjælp af passende grej, som svarer til delens vægt, der er angivet på typeskiltet.

## LEVERING - OPBEVARING

De emballerede drejekranse er blevet overfladebeskyttet mod korrosion, som gør det muligt at opbevare dem i 6 måneder i en tempereret lagerhal.
Hvis opbevaringen overstiger 6 måneder, skal der påføres ny beskyttelse. Efter et tidsrum på 18 måneder, vil det være nødvendigt at foretage en ny smøring *(se afsnittet VEDLIGEHOLDELSE - SMØRING).*

## FØR IBRUGTAGNING-KLARGØRING

### NÅR DREJEKRANSEN PAKKES UD :

- Vær opmærksom på ikke at skære i drejekransens tætninger, når emballagen fjernes.
- Skær i papiret, helst på den udvendige diameter, og ikke på fladerne.

Ved affedtning af drejekransen :

- Benyt en standard fortyndervæske, brug aldrig fortyndervæsker, som indeholder klorholdige opløsningsmidler;
- Pas på ikke at påføre fortyndervæske på tætninger.
- Før montering af smøreanordninger eller tilslutning af rørledninger, skal plastikpropperne eller unbracoskruerne fjernes fra smørehullerne.

### VED INSTALLATION AF DREJEKRANSEN

TILSLUTNINGSKONSTRUKTION

- Sørg for, at montageflanger er i overensstemmelse med forskrifterne

*(se kapitlet TILSLUTNINGSKONSTRUKTION).*

- Kontroller, at der ikke er nogen spåner, svejsekorn, mærker af korrosion, el. lign.
- Undersøg, at drejekransen hviler rigtigt på flangerne.

CENTRERING

I de tilfælde hvor påvirkningerne i radial retning er store, specielt hvis drejekransen er placeret lodret, er det nødvendigt at bruge centreringer, som er beregnet hertil.
Vi anbefaler at påføre et klæbemiddel af typen LOCTITE 586 for at begrænse den relative forskydning mellem drejekransen og understøtningerne.

POSITIONERING

Hærdningsovergangen, som er markeret med en rød streg på tandhjulet, eller på påfyldningsproppen, er synlig på den anden ring, skal placeres i 90° fra belastningernes hovedakse eller fra den arm, som bærer belastningen *(se kapitlet IDENTIFIKATION).*





# INSTALLATION

## MONTAGE

- Kontroller, at fastspændingsbolte og møtrikker er af den korrekte kvalitet : mærkning 10,9 på hovedet. Gevindene skal være korrekt smurte.
- Til drejekranse i standardiseret stål Z eller N, er det nødvendigt at bruge flade underlagsskiver. Disse skal have :
- en elasticitetsgrænse der er højere end eller lig med 600 Mpa,
- en diameter $D_R$ = 2 d,
- en tykkelse h > 0,3 d.


Brug a fjederskiver, lige meget hvilken type eller udførelse, er ikke tilladt og vil medføre bortfald af garanti.

- Foretag fastspændingen med let tilspænding.
- Foretag derefter den endelige tilspænding ved hjælp af momentnøgle, her anbefales hydraulisk værktøj.

- Tilspænd i den rækkefølge som vist i skemaet.

Tilspændingsmomentet er angivet i nedenstående skema for skrueklassen 10,9 og en friktionskoefficient for skrue/møtrik på 0,12 i henhold til VDI 2230.

**TILSPÆNDINGSRÆKKEFØLGE**




**TILSPÆNDINGSMOMENT**


| Diameter (mm) | 10 | 12 | 14 | 16 | 18 | 20 | 22 | 24 | 27 | 30 | 33 |
|---|---|---|---|---|---|---|---|---|---|---|---|
| Moment (N.m) | 69 | 117 | 185 | 280 | 390 | 560 | 750 | 960 | 1400 | 1900 | 2600 |

### VED INSTALLATION AF TANDHJULET

FORTANDING

- Indstil tandhjulsdrevet til det maksimale "udsvingspunkt" for fortandingen, som er mærket med en blå streg.
- Ved dette punkt skal spillerummet ligge inden for grænseværdierne, der er beregnet eller mindst 0,05 x modulet.
- Når der bruges flere drev, skal alle indstilles på samme betingelser.
- Ved prøvning skal man sørge for, at en justering af drev og drejekransen giver mulighed for en indstilling over hele fortandingens bredde.

Kontrol af fortandingens spillerum




- Smør fortandingen på drejekransen og drevet før i drifttagning *(se kapitlet VEDLIGEHOLDELSE).*

# INSTALLATION


## INSTALLATION

AFPRØVNINGER - KONTROL
Når hele fastspændingsenheden er korrekt tilspændt :
- Lad tandhjulet dreje mindst tre omgange.
- Check på ny fortandingens spillerum over en hel omgang.
- Mål det totale slør under en kendt belastning, og afmærk målepunkterne.

Disse værdier registreres i en kontrolbog til senere brug.

Metode :
- Anbring et mikrometerur mellem de to ringe nærmest løbebanen i belastningernes hovedakse. Præcisionsklasse : minimum 0,1 mm.
- Udfør en kalibrering til nul med en reference-belastning.
- Påfør måle-belastningen.
- Aflæs værdien på det målte punkt.
- Udfør flere aflæsninger på forskellige punkter, som på forhånd er udvalgt og mærket (også til senere brug).
- Tag højde for tilslutningsflangernes afbøjning samt boltenes strækforlæn-gelse ved placering af mikrometeruret.


KONTROL AF SLØR
UNDER BELASTNING




# IDENTIFIKATION

## TYPESKILT

Hvert enkelt drejekrans kan identificeres individuelt ved hjælp af et metalskilt, som er nittet fast ved siden af påfyld-ningsproppen på den ring, som ikke er fortandet.
Skiltet giver oplysninger om :
- Fabrikationsdato,
- Referencenr,
- Serienummer,
- Vægt i kg.




# PRODUKTKODER

ROLLIX' drejekranse benævnes med en produkt-reference, der både indeholder tal og bogstaver, i henhold til nedenstående koder :

| | GEOMETRI | | | | | MATERIALE | | | | |
|---|---|---|---|---|---|---|---|---|---|---|
| | 06 | 1116 | 00 | | | Z | Z | 1 | 2 | A |
| 06 | 1116 | 00 | Z | Z | 1 | 2 | A | Hovedgruppe | | |
| 06 | 1116 | 00 | Z | Z | 1 | 2 | A | Lejets gennemsnitlige diameter | | |
| 06 | 1116 | 00 | Z | Z | 1 | 2 | A | Undergruppe | | |
| 06 | 1116 | 00 | Z | Z | 1 | 2 | A | Materialekode for ring uden fortanding | | |
| 06 | 1116 | 00 | Z | Z | 1 | 2 | A | Materialekode for ring med fortanding | | |
| 06 | 1116 | 00 | Z | Z | 1 | 2 | A | Behandling af fortanding | | |
| 06 | 1116 | 00 | Z | Z | 1 | 2 | A | Overfladebehandling | | |





# IDENTIFIKATION

## MÆRKER TIL BRUG VED INSTALLATIONEN

For at kunne udføre en korrekt installation af drejekransen er følgende mærkeringer påført :

Hærdningsovergang :
- På den ikke fortandede ring sidder denne overgang ved påfyldnings-proppen.
- På den fortandede ring er over-gangen mærket med en rød streg på fladen. Disse områder skal om muligt anbringes i belastningens neutrale akse, dvs. nul-moments aksen.

Centreringsmærke :
Det maksimale udsvingspunkt for den "ikke-runde" fortanding er afmærket med :
- to blå streger på toppen af de pågældende tænder,
- et 0, der er præget i fladen modsat anlægsfladen.

Drevet spil skal indstilles på dette punkt.

# SERVICE

## VEDLIGEHOLDELSE - SMØRING

Det er yderst vigtigt for løbebanernes og tændernes levetid, at de bliver smurt regelmæssigt. Driftspåvirkninger såsom belastning, temperatur, hastighed, vibrationer, mv. er bestemmende for valget af smøremiddel.

LØBEBANE
Med mindre andet er angivet, er tandhjulene smurt fra fabrikken.
Standardfedt : ESSO BEACON EP2 eller lignende.

Krav til lejefedt :
- Litiumsæbe-fedt.
- Basisoljens minimums viskositet : 150 $mm^2/sek$.
- Grad : NLGI 2.
- Tilsætningsmidler mod slid og ekstreme tryk.
- Anvendelsestemperatur : - 30 ° C til + 120 ° C
- 4 kugletests (bæreevne) :

ASTM D 2596 (NT24) > 300
- $ND_M$ maksimum :

for kuglelejer ≃ 60 000
for rullelejer ≃ 30 000

FORTANDING
Der er anvendt beskyttelse mod oxidering.

# SERVICE

## VEDLIGEHOLDELSE - SMØRING

SMØREHULLER
Er som regel gevindskåret M10 x 1 og lukket med unbracoskruer. Disse skruer skal fjernes og erstattes enten af smørenipler eller tilslutninger til et centralsmøresystem.
BEMÆRK : Drejekransens påfyldings-prop har et gevindhul. Dette er ikke et smørehul.

SMØREMETODE
Smøringen bør foretages ved langsom drejning, over mindst to omgange, og der skal smøres i alle smøresteder.

INTERVALLER FOR SMØRING
Løbebane og fortanding
Smøreintervaller afhænger af brugen og omgivelserne. Det anbefales, at der smøres efter hver 150 timer drift, når der ikke forekommer særlige belastninger. Dette interval skal nedsættes til 50 timer, hvis anven-delsesforholdene er specielt vanskelige, eller hvis der arbejdes i meget støvfyldte eller fugtige omgivelser.
Før og efter en lang periode, hvor materiellet ikke har været i brug, er det nødvendigt at foretage en ny smøring. Hvis materiellet er henstillet i længere tid, skal der foretages smøring under omdrejning hver 6. måned.

MÆNGDEN AF FEDT
Løbebaner :
Mængden af fedt i en drejekrans kan tilnærmelsesvis findes i en formel
"Q", som kræves pr. $cm^3$ :
Q = 0,005/3 x D x H, hvor:
D = Drejekransens gennemsnitlige Ø i mm.
H = Drejekransens højde i mm.

I alle tilfælde bør der forekomme en lille udtrængning af nyt fedt i kanten af pakningerne.

Fortanding :
Fedtet skal enten sprøjtes på eller lægges på med pensel, og det skal dække tandhjulets flanker og ringen fuldstændig.

SÆRLIGE ANVENDELSER
ROLLIX' udviklingsafdeling hjælper gerne med at finde løsninger til brug under ekstreme forhold, hvad enten det angår temperatur-forhold eller hastighed. De kan få vor tekniske brochure
IT ETR 551 på forespørgsel.

SKEMA OVER SMØREMIDLER
Efter vor erfaring er de smøremidler, som er angivet i nedenstående skema, indbyrdes kompatible og ligeledes kompatible med drejekransens komponenter.
Man kan bruge andre smøremidler på betingelse af, at man på forhånd sikrer sig, at de kan blandes med ROLLIX' standard smøremiddel.De smøremidler, som indeholder molybdændisulfid MoS2 frarådes udtrykkeligt.

| LEJE | MÆRKE | FORTANDING |
|---|---|---|
| Aralub HLP2 | ARAL | Aralub LFZ1 |
| Rhus L 474/2 | MOTUL/BECHEM | Berulit GA 400 |
| Energrease LS - EP2 | BP | Energol WRL/GR 154 GS |
| Grease LMX | CASTROL | |
| Epexa 2 / Epexelf 2 | ELF | Cardrexa DC1 |
| Mobilux EP2 | ESSO | Surret Fluid NX |
| Mobilux EP2 | MOBIL | Mobilgear OGL 007 |
| Retina EP2-Alvania EPLF2 | SHELL | Malléus GL205 |
| Multis EP2-Lical EP2 | TOTAL | Ceran AD+ |

Der tages forbehold for aendrede betegnelser fra fabrikantens side.





# SERVICE

## FOREBYGGENDE VEDLIGEHOLDELSE

KONTROL AF TÆTNINGER
Ved hjælp af en visuel undersøgelse kan man sikre sig, at tætningerne er i driftssikker stand :
- der må ikke forekomme større spændinger eller revner,
- tætningerne skal sidde korrekt,
- undersøg sliddet på læben, der skraber imod.

Om nødvendigt, skal tætninger udskiftes. Efter smøring skal resterne af det gamle fedt fjernes, og det skal kontrolleres, at det ikke indeholder urenheder såsom sand, korn, metalpartikler el. lign.

KONTROL AF FASTSPÆNDINGEN
Fastspændingsbolte og møtrikker kan blive trætte og det er derfor yderst nødvendigt, at undersøge at niveauet af den krævede forspænding i boltene stadig er korrekt.
ROLLIX anbefaler at foretage en efterspænding af boltene efter de første 2 - 4 måneders brug, og siden ved hvert systematiske, årlige eftersyn. Hvis nogle af boltene har løsnet sig, vil det være nødvendigt med en sagkyndig undersøgelse.Visse bestemmelser pålægger en udskiftning af bolte hvert 7. år eller efter hver 14 000 driftstimer. Under alle omstændigheder skal man rette sig efter normer og bestemmelser, der er gældende for anvendelsen.

KONTROL AF INDSTILLINGEN
Under rengøringen, der går forud for smøring af fortandingen skal man :
- Være opmærksom på, at der ikke forekommer fremmedlegemer i bunden af tænderne, på drejekransen eller drevet.
- Undersøge om tandhjulets læng-deakse er jævn over hele fortandingens længde. Ret om nødvendigt justeringen af akserne.
- Kontroller værdien af udsvinget.

# DREJEKRANSENS MAX. SLØR

KONTROL AF SLØR UNDER BELASTNING
ROLLIX leverer sine drejekranse med en intern forspænding, der gør enheden driftssikker og optimerer produktets sikkerhed. Denne spænding mindskes, jo ældre produktet bliver, og medfører en langsom forøgelse af sløret under belastning.
Drejekransen skal udskiftes, når dennes sløret ikke længere kan sikre korrekt og sikkert drift.

For at kunne bestemme sliddet, er det nødvendigt at kende sløret under belastning
- når materiellet er nyt : $J_0$,
- på kontroltidspunktet : $J_1$.

Disse målinger skal udføres under samme forhold, efter at man først har undersøgt fastspændingsboltene
*(se kapitlet INSTALLATION)*

De målte værdier registreres i en kontrolbog til senere brug.
Sliddet udgør forskellen : $u = J_1 - J_0$.
- Drejekransen skal overvåges, når : $u \geq J_0$.
- Man bør tænke på at udskifte den, når : $u \geq 1{,}5\ J_0$. og den skal udskiftes, når : $u > 2\ J_0$.

Under alle omstændigheder skal man henholde sig til gældende bestemmelser for den pågældende anvendelse og det pågældende brugsland.

Produktet er således konstrueret og fremstillet i henhold til normen ISO 9000 og ofte på basis af Deres svar i spørgeskemaet IT ETR 916. Produktet vil leve op til Deres forventninger, hvis driftsbetingelserne for produktet er de samme som dem, ROLLIX har regnet med.

Hvad enten De er konstruktør, montør eller sælger påhviler det Dem at kontrollere endnu en gang, at Deres eller Deres kundes behov er blevet korrekt defineret i vort spørgeskema IT ETR 916 og at installations-, service-og vedligeholdelsesbetingelserne for vort produkt bliver overholdt på alle punkter.

For at lette brugen af disse dokumenter har vi vedlagt endnu et spørgeskema, som ikke er udtømmende, men som indeholder de vigtigste og kontrol-punkter, som under alle omstændigheder skal udføres.

Desuden vil det være en god idé at læse vore garantibestemmelser samt garantiens begrænsninger.

VALG AF DREJEKRANS

• For at bestemme hvilken drejekrans, De har brug for, skal der teges hensyn til flg. punkter :

- Nominelle belastninger ☐
- Overbelastninger på grund af :
  - vind ☐
  - sne ☐
  - driftsbetingelser ☐
- Belastninger på grund af dynamiske påvirkninger ☐
- Undtagelsesvise overbelastninger ☐
- Overbelastning ved test ☐

for :

- løbebanen ☐
- fortandingen ☐
- bolte og møtrikker ☐
- de maksimale driftshastigheder ☐

Ved modtagelsen af drejekransen

• Sørg for at drejekransen, som De netop har modtaget, svarer til den, De har bestilt (identifikation).

Betingelser for henstilling

- Under henstillingen, har drejekransen da været beskyttet mod påvirkninger udefra ? ☐
- Hvis henstillingen har varet i mere end 18 måneder, er drejekransen så blevet smurt igen før montering ? ☐

Før montering :

• sørg for, at drejekransen ikke har fået stød, som kan medføre, at den ikke længere opfylder specifikationerne (uoprettelige deformationer).

- at tætningerne er på plads ☐
- at tætningerne ikke er beskadiget ☐
- at redskaber til godshåndtering er i overensstemmelse med :
  - drejekransens kvalitet ☐
  - drejekransens mål ☐
  - drejekransens vægt ☐



ROLLIX

VED MODTAGELSE AF DREJEKRANSEN

Ved montering, bør De :

• undersøge

- at tilslutningsflangerne er plane ☐
- konstruktionens dimensionering ☐
- påfyldningproppens position ☐
- og positioneringen af hærdningssamlingen i forhold til kipmomenternes hovedakse. ☐

Ved fastspændingen bør De :

• undersøge

- kvaliteten af de benyttede bolte og møtrikker ☐
- antallet af benyttede bolte og møtrikker ☐
- tilspændingsværktøjets kalibrering ☐
- tilspændingsmoment ved smurte bolte ☐
- at der ikke er anvendt fjeder- eller sikringsskiver ☐
- at der er anvendt korrekte spændeskiver, hvis dette er foreskrevet ☐

Ved monteringen af drevet (hvis et sådant findes) bør De :

• undersøge

- at drevet svarer til drejekransens fortanding ☐
- at der ikke er risiko for interferens ☐
- at det minimale udsving er bestemt ☐
- at indstillingen af udsving sker ved :
  - den udvendige fortandings maksimale udsvingspunkt ☐
  - den udvendige fortandings minimale udsvingspunkt ☐
- at centerafstanden mellem drev og drejekransen ikke kan variere efter montering ☐
- at drevets længde på drejekransens fortanding er ensartet ☐

Før drejekransen tages i brug bør De sikre Dem

- at drejekransens maksimale omdrejningshastighed ikke overstiger den værdi, som den er beregnet til ☐
- at ingen elementer kan komme til at forstyrre drejekransens drift ☐
- at ingen elementer kan komme til at ødelægge pakningerne ☐
- at drejekransen og drevet ikke kan forårsage fare
  - for materiellet ☐
  - for personer ☐
- at de udførte beskyttelsesforanstaltninger er i overensstemmelse med bestemmelserne i normen 89/392 EØF ☐

• Undersøg

- slør under maksimal driftsbelastning og registrer resultatet ☐
- at omdrejningen sker uden unormal støj eller "hårde" punkter ☐

Efter igangsætningen bør De sikre Dem


- at der ikke er nogen deformationer, som kan komme til at forstyrre enhedens drift ☐
- at der ikke er nogen deformationer, som kan komme til at forkorte produktets levetid ☐

Under drift bør De sikre Dem at brugeren

- kender anvisningerne for smøring og herunder specielt
  - hvilken type smørefedt, der skal anvendes ☐
  - kender intervaller for smøring ☐
  - kender anvisningerne for smøring ☐

  af :
  - løbebanen ☐
  - fortandingen ☐
- kontroller pakningernes stand ☐
- kender intervallerne for :
  - undersøgelse af bolte og møtrikker ☐
  - udskiftning af bolte og møtrikker ☐
- kende det aksimale tilladelige slør for produktet før udskiftning ☐
- eller grænserne for levetid. ☐


# Riduttori epicicloidali
# Planetary Gearboxes



dinamic oil

# NS

## RE/RA 110 - 210 - 310 - 510 - 610 - 810






| | RE - RA | | | | | |
|---|---|---|---|---|---|---|
| | 110 | 210 | 310 | 510 | 610 | 810 |
| S1 | B40x36 DIN5482 | B40x36 DIN5482 | B58x53 DIN5482 | B58x53 DIN5482 | B58x53 DIN5482 | B70x64 DIN5482 |
| S2 | 30 | 30 | 37 | 37 | 37 | 51 |
| S3 | 43 | 43 | 50 | 50 | 50 | 70 |
| S4 | 5 | 5 | 8 | 8 | 8 | 10 |
| S5 | 55 | 55 | 68.5 | 68.5 | 68.5 | 90 |
| S6 | 42 f7 | 42 f7 | 60 f7 | 60 f7 | 60 f7 | 72 f7 |
| S7 | 35 f7 | 35 f7 | 50 f7 | 50 f7 | 50 f7 | 62 f7 |
| S8 | 24 | 24 | 32 | 32 | 32 | 40 |
| S9 | M6 | M6 | M10 | M10 | M10 | M10 |
| S10 | 13 | 13 | 20 | 20 | 20 | 22 |
| S11 | 120° | 120° | 120° | 120° | 120° | 120° |

| | RE - RA | | | | | |
|---|---|---|---|---|---|---|
| | 110 | 210 | 310 | 510 | 610 | 810 |
| Su1 | A40x36 DIN5482 | A40x36 DIN5482 | A58x53 DIN5482 | A58x53 DIN5482 | A58x53 DIN5482 | A70x64 DIN5482 |
| Su2 | Ø42 H7 | Ø42 H7 | Ø60 H7 | Ø60 H7 | Ø60 H7 | Ø72 H7 |
| Su3 | 6 | 6 | 7 | 7 | 7 | 11 |
| Su4 | 6 | 6 | 10 | 10 | 10 | 10 |
| Su5 | 20.5 | 20.5 | 25 | 25 | 25 | 29 |
| Su6 | Ø42 H7 | Ø42 H7 | Ø60 H7 | Ø60 H7 | Ø60 H7 | Ø72 H7 |
| Su7 | 49 | 49 | 69 | 69 | 69 | 80 |
| Su8 | Ø52 | Ø52 | Ø72 | Ø72 | Ø72 | Ø80 |
| Su9 | 1 | 1 | 1 | 1 | 1 | 1 |
| Su10 | 1 | 1 | 1 | 1 | 1 | 1 |


| | | RE - RA | | | | | |
|---|---|---|---|---|---|---|---|
| | stages | 110 | 210 | 310 | 510 | 610 | 810 |
| A1 | | 186 | 186 | 244 | 244 | 244 | 295 |
| F0 | | 185 | 185 | 222 | 222 | 222 | 280 |
| F2 | | 110 h7 | 110 h7 | 150 f7 | 150 f7 | 150 f7 | 200 f7 |
| F3 | | 165 | 165 | 195 | 195 | 195 | 250 |
| F4 | | 5 | 5 | 13.5 | 13.5 | 13.5 | 10.5 |
| F5 | | 12 | 12 | 16 | 16 | 16 | 18 |
| F6 | | Ø10.5 | Ø10.5 | Ø12.5 | Ø12.5 | Ø12.5 | Ø15 |
| | | M.. - 12.9 | | | | | |
| | | M10 | M10 | M12 | M12 | M12 | M14 |
| F7 | | 45° | 45° | 36° | 36° | 36° | 30° |
| F8 | | 22.5° | 22.5° | — | — | — | — |
| FA1 | | 6.5 | 6.5 | 15 | 15 | 15 | 40 |
| FL | 1 | 95 | 107 | 133 | 151 | 151 | 162.5 |
| | 2 | 138 | 150 | 185.5 | 215.5 | 209.5 | 229.5 |
| | 3 | 181 | 193 | 228.5 | 258.5 | 262 | 282 |
| | 4 | 224 | 236 | 271.5 | 301.5 | 305 | 325 |
| FL7 | 2 | 176 | 188 | 255 | 273 | 273 | 304.5 |
| | 3 | 219 | 231 | 266.5 | 296.5 | 331.5 | 351.5 |
| | 4 | 262 | 274 | 309.5 | 339.5 | 343 | 363 |
| FL8 | 2 | 250.5 | 262.5 | 346 | 364 | 364 | 412.5 |
| | 3 | 293.5 | 305.5 | 341 | 371 | 422.5 | 442.5 |
| | 4 | 336.5 | 348.5 | 384 | 414 | 417.5 | 437.5 |
| T3 | 2 | 113.8 | 113.8 | 171.5 | 171.5 | 171.5 | 277 |
| | 3 | 113.8 | 113.8 | 113.8 | 113.8 | 171.5 | 171.5 |
| | 4 | 113.8 | 113.8 | 113.8 | 113.8 | 113.8 | 113.8 |
| T4 | 2 | 184 | 184 | 183 | 183 | 183 | 242 |
| | 3 | 184 | 184 | 184 | 184 | 183 | 183 |
| | 4 | 184 | 184 | 184 | 184 | 184 | 184 |


**110 - 210**
**310 - 510**









**610**





**810**







**1**


| ø A | B | C | Code |
|---|---|---|---|
| 186 | 14.5 | 67 | K0700A1 |



| |
|---|
| **RE 111 - 112 - 113 - 114** |
| **RE 211 - 212 - 213 - 214** |
| **RE 241 - 242 - 243 - 244** |
| **RE 312 - 313 - 314** |
| **RE 512 - 513 - 514** |
| **RE 613 - 614** |
| **RE 813 - 814** |
| **RE 1023 - 1024** |
| **RE 1523 - 1524** |
| **RE 2004** |
| **RE 2524** |
| **RE 3004** |
| **RE 3514-4804** |
| **RE 6004L** |
| **RE 8005 - 8005L** |
| **GB 12015 - 12015L** |
| **GB 16005 - 16005L** |
| **CC30-CC120** |

**2**


| ø A | B | C | Code |
|---|---|---|---|
| 244 | 20.5 | 76.5 | K0700D2 |




| |
|---|
| **RE 311-511** |
| **RE 611 - 612** |
| **RE 812-1022** |
| **RE 1522-2003** |
| **RE 2523-3003** |
| **RE 3513-4803** |
| **RE 6003 - 6003L** |
| **RE 6004 - 6004L** |
| **RE 8004 - 8004L** |
| **GB 12014 - 12014L** |
| **GB 16004 - 16004L** |
| **GB 21004 - 21005** |
| **GB 26005-31005** |
| **GB 40005-45005** |
| **GB 53005** |
| **CC350** |


**3**


| ø A | B | C | Code |
|---|---|---|---|
| 295 | 16 | 121 | K0700D2 |



| |
|---|
| **RE 811** |
| **RE 1021** |
| **RE 2522** |
| **RE 3002** |
| **RE 3512** |
| **RE 8003 - 8003L** |
| **GB 12013 - 12013L** |
| **GB 16003L** |
| **GB 26004** |
| **GB 31004** |
| **GB 40004** |
| **GB 85005** |
| **GB 110005** |
| **CC1000** |
| **CC600** |












| | A | B | Code |
|---|---|---|---|
| **RE 811** | 30 | 114 | K0700D3 |
| **RE 1021** | | | |
| **RE 2522** | | | |
| **RE 3002** | | | |
| **RE 3512** | | | |
| **RE 8003 - 8003L** | | | |
| **GB 12013 - 12013L** | | | |
| **GB 16003L** | | | |
| **GB 26004** | | | |
| **GB 31004** | | | |
| **GB 40004** | | | |
| **GB 85005** | | | |
| **GB 110005** | | | |
| **CC600** | 50 | 134 | |
| **CC1000** | 61 | 145 | |

# CC30 - CC120









| | | øA | B | C | D | øE | øF | øG | H | L | N | P | R |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| **CC30**<br>**110/210/240** | **RA 112-113-114**<br>**RA 212-213-214**<br>**RA 242-243-244**<br>**RA 313-314**<br>**RA 513-514**<br>**RA 814**<br>**RA 1024**<br>**RA 1524**<br>**RA 2004L** | 178 | 84 | 71.5 | 113.8 | 184 | 178 | 165 | 4 | 15.7 | 23.75 | 18.25 | N°8-M10<br>AT 45° |

| | | øA | B | C | D | øE | øF | øG | H | L | M | P | R |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| **CC120**<br>**310/510/610** | **RA 312**<br>**RA 512-612**<br>**RA 613-813**<br>**RA 1023**<br>**RA 1523**<br>**RA 2003-2003L**<br>**RA 2524**<br>**RA 3004**<br>**RA 3514**<br>**RA 4804**<br>**RA 6004-6004L**<br>**GBA 12015-12015L**<br>**GBA 16005-16005L**<br>**GBA 21005** | 236 | 122 | 91 | 171.5 | 183 | 178 | 165 | 3.5 | 25 | 24.25 | 18.5 | N°8-M10<br>AT 45° |

# CC350 - CC600







| | | øA | B | C | D | øE | øF | G | H | L | M | P | R |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| **CC350** 810/1020 | **RA 812<br>RA 1022<br>RA 2523<br>RA 3023<br>RA 3523<br>RA 8004-8004L<br>GBA 12014-12014L<br>GB 16004L<br>GBA 26005<br>GBA 31005<br>GBA 40005** | 285 | 142 | 108 | 276.75 | 242 | 236 | 6 | 25 | 5,5 | 38 | N°24-M10 AT 15° | 222 |


| | | øA | B | C | D | øE | øF | G | H | L1 | M1 | P | R |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| **CC600** 810/1020 | **RA 812<br>RA 1022<br>RA 2523<br>RA 3023<br>RA 3523<br>RA 8004<br>GBA 12014<br>GBA 16004<br>GBA 26005<br>GBA 31005<br>GBA 40005** | 285 | 198 | 128 | 310 | 293 | 285 | 8 | 27 | 6,5 | 25,5 | N°12-M10 AT 30° | 265 |

| | | øA | B | C | D | øE | øF | G | H | L1 | M1 | P | R |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| **CC600** 1520/2000 | **RA 1522<br>RA 2002<br>RA 4803<br>RA 6003-6003L<br>GBA 16014<br>GBA 21004<br>GBA 45005<br>GBA 53005<br>GBA 61005** | 340 | 206 | 128 | 310 | 293 | 285 | 8 | 27 | 6,5 | 25,5 | N°12-M10 AT 30° | 265 |


| | | øA | B | C | D | øE | øF | G | H | L1 | M1 | P | R |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| **CC600** 2520/3000 | **RA 2522<br>RA 3002<br>RA 8003-8003L<br>GBA 12013-12013L<br>GBA 26004<br>GBA 31004<br>GBA 40004<br>GBA 85005<br>GBA 110005** | 395 | 194 | 128 | 310 | 293 | 285 | 8 | 27 | 6,5 | 25,5 | N°12-M10 AT 30° | 265 |


# CC1000








| CC1000 | | ø A |
|---|---|---|
| | **RA 3512-4802** | 452 |
| | **RA 6002-8002** | 490 |
| | **GBA 16003-16003L** | 452 |
| | **GBA 21003-26003** | 490 |
| | **GBA 45004** | 452 |
| | **GBA 53004-61004** | 490 |
| | **GBA 85004** | 490 |
| | **GBA 130005** | 452 |




| | Type | Code |
|---|---|---|
| **RE 111 - 112 - 113 - 114** | MO 25<br>MO 25.4<br>MO 1″6B<br>MZ | K0700AA<br>K0700AB<br>K0700AC<br>— |
| **RE 211 - 212 - 213 - 214** | | |
| **RE 241 - 242 - 243 - 244** | | |
| **RE 312 - 313 - 314** | | |
| **RE 512 - 513 - 514** | | |
| **RE 613 - 614** | | |
| **RE 813 - 814** | | |
| **RE 1023 - 1024** | | |
| **RE 1523 - 1524** | | |
| **RE 2004** | | |
| **RE 2524** | | |
| **RE 3004** | | |
| **RE 3514-4804** | | |
| **RE 6004L** | | |
| **RE 8005 - 8005L** | | |
| **GB 12015 - 12015L** | | |
| **GB 16005 - 16005L** | | |
| **CC30-CC120** | | |











| | Input type | Shaft | | | Flange | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | A | B | C | D | E | F | G | H | L | M | N | P | R | S | T |
| RE 111 - 112 - 113 - 114<br>RE 211 - 212 - 213 - 214<br>RE 241 - 242 - 243 - 244<br>RE 312 - 313 - 314<br>RE 512 - 513 - 514<br>RE 613 - 614<br>RE 813 - 814<br>RE 1023 - 1024<br>RE 1523 - 1524<br>RE 2004 - RE 2004L<br>RE 2524<br>RE 3004<br>RE 3514 - 4804<br>RE 6004L<br>RE 8005 - 8005L<br>GB 12015 - 12015L<br>GB 16005 - 16005L<br>CC30-CC120 | **ME 80** | 6 | 21.8 | 19 | 200 | 165 | 130 | 4 | 16 | 82.5 | 6.5 | 44.5 | — | 25 | N'4-M10 | 178 |
| | **ME 90** | 8 | 27.3 | 24 | 200 | 165 | 130 | 4 | 16 | 82.5 | 11.5 | 52 | — | 25 | N'4-M10 | |
| | **ME 100/112** | 8 | 31.3 | 28 | 250 | 215 | 180 | 4.5 | 16 | 91 | 11.5 | 61 | N°4-M12 | — | — | |
| | **ME 132** | 10 | 41.3 | 38 | 300 | 265 | 230 | 5 | 20 | 115.5 | 8 | 82.5 | N°4-M12 | — | — | |
| | **ME 160** | 12 | 45.3 | 42 | 350 | 300 | 250 | 6 | 20 | 145 | 23 | 110.5 | N°4-M16 | — | — | |
| | **ME 180** | 14 | 51.8 | 48 | 350 | 300 | 250 | 6 | 20 | 145 | 23 | 110.5 | N°4-M16 | — | — | |


| | Input type | Shaft | | | Flange | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | A | B | C | D | E | F | G | H | L | M | N | P | R | S | T |
| RE 311-511<br>RE 611 - 612<br>RE 812 -1022<br>RE 1522 - 2002 - 2002L<br>RE 2003<br>RE 2523 - 3003<br>RE 3513 - 4803<br>RE 6003 - 6003L<br>RE 6004 - 6004L<br>RE 8004 - 8004L<br>GB 12004 - 12004L<br>GB 16004 - 16004L<br>GB 21004 - 21005<br>GB 26005 - 31005<br>GB 40005 - 45005<br>GB 53005<br>CC350 | **ME132** | 10 | 41.3 | 38 | 300 | 265 | 230 | 5 | 20 | 125.5 | 8 | 82.5 | N°4-M12 | — | — | 236 |
| | **ME160** | 12 | 45.3 | 42 | 344 | 300 | 250 | 7 | 20 | 154.5 | 23 | 110.5 | N°4-M16 | — | — | |
| | **ME180** | 14 | 51.8 | 48 | 344 | 300 | 250 | 7 | 20 | 154.5 | 23 | 110.5 | N°4-M16 | — | — | |
| | **ME225** | 18 | 64.4 | 60 | 450 | 400 | 350 | 7 | 20 | 191.5 | 30 | 143.5 | N°4-M16 | — | — | |

| | Input type | Shaft | | | Flange | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | A | B | C | D | E | F | G | H | L | M | N | P | R | S | T |
| RE 811<br>RE 1021<br>RE 2522<br>RE 3002<br>RE 3512<br>RE 8003 - 8003L<br>GB 12013 - 12013L<br>GB 16003L<br>GB 26004<br>GB 31004<br>GB 40004<br>GB 85005<br>GB 110005<br>CC600 - CC1000 | **ME200** | 16 | 59.3 | 55 | 400 | 350 | 300 | 7 | 18 | 165 | 11.5 | 114.5 | N°4-M18 | — | — | 285 |
| | **ME225** | 18 | 64.4 | 60 | 450 | 400 | 350 | 7 | 20 | 194 | 30.5 | 143.5 | N°8-M18 | — | — | |
| | **ME250** | 18 | 6.4 | 65 | 550 | 500 | 450 | 7 | 22 | 195 | 17 | 145 | N°8-ø19 | — | — | |
| | **ME280** | 20 | 79.9 | 75 | 550 | 500 | 450 | 7 | 22 | 195 | 12 | 145 | N°8-ø19 | — | — | |








| | n1 x h = 1 500 000 Fa1 max (Fr1 = 0) | |
|---|---|---|
| | Fa1 (+) | Fa1 (-) |
| **AV1** | 4 800 | 4 800 |
| **AV2 - AV3L - AV4** | 7 800 | 7 800 |
| **AV2S - AV3** | 4 900 | 7 800 |
| **AV2RS - AV4RS** | 4 900 | 4 900 |





| | Type | øA | B | C | øD | E | F | G | H | L | M | N | Code |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| **RE 111 - 112 - 113 - 114**<br>**RE 211 - 212 - 213 - 214**<br>**RE 241 - 242 - 243 - 244**<br>**RE 312 - 313 - 314**<br>**RE 512 - 513 - 514**<br>**RE 613 - 614 - 813 - 814**<br>**RE 1023 - 1024 -1523 - 1524**<br>**RE 2000 - 2524 - 3004 -3514**<br>**RE 4804 - 6004L - 8005 - 8005L**<br>**GB 12015 - 12015L**<br>**GB 16005 - 16005L**<br>**CC30-CC120** | **AV1** | 186 | 83.5 | 58 | 38 | M12 | 30 | 10 | 8 | 50 | 4 | 41 | K0700AH |
| | **AV2** | 186 | 96.5 | 82 | 42 | M12 | 30 | 12 | 8 | 70 | 6 | 45 | K0700AI |
| | **AV3L** | 186 | 96.5 | 82 | 48 | M16 | 40 | 14 | 9 | 70 | 6 | 51.5 | K0700AI |
| | **AV4** | 186 | 108.5 | 65 | 40 | M12 | 30 | 12 | 8 | 60 | 2.5 | 43 | K0700AX |
| | **AV4RS** | 186 | 108.5 | 65 | 40 | M12 | 30 | 12 | 8 | 60 | 2.5 | 43 | K0700AX |

| | Type | øA | B | C | øD | E | F | G | H | L | M | N | Code |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| **RE 311-511-611-612**<br>**RE 812-1022-1522-2003**<br>**RE 2523-3003-3513-4803**<br>**RE 6003-6003L-6004-6004L**<br>**RE 8004-8004L**<br>**GB 12014-12014L-16004-16004L**<br>**GB 21004-21005-26005-31005**<br>**GB 40005-45005-53005**<br>**GB 61005**<br>**CC350-CC600** | **AV2** | 244 | 106 | 82 | 42 | M12 | 30 | 12 | 8 | 70 | 6 | 45 | K0700DL |
| | **AV2S** | 244 | 106 | 82 | 42 | M12 | 30 | 12 | 8 | 70 | 6 | 45 | K0700DL |
| | **AV2RS** | 244 | 106 | 82 | 42 | M12 | 30 | 12 | 8 | 70 | 6 | 45 | K0700DL |
| | **AV3** | 244 | 106 | 82 | 48 | M16 | 40 | 14 | 9 | 70 | 6 | 51.5 | K0700DM |
| | **AV4** | 244 | 118 | 65 | 40 | M12 | 30 | 12 | 8 | 60 | 2.5 | 43 | K0700DJ |
| | **AV4RS** | 244 | 118 | 65 | 40 | M12 | 30 | 12 | 8 | 60 | 2.5 | 43 | K0700DJ |


# AVF-AV110N-NL







| | Code |
|---|---|
| **RE 111 - 112 - 113 - 114** | K0700AY |
| **RE 211 - 212 - 213 - 214** | |
| **RE 241 - 242 - 243 - 244** | |
| **RE 312 - 313 - 314** | |
| **RE 512 - 513 - 514** | |
| **RE 613 - 614** | |
| **RE 813 - 814** | |
| **RE 1023 - 1024** | |
| **RE 1523 - 1524** | |
| **RE 2004** | |
| **RE 2524** | |
| **RE 3004** | |
| **RE 3514** | |
| **RE 4804** | |
| **RE 6004L** | |
| **RE 8005 - 8005L** | |
| **GB 12015 - 12015L** | |
| **GB 16005 - 16005L** | |
| **CC30-CC120** | |









| | n1 x h = 1 500 000 Fa1 max (Fr1 = 0) | |
|---|---|---|
| | Fa1 (+) | Fa1 (-) |
| **AV110N** | 4 900 | 7 800 |
| **AV110NL** | 3 750 | 3 750 |

# AVF-AV510N-NL












| | n1 x h = 1 500 000 Fa1 max (Fr1 = 0) | |
|---|---|---|
| | Fa1 (+) | Fa1 (-) |
| **AV510NL** | 6 600 | 6 600 |
| **AV510N** | 15 250 | 15 250 |




| | A | B |
|---|---|---|
| **RE 311-511-611-612-812-1022-1522-2003-2523-3003-3513-4803-6003-6003L** | 164 | — |
| **RE 6004-6004L-8004-8004L** | 164 | — |
| **GB 12014-12014L-16004-16004L-21004-21005-26005-31005-40005-45005** | 164 | — |
| **GB 53005-61005** | — | 172.5 |
| **RE 811-1021-2522-3002-3512-8003-8003L** | — | 172.5 |
| **GB 12013-12013L-16003L-26004-31004-40004-85005-110005** | — | 172.5 |
| **CC350** | 128 | — |
| **CC600** | — | 153 |

# AVF-AV510TL













| | n1 x h = 1 500 000 Fa1 max (Fr1 = 0) | |
|---|---|---|
| | Fa1 (+) | Fa1 (-) |
| **AV510TL** | 21 600 | 21 600 |


| | A | B |
|---|---|---|
| **RE 311-511-611-612-812-1022-1522-2003-2523-3003-3513-4803-6003-6003L** | 212 | — |
| **RE 6004-6004L-8004-8004L** | 212 | — |
| **GB 12014-12014L-16004-16004L-21004-21005-26005-31005-40005-45005** | 212 | — |
| **GB 53005-61005** | 212 | — |
| **RE 811-1021-2522-3002-3512-8003-8003L** | — | 221 |
| **GB 12013-12013L-16003L-26004-31004-40004-85005-110005** | — | 221 |
| **CC350** | 176 | — |
| **CC600** | — | 201 |

# AVF-AV810N-NL












| | n1 x h = 1 500 000 Fa1 max (Fr1 = 0) | |
|---|---|---|
| | Fa1 (+) | Fa1 (-) |
| **AV810NL** | 14 800 | 14 800 |
| **AV810N** | 25 900 | 25 900 |




| | A | B |
|---|---|---|
| **RE 811-1021-2522-3002-3512-8003-8003L** | 195.5 | — |
| **GB 12013-12013L-16003L-26004-31004-40004-85005-110005** | 195.5 | — |
| **RE 2521-3001-8002-8002L** | — | 278 |
| **GB 12012-12012L-26003-31003-40003-85004-110004-205005-235005** | — | 278 |
| **CC600** | 162.5 | — |
| **CC1000** | 162.5 | — |


# AVF-AV810T-TL












C










| | n1 x h = 1 500 000 Fa1 max (Fr1 = 0) | |
|---|---|---|
| | Fa1 (+) | Fa1 (-) |
| **AV810T** | 39 200 | 25 900 |





| | A | B |
|---|---|---|
| **RE 811-1021-2522-3002-3512-8003-8003L** | 218 | — |
| **GB 12013-12013L-16003L-26004-31004-40004-85005-110005** | 218 | — |
| **RE 2521-3001-8002-8002L** | — | 296 |
| **GB 12012-12012L-26003-31003-40003-85004-110004-205005-235005** | — | 296 |
| **CC600** | 185 | — |
| **CC1000** | 185 | — |


# AVF-AV1020T-TL
















| | n1 x h = 1 500 000 Fa1 max (Fr1 = 0) | |
|---|---|---|
| | Fa1 (+) | Fa1 (-) |
| **AV1020T** | 46 450 | 26 850 |


| | A | B | C |
|---|---|---|---|
| **RE 811-1021-2522-3002-3512-8003-8003L** | 249 | — | — |
| **GB 12013-12013L-16003L-26004-31004-40004-85005-110005** | 249 | — | — |
| **RE 2521-3001-8002-8002L** | — | 327 | 409 |
| **GB 12012-12012L-26003-31003-40003-85004-110004** | — | 327 | 409 |
| **RE 3511-4801** | — | 348 | 452 |
| **GB 16002-16002L-45003-130004** | — | 348 | 452 |
| **CC1000** | 216 | — | — |

# AVF-AV1520T












| | n1 x h = 1 500 000 Fa1 max (Fr1 = 0) | |
|---|---|---|
| | Fa1 (+) | Fa1 (-) |
| **AV1520T** | 26 000 | 8 500 |





| | A | B |
|---|---|---|
| **RE 1521-2001-6002-6002L** | 353 | 252 |
| **GB 21003-45004-53004-61004-130005** | 353 | 252 |
| **RE 6001** | 490 | 321 |
| **GB 21002-53003-61003-150004** | 490 | 321 |

# AV2520H-HL















**C**

| | n1 x h = 1 500 000 Fa1 max (Fr1 = 0) | |
|---|---|---|
| | Fa1 (+) | Fa1 (-) |
| **AV2520H** | 66 000 | 50 000 |
| **AV2520HL** | 29 700 | 29 700 |












| | A | B |
|---|---|---|
| **RE 2521-3001-8002-8002L** | 409 | 257 |
| **GB 12012-12012L--26003-31003-40003 GB 85004-110004-205005-235005** | 409 | 257 |
| **RE 3511-4801** | 452 | 320 |
| **GB 16002-16002L-45003-130004** | 452 | 320 |
| **RE 6001** | 490 | 293 |
| **GB 21002-53003-61003-150004** | 490 | 293 |
| **RE 8001** | 490 | 385 |
| **GB 26002-85003** | 490 | 385 |
| **GB 12011-16001-31002-40002-45002-110003 GB 130003-205004-235004** | 368 | 610 |


# AV80












| | n1 x h = 1 500 000 Fa1 max (Fr1 = 0) | |
|---|---|---|
| | Fa1 (+) | Fa1 (-) |
| **AV80** | 31 700 | 31 700 |





| | A | B |
|---|---|---|
| **RE 811-1021-2522-3002-3512-80003-8003L** | 295 | 187.5 |
| **GB 12013-12013L-16003L-260004-31004-40004-85005-110005** | 295 | 187.5 |
| **RE 2521-3001-8002-8002L** | 409 | 298 |
| **GB 12012-12012L-26003-31003-40003-85004-110004-205003** | 409 | 298 |








| | n1 x h = 1 500 000 Fa1 max (Fr1 = 0) | |
|---|---|---|
| | Fa1 (+) | Fa1 (-) |
| **AV100** | 52 000 | - |








| | A | B |
|---|---|---|
| **RE 3511-4801** | 452 | 464.5 |
| **GB 16002-45003-130004** | 452 | 464.5 |
| **RE 6001-8001** | 490 | 437 |
| **GB 21002-26002-53003-61003-85003-150004** | 490 | 437 |
| **GB 12011-16001** | 610 | 550 |
| **GB 31002-40002-45002-110003-130003-150003-205004-235004** | 610 | 550 |


# AV150












| | n1 x h = 1 500 000 Fa1 max (Fr1 = 0) | |
|---|---|---|
| | Fa1 (+) | Fa1 (-) |
| **AV150** | 63 000 | - |



| | A | B |
|---|---|---|
| **RE 6001-8001** | 490 | 634 |
| **GB 21002-26002-53003-61003-150004** | 490 | 634 |
| **GB 12011-16001** | 610 | 626 |
| **GB 31002-40002-45002-110003-130003-15000-205004-235004** | 610 | 626 |









| | ø A | B | | F 01 | F 10 | F 11 | F 12 | F 13 | F 14 | F 05 | F 16 | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| **RE 111 - 112 - 113 - 114**<br>**RE 211 - 212 - 213 - 214**<br>**RE 241 - 242 - 243 - 244**<br>**RE 312 - 313 - 314**<br>**RE 512 - 513 - 514**<br>**RE 613 - 614**<br>**RE 813 - 814**<br>**RE 1023 - 1024**<br>**RE 1523 - 1524**<br>**RE 2004**<br>**RE 2524**<br>**RE 3004**<br>**RE 3514-4804**<br>**RE 6004L**<br>**RE 8005 - 8005L**<br>**GB 12015 - 12015L**<br>**GB 16005 - 16005L**<br>**CC30-CC120** | 186 | 109.5 | **Tb** (Nm) | 132 | 133 | 182 | 235 | 332 | 468 | 530 | 608 | ±5% |
| | | | **pb** (bar) | 23 | 29 | 34 | 26 | 30 | 36 | 39 | 42 | |
| | | | **p max** (bar) | 300 | | | | | | | | |
| | | | **n1 max** (RPM) | 700 | | | | | | | | |

| | ø A | B | | F 02 | F 20 | F 21 | F 22 | F 23 | F 24 | F 25 | F 26 | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| **RE 311-511**<br>**RE 611 - 612**<br>**RE 812-1022**<br>**RE 1522-2003**<br>**RE 2523-3003**<br>**RE 3513-4803**<br>**RE 6003 - 6003L**<br>**RE 6004 - 6004L**<br>**RE 8004 - 8004L**<br>**GB 12014 - 12014L**<br>**GB 16004 - 16004L**<br>**GB 21004 - 21005**<br>**GB 26005-31005**<br>**GB 40005-45005**<br>**GB 53005**<br>**CC350** | 244 | 118.5 | **Tb** (Nm) | 132 | 133 | 182 | 235 | 332 | 468 | 530 | 608 | ±5% |
| | | | **pb** (bar) | 23 | 29 | 34 | 26 | 30 | 36 | 39 | 42 | |
| | | | **p max** (bar) | 300 | | | | | | | | |
| | | | **n1 max** (RPM) | 700 | | | | | | | | |

# F5-F6












| | ø A | B | | F 501 | F 502 | F 503 | F504 | F505 | F506 | F 508 | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| **RE 111 - 112 - 113 - 114**<br>**RE 211 - 212 - 213 - 214**<br>**RE 241 - 242 - 243 - 244**<br>**RE 312 - 313 - 314**<br>**RE 512 - 513 - 514**<br>**RE 613 - 614**<br>**RE 813 - 814**<br>**RE 1023 - 1024**<br>**RE 1523 - 1524**<br>**RE 2004**<br>**RE 2524**<br>**RE 3004**<br>**RE 3514-4804**<br>**RE 6004L**<br>**RE 8005 - 8005L**<br>**GB 12015 - 12015L**<br>**GB 16005 - 16005L**<br>**CC30**<br>**CC120** | 186 | 115 | **Tb** (Nm) | 110 | 215 | 325 | 405 | 500 | 630 | 818 | ±5% |
| | | | **pb** (bar) | 10 | 20 | 30 | 38 | 28 | 35 | 33 | |
| | | | **p max** (bar) | 300 | | | | | | | |
| | | | **n1 max** (RPM) | 1500 (standard) | | | | | | | |
| | | | | 3500 (special) | | | | | | | |

| | ø A | B | | F 601 | F 602 | F 603 | F604 | F 605 | F 606 | F608 | F610 | F612 | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| **RE 311-511**<br>**RE 611 - 612**<br>**RE 812-1022**<br>**RE 1522-2003**<br>**RE 2523-3003**<br>**RE 3513-4803**<br>**RE 6003 - 6003L**<br>**RE 6004 - 6004L**<br>**RE 8004 - 8004L**<br>**GB 12014 - 12014L**<br>**GB 16004 - 16004L**<br>**GB 21004 - 21005**<br>**GB 26005-31005**<br>**GB 40005-45005**<br>**GB 53005**<br>**CC350** | 244 | 125 | **Tb** (Nm) | 110 | 215 | 325 | 405 | 500 | 630 | 818 | 1005 | 1150 | ±5% |
| | | | **pb** (bar) | 10 | 20 | 30 | 38 | 28 | 35 | 33 | 40 | 40 | |
| | | | **p max** (bar) | 300 | | | | | | | | | |
| | | | **n1 max** (RPM) | 1500 (standard) | | | | | | | | | |
| | | | | 3500 (special) | | | | | | | | | |














| | A | B | | F 813 | F 815 | F 818 | F 820 | F 823 | F 827 | F 830 | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| | 272.5 | - | | | | | | | | | |
| **RE 811** | 272.5 | - | | | | | | | | | |
| **RE 1021** | - | 314.5 | **Tb** (Nm) | 1271 | 1525 | 1780 | 2034 | 2288 | 2670 | 3051 | |
| **RE 1521-2001** | 272.5 | - | | | | | | | | | |
| **RE 2522-3002** | 272.5 | - | | | | | | | | | |
| **RE 3512-4801** | - | 314.5 | | | | | | | | | |
| **RE 6002-6002L** | 272.5 | - | | | | | | | | | |
| **RE 8003-8003L** | 272.5 | - | | | | | | | | | |
| **GB 12013-12013L** | 272.5 | - | **pb** (bar) | 54 | 65 | 76 | 58 | 65 | 76 | 87 | |
| **GB 16003L** | - | 314.5 | | | | | | | | | |
| **GB 16003** | - | 314.5 | | | | | | | | | |
| **GB 21003** | 272.5 | - | | | | | | | | | |
| **GB 26004** | 272.5 | - | | | | | | | | | ±5% |
| **GB 31004** | 272.5 | - | | | | | | | | | |
| **GB 40004** | - | 314.5 | **p max** (bar) | 300 | | | | | | | |
| **GB 45004** | - | 314.5 | | | | | | | | | |
| **GB 53004** | - | 314.5 | | | | | | | | | |
| **GB 61004** | 272.5 | - | | | | | | | | | |
| **GB 85005** | 272.5 | - | | | | | | | | | |
| **GB 110005** | - | 314.5 | | | | | | | | | |
| **GB 130005** | - | 314.5 | **n1 max** (RPM) | 1500 (standard) | | | | | | | |
| **GB 150005** | 272.5 | - | | | | | | | | | |
| **CC600** | 272.5 | - | | 3500 (special) | | | | | | | |
| **CC1000** | 292.5 | - | | | | | | | | | |
| | 292.5 | - | | | | | | | | | |


# F8-MU










| | A | B | | F 813 | F 815 | F 818 | F 820 | F 823 | F 827 | F 830 | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| | 253.5 | - | | | | | | | | | |
| **RE 811** | 253.5 | - | | | | | | | | | |
| **RE 1021** | - | 314.5 | **Tb** (Nm) | 1271 | 1525 | 1780 | 2034 | 2288 | 2670 | 3051 | |
| **RE 1521-2001** | 253.5 | - | | | | | | | | | |
| **RE 2522-3002** | 253.5 | - | | | | | | | | | |
| **RE 3512-4801** | - | 314.5 | | | | | | | | | |
| **RE 6002-6002L** | 253.5 | - | | | | | | | | | |
| **RE 8003-8003L** | 253.5 | - | | | | | | | | | |
| **GB 12013-12013L** | 253.5 | - | **pb** (bar) | 54 | 65 | 76 | 58 | 65 | 76 | 87 | |
| **GB 16003L** | - | 314.5 | | | | | | | | | |
| **GB 16003** | - | 314.5 | | | | | | | | | |
| **GB 21003** | 253.5 | - | | | | | | | | | |
| **GB 26004** | 253.5 | - | | | | | | | | | ±5% |
| **GB 31004** | 253.5 | - | | | | | | | | | |
| **GB 40004** | - | 314.5 | **p max** (bar) | 300 | | | | | | | |
| **GB 45004** | - | 314.5 | | | | | | | | | |
| **GB 53004** | - | 314.5 | | | | | | | | | |
| **GB 61004** | 253.5 | - | | | | | | | | | |
| **GB 85005** | 253.5 | - | | | | | | | | | |
| **GB 110005** | - | 314.5 | | | | | | | | | |
| **GB 130005** | - | 314.5 | **n1 max** (RPM) | 1500 (standard) | | | | | | | |
| **GB 150005** | 253.5 | - | | | | | | | | | |
| **CC600** | 253.5 | - | | 3500 (special) | | | | | | | |
| **CC1000** | 253.5 | - | | | | | | | | | |
| | 253.5 | - | | | | | | | | | |








## ST




## SAE "C"






## SAE "D"




| | | F 902 | F 903 | F 904 | F 905 | F 906 | F 908 | F 910 | F 912 | F 915 | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| **RE 311-511**<br>**RE 611 - 612**<br>**RE 812-1022**<br>**RE 1522-2003**<br>**RE 2523-3003**<br>**RE 3513-4803**<br>**RE 6003 - 6003L**<br>**RE 6004 - 6004L**<br>**RE 8004 - 8004L**<br>**GB 12014 - 12014L**<br>**GB 16004 - 16004L**<br>**GB 21004 - 21005**<br>**GB 26005-31005**<br>**GB 40005-45005**<br>**GB 53005**<br>**CC350** | **Tb** (Nm) | 244 | 317 | 439 | 488 | 683 | 854 | 976 | 1120 | 1465 | ±5% |
| | **pb** (bar) | 16 | 21 | 20 | 16 | 23 | 23 | 26 | 32 | 39 | |
| | **p max** (bar) | 300 | | | | | | | | | |
| | **n1 max** (RPM) | 1500 (standard) | | | | | | | | | |
| | | 3500 (special) | | | | | | | | | |


*Upon request, brakes up to size F912 can be equipped with freewheeling clutch.*





| | | 20 | 30 | 40 | 45 | |
|---|---|---|---|---|---|---|
| **RE 111 - 112 - 113 - 114**<br>**RE 211 - 212 - 213 - 214**<br>**RE 241 - 242 - 243 - 244**<br>**RE 312 - 313 - 314**<br>**RE 512 - 513 - 514**<br>**RE 613 - 614**<br>**RE 813 - 814**<br>**RE 1023 - 1024**<br>**RE 1523 - 1524**<br>**RE 2004**<br>**RE 2524**<br>**RE 3004**<br>**RE 3514-4804**<br>**RE 6004L**<br>**RE 8005 - 8005L**<br>**GB 12015 - 12015L**<br>**GB 16005 - 16005L** | **Tb**<br>**(Nm)** | 220 | 308 | 396 | 459 | +5% |
| | **pb**<br>**(bar)** | 24 | 24 | 24 | 26 | |
| | **p max**<br>**(bar)** | 150 | | | | |
| | **n1 max**<br>**(RPM)** | 700 | | | | |




| AXIAL PUMP | øA | øB | øC | øD | E | F | G | H | 1 | 2 | 3 | 4 |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| **M1 15-21** | ø 19 | 82.55 | M12 | 106.4 | — | — | 26 | — | 20300047 | 40000659 | — | AQ |
| **M2 24-50** | 16/32-13 | 101.6 | M14 | 146 | — | — | 20 | — | 40000635 | 40000657 | — | AZ |
| **M2 24-50** | 16/32-15 | 101.6 | M14 | 146 | — | — | 20 | — | 40000635 | 40000671 | — | BB |
| **M3 40-65** | 16/32-13 | 101.6 | M14 | 146 | — | — | 20 | — | 40000635 | 40000657 | — | AZ |
| **M3 40-65** | 16/32-15 | 101.6 | M14 | 146 | — | — | 20 | — | 40000635 | 40000671 | — | BB |

| DANFOSS | øA | øB | øC | øD | E | F | G | H | 1 | 2 | 3 | 4 |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| **OMM** | ø 16 | 63 | M8 | 80 | — | — | 14 | — | 40000698 | 40000694 | — | CE |
| **OMP 25-400** | ø 25 | 82.55 | M12 | 106.4 | — | — | 26 | — | 20300047 | 40000649 | — | AN |
| **OMP 25-400** | ø 25.4 | 82.55 | M12 | 106.4 | — | — | 26 | — | 20300047 | 40000645 | — | AI |
| **OMP 25-400** | 1" B6 | 82.55 | M12 | 106.4 | — | — | 26 | — | 20300047 | 40000648 | — | AM |
| **OMP 25-400** | ø 32 | 82.55 | M12 | 106.4 | — | — | 38 | — | 2511001 | 40000665 | — | AD |
| **OMR 50-375** | ø 25 | 82.55 | M12 | 106.4 | — | — | 26 | — | 20300047 | 40000649 | — | AN |
| **OMR 50-375** | ø 25.4 | 82.55 | M12 | 106.4 | — | — | 26 | — | 20300047 | 40000645 | — | AI |
| **OMR 50-375** | 1" B6 | 82.55 | M12 | 106.4 | — | — | 26 | — | 20300047 | 40000648 | — | AM |
| **OMR 50-375** | ø 32 | 82.55 | M12 | 106.4 | — | — | 38 | — | 02511001 | 40000665 | — | AD |
| **OMH 200-500** | ø 32 | 82.55 | M12 | 106.4 | — | — | 38 | — | 02511001 | 40000665 | — | AD |
| **OMH 200-500** | 12/24-14 | 82.55 | M12 | 106.4 | — | — | 38 | — | 02511001 | 40000672 | — | AE |
| **OMS 80-400** | ø 31.75 | 82.55 | M12 | 1064 | — | — | 38 | — | 02511001 | 40000664 | — | UL |
| **OMS 80-400** | ø 32 | 82.55 | M12 | 106.4 | — | — | 38 | — | 02511001 | 40000665 | — | AD |
| **OMS 80-400** | 12/24-14 | 82.55 | M12 | 106.4 | — | — | 38 | — | 02511001 | 40000672 | — | AE |
| **OMS 80-400 SPEC.** | 12/24-14 | 82.55 | M10 | 106.4 | | | 30 | | 40000681 | 40000672 | | CV |
| **OMSS 80-400** | 12/24-12 | 100 | M10 | — | — | 125 | 21 | — | 02511017 | 02241030 | — | TR |
| **OMTS 160-500** | 12/24-16 | 125 | M12 | 160 | | | 42 | | 02511081 | 02241082 | | UR |
| **OMT 160-500** | 12/24-17 | 125 | M12 | — | — | 160 | 86 | — | 40001833 | 40000674 | — | CI |
| **OMT 160-500** | ø 40 | 125 | M12 | — | — | 160 | 78 | — | 02511041 | 02241051 | — | TW |
| **OMT 160-500(US)** | 12/24-17 | 127 | M12 | | | 150 | 79.5 | | 02511166 | 40000674 | | DF |
| **OMV 315-800** | Ø50 | 160 | M16 | | | 200 | 140 | | 02511006 | 02591003 | | VM |
| **OMVS 315-800** | 10/20-16 | 125 | M12 | — | — | 160 | 42 | — | 02511085 | 02241086 | — | US |
| **MTM** | 12/24-17 | 127 | M12 | — | — | 162 | 29 | 38 | 02511108 | 40000674 | 02731111 | UY |

| EATON (CHAR-LYNN) | øA | øB | øC | øD | E | F | G | H | 1 | 2 | 3 | 4 |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| **SERIE 2000** | ø 25 | 82.55 | M12 | 106.4 | — | — | 26 | — | 20300047 | 40000649 | — | AN |
| **SERIE 2000** | Ø25 | 82.55 | M12 | | 106.4 | | 26 | | 40000680 | 40000649 | | BN |
| **SERIE 2000** | ø 25.4 | 82.55 | M12 | 106.4 | — | — | 26 | — | 20300047 | 40000645 | — | AI |
| **SERIE 2000** | ø 31.75 | 82.55 | M12 | 106.4 | — | — | 26 | — | 20300047 | 40000664 | — | AR |
| **SERIE 2000** | ø 32 | 82.55 | M12 | 106.4 | — | — | 38 | — | 2511001 | 40000665 | — | AD |
| **SERIE 2000** | 1"6B | 82.55 | M12 | 106,4 | — | — | 26 | — | 20300047 | 40000648 | — | AM |
| **SERIE 2000** | 12/24-14 | 82.55 | M12 | 106.4 | — | — | 26 | — | 20300047 | 40000672 | — | AU |
| **SERIE 4000** | 12/24-14 | 101.6 | M12 | | | 127 | 20 | | 40000635 | 40000672 | | EH |
| **SERIE 4000** | 12/24-17 | 127 | M12 | — | — | 162 | 29 | — | 02511108 | 40000674 | — | BH |
| **SERIE 6000** | 12/24-17 | 127 | M12 | — | — | 162 | 29 | 14 | 02511108 | 02971179 | 02731096 | CQ |
| **SERIE 6000** | ø 40 | 127 | M12 | — | — | 162 | 29 | 38 | 02511108 | 02241057 | 02731111 | TV |
| **SERIE 6000** | 8.5/17 | 127 | M12 | — | — | 162 | 29 | 38 | 02511108 | 02241076 | 02731111 | UH |

| HP HYDRAULIC | øA | øB | øC | øD | E | F | G | H | 1 | 2 | 3 | 4 |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| **M4PV21-28** | ø 25.4 | 101.6 | M14 | 146 | — | — | 20 | — | 40000635 | 40000645 | — | AV |
| **M4PV21-28** | 16/32-13 | 101.6 | M14 | 146 | — | — | 20 | — | 40000635 | 40000657 | — | AZ |
| **M4PV21-28** | 16/32-15 | 101.6 | M14 | 146 | — | — | 20 | — | 40000635 | 40000671 | — | BB |
| **M4MF 21-28** | ø 25.4 | 82.55 | M12 | 106.4 | — | — | 26 | — | 20300047 | 40000645 | — | AI |
| **M4MF 21-28** | 16/32- 1 3 | 82.55 | M12 | 106.4 | — | — | 26 | — | 20300047 | 40000657 | — | AP |
| **M4MF 21-28** | 16/32-15 | 82.55 | M12 | 106.4 | — | — | 26 | — | 20300047 | 40000671 | — | AT |
| **M4PV 34-65** | ø 25.4 | 101.6 | M14 | 146 | — | — | 20 | — | 40000635 | 40000645 | — | AV |
| **M4PV 34-65** | 16/32-13 | 101.6 | M14 | 146 | — | — | 20 | — | 40000635 | 40000657 | — | AZ |
| **M4PV 34-65** | 16/32-15 | 101.6 | M14 | 146 | — | — | 20 | — | 40000635 | 40000671 | — | BB |
| **M4MF 34-65** | ø 25.4 | 101.6 | M14 | 146 | — | — | 20 | — | 40000635 | 40000645 | — | AV |
| **M4MF 34-65** | 16/32-13 | 101.6 | M14 | 146 | — | — | 20 | — | 40000635 | 40000657 | — | AZ |
| **M4MF 34-65** | 16/32-15 | 101.6 | M14 | 146 | — | — | 20 | — | 40000635 | 40000671 | — | BB |
| **M4MV 34-65** | ø 25.4 | 101.6 | M14 | 146 | — | — | 20 | — | 40000635 | 40000645 | — | AV |
| **M4MV 34-65** | 16/32-13 | 101.6 | M14 | 146 | — | — | 20 | — | 40000635 | 40000657 | — | AZ |
| **M4MV 34-65** | 16/32-15 | 101.6 | M14 | 146 | — | — | 20 | — | 40000635 | 40000671 | — | BB |

| LINDE | øA | øB | øC | øD | E | F | G | H | 1 | 2 | 3 | 4 |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| **HMF 35** | 16/32-15 | 101.6 | M14 | 146 | — | — | 20 | — | 40000635 | 40000671 | — | BB |
| **HMF 50-75** | 16/32-21 | 127 | M16 | 181 | — | — | 34 | — | 02511108 | 40000654 | — | CF |
| **HMF 105** | 16/32-23 | 127 | M16 | 181 | — | — | 34 | — | 40001811 | 40000686 | — | CH |
| **HMF 135** | 16/32-27 | 152.4 | M20 | 228.5 | — | — | 35 | — | 40001844 | 02241123 | — | CZ |
| **HMR 135** | 16/32-27 | 152.4 | M20 | 228.5 | — | — | 35 | — | 40001844 | 02241123 | — | CZ |
| **BPV 70** | W35x2 | 127 | M12 | 162 | — | — | 25 | — | 02511108 | 40000670 | — | VK |

| M + S | øA | øB | øC | øD | E | F | G | H | 1 | 2 | 3 | 4 |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| **EPMM 8-50** | ø 14 | 63 | M8 | 80 | — | — | 14 | — | 40000698 | 40000658 | — | CD |
| **EPM M 8-50** | ø 16 | 63 | M8 | 80 | — | — | 14 | — | 40000698 | 40000694 | — | CE |
| **EPM 40-630** | ø 25 | 82.55 | M12 | 106.4 | — | — | 26 | — | 20300047 | 40000649 | — | AN |
| **EPM 40-630** | ø 25.4 | 82.55 | M12 | 106.4 | — | — | 26 | — | 20300047 | 40000645 | — | AI |
| **EPM 40-630** | 1" 6B | 82.55 | M12 | 106.4 | — | — | 26 | — | 20300047 | 40000648 | — | AM |
| **EPM 40-630** | 25/22-14 | 82.55 | M12 | 106.4 | — | — | 26 | — | 20300047 | 40000647 | — | AL |
| **EPM 40-630** | 12/24-14 | 82.55 | M12 | 106.4 | — | — | 38 | — | 2511001 | 40000672 | — | AE |
| **EPM 40-630** | ø 32 | 82.55 | M12 | 106.4 | — | — | 38 | — | 2511001 | 40000665 | — | AD |
| **EPRM 50-400** | ø 25 | 82.55 | M12 | 106.4 | — | — | 26 | — | 20300047 | 40000649 | — | AN |
| **EPRM 50-400** | ø 25.4 | 82.55 | M12 | 106.4 | — | — | 26 | — | 20300047 | 40000645 | — | AI |
| **EPRM 50-400** | 1" 6B | 82.55 | M12 | 106.4 | — | — | 26 | — | 20300047 | 40000648 | — | AM |
| **EPRM 50-400** | 25/22-14 | 82.55 | M12 | 106.4 | — | — | 26 | — | 20300047 | 40000647 | — | AL |
| **EPRM 50-400** | 12/24-14 | 82.55 | M12 | 106.4 | — | — | 38 | — | 2511001 | 40000672 | — | AE |
| **EPRM 50-400** | ø 32 | 82.55 | M12 | 106.4 | — | — | 38 | — | 2511001 | 40000665 | — | AD |
| **EPMS 80-400** | ø 31.75 | 82.55 | M12 | 106.4 | — | — | 38 | — | 2511001 | 40000664 | — | AG |
| **EPMS 80-400** | ø 32 | 82.55 | M12 | 106.4 | — | — | 38 | — | 2511001 | 40000665 | — | AD |
| **EPMS 80-400** | 12/24-17 | 82.55 | M12 | 106.4 | — | — | 38 | — | 2511001 | 40000674 | — | AF |
| **EPMT 160-500** | 12/24-17 | 125 | M12 | — | — | 160 | 86 | — | 40001833 | 40000674 | — | CI |
| **MTS 250** | 12/24-16 | 125 | M12 | 160 | | | 42 | | 02511081 | 02241082 | | UR |

| REXROTH | øA | øB | øC | øD | E | F | G | H | 1 | 2 | 3 | 4 |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| **A2FE 45** | W30x2 | 160 | M16 | 200 | | | 107.5 | | 02511250 | 40000669 | | ER |
| **A2FE 56** | W30x2 | 160 | M16 | 200 | | | 107.5 | | 02511250 | 40000669 | | ER |
| **A2FE 80** | W35x3 | 190 | M20 | 224 | | | 133 | | 02511281 | 40000670 | | ES |
| **A2FM 10-16** | ø 25 | 80 | M8 | — | — | 100 | 36.5 | — | 40001842 | 40000649 | — | CL |
| **A2FM 10-16** | W25x1.25 | 80 | M8 | — | — | 100 | 36.5 | — | 40001842 | 40000668 | — | CM |
| **A2FM 23-32** | ø 25 | 100 | M10 | — | — | 125 | 48 | — | 40000682 | 40000649 | — | BS |
| **A2FM 23-32** | W25X1.25 | 100 | M10 | — | — | 125 | 48 | — | 40000682 | 40000668 | — | BT |
| **A2FM 23-32** | W30x2 | 100 | M10 | — | — | 125 | 48 | — | 40000682 | 40000669 | — | BU |
| **A2FM 45-63** | W30x2 | 125 | M12 | — | — | 160 | 44 | — | 40000684 | 40000669 | — | CA |
| **A2FM 45-63** | W35x2 | 125 | M12 | — | — | 160 | 44 | — | 40000684 | 40000670 | — | CB |
| **A2FM 80-90** | W35x2 | 140 | M12 | — | — | 180 | 53 | — | 40001852 | 40000670 | — | CN |
| **A2FM 80-90** | W40x2 | 140 | M12 | — | — | 180 | 53 | — | 40001852 | 40001858 | — | CP |
| **A2FM 107** | W40x2 | 160 | M16 | — | — | 200 | 56.5 | — | 02511039 | 40001858 | — | TP |
| **A2FM 125** | W40x2 | 160 | M16 | — | — | 200 | 56.5 | — | 02511039 | 40001858 | — | TP |
| **A2FM 160** | W50x2 | 180 | M16 | — | — | 224 | 62 | — | 02511109 | 02591102 | — | CT |
| **A2FM 200** | W50x2 | 200 | M20 | — | — | 250 | 73 | — | 02511232 | 02591102 | — | DB |
| **A4FM 22-28** | 16/32-13 | 101.6 | M14 | 146 | — | — | 20 | — | 40000635 | 40000657 | — | AZ |
| **A4FM 22-28** | 16/32-15 | 101.6 | M14 | 146 | — | — | 20 | — | 40000635 | 40000671 | — | BB |
| **A4FM 40** | W30x2 | 101.6 | M14 | 146 | — | — | 20 | — | 40000635 | 40000669 | — | BA |
| **A4FM 56** | W30x2 | 127 | M16 | 181 | — | — | 34 | — | 40001811 | 40000669 | — | CG |
| **A10FM 23-28** | 16/32-13 | 101.6 | M14 | 146 | — | — | 20 | — | 40000635 | 40000657 | — | AZ |
| **A10FM 37-45** | 16/32-15 | 101.6 | M14 | 146 | — | — | 20 | — | 40000635 | 40000671 | — | BB |
| **A6VM 28** | W25x1.25 | 100 | M10 | — | — | 125 | 48 | — | 40000682 | 40000668 | — | BT |
| **A6VM 28** | W30x2 | 100 | M10 | — | — | 125 | 48 | — | 40000682 | 40000669 | — | BU |
| **A6VM 55** | W30x2 | 125 | M12 | — | — | 160 | 44 | — | 40000684 | 40000669 | — | CA |
| **A6VM 55** | W35x2 | 125 | M12 | — | — | 160 | 44 | — | 40000684 | 40000670 | — | CB |
| **A6VM 80** | W35x2 | 140 | M12 | — | — | 180 | 53 | — | 40001818 | 40000670 | — | CN |
| **A6VM 80** | W40x2 | 140 | M12 | — | — | 180 | 53 | — | 40001818 | 40001858 | — | CP |
| **A6VM 107** | W45x2 | 160 | M16 | — | — | 200 | 56.5 | — | 02511039 | 02591073 | — | VN |
| **A6VM 140** | W45x2 | 180 | M16 | — | — | 224 | 62 | — | 02511109 | 02591073 | — | VQ |
| **A6VM 160** | W45x2 | 180 | M16 | — | — | 224 | 62 | — | 02511109 | 02591073 | — | VQ |
| **A6VM 160** | W50x2 | 180 | M16 | — | — | 224 | 62 | — | 02511109 | 02591102 | — | CT |
| **A6VM 250** | W50x2 | 200 | M20 | — | — | 250 | 73 | — | 02511232 | 02591102 | — | DB |
| **AA6VM 55, 80** | 12/24-12 | 127 | M14 | — | — | 162 | 29 | — | 02511108 | 40000672 | — | BG |
| **AA6VM 107, 160** | 8/16-13 | 152.4 | M20 | — | — | 228.5 | 41 | — | 40001844 | 02241043 | — | UX |
| **AA2FM 10, 12, 16** | 16/32-13 | 101.6 | M14 | 146 | — | — | 20 | — | 40000635 | 40000657 | — | AZ |
| **AA2FM 23, 28, 32** | 12/24-12 | 127 | M14 | — | — | — | 29 | — | 02511108 | 40000672 | — | BG |
| **AA2FM 45, 56 ,63** | 12/24-12 | 127 | M14 | — | — | 162 | 29 | — | 02511108 | 40000672 | — | BG |
| **AA2FM 80, 90** | 12/24-12 | 127 | M14 | — | — | 162 | 29 | — | 02511108 | 40000672 | — | BG |
| **AA2FM 56 ,63** | 16/32-21 | 127 | M14 | — | — | 162 | 29 | — | 02511108 | 40000654 | — | BD |
| **AA2FM 80, 90** | 16/32-21 | 127 | M14 | — | — | 162 | 29 | — | 02511108 | 40000654 | — | BD |
| **AA2FM 107, 125** | 8/16-13 | 152.4 | M20 | — | — | 228.5 | 41 | — | 40001844 | 02241043 | — | UX |
| **AA2FM 160, 180** | 8/16-13 | 152.4 | M20 | — | — | 228.5 | 41 | — | 40001844 | 02241043 | — | UX |

| SAE STANDARD | øA | øB | øC | øD | E | F | G | H | 1 | 2 | 3 | 4 |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| **SAE A** | ø 25 | 82.55 | M12 | 106.4 | — | — | 26 | — | 20300047 | 40000649 | — | — |
| | ø 25.4 | 82.55 | M12 | 106.4 | — | — | 26 | — | 20300047 | 40000645 | — | — |
| | ø 31.75 | 82.55 | M12 | 106.4 | — | — | 26 | — | 20300047 | 40000664 | — | — |
| | ø 32 | 82.55 | M12 | 106.4 | — | — | 26 | — | 20300047 | 40000665 | — | — |
| | 1"6B | 82.55 | M12 | 106.4 | — | — | 26 | — | 20300047 | 40000648 | — | — |
| | 12/24-14 | 82.55 | M12 | 106.4 | — | — | 26 | — | 20300047 | 40000672 | — | — |
| **SAE B** | ø 25 | 101.6 | M14 | 146 | — | — | 20 | — | 40000635 | 40000649 | — | — |
| | ø 25.4 | 101.6 | M14 | 148 | — | — | 20 | — | 40000635 | 40000645 | — | — |
| | ø 31.75 | 101.6 | M14 | 146 | — | — | 20 | — | 40000635 | 40000664 | — | — |
| | ø 32 | 101.6 | M14 | 146 | — | — | 20 | — | 40000635 | 40000665 | — | — |
| | 1" 6B | 101.6 | M14 | 146 | — | — | 20 | — | 40000635 | 40000648 | — | — |
| | 12/24-14 | 101.6 | M14 | 146 | — | — | 20 | — | 40000635 | 40000672 | — | — |


| SAE STANDARD | øA | øB | øC | øD | E | F | G | H | 1 | 2 | 3 | 4 |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| MAGNETO | ø 25 | 82.55 | M12 | — | 106.4 | — | 26 | — | 40000680 | 40000649 | — | — |
| | ø 25.4 | 82.55 | M12 | — | 106.4 | — | 26 | — | 40000680 | 40000645 | — | — |
| | ø 31.75 | 82.55 | M12 | — | 106.4 | — | 26 | — | 40000680 | 40000664 | — | — |
| | ø 32 | 82.55 | M12 | — | 106.4 | — | 26 | — | 40000680 | 40000665 | — | — |
| | 1" 6B | 82.55 | M12 | — | 106.4 | — | 26 | — | 40000680 | 40000648 | — | — |
| | 12/24-14 | 82.55 | M12 | — | 106.4 | — | 26 | — | 40000680 | 40000672 | — | — |
| SAE C | ø 31.75 | 127 | M14 | — | — | 162 | 29 | — | 02511108 | 40000664 | — | — |
| | 12/24-14 | 127 | M14 | — | — | 162 | 29 | — | 02511108 | 40000672 | — | — |
| | 12/24-17 | 127 | M14 | — | — | 162 | 29 | — | 02511108 | 40000674 | — | — |


| SAMHYDRAULIK | øA | øB | øC | øD | E | F | G | H | 1 | 2 | 3 | 4 |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| BGM 13-50 | ø16 | 63 | M8 | 80 | — | — | 14 | — | 40000698 | 40000694 | — | CE |
| BG 40-400 | ø25 | 82.55 | M12 | 106.4 | — | — | 26 | — | 20300047 | 40000649 | — | AN |
| BG 40-400 | ø25.4 | 82.55 | M12 | 106.4 | — | — | 26 | — | 20300047 | 40000645 | — | AI |
| BG 40-400 | 1" 6B | 82.55 | M12 | 106.4 | — | — | 26 | — | 20300047 | 40000648 | — | AM |
| AGF 50-400 | ø25 | 82.55 | M12 | 106.4 | — | — | 26 | — | 20300047 | 40000649 | — | AN |
| ARF 50-400 | ø25 | 82.55 | M12 | 106.4 | — | — | 26 | — | 20300047 | 40000649 | — | AN |
| BR 50-400 | ø25 | 82.55 | M12 | 106.4 | — | — | 26 | — | 20300047 | 40000649 | — | AN |
| BR 50-400 | ø25.4 | 82.55 | M12 | 106.4 | — | — | 26 | — | 20300047 | 40000645 | — | AI |
| BR 50-400 | ø31.75 | 82.55 | M12 | 106.4 | — | — | 26 | — | 20300047 | 40000664 | — | AR |
| BR 50-400 | ø 32 | 82.55 | M12 | 106.4 | — | — | 38 | — | 20300047 | 40000665 | — | AS |
| BR 50-400 | 1" 6B | 82.55 | M12 | 106.4 | — | — | 26 | — | 20300047 | 40000648 | — | AM |
| H1C 12 | Ø20 | 80 | M8 | — | — | 100 | 36.5 | — | 02971201 | 02591008 | — | CS |
| H1C 30 | W25x1,25 | 100 | M10 | — | — | 125 | 31 | — | 02511221 | 40000668 | — | DW |
| H1C 55 | 12/24-17 | 127 | M14 | — | — | 162 | 29 | — | 40000653 | 40000672 | — | UT |
| H1C 55 | W30x2 | 125 | M12 | — | — | 160 | 44 | — | 40000684 | 40000669 | — | CA |
| H1C 55 | Ø30 | 125 | M12 | — | — | 160 | 44 | — | 40000684 | 02591040 | — | DU |
| H1C 75 | W35x2 | 140 | M12 | — | — | 180 | 53 | — | 40001818 | 40000670 | — | TQ |
| H1C 90-108 | W40x2 | 160 | M16 | — | — | 200 | 57 | — | 02511039 | 40001858 | — | TP |
| H1C 90-108 | Ø40 | 160 | M16 | — | — | 200 | 56.5 | — | 02511039 | 02241057 | — | EF |
| H1C 160 | W45x2 | 180 | M16 | — | — | 224 | 62 | — | 02511109 | 02591073 | — | VQ |
| HPR 80-400 | ø31.75 | 82.55 | M12 | 106.4 | — | — | 38 | — | 02511001 | 40000664 | — | AG |
| HPR 80-400 | ø 32 | 82.55 | M12 | 106.4 | — | — | 38 | — | 02511001 | 40000665 | — | AD |
| HPR 80-400 | 12/24-14 | 82.55 | M12 | 106.4 | — | — | 38 | — | 02511001 | 40000672 | — | AE |
| H2V 55 | W30x2 | 125 | M12 | — | — | 160 | 44 | — | 40000684 | 40000669 | — | CA |
| H2V 160 | W45x2 | 180 | M16 | — | — | 224 | 62 | — | 02511109 | 02591073 | — | VQ |

| SAUER | øA | øB | øC | øD | E | F | G | H | 1 | 2 | 3 | 4 |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| SMF2 033-070 | 16/32-21 | 127 | M12 | — | — | 162 | 29 | — | 02511108 | 40000654 | — | BD |
| SMF2 089 | 16/32-23 | 127 | M14 | — | — | 162 | 29 | — | 40000653 | 40000686 | — | BI |
| M25MF | 16/32-13 | 101.6 | M14 | 146 | — | — | 20 | — | 40000635 | 40000657 | — | AZ |
| M35MF | 16/32-13 | 101.6 | M14 | 146 | — | — | 20 | — | 40000635 | 40000657 | — | AZ |
| M35/M44 MF | 16/32-15 | 101.6 | M14 | 146 | — | — | 20 | — | 40000635 | 40000671 | — | BB |
| M44MF | 16/32-13 | 101.6 | M14 | 146 | — | — | 20 | — | 40000635 | 40000657 | — | AZ |
| M46MF | 16/32-13 | 101.6 | M14 | 146 | — | — | 20 | — | 40000635 | 40000657 | — | AZ |
| 51D 80 | W40x2 | 140 | M12 | — | — | 180 | 53 | — | 40001818 | 40001858 | — | CP |
| 51D 110 | W40x3 | 160 | M16 | — | — | 200 | 56.5 | — | 02511039 | 40001858 | — | TP |
| 51V 080 | 12/24-14 | 127 | M12 | — | — | 162 | 29 | — | 02511108 | 40000672 | — | BG |
| 51V 080 | 16/32-23 | 127 | M12 | — | — | 162 | 29 | — | 02511108 | 40000686 | — | BI |
| 51V 110/160A | 8/16-13 | 152.4 | M20 | — | — | 228.5 | 40 | — | 02511164 | 02631152 | — | 8X |
| 51V 160/A | 8/16-13 | 152.4 | M20 | — | — | 228.5 | 40 | — | 40001844 | 02241043 | — | UX |
| 51V 250 | 16/32-27 | 161.5 | M20 | — | — | 317.15 | 35 | — | 02511147 | 02241123 | — | EJ |
| 90M 030 | 16/32-13 | 101.6 | M14 | 146 | — | — | 20 | — | 40000635 | 40000657 | — | AZ |
| 90M 030 | 16/32-15 | 101.6 | M14 | 146 | — | — | 20 | — | 40000635 | 40000671 | — | BB |
| 90M 042 | 16/32-13 | 101.6 | M14 | 146 | — | — | 20 | — | 40000635 | 40000657 | — | AZ |
| 90M 042 | 16/32-15 | 101.6 | M14 | 146 | — | — | 20 | — | 40000635 | 40000671 | — | BB |
| 90M 055 | 16/32-21 | 127 | M12 | — | — | 162 | 29 | — | 02511108 | 40000654 | — | BD |
| 90M 075 | 16/32-21 | 127 | M12 | — | — | 162 | 29 | — | 02511108 | 40000654 | — | BD |
| 90M 100 | 16/32-23 | 127 | M12 | — | — | 162 | 29 | — | 02511108 | 40000686 | — | BI |
| 90M 100 | 8/16-13 | 127 | M12 | — | — | 162 | 29 | — | 02511108 | 02241013 | — | EV |
| 90M 130 | 8/16-Z13 | 152.4 | M20 | — | — | 228.5 | 40 | — | 40001844 | 022411043 | — | UX |

| VOAC | øA | øB | øC | øD | E | F | G | H | 1 | 2 | 3 | 4 |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| **F11-150 SAE** | 8/16-13 | 152.4 | M20 | 228.5 | — | — | 41 | — | 40001844 | 02241043 | — | UX |
| **F12-30 SAE** | ø25.4 | 101.6 | M14 | 146 | — | — | 20 | — | 40000635 | 40000645 | — | AV |
| **F12-30 SAE** | 16/32-13 | 101.6 | M14 | 146 | — | — | 20 | — | 40000635 | 40000657 | — | AZ |
| **F12-40 SAE** | ø31.75 | 127 | M12 | — | — | 162 | 29 | — | 02511108 | 40000664 | — | BF |
| **F12-40 SAE** | 12/24-14 | 127 | M12 | — | — | 162 | 29 | — | 02511108 | 40000672 | — | BG |
| **F12-60 SAE** | ø31.75 | 127 | M12 | — | — | 162 | 29 | — | 02511108 | 40000664 | — | BF |
| **F12-60 SAE** | 12/24-14 | 127 | M12 | — | — | 162 | 29 | — | 02511108 | 40000672 | — | BG |
| **F12-80 SAE** | 12/24-17 | 127 | M12 | — | — | 162 | 29 | — | 02511108 | 40000674 | — | BH |
| **V12-60 SAE** | 12/24-14 | 127 | M12 | — | — | 162 | 29 | — | 02511108 | 40000672 | — | BG |
| **V12-80 SAE** | 12/24-14 | 127 | M12 | — | — | 162 | 29 | — | 02511108 | 40000672 | — | BG |
| **F12-110 SAE** | 8/16-13 | 152.4 | M20 | 228.5 | — | — | 41 | — | 40001844 | 02241043 | — | UX |
| **V14-160 ISO** | W45x2 | 180 | M16 | 224 | — | — | 62 | — | 02511109 | 02591073 | — | VQ |
| **F12-80 ISO** | ø40 | 140 | M12 | — | — | 180 | 53 | 38 | 40001852 | 02241057 | 2731111 | UW |
| **TK** | 12/24-17 | 127 | M12 | — | — | 162 | 29 | 14 | 02511108 | 40000674 | 2731096 | CQ |
| **F12-30 ISO** | W30x2 | 100 | M10 | — | — | 125 | 48 | — | 40000682 | 40000669 | — | BU |
| **F12-40 MF-HI ISO** | W30x2 | 125 | M12 | 160 | — | — | 44 | — | 40000684 | 40000669 | — | CA |
| **F12-60 ISO** | W35x2 | 125 | M12 | — | — | 160 | 44 | — | 40000684 | 40000670 | — | CB |
| **F12-80 ISO** | W40x2 | 140 | M12 | — | — | 180 | 53 | — | 40001852 | 40001858 | — | CP |
| **F12-110 ISO** | W45x2 | 160 | M16 | 200 | — | — | 56.5 | — | 02511039 | 02591073 | — | VN |

| WHITE | øA | øB | øC | øD | E | F | G | H | 1 | 2 | 3 | 4 |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| **RS 03-24** | ø25 | 82.55 | M12 | 106.4 | — | — | 26 | — | 20300047 | 40000649 | — | AN |
| **RS 03-24** | ø25.4 | 82.55 | M12 | 106.4 | — | — | 26 | — | 20300047 | 40000645 | — | AI |
| **RS 03-24** | 1" 6B | 82.55 | M12 | 106.4 | — | — | 26 | — | 20300047 | 40000648 | — | AM |
| **HB 03-24** | ø25 | 82.55 | M12 | 106.4 | — | — | 26 | — | 20300047 | 40000649 | — | AN |
| **HB 03-24** | ø25.4 | 82.55 | M12 | 106.4 | — | — | 26 | — | 20300047 | 40000645 | — | AI |
| **HB 03-24** | ø31.75 | 82.55 | M12 | 106.4 | — | — | 26 | — | 20300047 | 40000664 | — | AR |
| **HB 03-24** | ø32 | 82.55 | M12 | 106.4 | — | — | 26 | — | 20300047 | 40000665 | — | AS |
| **HB 03-24** | 1" 6B | 82.55 | M12 | 106.4 | — | — | 26 | — | 20300047 | 40000648 | — | AM |
| **HB 03-24** | 12/24-14 | 82.55 | M12 | 106.4 | — | — | 26 | — | 20300047 | 40000672 | — | AU |
| **HB 03-24** | 16/32-13 | 82.55 | M12 | 106.4 | — | — | 26 | — | 20300047 | 40000657 | — | AP |
| **RE 07-45** | ø25 | 82.55 | M12 | — | 106.4 | — | 26 | — | 40000680 | 40000649 | — | BN |
| **RE 07-45** | ø25.4 | 82.55 | M12 | — | 106.4 | — | 26 | — | 40000680 | 40000645 | — | BL |
| **RE 07-45** | ø31.75 | 82.55 | M12 | — | 106.4 | — | 26 | — | 40000680 | 40000664 | — | BP |
| **RE 07-45** | ø32 | 82.55 | M12 | — | 106.4 | — | 26 | — | 40000680 | 40000665 | — | BQ |
| **RE 07-45** | 1" 6B | 82.55 | M12 | — | 106.4 | — | 26 | — | 40000680 | 40000648 | — | BM |
| **RE 07-45** | 12/24-14 | 82.55 | M12 | — | 106.4 | — | 26 | — | 40000680 | 40000672 | — | BR |
| **DR 12-46** | ø25 | 82.55 | M12 | — | 106.4 | — | 26 | — | 40000680 | 40000649 | — | BN |
| **DR 12-46** | ø25.4 | 82.55 | M12 | — | 106.4 | — | 26 | — | 40000680 | 40000645 | — | BL |
| **DR 12-46** | ø31.75 | 82.55 | M12 | — | 106.4 | — | 26 | — | 40000680 | 40000664 | — | BP |
| **DR 12-46** | ø32 | 82.55 | M12 | — | 106.4 | — | 26 | — | 40000680 | 40000665 | — | BQ |
| **DR 12-46** | 1" 6B | 82.55 | M12 | — | 106.4 | — | 26 | — | 40000680 | 40000648 | — | BM |
| **DR 12-46** | 12/24-14 | 82.55 | M12 | — | 106.4 | — | 26 | — | 40000680 | 40000672 | — | BR |







| INTERMOT | øA | øB | C | øD1 | E | F | G | H | 1 | 2 | 3 | 4 |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| **G34/A-AA** | ø30 | 82.55 | M12 | 106.4 | — | — | 10.5 | 26 | 02511082 | 2591040 | 02511018 | UM |
| **G 100** | W40x2 | 125 | M8 | 175 | — | — | 44 | — | 02511282 | 40001858 | — | EQ |
| **G 100** | A40x36 | 125 | M8 | 175 | — | — | 44 | — | 02511282 | 40001858 | — | ET |
| **IAM 195** | 6x26x32 | 172 | M10 | 190 | — | — | 39.5 | — | 02511170 | 40001829 | — | DE |

| SAI | øA | øB | C | øD1 | E | F | G | H | 1 | 2 | 3 | 4 |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| **BD2** | W40x2 | 150 | M12 | 250 | — | — | 38 | — | 02511070 | 02591049 | — | UE |
| **BV2** | W40x2 | 150 | M12 | 250 | — | — | 38 | — | 02511070 | 02591049 | — | UE |
| **GM05 40-200** | 28x34x6 | 125 | M10 | 160 | — | — | 40 | — | 02511045 | 40000646 | — | TZ |
| **GM05 40-200** | 35x2x16 | 125 | M10 | 160 | — | — | 40 | — | 02511045 | 40000670 | — | TT |
| **GM05 40-200** | ø30 | 125 | M10 | 160 | — | — | 40 | — | 02511045 | 02591040 | — | TM |
| **GM1 100-320** | 28x34x6 | 175 | M12 | 210 | — | — | 29 | — | 02971466 | 40000646 | — | VB |
| **GM1 100-320** | 35x2x16 | 175 | M12 | 210 | — | — | 29 | — | 02971466 | 40000670 | — | TJ |
| **GM2 200-630** | 40x3x12 | 150 | M12 | 250 | — | — | 38 | — | 02511070 | 02591044 | — | UB |
| **GM2 200-630** | 36x40 | 150 | M12 | 250 | — | — | 38 | — | 02511070 | 02591063 | — | VA |
| **GM3** | W40x3 | 265 | M18 | 310 | | | 43.5 | | 02511151 | 02591044 | | DS |

| CALZONI | øA | øB | øC | øD1 | E | F | G | H | 1 | 2 | 3 | 4 |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| **MR 250-300** | 42x48x8 | 175 | M10 | 232 | — | — | 92 | — | 02511030 | 02591016 | — | FA |







| IEC | øA | øB | C | øD | E | F | G | H | 1 | 2 | 3 | 4 |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| **63 B5** | ø11 | 95 | M8 | 115 | — | — | 20 | — | 02511000 | 02591001 | — | TL |
| **71 B5** | ø14 | 110 | M8 | 130 | — | — | 16 | — | 40000690 | 40000658 | — | CC |
| **80 B5** | ø19 | 130 | M10 | 165 | — | — | 16 | — | 40000683 | 40000659 | — | BV |
| **90 B5** | ø24 | 130 | M10 | 165 | — | — | 16 | — | 40000683 | 40000660 | — | BZ |
| **100 B5** ø24 | ø24 | 180 | M12 | 215 | — | — | 16 | — | 02511018 | 40000660 | — | UÀ |
| **100/112 B5** | ø28 | 180 | M12 | 215 | — | — | 24.5 | — | 02511018 | 40000661 | — | AH |
| **112 B5** | ø38 | 180 | M12 | 215 | — | — | 24 | 38 | 02511018 | 02241029 | 02731111 | UU |
| **132 B5** | ø38 | 230 | M12 | 265 | — | — | 49 | — | 02511016 | — | — | AG |
| **132 B14** | ø38 | 130 | ø 11 | 165 | — | — | 69 | — | 02511076 | — | — | UF |
| **200 B5** | ø55 | 300 | M18 | 350 | — | — | 130 | — | 02511067 | 02241066 | — | TX |

| NEMA | øA | øB | C | øD | E | F | G | H | 1 | 2 | 3 | 4 |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| **56 H** | ø15.88 (0.625) | 114.3 (4.500) | Ø10 (0.394) | 149.2 (5.874) | — | — | 53 (2.087) | — | 02511122 | 02591085 | — | VX |
| **143-145 TC** | ø22.22 (0.875) | 114.3 (4.500) | Ø10 (0.394) | 149.2 (5.874) | — | — | 53 (2.087) | — | 02511122 | 02591084 | — | VZ |
| **182-184 TC** | ø28.57 (1.125) | 215.9 (8.500) | Ø14 (0.551) | 206 (8.110) | — | — | 38 (1.496) | — | 02511073 | 02591045 | — | UC |
| **213-215 TC** | ø34.925 (1.375) | 215.9 (8.500) | Ø14 (0.551) | 184.5 (7.264) | — | — | 55.5 (2.185) | — | 02511037 | 02241048 | — | VT |
| **254-256 TC** | ø41.275 (1.625) | 215.9 (8.500) | Ø14 (0.551) | 150 (5.906) | — | — | 70 (2.756) | — | 02511141 | 02241131 | — | VJ |
| **284-286 TC** | ø47.625 (1.875) | 266.7 (10.500) | Ø14 (0.551) | 228.6 (9.000) | — | — | 86 (3.386) | — | 02511142 | 02241132 | — | CR |


mm (inch)




| VARVEL | øA | øB | øC | øD | E | F | G | H | 1 | 2 | 3 | 4 |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| **FRS 50 FL** | Ø24 | 110 | M10 | 130 | — | — | 16 | — | 02511022 | 40000660 | — | VR |
| **FRS 60 FL** | Ø25 | 115 | M10 | 150 | — | — | 16 | — | 02511095 | 40000649 | — | UZ |
| **FRS 70 FL** | Ø28 | 130 | M12 | 165 | — | — | 13.5 | — | 40000644 | 40000650 | — | TI |
| **FRS 85 FL** | Ø32 | 130 | M12 | 165 | — | — | 13.5 | — | 40000644 | 40000655 | — | TG |
| **FRS 130 PC** | Ø48 | 180 | Ø13 | 215 | — | | 20 | — | 40001804 | 40000652 | — | VI |

| STM | øA | øB | øC | øD | E | F | G | H | 1 | 2 | 3 | 4 |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| **RMI 50 FL** | Ø24 | 110 | M10 | 130 | — | — | 16 | — | 02511022 | 40000660 | — | VR |
| **RMI 60 FL** | Ø25 | 115 | M10 | 150 | — | — | 16 | — | 02511095 | 40000649 | — | UZ |
| **RMI 70 FL** | Ø28 | 130 | M12 | 165 | — | — | 13.5 | — | 40000644 | 40000650 | — | TI |
| **RMI 85 FL** | Ø32 | 130 | M12 | 165 | — | — | 13.5 | — | 40000644 | 40000655 | — | TG |
| **RMI 110 F1** | Ø42 | 130 | M10 | 165 | — | — | 17 | — | 40001810 | 40001809 | — | VH |
| **RMI 130 P** | Ø48 | 180 | Ø13 | 215 | — | — | 20 | — | 40001804 | 40000652 | — | VI |
| **RMI 150 P** | Ø55 | 180 | Ø13 | 215 | — | — | 20 | — | 40001804 | 40001808 | — | EN |

| MOTOVARIO | øA | øB | øC | øD | E | F | G | H | 1 | 2 | 3 | 4 |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| **NMRV 110** | Ø42 | 180 | M12 | 215 | — | — | 24.5 | — | 02511018 | 40001890 | — | FE |
| **NMRV 90** | Ø35 | 130 | M10 | 165 | — | — | 17 | 4 | 40001810 | 02591038 | — | UQ |




| CALZONI | A | øB | øC | øD1 | E | F | G | H | 1 | 2 | 3 | 4 |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| **MR700** | 8x52x60 | 220 | M12 | 290 | — | — | 55.5 | — | 02511229 | 02591156 | — | 4J |

| DANFOSS | A | øB | øC | øD | E | F | G | H | 1 | 2 | 3 | 4 |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| **OMV** | 16/32-16 | 160 | M16 | — | — | 200 | 73 | — | 025110102 | 025910102 | — | 5U |
| **OMT 160-500** | 12/24-17 | 125 | M12 | — | — | 160 | 66.5 | — | 025110117 | 02591123 | — | 3I |
| **OMT 160-500** | Ø40 | 125 | M12 | — | — | 160 | 66.5 | — | 025110117 | 025910109 | — | 7W |

| EATON | A | øB | øC | øD | E | F | G | H | 1 | 2 | 3 | 4 |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| **SERIE 6000** | 12/24-17 | 127 | M14 | — | — | 162 | 29 | — | 02511192 | 02591123 | — | 3Q |
| **SERIE 6000** | 12/24-14 | 127 | M12 | — | — | 162 | 37 | — | 02511192 | 02591163 | — | 2G |

| INTERMOT | A | øB | øC | øD1 | E | F | G | H | 1 | 2 | 3 | 4 |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| **IAM H3 400-700** | 36x42x8 | 230 | M14 | 254 | — | — | 43 | — | 02511197 | 02591128 | — | 8I |
| **IAM300** | 8x32x38 | 190 | M12 | 210 | — | — | 38.5 | — | 02511248 | 02591166 | — | 4N |

| LINDE | A | øB | øC | øD | E | F | G | H | 1 | 2 | 3 | 4 |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| **HMF 135** | 16/32-27 | 152.4 | M20 | 228.5 | — | — | 35 | — | 02511164 | 02631166 | — | 3Z |
| **HMR 135** | 16/32-27 | 152.4 | M20 | 228.5 | — | — | 35 | — | 02511164 | 02631166 | — | 3Z |
| **HMF 105** | 16/32-23 | 127 | M16 | 181 | — | — | 34 | — | 02511192 | 02631203 | — | 3H |

| M+S | A | øB | øC | øD | E | F | G | H | 1 | 2 | 3 | 4 |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| **EPMT 160-500** | 12/24-17 | 125 | M12 | — | — | 160 | 66.5 | — | 025110117 | 02591123 | — | 3I |
| **EPMT 160-500** | Ø40 | 125 | M12 | — | — | 160 | 66.5 | — | 025110117 | 025910109 | — | 7W |

| REXROTH | A | øB | øC | øD | E | F | G | H | 1 | 2 | 3 | 4 |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| **A2FM 107** | W40x2 | 160 | M16 | — | — | 200 | 51.5 | — | 02511230 | 02631193 | — | 3U |
| **A2FM 160** | W50x2 | 180 | M16 | — | — | 224 | 62 | — | 02511163 | 02631150 | — | 3T |
| **A2FM 200** | W50x2 | 200 | M20 | — | — | 250 | 73 | — | 02511165 | 02631150 | — | 4B |
| **A6VM 107** | W45x2 | 160 | M16 | — | — | 200 | 53 | — | 02511167 | 02631160 | — | 9N |
| **A6VM 160** | W45x2 | 180 | M16 | — | — | 224 | 62 | — | 02511163 | 02631151 | — | 9Q |
| **A6VM 160** | W50x2 | 180 | M16 | — | — | 224 | 62 | — | 02511163 | 02631150 | — | 3T |
| **A6VM 250** | W50x2 | 200 | M 20 | — | — | 250 | 73 | — | 02511165 | 02631150 | — | 4B |
| **A6VM 355** | W60x2 | 280 | M16 | — | — | 320 | 84.5 | — | 02511261 | 02631210 | — | 5L |
| **AA6VM 107, 160** | 8/16-13 | 152.4 | M20 | — | — | 228.5 | 40 | — | 02511164 | 02631152 | — | 8X |
| **AA2FM 107, 125** | 8/16-13 | 152.4 | M20 | — | — | 228.5 | 40 | — | 02511164 | 02631152 | — | 8X |
| **AA2FM 160, 180** | 8/16-13 | 152.4 | M20 | — | — | 228.5 | 40 | — | 02511164 | 02631152 | — | 8X |

| SAI | A | øB | øC | øD | E | F | G | H | 1 | 2 | 3 | 4 |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| GM1 | 28x34x6 | 175 | M12 | 210 | — | — | 29 | — | 02511263 | 02591176 | — | 6B |
| GM2 | 36x40 | 150 | M12 | 250 | — | — | 38 | — | 02511209 | 02591141 | — | 9A |
| GM2 | W40x3 | 150 | M12 | 250 | — | — | 38 | — | 02511209 | 02591170 | — | 8B |
| GM3 | W40x3 | 265 | M18 | 310 | — | — | 43.5 | — | 02511151 | 02591044 | — | 4S |

| SAMHYDRAULIK | A | øB | øC | øD | E | F | G | H | 1 | 2 | 3 | 4 |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| H1C 160 M | W45x2 | 180 | M16 | — | — | 224 | 62 | — | 02511039 | 02631151 | — | 9Q |
| H1C 226 M | W50x2 | 200 | M20 | — | — | 250 | 73 | — | 02511165 | 02631150 | — | 4B |
| H2V 160 M | W45x2 | 1801 | M16 | — | — | 224 | 62 | — | 02511163 | 02631151 | — | 9Q |

| SAUER | A | øB | øC | øD | E | F | G | H | 1 | 2 | 3 | 4 |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| 51V250 | 16/32-27 | 165.1 | M20 | — | — | 317.5 | 38 | — | 02511201 | 02631166 | — | 5J |
| 90M 130 | 8/16-13 | 152.4 | M 20 | — | — | 228.5 | 40 | — | 02511164 | 02631152 | — | 8X |

| VOAC | A | øB | øC | øD | E | F | G | H | 1 | 2 | 3 | 4 |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| F11-50 CETOP | W45x2 | 200 | M20 | 250 | — | — | 73 | — | 02511165 | 02631151 | — | 5P |
| F11-150 SAE | 8/16-13 | 152.4 | M20 | — | — | 228.5 | 40 | — | 02511164 | 02631152 | — | 8X |
| F12-110 SAE | 8/16-13 | 152.4 | M20 | — | — | 228.5 | 40 | — | 02511164 | 02631152 | — | 8X |
| V14-160 ISO | W45x2 | 180 | M16 | — | — | 224 | 62 | — | 02511163 | 02631151 | — | 9Q |
| F12-110 ISO | W45x2 | 160 | M116 | — | — | 200 | 53 | — | 02511167 | 02631160 | — | 9N |


## Direct motor adapters available for:


| KAWASAKY | Shaft |
|---|---|
| KAWASAKI HMC 80 | 6/12-14 |
| KAWASAKI HMC/HMB/HPC 125 | 6/12-20 |
| KAWASAKI HMB 200 | 6/12 -14 |
| KAWASAKI HMB 200 | W85x3 |


| SAI | Shaft |
|---|---|
| GM3 | W40x3 |
| GM3 | 8x46x54 |
| GM4/5 | 8x56x65 |
| GM4/5 | W65x3 |
| GM6 | N80x3 |


| POCLAIN | Shaft |
|---|---|
| MS08/MSE08 | W70x3 |
| MS18/MSE18 | W90x3 |
| MS18/MSE18 | NF E-22 141 (m2.5 z34) |
| MS50 | NF E-22 141 (m3.75 z33) |
| MS02/MSE02 | W50x2 |

| POCLAIN HYDROBASE | Shaft |
|---|---|
| MS18/MSE18 | NF E-22 141 (m2.5 z34) |
| MS35 | NF E-22 141 (m2.5 z34) |
| MS50 | NF E-22 141 (m2.5 z38) |











| | VERSION | A | ø B | ø C | ø D | ø E | ø F | ø G | ø H | L |
|---|---|---|---|---|---|---|---|---|---|---|
| **RE 110-210** | N-P-T-TR | A40x36 DIN 5482 | 42 | 42 | 52 | 75 | 135 | 98 | M12x1.5 (4) | 90° |
| **RE 240** | T-TR | A58x53 DIN 5482 | 60 | 60 | — | 95 | 165 | 145 | 12.5 (12) | 30° |
| **RE 310-510-610** | N-P-T-TL | A58x53 DIN 5482 | 60 | 60 | — | 95 | 165 | 145 | 12.5 (12) | 30° |
| **RE 810** | N-P-T | A70x64 DIN 5482 | 72 | 72 | — | 125 | 208 | 175 | 19(12) | 30° |
| **RE 1020-1520-2000** | T-H | A80x74 DIN 5482 | 85 | 85 | — | 125 | 208 | 175 | 19(12) | 30° |
| **RE 2520-3000** | H | A100x94 DIN 5482 | 105 | 105 | — | 170 | 254 | 212 | 21 (12) | 30° |
| **RE 3510-4800** | H | N 120x3 DIN 5480 | 124 | 130 | — | 160 | 298 | 250 | 21 (12) | 30° |
| **RE 6000** | H | N 120x3 DIN 5480 | 120 | 120 | — | 200 | 308 | 260 | 25 (12) | 30° |
| **RE 6000** | H6 | N 150x5 DIN 5480 | 151 | 151 | — | 240 | 385 | 320 | 32 (12) | 30° |
| **RE 8000** | H | N 150x5 DIN 5480 | 151 | 151 | — | 240 | 385 | 320 | 32 (12) | 30° |
| **GB 12010-16000** | H | N 170x5 DIN 5480 | 170 | 175 | — | 250 | 450 | 400 | 28 (18) | 20° |
| **GB 21000** | H | N220x5 DIN 5480 | 220 | 230 | — | 315 | 500 | 450 | 32 (18) | 20° |


| | VERSION | M | N | P | R | S | T | CODE |
|---|---|---|---|---|---|---|---|---|
| **RE 110-210** | N-P-T-TR | 63 | 12 | 10 | 7.5 | 13.5 | 20.5 | 40000618 |
| **RE 240** | T-TR | 74 | 14 | 10 | 8 | — | 24 | 02571148 |
| **RE 310-510-610** | N-P-T-TL | 74 | 14 | 10 | 8 | — | 24 | 02571148 |
| **RE 810** | N-P-T | 90 | 21 | 14 | 10 | — | 29 | 40001838 |
| **RE 1020-1520-2000** | T-H | 90.5 | 21 | 14 | 9.5 | — | 30.5 | 40001848 |
| **RE 2520-3000** | H | 110 | 24 | 20 | 12 | — | 37 | 40001851 |
| **RE 3510-4800** | H | 150 | 30 | 20 | 28 | — | 29 | 02571068 |
| **RE 6000** | H | 125 | 31 | 19 | 11 | — | 30 | 02571054 |
| **RE 6000** | H6 | 150 | 35 | 25 | 11 | — | 33 | 02571063 |
| **RE 8000** | H | 150 | 35 | 25 | 11 | — | 33 | 02571063 |
| **GB 12010-16000** | H | 163 | 42 | 48 | 14 | — | 42 | 02571048 |
| **GB 21000** | H | 205 | 47 | 70 | 16 | — | 51.5 | 02571049 |

On demand for different size

# BS - EP

## BS









| | VERSION | A | ø B | ø C | ø D | ø E | F | G | H | L | CODE |
|---|---|---|---|---|---|---|---|---|---|---|---|
| **RE 110-210** | N-P | A40x36 DIN 5482 | 42 | 42 | — | 60 | 55 | — | 7 | 20.5 | 40000608 |
| **RE 110-210** | T-TR | A40x36 DIN 5482 | 42 | 42 | 51 | 60 | 67.5 | 5 | 12 | 20.5 | 40000617 |
| **RE 240** | T-TR | A58x53 DIN 5482 | 60 | 60 | 72 | 94 | 85 | 16 | 23 | 25 | 40000642 |
| **RE 310-510-610** | N-P-T-TL | A58x53 DIN 5482 | 60 | 60 | 72 | 94 | 85 | 16 | 23 | 25 | 40000642 |
| **RE 810** | N-P-T | A70x64 DIN 5482 | 72 | 72 | — | 95 | 90 | — | 10 | 29 | 40001836 |
| **RE 1020-1520-2000** | T-H | A80x74 DIN 5482 | 85 | 85 | — | 108 | 90.5 | — | 10.5 | 30.5 | 40001847 |
| **RE 2520-3000** | H | A100x94 DIN 5482 | 105 | 105 | — | 136 | 110 | — | 12 | 33 | 40001850 |
| **RE 3510-4800** | H | N120x3x9H DIN 5480 | 124 | 130 | — | 175 | 150 | — | 28 | 29 | 02631054 |
| **RE 6000** | H | N120x3x9H DIN 5480 | 120 | 120 | — | 160 | 124.5 | — | 10.5 | 31 | 02631082 |
| **RE 6000** | H6 | N150x5x9H DIN 5480 | 151 | 151 | — | 220 | 150 | — | 11 | 33 | 02631092 |
| **RE 8000** | H | N150x5x9H DIN 5480 | 151 | 151 | — | 220 | 150 | — | 11 | 33 | 02631092 |
| **GB 12010-16000** | H | N170x5x9H DIN 5480 | 170 | 175 | — | 235 | 163 | — | 14 | 42 | 02631026 |
| **GB 21000** | H | N220x5x9H DIN 5480 | 220 | 230 | — | 295 | 205 | — | 16 | 51.5 | 02631027 |

On demand for different size

## EP







| | VERSION | ø A | ø B | ø C | D | E | F | CODE |
|---|---|---|---|---|---|---|---|---|
| **RE 110-210** | N-P | 35 | 42 | 50 | 9.5 | 4.5 | — | 40000609 |
| **RE 110-210** | T-TR | 35 | 52 | 50 | 14 | — | 6.8 | 40000614 |
| **RE 240** | T-TR | 50 | 60 | 70 | 13 | 5.5 | — | 40000613 |
| **RE 310-510** | N-P | 50 | 60 | 70 | 13 | 5.5 | — | 40000613 |
| **RE 310-510-610** | T-TL | 50 | 72 | — | 18 | — | 9 | 40000616 |
| **RE 810** | N-P-T | 62 | 72 | 80 | 18 | 9.25 | — | 40001832 |
| **RE 1020-1520-2000** | T-H | 70 | 85 | 98 | 19.5 | 8.5 | — | 40001840 |
| **RE 2520-3000** | H | 85 | 105 | 114 | 20 | 10 | — | 40001849 |
| **RE 3510-4800** | H | 90 | 130 | — | 26 | — | 14 | 02551072 |
| **RE 6000** | H | 100 | 120 | 135 | 21 | 9.5 | — | 02551060 |
| **RE 6000** | H6 | 125 | 151 | 170 | 25 | 9 | — | 02551077 |
| **RE 8000** | H | 125 | 151 | 170 | 25 | 9 | — | 02551077 |
| **GB 12010-16000** | H | 150 | 175 | 198 | 31 | 13.5 | — | 02551044 |
| **GB 21000** | H | 200 | 230 | 260 | 43.5 | 19 | — | 02551046 |

On demand for different size


# P




| | M | z | x | ø de | ø dp | bu | H | S5 | ø S6 | Code |
|---|---|---|---|---|---|---|---|---|---|---|
| RE 110<br>RE 210 | 4 | 20 | 0 | 88 | 80 | 42 | 55 | 20.5 | ø 42 H7 | 40100882 |
| | 4 | 24 | 0 | 104 | 96 | 45 | 57 | 20.5 | ø 42 H7 | 40100889 |
| | 4.5 | 14 | 0.5 | 76.5 | 63 | 55 | 55 | 20.5 | ø 42 H7 | 40100835 |
| | 4.5 | 16 | 0 | 81 | 72 | 70 | 80 | 20.5 | ø 42 H7 | 40100802 |
| | 4.5 | 16 | 0 | 81 | 72 | 45 | 55 | 20.5 | ø 42 H7 | 40100926 |
| | 4.5 | 16 | 0 | 81 | 72 | 45 | 75 | 20.5 | ø 42 H7 | 40100943 |
| | 5 | 14 | 0 | 80 | 70 | 60 | 60 | 20.5 | ø 42 H7 | 40100810 |
| | 5 | 14 | 0 | 80 | 70 | 70 | 80 | 20.5 | ø 42 H7 | 40100812 |
| | 5 | 14 | 0.5 | 85 | 70 | 65 | 65 | 20.5 | ø 42 H7 | 40100811 |
| | 5 | 14 | 0.5 | 85 | 70 | 60 | 90 | 20.5 | ø 42 H7 | 40100885 |
| | 5 | 14 | 0.5 | 85 | 70 | 55 | 78 | 20.5 | ø 42 H7 | 40100888 |
| | 5 | 14 | 0.5 | 84.5 | 70 | 47 | 55 | 20.5 | ø 42 H7 | 02571014 |
| | 5 | 16 | 0 | 90 | 80 | 70 | 80 | 20.5 | ø 42 H7 | 40100813 |
| | 5 | 17 | 0 | 95 | 85 | 70 | 80 | 20.5 | ø 42 H7 | 40100815 |
| | 5 | 18 | 0 | 100 | 90 | 70 | 80 | 20.5 | ø 42 H7 | 40100814 |
| | 5 | 20 | 0 | 109.5 | 100 | 45 | 74 | 20.5 | ø 42 H7 | 40100918 |
| | 5 | 22 | 0 | 120 | 110 | 50 | 76 | 20.5 | ø 42 H7 | 40100934 |
| | 6 | 12 | 0.5 | 89 | 72 | 70 | 80 | 20.5 | ø 42 H7 | 40100825 |
| | 6 | 13 | 0 | 90 | 78 | 60 | 85 | 20.5 | ø 42 H7 | 40100914 |
| | 6 | 13 | 0 | 90 | 78 | 50 | 80 | 20.5 | ø 42 H7 | 40100915 |
| | 6 | 13 | 0.5 | 95 | 78 | 61 | 97 | 20.5 | ø 42 H7 | 40100823 |
| | 6 | 14 | 0 | 96 | 84 | 50 | 60 | 20.5 | ø 42 H7 | 40100824 |
| | 6 | 14 | 0 | 96 | 84 | 70 | 80 | 20.5 | ø 42 H7 | 40100826 |
| | 6 | 14 | 0 | 96 | 84 | 70 | 100 | 20.5 | ø 42 H7 | 40100827 |
| | 6 | 15 | 0 | 102 | 90 | 60 | 82.5 | 20.5 | ø 42 H7 | 40100935 |
| | 6 | 15 | 0.5 | 108 | 90 | 40 | 73 | 20.5 | ø 42 H7 | 40100819 |
| | 6 | 17 | 0 | 114 | 102 | 80 | 110 | 20.5 | ø 42 H7 | 40100913 |
| | 6 | 18 | 0 | 120 | 108 | 70 | 80 | 20.5 | ø 42 H7 | 40100830 |
| | 6 | 20 | 0 | 132 | 120 | 60 | 85 | 20.5 | ø 42 H7 | 40100894 |
| | 8 | 12 | 0.5 | 118 | 96 | 60 | 65 | 20.5 | ø 42 H7 | 40100841 |
| | 8 | 14 | 0.5 | 136 | 112 | 80 | 110 | 20.5 | ø 42 H7 | 40100912 |
| | 8 | 15 | 0 | 136 | 120 | 70 | 80 | 20.5 | ø 42 H7 | 40100846 |

On demand for different size

# P





| | M | z | x | ø de | ø dp | bu | H | S5 | ø S6 | Code |
|---|---|---|---|---|---|---|---|---|---|---|
| RE 240<br>RE 310<br>RE 510<br>RE 610 | 5 | 21 | 0 | 115 | 105 | 60 | 76 | 25 | ø 60 H7 | 40100883 |
| | 5 | 22 | 0 | 120 | 110 | 50 | 76 | 25 | ø 60 H7 | 02571051 |
| | 6 | 14 | 0.5 | 101.5 | 90 | 65 | 78 | 25 | ø 60 H7 | 40100923 |
| | 6 | 16 | 0 | 108 | 96 | 70 | 80 | 25 | ø 60 H7 | 40100867 |
| | 6 | 18 | 0 | 120 | 108 | 70 | 80 | 25 | ø 60 H7 | 40100831 |
| | 6 | 20 | 0 | 132 | 120 | 75 | 80 | 25 | ø 60 H7 | 40100873 |
| | 6 | 24 | 0 | 156 | 144 | 68 | 77.5 | 25 | ø 60 H7 | 40100808 |
| | 7 | 14 | 0 | 112 | 98 | 78.5 | 78.5 | 25 | ø 60 H7 | 40100874 |
| | 8 | 12 | 0.5 | 120 | 96 | 80 | 100 | 25 | ø 60 H7 | 40100818 |
| | 8 | 13 | 0 | 120 | 104 | 68 | 78 | 25 | ø 60 H7 | 02571111 |
| | 8 | 14 | 0 | 128 | 112 | 65 | 68 | 25 | ø 60 H7 | 40100844 |
| | 8 | 14 | 0 | 128 | 112 | 75 | 85 | 25 | ø 60 H7 | 40100845 |
| | 8 | 15 | 0 | 136 | 120 | 75 | 85 | 25 | ø 60 H7 | 40100848 |
| | 8 | 16 | 0 | 144 | 128 | 75 | 85 | 25 | ø 60 H7 | 40100849 |
| | 8 | 16 | 0.5 | 152 | 128 | 75 | 85 | 25 | ø 60 H7 | 40100893 |
| | 8 | 17 | 0 | 149 | 136 | 78 | 110 | 25 | ø 60 H7 | 40100937 |
| | 8 | 18 | 0 | 160 | 144 | 76 | 78 | 25 | ø 60 H7 | 40100850 |
| | 8 | 18 | 0 | 160 | 144 | 96 | 98 | 25 | ø 60 H7 | 40100898 |
| | 8 | 19 | 0 | 174 | 152 | 85 | 102 | 25 | ø 60 H7 | 02571055 |
| | 10 | 11 | 0.5 | 136 | 110 | 80 | 96.5 | 25 | ø 60 H7 | 40100807 |
| | 10 | 11 | 0.5 | 136 | 110 | 100 | 120.5 | 25 | ø 60 H7 | 40100938 |
| | 10 | 12 | 0.5 | 149 | 120 | 80 | 96.5 | 25 | ø 60 H7 | 40100820 |
| | 10 | 12 | 0.35 | 143 | 120 | 80 | 100 | 25 | ø 60 H7 | 40100838 |
| | 10 | 13 | 0 | 150 | 130 | 80 | 80 | 25 | ø 60 H7 | 40100929 |
| | 10 | 13 | 0 | 150 | 130 | 90 | 105 | 25 | ø 60 H7 | 40100942 |
| | 10 | 14 | 0 | 160 | 140 | 80 | 80 | 25 | ø 60 H7 | 40100866 |
| | 10 | 14 | 0 | 160 | 140 | 90 | 105 | 25 | ø 60 H7 | 40100868 |
| | 10 | 15 | 0 | 170 | 150 | 80 | 80 | 25 | ø 60 H7 | 40100839 |

| | M | z | x | ø de | ø dp | bu | H | S5 | ø S6 | Code |
|---|---|---|---|---|---|---|---|---|---|---|
| RE 810 | 8 | 15 | 0.3 | 140.8 | 120 | 67 | 96 | 29 | ø 72 H7 | 02571235 |
| | 8 | 17 | 0 | 152 | 136 | 80 | 99 | 29 | ø 72 H7 | 02571121 |
| | 8 | 20 | 0 | 176 | 160 | 115 | 124 | 29 | ø 72 H7 | 025710101 |
| | 8 | 23 | 0.5 | 208 | 184 | 86 | 131 | 29 | ø 72 H7 | 40100853 |
| | 10 | 11 | 0.5 | 136 | 110 | 80 | 90 | 29 | ø 72 H7 | 40100857 |
| | 10 | 12 | 0.5 | 150 | 120 | 90 | 90 | 29 | ø 72 H7 | 02571110 |
| | 10 | 13 | 0.5 | 160 | 130 | 90 | 90 | 29 | ø 72 H7 | 40100852 |
| | 10 | 13 | 0.5 | 160 | 130 | 99 | 99 | 29 | ø 72 H7 | 02571000 |
| | 10 | 14 | 0 | 160 | 140 | 99 | 99 | 29 | ø 72 H7 | 02571024 |
| | 10 | 14 | 0.5 | 170 | 140 | 67 | 96 | 29 | ø 72 H7 | 02571236 |
| | 10 | 15 | 0 | 170 | 150 | 98 | 112 | 29 | ø 72 H7 | 02571037 |
| | 10 | 15 | 0.5 | 180 | 150 | 98 | 112 | 29 | ø 72 H7 | 02571183 |
| | 10 | 17 | 0.48 | 198 | 170 | 80 | 90 | 29 | ø 72 H7 | 02571013 |
| | 12 | 11 | 0.5 | 167 | 132 | 90 | 120 | 29 | ø 72 H7 | 40100821 |
| | 12 | 13 | 0.5 | 192 | 156 | 118 | 126 | 29 | ø 72 H7 | 40100840 |
| | 12 | 13 | 0.3 | 187 | 156 | 75 | 90 | 29 | ø 72 H7 | 02571019 |
| | 12 | 14 | 0.5 | 199 | 168 | 90 | 100 | 29 | ø 72 H7 | 02571101 |
| | 14 | 12 | 0.3 | 205 | 168 | 80 | 110 | 29 | ø 72 H7 | 02571102 |

On demand for different size

# P





| | M | z | x | ø de | ø dp | bu | H | S5 | ø S6 | Code |
|---|---|---|---|---|---|---|---|---|---|---|
| **RE 1020 RE 1520 RE 2000** | 10 | 14 | 0.32 | 162.4 | 140 | 103 | 116 | 30.5 | ø 85 H7 | 02571001 |
| | 10 | 15 | 0 | 170 | 150 | 90 | 115 | 30.5 | ø 85 H7 | 40100940 |
| | 10 | 18 | 0 | 198 | 180 | 87 | 116 | 30.5 | ø 85 H7 | 40100822 |
| | 12 | 11 | 0.5 | 167 | 132 | 100 | 120 | 30.5 | ø 85 H7 | 02571136 |
| | 12 | 13 | 0.5 | 192 | 156 | 120 | 120 | 30.5 | ø 85 H7 | 02571173 |
| | 12 | 14 | 0.5 | 199 | 168 | 90.5 | 90.5 | 30.5 | ø 85 H7 | 40100856 |
| | 12 | 16 | 0 | 214 | 192 | 90 | 95 | 30.5 | ø 85 H7 | 40100850 |
| | 14 | 11 | 0.5 | 192.36 | 154 | 97 | 97 | 30.5 | ø 85 H7 | 025710113 |
| | 14 | 12 | 0.5 | 210 | 168 | 135 | 135 | 30.5 | ø 85 H7 | 02571182 |
| | 14 | 14 | 0.5 | 233.8 | 196 | 105 | 105 | 30.5 | ø 85 H7 | 02571103 |
| | 16 | 10 | 0.5 | 208 | 160 | 115 | 115 | 30.5 | ø 85 H7 | 025710126 |
| | 16 | 19 | 0 | 336 | 304 | 120 | 120 | 30.5 | ø 85 H7 | 02571006 |
| | 18 | 10 | 0.5 | 234 | 180 | 157 | 157 | 30.5 | ø 85 H7 | 02571152 |
| | 18 | 13 | 0.5 | 288 | 234 | 100 | 100 | 30.5 | ø 85 H7 | 02571208 |
| | 20 | 14 | 0.5 | 340 | 280 | 125 | 140 | 30.5 | ø 85 H7 | 025710102 |

| | M | z | x | ø de | ø dp | bu | H | S5 | ø S6 | Code |
|---|---|---|---|---|---|---|---|---|---|---|
| **RE 2520 RE 3000** | 12 | 16 | 0.5 | 228.4 | 192 | 120 | 130 | 34 | ø 105 H7 | 02571044 |
| | 14 | 14 | 0 | 224 | 196 | 110 | 110 | 34 | ø 105 H7 | 02571030 |
| | 14 | 15 | 0.5 | 250.6 | 210 | 110 | 120 | 34 | ø 105 H7 | 02571221 |
| | 16 | 13 | 0.5 | 256 | 208 | 145 | 145 | 34 | ø 105 H7 | 02571201 |
| | 16 | 17 | 0.5 | 320 | 272 | 140 | 150 | 34 | ø 105 H7 | 02571159 |
| | 16 | 19 | 0.5 | 352 | 304 | 140 | 150 | 34 | ø 105 H7 | 02571167 |
| | 20 | 12 | 0.5 | 299 | 240 | 150 | 150 | 34 | ø 105 H7 | 02571176 |

On demand for different size










# VE

## VE





| A | ø B | C | D | Capacity [Liters] | CODE |
|---|---|---|---|---|---|
| 230 | 80 | 55 | 1/4" GAS (4) | 1.0 | 40000712 |
| 330 | 130 | 85 | 1/4" GAS (4) | 3.8 | 40000711 |
| 330 | 160 | 85 | 1/4" GAS (4) | 5.5 | 40000710 |
| 510 | 150 | 85 | 1/4" GAS (4) | 7.7 | 40000704 |
| 690 | 150 | 85 | 1/4" GAS (4) | 10.7 | 40000706 |

On demand for different size

| | | | |
|---|---|---|---|
|  |  |  |  |
| **B3** | **V5** | **V6** | **B8** |
|  |  |  |  |
| **B6** | **B7** | **B5** | **V1** |
|  | | | |
| **V3** | | | |


**pos. 0 = STANDARD**





**pos. 1= 90°** **pos. 3= 270°**

**pos. 2 = 180°**

## N



B5



V1



V3

**110÷1520**

## T - TL - TR



B5



V1



V3

**110÷810**

## H



B5



V1



V3

**1520÷130000**

## F



B5



V1



V3

**110÷810**

## F



B5



V1



V3


**1020÷1520**


## P



B3


V5


V6



B8



B6



B7


**110÷810**

## RAS


POS. 0



POS. 1



POS. 2



POS. 3


**110÷510**

## RAD










POS. 0





POS. 1





POS. 2





POS. 3




**110÷510**










| [Liters] | B3 | V5 | V6 | B6 | B7 | B8 | B5 | V1 | V3 |
|---|---|---|---|---|---|---|---|---|---|
| |  |  |  |  |  |  |  |  |  |
| **RE 111** | 0.7 | 1.4 | 1.4 | 0.7 | 1.4 | 1.4 | 0.4 | 0.8 | 0.8 |
| **RE 112** | 0.9 | 1.8 | 1.8 | 0.9 | 1.8 | 1.8 | 0.5 | 1 | 1 |
| **RE 113** | 1.1 | 2.2 | 2.2 | 1.1 | 2.2 | 2.2 | 0.7 | 1.4 | 1.4 |
| **RE 114** | 1.3 | 2.6 | 2.6 | 1.3 | 2.6 | 2.6 | 0.8 | 1.6 | 1.6 |
| **RE 211** | 0.8 | 1.6 | 1.6 | 0.8 | 1.6 | 1.6 | 0.5 | 1 | 1 |
| **RE 212** | 1 | 2 | 2 | 1 | 2 | 2 | 0.6 | 1.2 | 1.2 |
| **RE 213** | 1.2 | 2.4 | 2.4 | 1.2 | 2.4 | 2.4 | 0.7 | 1.4 | 1.4 |
| **RE 214** | 1.4 | 2.8 | 2.8 | 1.4 | 2.8 | 2.8 | 0.9 | 1.8 | 1.8 |
| **RE 241** | 0.8 | 1.6 | 1.6 | 0.8 | 1.6 | 1.6 | 0.5 | 1 | 1 |
| **RE 242** | 1 | 2 | 2 | 1 | 2 | 2 | 0.6 | 1.2 | 1.2 |
| **RE 243** | 1.2 | 2.4 | 2.4 | 1.2 | 2.4 | 2.4 | 0.7 | 1.4 | 1.4 |
| **RE 244** | 1.4 | 2.8 | 2.8 | 1.4 | 2.8 | 2.8 | 0.9 | 1.8 | 1.8 |
| **RE 311** | 1.4 | 2.8 | 2.8 | 1.4 | 2.8 | 2.8 | 1 | 2 | 2 |
| **RE 312** | 1.6 | 3.2 | 3.2 | 1.6 | 3.2 | 3.2 | 1.2 | 2.4 | 2.4 |
| **RE 313** | 1.7 | 3.4 | 3.4 | 1.7 | 3.4 | 3.4 | 1.3 | 2.6 | 2.6 |
| **RE 314** | 1.8 | 3.6 | 3.6 | 1.8 | 3.6 | 3.6 | 1.4 | 2.8 | 2.8 |
| **RE 511** | 1.5 | 3 | 3 | 1.5 | 3 | 3 | 1.1 | 2.2 | 2.2 |
| **RE 512** | 1.7 | 3.4 | 3.4 | 1.7 | 3.4 | 3.4 | 1.3 | 2.6 | 2.6 |
| **RE 513** | 1.8 | 3.6 | 3.6 | 1.8 | 3.6 | 3.6 | 1.5 | 3 | 3 |
| **RE 514** | 1.9 | 3.8 | 3.8 | 1.9 | 3.8 | 3.8 | 1.6 | 3.2 | 3.2 |
| **RE 611** | 1.6 | 3.2 | 3.2 | 1.6 | 3.2 | 3.2 | 1.2 | 2.4 | 2.4 |
| **RE 612** | 1.8 | 3.6 | 3.6 | 1.8 | 3.6 | 3.6 | 1.4 | 2.8 | 2.8 |
| **RE 613** | 1.9 | 3.8 | 3.8 | 1.9 | 3.8 | 3.8 | 1.6 | 3.2 | 3.2 |
| **RE 614** | 20 | 40 | 40 | 20 | 40 | 40 | 1.7 | 3.4 | 3.4 |
| **RE 811** | 1.8 | 3.6 | 3.6 | 1.8 | 3.6 | 3.6 | 1.5 | 3 | 3 |
| **RE 812** | 2 | 4 | 4 | 2 | 4 | 4 | 1.7 | 3.4 | 3.4 |
| **RE 813** | 2.2 | 4.4 | 4.4 | 2.2 | 4.4 | 4.4 | 1.9 | 3.8 | 3.8 |
| **RE 814** | 2.3 | 4.6 | 4.6 | 2.3 | 4.6 | 4.6 | 2 | 4 | 4 |
| **RE 1021** | 2.4 | 4.8 | 4.8 | 2.4 | 4.8 | 4.8 | 2.1 | 4.2 | 4.2 |
| **RE 1022** | 2.6 | 5.2 | 5.2 | 2.6 | 5.2 | 5.2 | 2.3 | 4.6 | 4.6 |
| **RE 1023** | 2.7 | 5.4 | 5.4 | 2.7 | 5.4 | 5.4 | 2.4 | 4.8 | 4.8 |
| **RE 1024** | 2.9 | 5.8 | 5.8 | 2.9 | 5.8 | 5.8 | 2.6 | 5.2 | 5.2 |




| [Liters] | B5 | V1 | V3 |
|---|---|---|---|
| |  |  |  |
| **RE 1521** | 2.7 | 5.4 | 5.4 |
| **RE 1522** | 3 | 6 | 6 |
| **RE 1523** | 3.2 | 6.4 | 6.4 |
| **RE 1524** | 3.4 | 6.8 | 6.8 |
| **RE 2001** | 2.7 | 5.4 | 5.4 |
| **RE 2002** | 3 | 6 | 6 |
| **RE 2003** | 3.3 | 6.6 | 6.6 |
| **RE 2004** | 3.4 | 6.8 | 6.8 |
| **RE 2002L** | 3 | 6 | 6 |
| **RE 2003L** | 3.1 | 6.2 | 6.2 |
| **RE 2004L** | 3.2 | 6.4 | 6.4 |
| **RE 2521** | 3.9 | 7.7 | 7.7 |
| **RE 2522** | 4.5 | 9 | 9 |
| **RE 2523** | 4.7 | 9.4 | 9.4 |
| **RE 2524** | 5 | 9.9 | 9.9 |
| **RE 3001** | 3.8 | 7.6 | 7.6 |
| **RE 3002** | 4.6 | 9.1 | 9.1 |
| **RE 3003** | 4.8 | 9.5 | 9.5 |
| **RE 3004** | 5 | 10 | 10 |
| **RE 3511** | 4.9 | 9.8 | 9.8 |
| **RE 3512** | 5.7 | 11.4 | 11.4 |
| **RE 3513** | 6 | 12 | 12 |
| **RE 3514** | 6.2 | 12.4 | 12.4 |
| **RE 4801** | 4.7 | 9.4 | 9.4 |
| **RE 4802** | 6.8 | 13.6 | 13.6 |
| **RE 4803** | 7.2 | 14.4 | 14.4 |
| **RE 4804** | 7.4 | 14.8 | 14.8 |
| **RE 6001** | 7.5 | 15 | 15 |
| **RE 6002** | 8.5 | 17 | 17 |
| **RE 6003** | 9 | 18 | 18 |
| **RE 6004** | 9.3 | 18.6 | 18.6 |
| **RE 6002L** | 8.5 | 17 | 17 |
| **RE 6003L** | 9 | 18 | 18 |




| [Liters] | B5 | V1 | V3 |
|---|---|---|---|
| |  |  |  |
| **RE 6004L** | 9.2 | 18.4 | 18.4 |
| **RE 8001** | 8.3 | 16.6 | 16.6 |
| **RE 8002** | 10.2 | 20.4 | 20.4 |
| **RE 8003** | 11 | 22 | 22 |
| **RE 8004** | 11.5 | 23 | 23 |
| **RE 8005** | 11.7 | 23.4 | 23.4 |
| **RE 8002L** | 10.2 | 20.4 | 20.4 |
| **RE 8003L** | 10.8 | 21.6 | 21.6 |
| **RE 8004L** | 11.4 | 22.8 | 22.8 |
| **RE 8005L** | 11.6 | 23.2 | 23.2 |
| **GB 12011** | 13.5 | 27 | 27 |
| **GB 12012** | 15.5 | 31 | 31 |
| **GB 12013** | 16.5 | 33 | 33 |
| **GB 12014** | 16.8 | 33.6 | 33.6 |
| **GB 12015** | 17 | 34 | 34 |
| **GB 12012L** | 15.5 | 31 | 31 |
| **GB 12013L** | 16.3 | 32.6 | 32.6 |
| **GB 12014L** | 16.7 | 33.4 | 33.4 |
| **GB 12015L** | 17 | 34 | 34 |
| **GB 16001** | 14.5 | 29 | 29 |
| **GB 16002** | 18 | 36 | 36 |
| **GB 16003** | 19.2 | 38.4 | 38.4 |
| **GB 16004** | 19.6 | 39.2 | 39.2 |
| **GB 16005** | 19.8 | 39.6 | 39.6 |
| **GB 16002L** | 17 | 34 | 34 |
| **GB 16003L** | 18 | 36 | 36 |
| **GB 16004L** | 18.5 | 37 | 37 |
| **GB 16005L** | 18.7 | 37.4 | 37.4 |
| **GB 21001** | 20 | 40 | 40 |
| **GB 21002** | 23.5 | 47 | 47 |
| **GB 21003** | 24.5 | 49 | 49 |
| **GB 21004** | 25 | 50 | 50 |
| **GB 21005** | 25.5 | 51 | 51 |


| [Liters] | B5 | V1 | V3 |
|---|---|---|---|
| |  |  |  |
| **GB 26001** | 20 | 40 | 40 |
| **GB 26002** | 25.5 | 51 | 51 |
| **GB 26003** | 27.5 | 55 | 55 |
| **GB 26004** | 28.5 | 57 | 57 |
| **GB 26005** | 29 | 58 | 58 |
| **GB 31001** | 38 | 76 | 76 |
| **GB 31002** | 46.5 | 93 | 93 |
| **GB 31003** | 48.5 | 97 | 97 |
| **GB 31004** | 49.5 | 99 | 99 |
| **GB 31005** | 50 | 100 | 100 |
| **GB 40001** | 41 | 82 | 82 |
| **GB 40002** | 49 | 98 | 98 |
| **GB 40003** | 51 | 102 | 102 |
| **GB 40004** | 52 | 104 | 104 |
| **GB 40005** | 52 | 104 | 104 |
| **GB 45001** | 41 | 82 | 82 |
| **GB 45002** | 50 | 100 | 100 |
| **GB 45003** | 53.5 | 107 | 107 |
| **GB 45004** | 55 | 110 | 110 |
| **GB 45005** | 55.5 | 111 | 111 |
| **GB 53001** | 70 | 140 | 140 |
| **GB 53002** | 80 | 160 | 160 |
| **GB 53003** | 85 | 170 | 170 |
| **GB 53004** | 86.5 | 173 | 173 |
| **GB 53005** | 87 | 174 | 174 |
| **GB 61001** | 70 | 140 | 140 |
| **GB 61002** | 80 | 160 | 160 |
| **GB 61003** | 85 | 170 | 170 |
| **GB 61004** | 86.5 | 173 | 173 |
| **GB 61005** | 87 | 174 | 174 |
| **GB 85001** | 75 | 150 | 150 |
| **GB 85002** | 87.5 | 175 | 175 |
| **GB 85003** | 93 | 186 | 186 |








| [Liters] | B5 | V1 | V3 |
|---|---|---|---|
| |  |  |  |
| **GB 85004** | 95 | 190 | 190 |
| **GB 85005** | 95.5 | 191 | 191 |
| **GB 110001** | 145 | 290 | 290 |
| **GB 110002** | 170 | 340 | 340 |
| **GB 110003** | 180 | 360 | 360 |
| **GB 110004** | 183 | 366 | 366 |
| **GB 110005** | 185 | 370 | 370 |
| **GB 130001** | 144 | 288 | 288 |
| **GB 130002** | 172 | 344 | 344 |
| **GB 130003** | 181 | 362 | 362 |
| **GB 130004** | 185 | 370 | 370 |
| **GB 130005** | 186 | 372 | 372 |
| **GB 150001** | 143 | 286 | 286 |
| **GB 150002** | 172 | 344 | 344 |
| **GB 150003** | 185 | 370 | 370 |
| **GB 150004** | 187 | 374 | 374 |
| **GB 150005** | 188 | 376 | 376 |
| **GB 205001** | 255 | 510 | 510 |
| **GB 205002** | 300 | 600 | 600 |
| **GB 205003** | 318 | 636 | 636 |
| **GB 205004** | 326 | 652 | 652 |
| **GB 205005** | 329 | 658 | 658 |
| **GB 235001** | 255 | 510 | 510 |
| **GB 235002** | 300 | 600 | 600 |
| **GB 235003** | 335 | 670 | 670 |
| **GB 235004** | 345 | 690 | 690 |
| **GB 235005** | 247 | 494 | 494 |








| [Liters] | B3-1 | V5 | V6 | B6-1 | B7 | B8 | B5-1 | V1 | V3 |
|---|---|---|---|---|---|---|---|---|---|
|  |  |  |  |  |  |  |  |  |  |
| **RA 112** | 1.5 | 3 | 3 | 1.5 | 3 | 3 | 1.2 | 2.4 | 2.4 |
| **RA 113** | 1.7 | 3.4 | 3.4 | 1.7 | 3.4 | 3.4 | 1.3 | 2.6 | 2.6 |
| **RA 114** | 1.9 | 3.8 | 3.8 | 1.9 | 3.8 | 3.8 | 1.5 | 3 | 3 |
| **RA 212** | 1.6 | 3.2 | 3.2 | 1.6 | 3.2 | 3.2 | 1.3 | 2.6 | 2.6 |
| **RA 213** | 1.8 | 3.6 | 3.6 | 1.8 | 3.6 | 3.6 | 1.4 | 2.8 | 2.8 |
| **RA 214** | 2 | 4 | 4 | 2 | 4 | 4 | 1.5 | 3 | 3 |
| **RA 242** | 1.6 | 3.2 | 3.2 | 1.6 | 3.2 | 3.2 | 1.3 | 2.6 | 2.6 |
| **RA 243** | 1.8 | 3.6 | 3.6 | 1.8 | 3.6 | 3.6 | 1.4 | 2.8 | 2.8 |
| **RA 244** | 2 | 4 | 4 | 2 | 4 | 4 | 1.5 | 3 | 3 |
| **RA 312** | 2.5 | 5 | 5 | 2.5 | 5 | 5 | 2.1 | 4.2 | 4.2 |
| **RA 313** | 2.4 | 4.8 | 4.8 | 2.4 | 4.8 | 4.8 | 2 | 4 | 4 |
| **RA 314** | 2.5 | 5 | 5 | 2.5 | 5 | 5 | 2.1 | 4.2 | 4.2 |
| **RA 512** | 2.6 | 5.2 | 5.2 | 2.6 | 5.2 | 5.2 | 2.2 | 4.4 | 4.4 |
| **RA 513** | 2.5 | 5 | 5 | 2.5 | 5 | 5 | 2.1 | 4.2 | 4.2 |
| **RA 514** | 2.6 | 5.2 | 5.2 | 2.6 | 5.2 | 5.2 | 2.3 | 4.6 | 4.6 |
| **RA 612** | 2.7 | 5.4 | 5.4 | 2.7 | 5.4 | 5.4 | 2.3 | 4.6 | 4.6 |
| **RA 613** | 2.9 | 5.8 | 5.8 | 2.9 | 5.8 | 5.8 | 2.5 | 5 | 5 |
| **RA 614** | 2.7 | 5.4 | 5.4 | 2.7 | 5.4 | 5.4 | 2.4 | 4.8 | 4.8 |
| **RA 812** | 3.8 | 7.6 | 7.6 | 3.8 | 7.6 | 7.6 | 3.5 | 7 | 7 |
| **RA 813** | 3.1 | 6.2 | 6.2 | 3.1 | 6.2 | 6.2 | 2.8 | 5.6 | 5.6 |
| **RA 814** | 3 | 6 | 6 | 3 | 6 | 6 | 2.7 | 5.4 | 5.4 |
| **RA 1022** | 4.4 | 8.8 | 8.8 | 4.4 | 8.8 | 8.8 | 4.1 | 8.2 | 8.2 |
| **RA 1023** | 3.7 | 7.4 | 7.4 | 3.7 | 7.4 | 7.4 | 3.4 | 6.8 | 6.8 |
| **RA 1024** | 3.5 | 7 | 7 | 3.5 | 7 | 7 | 3.2 | 6.4 | 6.4 |



| [Liters] | B5-1 | V1 | V3 |
|---|---|---|---|
| |  |  |  |
| **RA 1522** | 5.7 | 11.4 | 11.4 |
| **RA 1523** | 4.1 | 8.2 | 8.2 |
| **RA 1524** | 4 | 8 | 8 |
| **RA 2002** | 5.7 | 11.4 | 11.4 |
| **RA 2003** | 4.1 | 8.2 | 8.2 |
| **RA 2004** | 4.1 | 8.2 | 8.2 |
| **RA 2003L** | 4.1 | 8.2 | 8.2 |
| **RA 2004L** | 3.9 | 7.8 | 7.8 |
| **RA 2522** | 10.7 | 21.4 | 21.4 |
| **RA 2523** | 11 | 22 | 22 |
| **RA 2524** | 10.5 | 21 | 21 |
| **RA 3002** | 10.6 | 21.2 | 21.2 |
| **RA 3003** | 11.1 | 22.2 | 22.2 |
| **RA 3004** | 10.6 | 21.2 | 21.2 |
| **RA 3512** | 14.9 | 29.8 | 29.8 |
| **RA 3513** | 7.7 | 15.4 | 15.4 |
| **RA 3514** | 7.1 | 14.2 | 14.2 |
| **RA 4802** | 14.7 | 29.4 | 29.4 |
| **RA 4803** | 9.8 | 19.6 | 19.6 |
| **RA 4804** | 8.3 | 16.6 | 16.6 |
| **RA 6002** | 17.5 | 35 | 35 |
| **RA 6003** | 11.5 | 23 | 23 |
| **RA 6004** | 10.1 | 20.2 | 20.2 |
| **RA 6003L** | 11.5 | 23 | 23 |
| **RA 6004L** | 10.1 | 20.2 | 20.2 |
| **RA 8002** | 18.3 | 36.6 | 36.6 |
| **RA 8003** | 13.2 | 26.4 | 26.4 |
| **RA 8004** | 13 | 26 | 26 |
| **RA 8003L** | 13.2 | 26.4 | 26.4 |
| **RA 8004L** | 12.8 | 25.6 | 25.6 |
| **GBA 12013** | 18.5 | 37 | 37 |
| **GBA 12014** | 18.5 | 37 | 37 |
| **GBA 12015** | 17.9 | 35.8 | 35.8 |
| **GBA 12013L** | 18.5 | 37 | 37 |
| **GBA 12014L** | 18.3 | 36.6 | 36.6 |
| **GBA 12015L** | 18 | 36 | 36 |
| **GBA 16003** | 28 | 56 | 56 |
| **GBA 16004** | 22.2 | 44.4 | 44.4 |
| **GBA 16005** | 20.7 | 41.4 | 41.4 |



| [Liters] | B5-1 | V1 | V3 |
|---|---|---|---|
| |  |  |  |
| **GBA 16003L** | 27 | 54 | 54 |
| **GBA 16004L** | 21 | 42 | 42 |
| **GBA 16005L** | 19.6 | 39.2 | 39.2 |
| **GBA 21003** | 33.5 | 67 | 67 |
| **GBA 21004** | 27.5 | 55 | 55 |
| **GBA 21005** | 26.1 | 52.2 | 52.2 |
| **GBA 26003** | 35.5 | 71 | 71 |
| **GBA 26004** | 30.5 | 61 | 61 |
| **GBA 26005** | 30.5 | 61 | 61 |
| **GBA 31004** | 51.5 | 103 | 103 |
| **GBA 31005** | 51.5 | 103 | 103 |
| **GBA 40004** | 54 | 108 | 108 |
| **GBA 40005** | 54 | 108 | 108 |
| **GBA 45004** | 63.5 | 127 | 127 |
| **GBA 45005** | 58.5 | 117 | 117 |
| **GBA 53004** | 96.5 | 193 | 193 |
| **GBA 53005** | 90 | 180 | 180 |
| **GBA 61004** | 95 | 190 | 190 |
| **GBA 61005** | 89.5 | 179 | 179 |
| **GBA 61006** | 88 | 176 | 176 |
| **GBA 85004** | 103 | 206 | 206 |
| **GBA 85005** | 98 | 196 | 196 |
| **GBA 85006** | 97 | 194 | 194 |
| **GBA 110005** | 186 | 372 | 372 |
| **GBA 110006** | 187 | 374 | 374 |
| **GBA 130005** | 380 | 760 | 388 |
| **GBA 130006** | 189 | 378 | 378 |








| CC | | |
|---|---|---|
| [Liters] |  | |
| **CC30** | 1.6 | **Complete filling** |
| **CC120** | 2.2 | |
| **CC350** | 4 | |
| **CC600** | 6 | |
| **CC1000** | 16 | |



| | P | T | TL | TR | F | N | H |
|---|---|---|---|---|---|---|---|
| kg |  |  |  |  |  |  |  |
| **RE 111** | 23 | 20 | — | 20 | 14 | 17 | — |
| **RE 112** | 29.5 | 26.5 | — | 26.5 | 21 | 24 | — |
| **RE 113** | 36.5 | 33.5 | — | 33.5 | 27.5 | 30.5 | — |
| **RE 114** | 43 | 40 | — | 40 | 34 | 37 | — |
| **RE 211** | 25 | 22 | — | 22 | 16 | 19 | — |
| **RE 212** | 32 | 29 | — | 29 | 23 | 26 | — |
| **RE 213** | 38 | 35 | — | 35 | 30 | 32 | — |
| **RE 214** | 45 | 42 | — | 42 | 37 | 39 | — |
| **RE 241** | 25 | — | — | 22 | — | — | — |
| **RE 242** | 32 | — | — | 29 | — | — | — |
| **RE 243** | 38 | — | — | 35 | — | — | — |
| **RE 244** | 45 | — | — | 42 | — | — | — |
| **RE 311** | 52 | 47 | 47 | — | 24 | 35 | — |
| **RE 312** | 59 | 54 | 54 | — | 31 | 42 | — |
| **RE 313** | 66 | 61 | 61 | — | 38 | 49 | — |
| **RE 314** | 72 | 67 | 66 | — | 45 | 56 | — |
| **RE 511** | 57 | 52 | 52 | — | 29 | 40 | — |
| **RE 512** | 66 | 61 | 61 | — | 38 | 49 | — |
| **RE 513** | 73 | 68 | 68 | — | 45 | 56 | — |
| **RE 514** | 80 | 75 | 75 | — | 52 | 63 | — |
| **RE 611** | 58 | 53 | 53 | — | 30 | 41 | — |
| **RE 612** | 72 | 67 | 67 | — | 44 | 55 | — |
| **RE 613** | 79 | 74 | 74 | — | 51 | 62 | — |
| **RE 614** | 86 | 81 | 81 | — | 58 | 69 | — |
| **RE 811** | 80 | 70 | — | — | — | 67 | — |
| **RE 812** | 94 | 84 | — | — | — | 80 | — |
| **RE 813** | 100 | 90 | — | — | — | 87 | — |
| **RE 814** | 107 | 97 | — | — | — | 94 | — |
| **RE 1021** | 100 | 90 | — | — | 60 | — | — |
| **RE 1022** | 117 | 107 | — | — | 77 | — | — |


| kg | P | T | TL | TR | F | N | H |
|---|---|---|---|---|---|---|---|
| |  |  |  |  |  |  |  |
| **RE 1023** | 126 | 116 | — | — | 86 | — | — |
| **RE 1024** | 133 | 123 | — | — | 93 | — | — |
| **RE 1521** | — | 123 | — | — | 84 | — | 130 |
| **RE 1522** | — | 141 | — | — | 102 | — | 148 |
| **RE 1523** | — | 149 | — | — | 110 | — | 156 |
| **RE 1524** | — | 156 | — | — | 117 | — | 163 |
| **RE 2001** | — | 124 | — | — | 85 | — | 131 |
| **RE 2002** | — | 142 | — | — | 104 | — | 150 |
| **RE 2003** | — | 156 | — | — | 118 | — | 163 |
| **RE 2004** | — | 163 | — | — | 125 | — | 170 |
| **RE 2002L** | — | 137 | — | — | 99 | — | 145 |
| **RE 2003L** | — | 149 | — | — | 111 | — | 156 |
| **RE 2004L** | — | 153 | — | — | 115 | — | 160 |
| **RE 2521** | — | — | — | — | 151 | — | 185 |
| **RE 2522** | — | — | — | — | 180 | — | 214 |
| **RE 2523** | — | — | — | — | 194 | — | 228 |
| **RE 2524** | — | — | — | — | 201 | — | 235 |
| **RE 3001** | — | — | — | — | 152 | — | 186 |
| **RE 3002** | — | — | — | — | 199 | — | 233 |
| **RE 3003** | — | — | — | — | 207 | — | 241 |
| **RE 3004** | — | — | — | — | 216 | — | 250 |
| **RE 3511** | — | — | — | — | 225 | — | 239 |
| **RE 3512** | — | — | — | — | 260 | — | 274 |
| **RE 3513** | — | — | — | — | 278 | — | 292 |
| **RE 3514** | — | — | — | — | 287 | — | 301 |
| **RE 4801** | — | — | — | — | 226 | — | 240 |
| **RE 4802** | — | — | — | — | 311 | — | 325 |
| **RE 4803** | — | — | — | — | 330 | — | 344 |
| **RE 4804** | — | — | — | — | 339 | — | 353 |

| kg | H  | F  |
|---|---|---|
| **RE 6002L** | 365 | 340 |
| **RE 6003L** | 375 | 350 |
| **RE 6004L** | 382 | 357 |
| **RE 6001** | 315 | 290 |
| **RE 6002** | 370 | 345 |
| **RE 6003** | 390 | 365 |
| **RE 6004** | 395 | 370 |
| **RE 8001** | 410 | 380 |
| **RE 8002** | 500 | 470 |
| **RE 8003** | 540 | 510 |
| **RE 8004** | 555 | 525 |
| **RE 8005** | 560 | 530 |
| **RE 8002L** | 485 | 455 |
| **RE 8003L** | 520 | 490 |
| **RE 8004L** | 530 | 500 |
| **RE 8005L** | 535 | 505 |
| **GB 12011** | 650 | 615 |
| **GB 12012** | 750 | 715 |
| **GB 12013** | 785 | 750 |
| **GB 12014** | 800 | 765 |
| **GB 12015** | 810 | 775 |
| **GB 12012L** | 700 | 665 |
| **GB 12013L** | 745 | 710 |
| **GB 12014L** | 750 | 715 |
| **GB 12015L** | 757 | 722 |
| **GB 16001** | 690 | 655 |
| **GB 16002** | 860 | 825 |
| **GB 16003** | 915 | 880 |
| **GB 16004** | 935 | 900 |
| **GB 16005** | 940 | 905 |
| **GB 16002L** | 860 | 825 |
| **GB 16003L** | 865 | 830 |
| **GB 16004L** | 885 | 850 |
| **GB 16005L** | 890 | 855 |
| **GB 21001** | 930 | 880 |
| **GB 21002** | 1115 | 1065 |
| **GB 21003** | 1165 | 1115 |
| **GB 21004** | 1190 | 1140 |
| **GB 21005** | 1205 | 1155 |
| **GB 26001** | 980 | 920 |
| **GB 26002** | 1230 | 1170 |
| **GB 26003** | 1330 | 1270 |
| **GB 26004** | 1360 | 1300 |
| **GB 26005** | 1380 | 1320 |
| **GB 31001** | 1900 | 1750 |
| **GB 31002** | 2280 | 2130 |
| **GB 31003** | 2375 | 2225 |
| **GB 31004** | 2410 | 2260 |
| **GB 31005** | 2425 | 2275 |
| **GB 40001** | 2030 | 1880 |

| kg | H  | F  |
|---|---|---|
| **GB 40002** | 2400 | 2250 |
| **GB 40003** | 2500 | 2350 |
| **GB 40004** | 2530 | 2380 |
| **GB 40005** | 2540 | 2390 |
| **GB 45001** | 2030 | 1880 |
| **GB 45002** | 2435 | 2285 |
| **GB 45003** | 2610 | 2460 |
| **GB 45004** | 2665 | 2515 |
| **GB 45005** | 2682 | 2532 |
| **GB 53001** | 3550 | 3200 |
| **GB 53002** | 4060 | 3710 |
| **GB 53003** | 4250 | 3900 |
| **GB 53004** | 4350 | 4000 |
| **GB 53005** | 4370 | 4020 |
| **GB 61001** | 3550 | 3200 |
| **GB 61002** | 4060 | 3710 |
| **GB 61003** | 4250 | 3900 |
| **GB 61004** | 4350 | 4000 |
| **GB 61005** | 4370 | 4020 |
| **GB 85001** | 3850 | 3450 |
| **GB 85002** | 4410 | 4010 |
| **GB 85003** | 4650 | 4250 |
| **GB 85004** | 4750 | 4350 |
| **GB 85005** | 4785 | 4385 |
| **GB 110001** | 7520 | 6620 |
| **GB 110002** | 8780 | 7880 |
| **GB 110003** | 9155 | 8255 |
| **GB 110004** | 9250 | 8350 |
| **GB 110005** | 9285 | 8385 |
| **GB 130001** | 7535 | 6635 |
| **GB 130002** | 8800 | 7900 |
| **GB 130003** | 9210 | 8310 |
| **GB 130004** | 9380 | 8480 |
| **GB 130005** | 9430 | 8530 |
| **GB 150001** | 7550 | 6650 |
| **GB 150002** | 8795 | 7895 |
| **GB 150003** | 9280 | 8380 |
| **GB 150004** | 9460 | 8560 |
| **GB 150005** | 9500 | 8600 |
| **GB 205001** | 12240 | 11790 |
| **GB 205002** | 14330 | 13880 |
| **GB 205003** | 15040 | 14590 |
| **GB 205004** | 15410 | 14960 |
| **GB 205005** | 15500 | 15050 |
| **GB 235001** | 12250 | 11800 |
| **GB 235002** | 14580 | 14130 |
| **GB 235003** | 15830 | 15380 |
| **GB 235004** | 16200 | 15750 |
| **GB 235005** | 16300 | 15850 |

| | P | T | TL | TR | F | N | H |
|---|---|---|---|---|---|---|---|
| kg |  |  |  |  |  |  |  |
| **RA 112** | 43 | 40 | — | 40 | 34 | 37 | — |
| **RA 113** | 49.5 | 46.5 | — | 46.5 | 41 | 44 | — |
| **RA 114** | 56.5 | 53.5 | — | 53.5 | 47.5 | 50.5 | — |
| **RA 212** | 45 | 42 | — | 42 | 36 | 39 | — |
| **RA 213** | 52 | 49 | — | 49 | 43 | 46 | — |
| **RA 214** | 58 | 55 | — | 55 | 50 | 52 | — |
| **RA 242** | 45 | — | — | 42 | — | — | — |
| **RA 243** | 52 | — | — | 49 | — | — | — |
| **RA 244** | 58 | — | — | 55 | — | — | — |
| **RA 312** | 102 | 97 | 97 | — | 74 | 85 | — |
| **RA 313** | | 74 | 74 | — | 51 | 62 | — |
| **RA 314** | 86 | 81 | 81 | — | 58 | 69 | — |
| **RA 512** | 107 | 102 | 102 | — | 79 | 90 | — |
| **RA 513** | 86 | 81 | 81 | — | 58 | 69 | — |
| **RA 514** | 93 | 88 | 88 | — | 65 | 76 | — |
| **RA 612** | 108 | 103 | 103 | — | 80 | 91 | — |
| **RA 613** | 122 | 117 | 117 | — | 94 | 105 | — |
| **RA 614** | 99 | 94 | 94 | — | 71 | 82 | — |
| **RA 812** | 170 | 160 | — | — | — | 157 | — |
| **RA 813** | 144 | 134 | — | — | — | 130 | — |
| **RA 814** | 120 | 110 | — | — | — | 107 | — |
| **RA 1022** | 190 | 180 | — | — | 150 | — | — |
| **RA 1023** | 167 | 157 | — | — | 127 | — | — |
| **RA 1024** | 146 | 136 | — | — | 106 | — | — |
| **RA 1522** | — | 258 | — | — | 219 | — | 265 |
| **RA 1523** | — | 191 | — | — | 152 | — | 198 |
| **RA 1524** | — | 169 | — | — | 130 | — | 176 |
| **RA 2002** | — | 259 | — | — | 220 | — | 266 |
| **RA 2003** | — | 192 | — | — | 154 | — | 200 |
| **RA 2004** | — | 176 | — | — | 138 | — | 183 |
| **RA 2003L** | — | 187 | — | — | 149 | — | 195 |
| **RA 2004L** | — | 169 | — | — | 131 | — | 176 |
| **RA 2522** | — | — | — | — | 286 | — | 320 |
| **RA 2523** | — | — | — | — | 270 | — | 304 |
| **RA 2524** | — | — | — | — | 214 | — | 248 |
| **RA 3002** | — | — | — | — | 287 | — | 321 |
| **RA 3003** | — | — | — | — | 289 | — | 323 |
| **RA 3004** | — | — | — | — | 257 | — | 291 |
| **RA 3512** | — | — | — | — | 575 | — | 589 |
| **RA 3513** | — | — | — | — | 350 | — | 364 |
| **RA 3514** | — | — | — | — | 398 | — | 412 |
| **RA 4802** | — | — | — | — | 576 | — | 590 |
| **RA 4803** | — | — | — | — | 446 | — | 460 |
| **RA 4804** | — | — | — | — | 380 | — | 394 |

| | H | F |
|---|---|---|
| kg |  |  |
| **RA 6002** | 665 | 640 |
| **RA 6003** | 505 | 480 |
| **RA 6004** | 440 | 415 |
| **RA 6003L** | 500 | 475 |
| **RA 6004L** | 425 | 400 |
| **RA 8002** | 760 | 730 |
| **RA 8003** | 635 | 605 |
| **RA 8004** | 630 | 600 |
| **RA 8003L** | 620 | 590 |
| **RA 8004L** | 610 | 580 |
| **GBA 12013** | 885 | 850 |
| **GBA 12014** | 875 | 840 |
| **GBA 12015** | 850 | 815 |
| **GBA 12013L** | 835 | 800 |
| **GBA 12014L** | 835 | 800 |
| **GBA 12015L** | 800 | 765 |
| **GBA 16003** | 1210 | 1175 |
| **GBA 16004** | 1050 | 1015 |
| **GBA 16005** | 985 | 950 |
| **GBA 16003L** | 1210 | 1175 |
| **GBA 16004L** | 1000 | 965 |
| **GBA 16005L** | 935 | 900 |
| **GBA 21003** | 1465 | 1415 |
| **GBA 21004** | 1300 | 1250 |
| **GBA 21005** | 1240 | 1190 |
| **GBA 26003** | 1580 | 1520 |
| **GBA 26004** | 1465 | 1405 |
| **GBA 26005** | 1450 | 1390 |
| **GBA 31004** | 2510 | 2360 |
| **GBA 31005** | 2500 | 2350 |
| **GBA 40004** | 2635 | 2485 |
| **GBA 40005** | 2620 | 2470 |
| **GBA 45004** | 2960 | 2810 |
| **GBA 45005** | 2800 | 2650 |
| **GBA 53004** | 4600 | 4250 |
| **GBA 53005** | 4485 | 4135 |
| **GBA 61004** | 4600 | 4250 |
| **GBA 61005** | 4485 | 4135 |
| **GBA 61006** | 4420 | 4070 |
| **GBA 85004** | 5000 | 4600 |
| **GBA 85005** | 4885 | 4485 |
| **GBA 85006** | 4875 | 4475 |
| **GBA 110005** | 9385 | 8485 |
| **GBA 110006** | 9375 | 8475 |
| **GBA 130005** | 9730 | 8830 |
| **GBA 130006** | 9365 | 8665 |

| | CC |
|---|---|
| kg |  |
| **CC30** | 35 |
| **CC120** | 50 |
| **CC350** | 90 |
| **CC600** | 135 |
| **CC1000** | 350 |

# RE 310

| | | $n_1$= **750** RPM | | | $n_1$= **900** RPM | | | $n_1$= **1450** RPM | | | $n_1$= **2900** RPM | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | **ie** | **$n_2$** [RPM] | **$P_1$** [kW] | **$T_2$** [Nm] | **$n_2$** [RPM] | **$P_1$** [kW] | **$T_2$** [Nm] | **$n_2$** [RPM] | **$P_1$** [kW] | **$T_2$** [Nm] | **$n_2$** [RPM] | **$P_1$** [kW] | **$T_2$** [Nm] | **$T_{2max}$** [Nm] | **$P_t$** [kW] |
| **RE 311** | **3.60** | 208 | ***43.9*** | 1960 | 250 | ***49.9*** | 1860 | 403 | ***70*** | 1610 | 806 | ***113*** | 1310 | 4320 | 18 (N)<br>22 (T)<br>13 (F)<br>36 (P) |
| | **4.25** | 176 | ***38.5*** | 2030 | 212 | ***43.8*** | 1920 | 341 | ***61*** | 1670 | 682 | ***99*** | 1350 | 5630 | |
| | **5.33** | 141 | ***25.3*** | 1680 | 169 | ***30.1*** | 1660 | 272 | ***47.1*** | 1610 | 544 | ***82*** | 1410 | 4610 | |
| | **6.20** | 121 | ***18.4*** | 1410 | 145 | ***21.8*** | 1400 | 234 | ***34.2*** | 1360 | 468 | ***66*** | 1310 | 3900 | |
| | **7.50** | 100 | ***11.9*** | 1110 | 120 | ***14.2*** | 1100 | 193 | ***22.2*** | 1070 | 387 | ***42.7*** | 1030 | 3070 | |
| **RE 312** | **12.53** | 60 | ***14.9*** | 2260 | 72 | ***17.3*** | 2180 | 116 | ***24.1*** | 1890 | 231 | ***39.2*** | 1540 | 4320 | 10 (N)<br>12 (T)<br>8 (F)<br>21 (P) |
| | **14.79** | 51 | ***12.3*** | 2200 | 61 | ***14.6*** | 2180 | 98 | ***22.9*** | 2120 | 196 | ***39.2*** | 1810 | 5630 | |
| | **15.35** | 48.9 | ***12.3*** | 2280 | 59 | ***14.6*** | 2260 | 94 | ***20.6*** | 1980 | 189 | ***33.5*** | 1610 | 4320 | |
| | **18.12** | 41.4 | ***10.2*** | 2230 | 49.7 | ***12.1*** | 2210 | 80 | ***18.9*** | 2150 | 160 | ***33.5*** | 1900 | 5630 | |
| | **20.77** | 36.1 | ***6.8*** | 1720 | 43.3 | ***8.1*** | 1700 | 70 | ***12.7*** | 1650 | 140 | ***24.5*** | 1590 | 4320 | |
| | **22.74** | 33.0 | ***6.6*** | 1820 | 39.6 | ***7.9*** | 1800 | 64 | ***12.3*** | 1750 | 128 | ***23.7*** | 1690 | 4610 | |
| | **24.52** | 30.6 | ***6.8*** | 2030 | 36.7 | ***8.1*** | 2010 | 59 | ***12.7*** | 1950 | 118 | ***24.5*** | 1880 | 5960 | |
| | **26.43** | 28.4 | ***4.8*** | 1540 | 34.1 | ***5.7*** | 1520 | 55 | ***8.9*** | 1480 | 110 | ***17.2*** | 1420 | 3900 | |
| | **30.77** | 24.4 | ***5.0*** | 1850 | 29.3 | ***5.9*** | 1830 | 47.1 | ***9.3*** | 1780 | 94 | ***17.8*** | 1720 | 4610 | |
| | **35.77** | 21.0 | ***3.6*** | 1560 | 25.2 | ***4.3*** | 1550 | 40.5 | ***6.7*** | 1510 | 81 | ***12.9*** | 1450 | 3900 | |
| | **38.40** | 19.5 | ***3.9*** | 1830 | 23.4 | ***4.7*** | 1810 | 37.8 | ***7.3*** | 1760 | 76 | ***14.1*** | 1690 | 4610 | |
| | **44.64** | 16.8 | ***2.9*** | 1580 | 20.2 | ***3.5*** | 1570 | 32.5 | ***5.5*** | 1520 | 65 | ***10.5*** | 1470 | 3900 | |
| | **54.00** | 13.9 | ***1.9*** | 1240 | 16.7 | ***2.3*** | 1230 | 26.9 | ***3.5*** | 1200 | 54 | ***6.8*** | 1150 | 3070 | |
| **RE 313** | **43.60** | 17.2 | ***4.7*** | 2420 | 20.6 | ***5.6*** | 2400 | 33.3 | ***8.8*** | 2330 | 67 | ***16.8*** | 2230 | 4320 | 8 (N)<br>9 (T)<br>6 (F)<br>15 (P) |
| | **51.47** | 14.6 | ***3.9*** | 2370 | 17.5 | ***4.6*** | 2340 | 28.2 | ***7.3*** | 2280 | 56 | ***13.9*** | 2190 | 5630 | |
| | **53.41** | 14.0 | ***3.9*** | 2450 | 16.9 | ***4.6*** | 2430 | 27.1 | ***7.2*** | 2360 | 54 | ***13.9*** | 2270 | 4320 | |
| | **63.05** | 11.9 | ***3.2*** | 2390 | 14.3 | ***3.8*** | 2370 | 23.0 | ***6.0*** | 2310 | 46.0 | ***11.5*** | 2220 | 5630 | |
| | **72.28** | 10.4 | ***2.9*** | 2500 | 12.5 | ***3.5*** | 2470 | 20.1 | ***5.4*** | 2400 | 40.1 | ***10.5*** | 2310 | 4320 | |
| | **77.24** | 9.7 | ***2.7*** | 2420 | 11.7 | ***3.2*** | 2400 | 18.8 | ***4.9*** | 2330 | 37.5 | ***9.5*** | 2240 | 5630 | |
| | **85.33** | 8.8 | ***2.4*** | 2440 | 10.5 | ***2.9*** | 2410 | 17.0 | ***4.5*** | 2350 | 34.0 | ***8.7*** | 2250 | 5630 | |
| | **104.53** | 7.2 | ***2.0*** | 2510 | 8.6 | ***2.4*** | 2440 | 13.9 | ***3.7*** | 2370 | 27.7 | ***7.2*** | 2280 | 5630 | |
| | **106.49** | 7.0 | ***2.0*** | 2510 | 8.5 | ***2.3*** | 2440 | 13.6 | ***3.7*** | 2380 | 27.2 | ***7.0*** | 2280 | 5630 | |
| | **130.45** | 5.7 | ***1.7*** | 2590 | 6.9 | ***2.0*** | 2520 | 11.1 | ***3.0*** | 2400 | 22.2 | ***5.8*** | 2310 | 5630 | |
| | **141.46** | 5.3 | ***1.3*** | 2240 | 6.4 | ***1.6*** | 2220 | 10.3 | ***2.5*** | 2160 | 20.5 | ***4.8*** | 2080 | 5960 | |
| | **163.71** | 4.6 | ***1.1*** | 2100 | 5.5 | ***1.3*** | 2050 | 8.9 | ***2.0*** | 1960 | 17.7 | ***3.8*** | 1890 | 4610 | |
| | **176.54** | 4.2 | ***1.1*** | 2270 | 5.1 | ***1.3*** | 2250 | 8.2 | ***2.0*** | 2190 | 16.4 | ***3.9*** | 2100 | 5960 | |
| | **190.31** | 3.9 | ***0.79*** | 1770 | 4.7 | ***0.92*** | 1720 | 7.6 | ***1.4*** | 1660 | 15.2 | ***2.7*** | 1590 | 3900 | |
| | **221.54** | 3.4 | ***0.84*** | 2200 | 4.1 | ***0.98*** | 2140 | 6.5 | ***1.5*** | 2000 | 13.1 | ***2.8*** | 1920 | 4610 | |
| | **257.54** | 2.9 | ***0.61*** | 1850 | 3.5 | ***0.71*** | 1800 | 5.6 | ***1.1*** | 1680 | 11.3 | ***2.1*** | 1620 | 3900 | |
| | **276.48** | 2.7 | ***0.63*** | 2040 | 3.3 | ***0.74*** | 2020 | 5.2 | ***1.2*** | 1970 | 10.5 | ***2.2*** | 1890 | 4610 | |
| | **321.41** | 2.3 | ***0.50*** | 1920 | 2.8 | ***0.59*** | 1860 | 4.5 | ***0.88*** | 1730 | 9.0 | ***1.7*** | 1640 | 3900 | |
| **RE 314** | **219.42** | 3.4 | ***1.1*** | 2800 | 4.1 | ***1.30*** | 2730 | 6.6 | ***1.9*** | 2540 | 13.2 | ***3.6*** | 2380 | 5630 | 6 (N)<br>7 (T)<br>5 (F)<br>12 (P) |
| | **268.80** | 2.8 | ***0.93*** | 2890 | 3.3 | ***1.09*** | 2810 | 5.4 | ***1.6*** | 2620 | 10.8 | ***3.0*** | 2410 | 5630 | |
| | **296.94** | 2.5 | ***0.86*** | 2930 | 3.0 | ***1.00*** | 2850 | 4.9 | ***1.5*** | 2660 | 9.8 | ***2.7*** | 2420 | 5630 | |
| | **329.29** | 2.3 | ***0.79*** | 2980 | 2.7 | ***0.92*** | 2900 | 4.4 | ***1.4*** | 2700 | 8.8 | ***2.5*** | 2440 | 5630 | |
| | **363.76** | 2.1 | ***0.72*** | 3030 | 2.5 | ***0.84*** | 2940 | 4.0 | ***1.3*** | 2740 | 8.0 | ***2.3*** | 2470 | 5630 | |
| | **416.98** | 1.8 | ***0.61*** | 2930 | 2.2 | ***0.71*** | 2850 | 3.5 | ***1.1*** | 2680 | 7.0 | ***2.1*** | 2580 | 4320 | |
| | **453.98** | 1.7 | ***0.60*** | 3130 | 2.0 | ***0.70*** | 3040 | 3.2 | ***1.0*** | 2830 | 6.4 | ***1.9*** | 2550 | 5630 | |
| | **492.27** | 1.5 | ***0.56*** | 3170 | 1.8 | ***0.65*** | 3080 | 2.9 | ***0.98*** | 2870 | 5.9 | ***1.8*** | 2580 | 5630 | |
| | **556.14** | 1.3 | ***0.50*** | 3230 | 1.6 | ***0.59*** | 3140 | 2.6 | ***0.88*** | 2920 | 5.2 | ***1.6*** | 2630 | 5630 | |
| | **614.35** | 1.2 | ***0.46*** | 3280 | 1.5 | ***0.54*** | 3190 | 2.4 | ***0.81*** | 2960 | 4.7 | ***1.5*** | 2670 | 5630 | |
| | **766.71** | 0.98 | ***0.38*** | 3390 | 1.2 | ***0.45*** | 3290 | 1.9 | ***0.67*** | 3070 | 3.8 | ***1.2*** | 2760 | 5630 | |
| | **795.61** | 0.94 | ***0.35*** | 3190 | 1.1 | ***0.41*** | 3100 | 1.8 | ***0.61*** | 2880 | 3.6 | ***1.1*** | 2700 | 4320 | |
| | **939.26** | 0.80 | ***0.32*** | 3490 | 0.96 | ***0.38*** | 3400 | 1.5 | ***0.57*** | 3160 | 3.1 | ***1.0*** | 2850 | 5630 | |
| | **1018.49** | 0.74 | ***0.23*** | 2660 | 0.88 | ***0.27*** | 2590 | 1.4 | ***0.40*** | 2420 | 2.8 | ***0.77*** | 2320 | 5960 | |
| | **1178.68** | 0.64 | ***0.21*** | 2840 | 0.76 | ***0.24*** | 2760 | 1.2 | ***0.37*** | 2570 | 2.5 | ***0.66*** | 2310 | 4610 | |
| | **1271.08** | 0.59 | ***0.19*** | 2750 | 0.71 | ***0.22*** | 2680 | 1.1 | ***0.33*** | 2490 | 2.3 | ***0.62*** | 2350 | 5960 | |
| | **1595.08** | 0.47 | ***0.16*** | 2970 | 0.56 | ***0.19*** | 2890 | 0.91 | ***0.28*** | 2690 | 1.8 | ***0.51*** | 2420 | 4610 | |
| | **1990.66** | 0.38 | ***0.11*** | 2470 | 0.45 | ***0.13*** | 2400 | 0.73 | ***0.19*** | 2230 | 1.5 | ***0.36*** | 2120 | 4610 | |

| | | $n_1$= **750** RPM | | | $n_1$= **900** RPM | | | $n_1$= **1450** RPM | | | $n_1$= **2900** RPM | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | **ie** | **$n_2$** [RPM] | **$P_1$** [kW] | **$T_2$** [Nm] | **$n_2$** [RPM] | **$P_1$** [kW] | **$T_2$** [Nm] | **$n_2$** [RPM] | **$P_1$** [kW] | **$T_2$** [Nm] | **$n_2$** [RPM] | **$P_1$** [kW] | **$T_2$** [Nm] | **$T_{2max}$** [Nm] | **$P_t$** [kW] |
| **RA 312** | **10.03** | 75 | ***18.6*** | 2230 | 90 | ***22.1*** | 2200 | 145 | ***34.7*** | 2150 | 289 | ***58*** | 1780 | 4320 | 10 (N)<br>12 (T)<br>8 (F)<br>17 (P) |
| | **11.84** | 63 | ***15.4*** | 2180 | 76 | ***18.3*** | 2150 | 122 | ***28.7*** | 2100 | 245 | ***50*** | 1840 | 5630 | |
| | **14.40** | 52 | ***13.3*** | 2270 | 63 | ***15.7*** | 2250 | 101 | ***24.7*** | 2190 | 201 | ***44.7*** | 1980 | 4320 | |
| | **17.00** | 44.1 | ***11.0*** | 2220 | 53 | ***13.0*** | 2200 | 85 | ***20.4*** | 2140 | 171 | ***39.2*** | 2050 | 5630 | |
| | **21.33** | 35.2 | ***7.1*** | 1810 | 42.2 | ***8.5*** | 1800 | 68 | ***13.3*** | 1750 | 136 | ***25.5*** | 1680 | 4610 | |
| | **24.80** | 30.2 | ***5.2*** | 1530 | 36.3 | ***6.1*** | 1510 | 58 | ***9.6*** | 1470 | 117 | ***18.5*** | 1420 | 3900 | |
| | **30.00** | 25.0 | ***3.4*** | 1200 | 30.0 | ***4.0*** | 1190 | 48.3 | ***6.3*** | 1160 | 97 | ***12.0*** | 1110 | 3070 | |
| **RA 313** | **40.09** | 18.7 | ***5.2*** | 2410 | 22.4 | ***6.1*** | 2390 | 36.2 | ***9.6*** | 2320 | 72 | ***18.1*** | 2180 | 4320 | 6 (N)<br>7 (T)<br>5 (F)<br>11 (P) |
| | **47.33** | 15.8 | ***4.3*** | 2360 | 19.0 | ***5.1*** | 2330 | 30.6 | ***8.0*** | 2270 | 61 | ***15.3*** | 2180 | 5630 | |
| | **49.11** | 15.3 | ***4.3*** | 2440 | 18.3 | ***5.1*** | 2410 | 29.5 | ***8.0*** | 2350 | 59 | ***15.3*** | 2260 | 4320 | |
| | **57.98** | 12.9 | ***3.5*** | 2380 | 15.5 | ***4.2*** | 2360 | 25.0 | ***6.6*** | 2290 | 50 | ***12.7*** | 2210 | 5630 | |
| | **66.46** | 11.3 | ***2.4*** | 1840 | 13.5 | ***2.8*** | 1820 | 21.8 | ***4.4*** | 1770 | 43.6 | ***8.5*** | 1700 | 4730 | |
| | **72.76** | 10.3 | ***2.3*** | 1950 | 12.4 | ***2.7*** | 1930 | 19.9 | ***4.3*** | 1870 | 39.9 | ***8.2*** | 1800 | 4610 | |
| | **78.46** | 9.6 | ***2.4*** | 2170 | 11.5 | ***2.8*** | 2150 | 18.5 | ***4.4*** | 2090 | 37.0 | ***8.5*** | 2010 | 5590 | |
| | **84.58** | 8.9 | ***1.7*** | 1640 | 10.6 | ***2.0*** | 1620 | 17.1 | ***3.1*** | 1580 | 34.3 | ***6.0*** | 1520 | 3900 | |
| | **98.46** | 7.6 | ***1.7*** | 1980 | 9.1 | ***2.1*** | 1960 | 14.7 | ***3.2*** | 1910 | 29.5 | ***6.2*** | 1830 | 4610 | |
| | **114.46** | 6.6 | ***1.3*** | 1670 | 7.9 | ***1.5*** | 1650 | 12.7 | ***2.3*** | 1610 | 25.3 | ***4.5*** | 1550 | 3900 | |
| | **122.88** | 6.1 | ***1.4*** | 1950 | 7.3 | ***1.6*** | 1930 | 11.8 | ***2.5*** | 1880 | 23.6 | ***4.9*** | 1810 | 4610 | |
| | **142.85** | 5.3 | ***1.0*** | 1690 | 6.3 | ***1.2*** | 1670 | 10.2 | ***1.9*** | 1630 | 20.3 | ***3.6*** | 1570 | 3900 | |
| | **172.80** | 4.3 | ***0.66*** | 1330 | 5.2 | ***0.79*** | 1320 | 8.4 | ***1.23*** | 1280 | 16.8 | ***2.37*** | 1230 | 3070 | |
| **RA 314** | **139.51** | 5.4 | ***1.7*** | 2620 | 6.5 | ***2.0*** | 2590 | 10.4 | ***3.1*** | 2500 | 20.8 | ***5.9*** | 2400 | 4320 | 5 (N)<br>6 (T)<br>4 (F)<br>10 (P) |
| | **164.70** | 4.6 | ***1.4*** | 2680 | 5.5 | ***1.7*** | 2610 | 8.8 | ***2.5*** | 2440 | 17.6 | ***4.9*** | 2340 | 5630 | |
| | **170.91** | 4.4 | ***1.4*** | 2680 | 5.3 | ***1.6*** | 2650 | 8.5 | ***2.6*** | 2580 | 17.0 | ***4.8*** | 2430 | 4320 | |
| | **201.77** | 3.7 | ***1.2*** | 2770 | 4.5 | ***1.4*** | 2690 | 7.2 | ***2.1*** | 2500 | 14.4 | ***4.0*** | 2370 | 5630 | |
| | **231.29** | 3.2 | ***1.0*** | 2690 | 3.9 | ***1.2*** | 2670 | 6.3 | ***1.9*** | 2590 | 13.9 | ***3.6*** | 2470 | 4320 | |
| | **247.17** | 3.0 | ***1.0*** | 2850 | 3.6 | ***1.2*** | 2780 | 5.9 | ***1.8*** | 2580 | 11.7 | ***3.3*** | 2400 | 5630 | |
| | **273.05** | 2.7 | ***0.94*** | 2900 | 3.3 | ***1.1*** | 2820 | 5.3 | ***1.6*** | 2620 | 10.6 | ***3.0*** | 2410 | 5630 | |
| | **310.18** | 2.4 | ***0.66*** | 2320 | 2.9 | ***0.77*** | 2250 | 4.7 | ***1.15*** | 2100 | 9.3 | ***2.15*** | 1960 | 4610 | |
| | **340.76** | 2.2 | ***0.78*** | 3000 | 2.6 | ***0.91*** | 2910 | 4.3 | ***1.36*** | 2710 | 8.5 | ***2.45*** | 2440 | 5630 | |
| | **417.45** | 1.8 | ***0.65*** | 3090 | 2.2 | ***0.76*** | 3010 | 3.5 | ***1.14*** | 2800 | 6.9 | ***2.06*** | 2520 | 5630 | |
| | **452.66** | 1.7 | ***0.47*** | 2400 | 2.0 | ***0.55*** | 2370 | 3.2 | ***0.87*** | 2310 | 6.4 | ***1.67*** | 2220 | 5590 | |
| | **497.11** | 1.5 | ***0.36*** | 2050 | 1.8 | ***0.42*** | 1990 | 2.9 | ***0.64*** | 1850 | 5.8 | ***1.15*** | 1680 | 3900 | |
| | **564.92** | 1.3 | ***0.38*** | 2430 | 1.6 | ***0.45*** | 2400 | 2.6 | ***0.71*** | 2340 | 5.1 | ***1.36*** | 2250 | 5590 | |
| | **608.98** | 1.2 | ***0.31*** | 2110 | 1.5 | ***0.36*** | 2050 | 2.4 | ***0.54*** | 1910 | 4.8 | ***0.96*** | 1720 | 3900 | |
| | **708.92** | 1.1 | ***0.33*** | 2630 | 1.3 | ***0.38*** | 2560 | 2.0 | ***0.57*** | 2380 | 4.1 | ***1.03*** | 2140 | 4610 | |
| | **824.12** | 0.91 | ***0.24*** | 2210 | 1.1 | ***0.28*** | 2150 | 1.8 | ***0.41*** | 2000 | 3.5 | ***0.75*** | 1800 | 3900 | |
| | **884.74** | 0.85 | ***0.22*** | 2190 | 1.0 | ***0.26*** | 2160 | 1.6 | ***0.41*** | 2100 | 3.3 | ***0.78*** | 2020 | 4610 | |
| | **1028.51** | 0.73 | ***0.20*** | 2280 | 0.88 | ***0.23*** | 2220 | 1.4 | ***0.34*** | 2070 | 2.8 | ***0.62*** | 1860 | 3900 | |
| | **1244.16** | 0.60 | ***0.13*** | 1790 | 0.72 | ***0.15*** | 1740 | 1.2 | ***0.22*** | 1620 | 2.3 | ***0.40*** | 1460 | 3070 | |

# RE 510

| | | $n_1$= **750** RPM | | | $n_1$= **900** RPM | | | $n_1$= **1450** RPM | | | $n_1$= **2900** RPM | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | **ie** | **$n_2$** [RPM] | **$P_1$** [kW] | **$T_2$** [Nm] | **$n_2$** [RPM] | **$P_1$** [kW] | **$T_2$** [Nm] | **$n_2$** [RPM] | **$P_1$** [kW] | **$T_2$** [Nm] | **$n_2$** [RPM] | **$P_1$** [kW] | **$T_2$** [Nm] | **$T_{2max}$** [Nm] | **$P_t$** [kW] |
| **RE 511** | **3.60** | 208 | ***76*** | 3400 | 250 | ***86*** | 3220 | 403 | ***121*** | 2790 | 806 | ***196*** | 2260 | 11600 | 19 (N)<br>24 (T)<br>14 (F)<br>37 (P) |
| | **4.25** | 176 | ***67*** | 3520 | 212 | ***76*** | 3330 | 341 | ***106*** | 2890 | 682 | ***172*** | 2340 | 11600 | |
| | **5.33** | 141 | ***52*** | 3450 | 169 | ***62*** | 3420 | 272 | ***88*** | 3010 | 544 | ***143*** | 2440 | 9500 | |
| | **6.20** | 121 | ***37.9*** | 2920 | 145 | ***45.1*** | 2890 | 234 | ***71*** | 2810 | 468 | ***127*** | 2530 | 8050 | |
| | **7.50** | 100 | ***24.6*** | 2290 | 120 | ***29.2*** | 2260 | 193 | ***45.8*** | 2200 | 387 | ***88*** | 2120 | 6320 | |
| **RE 512** | **12.53** | 60 | ***27.2*** | 4120 | 72 | ***30.9*** | 3900 | 116 | ***43.1*** | 3380 | 231 | ***70*** | 2750 | 11600 | 11 (N)<br>13 (T)<br>8 (F)<br>21 (P) |
| | **14.79** | 51 | ***25.4*** | 4540 | 61 | ***30.1*** | 4500 | 98 | ***43.1*** | 3990 | 196 | ***70*** | 3240 | 11600 | |
| | **15.35** | 48.9 | ***23.2*** | 4320 | 59 | ***26.4*** | 4090 | 94 | ***36.9*** | 3540 | 189 | ***60*** | 2880 | 11600 | |
| | **18.12** | 41.4 | ***21.0*** | 4600 | 49.7 | ***24.9*** | 4550 | 80 | ***36.9*** | 4180 | 160 | ***60*** | 3400 | 11600 | |
| | **20.77** | 36.1 | ***13.8*** | 3470 | 43.3 | ***16.4*** | 3430 | 70 | ***25.7*** | 3340 | 140 | ***46.9*** | 3050 | 9540 | |
| | **22.74** | 33.0 | ***13.6*** | 3750 | 39.6 | ***16.2*** | 3710 | 64 | ***25.4*** | 3610 | 128 | ***48.8*** | 3470 | 9500 | |
| | **24.52** | 30.6 | ***13.8*** | 4090 | 36.7 | ***16.4*** | 4050 | 59 | ***25.7*** | 3940 | 118 | ***46.9*** | 3600 | 11300 | |
| | **26.43** | 28.4 | ***9.9*** | 3170 | 34.1 | ***11.8*** | 3140 | 55 | ***18.5*** | 3060 | 110 | ***35.5*** | 2940 | 8050 | |
| | **30.77** | 24.4 | ***10.2*** | 3820 | 29.3 | ***12.2*** | 3780 | 47.1 | ***19.1*** | 3680 | 94 | ***36.7*** | 3530 | 9500 | |
| | **35.77** | 21.0 | ***7.5*** | 3230 | 25.2 | ***8.9*** | 3190 | 40.5 | ***13.9*** | 3110 | 81 | ***26.7*** | 2990 | 8050 | |
| | **38.40** | 19.5 | ***8.0*** | 3700 | 23.4 | ***9.4*** | 3660 | 37.8 | ***14.8*** | 3560 | 76 | ***28.5*** | 3420 | 9500 | |
| | **44.64** | 16.8 | ***6.0*** | 3270 | 20.2 | ***7.2*** | 3230 | 32.5 | ***11.3*** | 3150 | 65 | ***21.7*** | 3030 | 8050 | |
| | **54.00** | 13.9 | ***3.9*** | 2560 | 16.7 | ***4.7*** | 2530 | 26.9 | ***7.3*** | 2470 | 54 | ***14.0*** | 2370 | 6320 | |
| **RE 513** | **43.60** | 17.2 | ***9.5*** | 4870 | 20.6 | ***11.2*** | 4820 | 33.3 | ***17.6*** | 4690 | 67 | ***30.0*** | 3990 | 11600 | 8 (N)<br>10 (T)<br>6 (F)<br>15 (P) |
| | **51.47** | 14.6 | ***8.0*** | 4880 | 17.5 | ***9.5*** | 4830 | 28.2 | ***15.0*** | 4700 | 56 | ***28.7*** | 4520 | 11600 | |
| | **53.41** | 14.0 | ***7.8*** | 4920 | 16.9 | ***9.3*** | 4870 | 27.1 | ***14.5*** | 4740 | 54 | ***25.7*** | 4180 | 11600 | |
| | **63.05** | 11.9 | ***6.6*** | 4940 | 14.3 | ***7.9*** | 4880 | 23.0 | ***12.3*** | 4750 | 46.0 | ***23.7*** | 4570 | 11600 | |
| | **72.28** | 10.4 | ***5.9*** | 5020 | 12.5 | ***7.0*** | 4960 | 20.1 | ***10.9*** | 4820 | 40.1 | ***21.0*** | 4640 | 11600 | |
| | **77.24** | 9.7 | ***5.5*** | 4990 | 11.7 | ***6.5*** | 4940 | 18.8 | ***10.2*** | 4810 | 37.5 | ***19.6*** | 4620 | 11600 | |
| | **85.33** | 8.8 | ***5.0*** | 5020 | 10.5 | ***5.9*** | 4970 | 17.0 | ***9.3*** | 4840 | 34.0 | ***17.8*** | 4650 | 11600 | |
| | **104.53** | 7.2 | ***4.2*** | 5160 | 8.6 | ***4.9*** | 5030 | 13.9 | ***7.7*** | 4890 | 27.7 | ***14.7*** | 4700 | 11600 | |
| | **110.50** | 6.8 | ***4.0*** | 5220 | 8.1 | ***4.8*** | 5170 | 13.1 | ***7.3*** | 4940 | 26.2 | ***14.1*** | 4750 | 11600 | |
| | **130.45** | 5.7 | ***3.5*** | 5340 | 6.9 | ***4.0*** | 5200 | 11.1 | ***6.2*** | 4960 | 22.2 | ***12.0*** | 4760 | 11600 | |
| | **141.46** | 5.3 | ***2.7*** | 4520 | 6.4 | ***3.2*** | 4480 | 10.3 | ***5.0*** | 4360 | 20.5 | ***9.7*** | 4190 | 11300 | |
| | **163.71** | 4.6 | ***2.2*** | 4330 | 5.5 | ***2.6*** | 4220 | 8.9 | ***4.0*** | 4040 | 17.7 | ***7.8*** | 3890 | 9500 | |
| | **176.54** | 4.2 | ***2.2*** | 4580 | 5.1 | ***2.6*** | 4530 | 8.2 | ***4.1*** | 4410 | 16.4 | ***7.9*** | 4240 | 11300 | |
| | **190.31** | 3.9 | ***1.6*** | 3650 | 4.7 | ***1.9*** | 3550 | 7.6 | ***2.9*** | 3420 | 15.2 | ***5.7*** | 3290 | 8050 | |
| | **221.54** | 3.4 | ***1.7*** | 4540 | 4.1 | ***2.0*** | 4410 | 6.5 | ***3.0*** | 4120 | 13.1 | ***5.8*** | 3960 | 9500 | |
| | **257.54** | 2.9 | ***1.3*** | 3830 | 3.5 | ***1.5*** | 3720 | 5.6 | ***2.2*** | 3480 | 11.3 | ***4.3*** | 3340 | 8050 | |
| | **276.48** | 2.7 | ***1.3*** | 4140 | 3.3 | ***1.5*** | 4100 | 5.2 | ***2.4*** | 3990 | 10.5 | ***4.5*** | 3830 | 9500 | |
| | **321.41** | 2.3 | ***1.0*** | 3960 | 2.8 | ***1.2*** | 3850 | 4.5 | ***1.8*** | 3580 | 9.0 | ***3.5*** | 3390 | 8050 | |
| **RE 514** | **219.42** | 3.4 | ***2.3*** | 5780 | 4.1 | ***2.7*** | 5620 | 6.6 | ***4.0*** | 5230 | 13.2 | ***7.5*** | 4910 | 11600 | 7 (N)<br>8 (T)<br>5 (F)<br>12 (P) |
| | **268.80** | 2.8 | ***1.9*** | 5960 | 3.3 | ***2.2*** | 5800 | 5.4 | ***3.4*** | 5390 | 10.8 | ***6.2*** | 4960 | 11600 | |
| | **296.94** | 2.5 | ***1.8*** | 6050 | 3.0 | ***2.1*** | 5880 | 4.9 | ***3.1*** | 5470 | 9.8 | ***5.6*** | 4990 | 11600 | |
| | **329.29** | 2.3 | ***1.6*** | 6140 | 2.7 | ***1.9*** | 5980 | 4.4 | ***2.8*** | 5560 | 8.8 | ***5.1*** | 5020 | 11600 | |
| | **363.76** | 2.1 | ***1.5*** | 6240 | 2.5 | ***1.7*** | 6070 | 4.0 | ***2.6*** | 5650 | 8.0 | ***4.7*** | 5080 | 11600 | |
| | **416.98** | 1.8 | ***1.3*** | 6100 | 2.2 | ***1.5*** | 5940 | 3.5 | ***2.2*** | 5580 | 7.0 | ***4.3*** | 5340 | 11600 | |
| | **453.98** | 1.7 | ***1.2*** | 6450 | 2.0 | ***1.4*** | 6270 | 3.2 | ***2.2*** | 5840 | 6.4 | ***3.9*** | 5260 | 11600 | |
| | **492.27** | 1.5 | ***1.2*** | 6530 | 1.8 | ***1.3*** | 6350 | 2.9 | ***2.0*** | 5910 | 5.9 | ***3.6*** | 5320 | 11600 | |
| | **556.14** | 1.3 | ***1.0*** | 6650 | 1.6 | ***1.2*** | 6470 | 2.6 | ***1.8*** | 6020 | 5.2 | ***3.3*** | 5420 | 11600 | |
| | **614.35** | 1.2 | ***0.96*** | 6750 | 1.5 | ***1.1*** | 6570 | 2.4 | ***1.7*** | 6110 | 4.7 | ***3.0*** | 5500 | 11600 | |
| | **766.71** | 0.98 | ***0.64*** | 5670 | 1.2 | ***0.76*** | 5610 | 1.9 | ***1.2*** | 5460 | 3.8 | ***2.3*** | 5250 | 11600 | |
| | **939.26** | 0.80 | ***0.64*** | 6950 | 0.96 | ***0.76*** | 6880 | 1.5 | ***1.2*** | 6520 | 3.1 | ***2.1*** | 5870 | 11600 | |
| | **1018.49** | 0.74 | ***0.46*** | 5370 | 0.88 | ***0.53*** | 5220 | 1.4 | ***0.80*** | 4880 | 2.8 | ***1.5*** | 4690 | 11300 | |
| | **1178.68** | 0.64 | ***0.43*** | 5840 | 0.76 | ***0.50*** | 5680 | 1.2 | ***0.75*** | 5290 | 2.5 | ***1.4*** | 4760 | 9500 | |
| | **1271.08** | 0.59 | ***0.38*** | 5550 | 0.71 | ***0.44*** | 5400 | 1.1 | ***0.66*** | 5030 | 2.3 | ***1.3*** | 4750 | 11300 | |
| | **1595.08** | 0.47 | ***0.33*** | 6120 | 0.56 | ***0.39*** | 5950 | 0.91 | ***0.58*** | 5540 | 1.8 | ***1.1*** | 4990 | 9500 | |
| | **1854.28** | 0.40 | ***0.24*** | 5160 | 0.49 | ***0.28*** | 5020 | 0.78 | ***0.42*** | 4670 | 1.6 | ***0.76*** | 4200 | 8050 | |
| | **1990.66** | 0.38 | ***0.22*** | 5000 | 0.45 | ***0.25*** | 4860 | 0.73 | ***0.38*** | 4520 | 1.5 | ***0.72*** | 4290 | 9500 | |


| | | $n_1$= **750** RPM | | | $n_1$= **900** RPM | | | $n_1$= **1450** RPM | | | $n_1$= **2900** RPM | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | **ie** | **$n_2$** [RPM] | **$P_1$** [kW] | **$T_2$** [Nm] | **$n_2$** [RPM] | **$P_1$** [kW] | **$T_2$** [Nm] | **$n_2$** [RPM] | **$P_1$** [kW] | **$T_2$** [Nm] | **$n_2$** [RPM] | **$P_1$** [kW] | **$T_2$** [Nm] | **$T_{2max}$** [Nm] | **$P_t$** [kW] |
| **RA 512** | **10.03** | 75 | ***27.1*** | 3240 | 90 | ***30.8*** | 3070 | 145 | ***43.0*** | 2660 | 289 | ***70*** | 2160 | 11600 | 10 (N)<br>12 (T)<br>9 (F)<br>17 (P) |
| | **11.84** | 63 | ***27.1*** | 3820 | 76 | ***30.8*** | 3620 | 122 | ***43.0*** | 3140 | 245 | ***70*** | 2550 | 11600 | |
| | **14.40** | 52 | ***20.0*** | 3440 | 63 | ***22.8*** | 3260 | 101 | ***31.8*** | 2820 | 201 | ***51.7*** | 2290 | 10000 | |
| | **17.00** | 44.1 | ***20.0*** | 4060 | 53 | ***22.8*** | 3840 | 85 | ***31.8*** | 3330 | 171 | ***51.7*** | 2710 | 11600 | |
| | **20.89** | 35.9 | ***9.7*** | 2430 | 43.1 | ***11.6*** | 2400 | 69 | ***18.1*** | 2340 | 139 | ***34.9*** | 2250 | 6320 | |
| | **21.33** | 35.2 | ***14.7*** | 3740 | 42.2 | ***17.5*** | 3700 | 68 | ***27.4*** | 3600 | 136 | ***51.7*** | 3400 | 9500 | |
| | **24.80** | 30.2 | ***10.7*** | 3160 | 36.3 | ***12.7*** | 3130 | 58 | ***19.9*** | 3040 | 117 | ***38.3*** | 2930 | 8050 | |
| | **30.00** | 25.0 | ***6.9*** | 2480 | 30.0 | ***8.2*** | 2450 | 48.3 | ***12.9*** | 2390 | 97 | ***24.8*** | 2290 | 6320 | |
| **RA 513** | **40.09** | 18.7 | ***7.3*** | 3390 | 22.4 | ***8.6*** | 3350 | 36.2 | ***12.7*** | 3070 | 72 | ***20.7*** | 2490 | 8660 | 7 (N)<br>9 (T)<br>5 (F)<br>12 (P) |
| | **47.33** | 15.8 | ***7.3*** | 4000 | 19.0 | ***8.6*** | 3960 | 30.6 | ***12.7*** | 3630 | 61 | ***20.7*** | 2950 | 10300 | |
| | **49.11** | 15.3 | ***7.3*** | 4150 | 18.3 | ***8.6*** | 4110 | 29.5 | ***12.7*** | 3760 | 59 | ***20.7*** | 3060 | 10700 | |
| | **57.98** | 12.9 | ***7.3*** | 4900 | 15.5 | ***8.6*** | 4850 | 25.0 | ***12.7*** | 4440 | 50 | ***20.7*** | 3610 | 11600 | |
| | **66.46** | 11.3 | ***4.8*** | 3710 | 13.5 | ***5.7*** | 3670 | 21.8 | ***8.9*** | 3570 | 43.6 | ***17.2*** | 3430 | 9540 | |
| | **72.76** | 10.3 | ***4.7*** | 4010 | 12.4 | ***5.6*** | 3970 | 19.9 | ***8.8*** | 3860 | 39.9 | ***17.0*** | 3710 | 9500 | |
| | **78.46** | 9.6 | ***4.8*** | 4370 | 11.5 | ***5.7*** | 4330 | 18.5 | ***8.9*** | 4210 | 37.0 | ***17.2*** | 4050 | 11300 | |
| | **84.58** | 8.9 | ***3.4*** | 3390 | 10.6 | ***4.1*** | 3360 | 17.1 | ***6.4*** | 3270 | 34.3 | ***12.3*** | 3140 | 8050 | |
| | **98.46** | 7.6 | ***3.6*** | 4080 | 9.1 | ***4.2*** | 4040 | 14.7 | ***6.6*** | 3930 | 29.5 | ***12.8*** | 3780 | 9500 | |
| | **114.46** | 6.6 | ***2.6*** | 3450 | 7.9 | ***3.1*** | 3410 | 12.7 | ***4.8*** | 3320 | 25.3 | ***9.3*** | 3190 | 8050 | |
| | **122.88** | 6.1 | ***2.8*** | 3950 | 7.3 | ***3.3*** | 3910 | 11.8 | ***5.2*** | 3810 | 23.6 | ***9.9*** | 3660 | 9500 | |
| | **142.85** | 5.3 | ***2.1*** | 3500 | 6.3 | ***2.5*** | 3460 | 10.2 | ***3.9*** | 3360 | 20.3 | ***7.5*** | 3230 | 8050 | |
| | **172.80** | 4.3 | ***1.4*** | 2740 | 5.2 | ***1.6*** | 2710 | 8.4 | ***2.5*** | 2640 | 16.8 | ***4.9*** | 2530 | 6320 | |
| **RA 514** | **139.51** | 5.4 | ***3.4*** | 5440 | 6.5 | ***4.1*** | 5390 | 10.4 | ***6.1*** | 5020 | 20.8 | ***11.8*** | 4810 | 11600 | 6 (N)<br>7 (T)<br>5 (F)<br>11 (P) |
| | **164.70** | 4.6 | ***3.0*** | 5530 | 5.5 | ***3.5*** | 5380 | 8.8 | ***5.2*** | 5020 | 17.6 | ***10.0*** | 4830 | 11600 | |
| | **170.91** | 4.4 | ***2.8*** | 5350 | 5.3 | ***3.3*** | 5300 | 8.5 | ***5.1*** | 5150 | 17.0 | ***9.7*** | 4870 | 11600 | |
| | **201.77** | 3.7 | ***2.5*** | 5710 | 4.5 | ***2.9*** | 5550 | 7.2 | ***4.4*** | 5160 | 14.4 | ***8.3*** | 4880 | 11600 | |
| | **231.29** | 3.2 | ***2.1*** | 5600 | 3.9 | ***2.5*** | 5540 | 6.3 | ***4.0*** | 5400 | 12.5 | ***7.3*** | 4950 | 11600 | |
| | **247.17** | 3.0 | ***2.1*** | 5880 | 3.6 | ***2.5*** | 5720 | 5.9 | ***3.7*** | 5320 | 11.7 | ***6.8*** | 4940 | 11600 | |
| | **273.05** | 2.7 | ***1.9*** | 5970 | 3.3 | ***2.3*** | 5810 | 5.3 | ***3.4*** | 5410 | 10.6 | ***6.2*** | 4970 | 11600 | |
| | **310.18** | 2.4 | ***1.4*** | 4770 | 2.9 | ***1.6*** | 4640 | 4.7 | ***2.4*** | 4320 | 9.3 | ***4.4*** | 4030 | 9500 | |
| | **340.76** | 2.2 | ***1.4*** | 5410 | 2.6 | ***1.7*** | 5360 | 4.3 | ***2.6*** | 5210 | 8.5 | ***5.0*** | 5010 | 11600 | |
| | **417.45** | 1.8 | ***1.3*** | 6370 | 2.2 | ***1.6*** | 6200 | 3.5 | ***2.4*** | 5760 | 6.9 | ***4.2*** | 5190 | 11600 | |
| | **452.66** | 1.7 | ***0.94*** | 4830 | 2.0 | ***1.1*** | 4780 | 3.2 | ***1.8*** | 4660 | 6.4 | ***3.4*** | 4480 | 11300 | |
| | **497.11** | 1.5 | ***0.75*** | 4230 | 1.8 | ***0.88*** | 4110 | 2.9 | ***1.3*** | 3820 | 5.8 | ***2.4*** | 3470 | 8050 | |
| | **564.92** | 1.3 | ***0.77*** | 4910 | 1.6 | ***0.91*** | 4850 | 2.6 | ***1.4*** | 4720 | 5.1 | ***2.7*** | 4530 | 11300 | |
| | **608.98** | 1.2 | ***0.63*** | 4360 | 1.5 | ***0.74*** | 4240 | 2.4 | ***1.1*** | 3940 | 4.8 | ***2.0*** | 3550 | 8050 | |
| | **708.92** | 1.1 | ***0.67*** | 5410 | 1.3 | ***0.79*** | 5260 | 2.0 | ***1.2*** | 4900 | 4.1 | ***2.1*** | 4410 | 9500 | |
| | **824.12** | 0.91 | ***0.49*** | 4560 | 1.1 | ***0.57*** | 4440 | 1.8 | ***0.85*** | 4130 | 3.5 | ***1.5*** | 3720 | 8050 | |
| | **884.74** | 0.85 | ***0.44*** | 4420 | 1.0 | ***0.52*** | 4380 | 1.6 | ***0.82*** | 4260 | 3.3 | ***1.6*** | 4100 | 9500 | |
| | **1028.51** | 0.73 | ***0.40*** | 4720 | 0.88 | ***0.47*** | 4590 | 1.4 | ***0.71*** | 4270 | 2.8 | ***1.3*** | 3840 | 8050 | |
| | **1244.16** | 0.60 | ***0.26*** | 3680 | 0.72 | ***0.31*** | 3580 | 1.2 | ***0.46*** | 3340 | 2.3 | ***0.82*** | 3000 | 6320 | |

# RE 610


| | | $n_1$= **750** RPM | | | $n_1$= **900** RPM | | | $n_1$= **1450** RPM | | | $n_1$= **2900** RPM | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | **ie** | **$n_2$** [RPM] | **$P_1$** [kW] | **$T_2$** [Nm] | **$n_2$** [RPM] | **$P_1$** [kW] | **$T_2$** [Nm] | **$n_2$** [RPM] | **$P_1$** [kW] | **$T_2$** [Nm] | **$n_2$** [RPM] | **$P_1$** [kW] | **$T_2$** [Nm] | **$T_{2max}$** [Nm] | **$P_t$** [kW] |
| **RE 611** | **4.00** | 188 | ***93*** | 4630 | 225 | ***106*** | 4380 | 363 | ***148*** | 3800 | 725 | ***240*** | 3080 | 14900 | 20 (N)<br>24 (T) |
| | **4.55** | 165 | ***84*** | 4730 | 198 | ***95*** | 4480 | 319 | ***133*** | 3880 | 638 | ***216*** | 3160 | 12860 | 14 (F)<br>37 (P) |
| **RE 612** | **14.40** | 52 | ***34.3*** | 5970 | 63 | ***40.7*** | 5910 | 101 | ***62*** | 5580 | 201 | ***100*** | 4530 | 14900 | |
| | **16.36** | 45.8 | ***26.8*** | 5320 | 55 | ***31.9*** | 5260 | 89 | ***50*** | 5120 | 177 | ***90*** | 4630 | 12860 | |
| | **17.00** | 44.1 | ***29.3*** | 6030 | 53 | ***34.8*** | 5970 | 85 | ***55*** | 5810 | 171 | ***89*** | 4760 | 14900 | |
| | **19.32** | 38.8 | ***23.0*** | 5370 | 46.6 | ***27.3*** | 5310 | 75 | ***42.7*** | 5170 | 150 | ***81*** | 4870 | 12860 | 15 (N) |
| | **21.33** | 35.2 | ***23.6*** | 6110 | 42.2 | ***28.1*** | 6040 | 68 | ***44.0*** | 5880 | 136 | ***76*** | 5100 | 14900 | 14 (T)<br>9 (F) |
| | **24.24** | 30.9 | ***18.5*** | 5440 | 37.1 | ***22.0*** | 5380 | 60 | ***34.5*** | 5240 | 120 | ***66*** | 5030 | 12860 | 22 (P) |
| | **28.18** | 26.6 | ***16.1*** | 5490 | 31.9 | ***19.1*** | 5430 | 51 | ***29.9*** | 5280 | 103 | ***58*** | 5080 | 12860 | |
| | **30.00** | 25.0 | ***12.2*** | 4440 | 30.0 | ***14.5*** | 4400 | 48.3 | ***22.8*** | 4280 | 97 | ***43.8*** | 4110 | 12300 | |
| | **34.09** | 22.0 | ***12.2*** | 5050 | 26.4 | ***14.5*** | 5000 | 42.5 | ***22.8*** | 4860 | 85 | ***43.8*** | 4670 | 12860 | |
| **RE 613** | **50.11** | 15.0 | ***10.8*** | 6410 | 18.0 | ***12.9*** | 6350 | 28.9 | ***20.2*** | 6180 | 58 | ***38.8*** | 5940 | 14900 | |
| | **56.95** | 13.2 | ***8.5*** | 5710 | 15.8 | ***10.1*** | 5650 | 25.5 | ***15.8*** | 5500 | 51 | ***30.4*** | 5290 | 12860 | |
| | **61.39** | 12.2 | ***9.0*** | 6490 | 14.7 | ***10.6*** | 6420 | 23.6 | ***16.7*** | 6250 | 47.2 | ***32.0*** | 6000 | 14900 | |
| | **69.76** | 10.8 | ***7.0*** | 5780 | 12.9 | ***8.3*** | 5720 | 20.8 | ***13.1*** | 5560 | 41.6 | ***25.1*** | 5350 | 12860 | |
| | **82.36** | 9.1 | ***6.0*** | 5830 | 10.9 | ***7.1*** | 5770 | 17.6 | ***11.2*** | 5620 | 35.2 | ***21.5*** | 5400 | 12860 | |
| | **90.95** | 8.2 | ***6.2*** | 6630 | 9.9 | ***7.3*** | 6570 | 15.9 | ***11.5*** | 6390 | 31.9 | ***22.1*** | 6140 | 14900 | 9 (N) |
| | **98.08** | 7.6 | ***5.8*** | 6660 | 9.2 | ***6.8*** | 6590 | 14.8 | ***10.7*** | 6420 | 29.6 | ***20.6*** | 6170 | 14900 | 10 (T)<br>7 (F) |
| | **111.45** | 6.7 | ***4.5*** | 5930 | 8.1 | ***5.4*** | 5870 | 13.0 | ***8.4*** | 5710 | 26.0 | ***16.1*** | 5490 | 12860 | 17 (P) |
| | **123.08** | 6.1 | ***4.7*** | 6830 | 7.3 | ***5.5*** | 6680 | 11.8 | ***8.7*** | 6500 | 23.6 | ***16.6*** | 6250 | 14900 | |
| | **139.86** | 5.4 | ***3.7*** | 6060 | 6.4 | ***4.3*** | 5950 | 10.4 | ***6.8*** | 5790 | 20.7 | ***13.0*** | 5560 | 12860 | |
| | **153.60** | 4.9 | ***3.9*** | 7070 | 5.9 | ***4.6*** | 6870 | 9.4 | ***7.0*** | 6580 | 18.9 | ***13.5*** | 6330 | 14900 | |
| | **174.55** | 4.3 | ***3.0*** | 6270 | 5.2 | ***3.6*** | 6100 | 8.3 | ***5.5*** | 5860 | 16.6 | ***10.6*** | 5640 | 12860 | |
| | **202.91** | 3.7 | ***2.7*** | 6410 | 4.4 | ***3.1*** | 6240 | 7.1 | ***4.8*** | 5910 | 14.3 | ***9.2*** | 5680 | 12860 | |
| **RE 614** | **174.39** | 4.3 | ***3.6*** | 7200 | 5.2 | ***4.2*** | 7010 | 8.3 | ***6.4*** | 6630 | 16.6 | ***12.3*** | 6370 | 14900 | |
| | **205.88** | 3.6 | ***3.1*** | 7390 | 4.4 | ***3.6*** | 7190 | 7.0 | ***5.5*** | 6690 | 14.1 | ***10.5*** | 6430 | 14900 | |
| | **233.95** | 3.2 | ***2.4*** | 6550 | 3.8 | ***2.8*** | 6380 | 6.2 | ***4.3*** | 5960 | 12.4 | ***8.2*** | 5730 | 12860 | |
| | **252.21** | 3.0 | ***2.6*** | 7620 | 3.6 | ***3.1*** | 7410 | 5.7 | ***4.6*** | 6890 | 11.5 | ***8.7*** | 6510 | 14900 | |
| | **286.60** | 2.6 | ***2.0*** | 6760 | 3.1 | ***2.4*** | 6570 | 5.1 | ***3.6*** | 6120 | 10.1 | ***6.8*** | 5800 | 12860 | |
| | **316.50** | 2.4 | ***2.1*** | 7820 | 2.8 | ***2.5*** | 7670 | 4.6 | ***3.8*** | 7140 | 9.2 | ***7.0*** | 6590 | 14900 | |
| | **354.17** | 2.1 | ***2.0*** | 8020 | 2.5 | ***2.3*** | 7800 | 4.1 | ***3.4*** | 7260 | 8.2 | ***6.3*** | 6640 | 14900 | |
| | **402.47** | 1.9 | ***1.5*** | 7110 | 2.2 | ***1.8*** | 6920 | 3.6 | ***2.7*** | 6440 | 7.2 | ***4.9*** | 5910 | 12860 | |
| | **450.73** | 1.7 | ***1.3*** | 6680 | 2.0 | ***1.5*** | 6610 | 3.2 | ***2.4*** | 6430 | 6.4 | ***4.6*** | 6180 | 14900 | 7 (N) |
| | **502.28** | 1.5 | ***1.3*** | 7360 | 1.8 | ***1.5*** | 7160 | 2.9 | ***2.2*** | 6660 | 5.8 | ***4.0*** | 6000 | 12860 | 9 (T)<br>6 (F) |
| | **565.83** | 1.3 | ***1.3*** | 8610 | 1.6 | ***1.5*** | 8370 | 2.6 | ***2.3*** | 7790 | 5.1 | ***4.2*** | 7020 | 14900 | 13 (P) |
| | **642.99** | 1.2 | ***1.0*** | 7640 | 1.4 | ***1.2*** | 7430 | 2.3 | ***1.8*** | 6910 | 4.5 | ***3.3*** | 6220 | 12860 | |
| | **706.15** | 1.1 | ***1.1*** | 8900 | 1.3 | ***1.3*** | 8660 | 2.1 | ***1.9*** | 8060 | 4.1 | ***3.5*** | 7250 | 14900 | |
| | **802.45** | 0.93 | ***0.86*** | 7900 | 1.1 | ***1.0*** | 7680 | 1.8 | ***1.5*** | 7150 | 3.6 | ***2.7*** | 6440 | 12860 | |
| | **886.15** | 0.85 | ***0.86*** | 8810 | 1.0 | ***1.0*** | 8570 | 1.6 | ***1.5*** | 7990 | 3.3 | ***2.8*** | 7510 | 14900 | |
| | **1006.99** | 0.74 | ***0.71*** | 8170 | 0.89 | ***0.82*** | 7950 | 1.4 | ***1.2*** | 7400 | 2.9 | ***2.2*** | 6660 | 12860 | |
| | **1105.92** | 0.68 | ***0.64*** | 8180 | 0.81 | ***0.76*** | 8100 | 1.3 | ***1.2*** | 7880 | 2.6 | ***2.3*** | 7570 | 14900 | |
| | **1256.73** | 0.60 | ***0.58*** | 8450 | 0.72 | ***0.68*** | 8220 | 1.2 | ***1.0*** | 7650 | 2.3 | ***1.8*** | 6890 | 12860 | |
| | **1416.08** | 0.53 | ***0.40*** | 6590 | 0.64 | ***0.47*** | 6410 | 1.0 | ***0.71*** | 6020 | 2.0 | ***1.4*** | 5780 | 12860 | |


| | | $n_1$= **750** RPM | | | $n_1$= **900** RPM | | | $n_1$= **1450** RPM | | | $n_1$= **2900** RPM | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | **ie** | **$n_2$** [RPM] | **$P_1$** [kW] | **$T_2$** [Nm] | **$n_2$** [RPM] | **$P_1$** [kW] | **$T_2$** [Nm] | **$n_2$** [RPM] | **$P_1$** [kW] | **$T_2$** [Nm] | **$n_2$** [RPM] | **$P_1$** [kW] | **$T_2$** [Nm] | **$T_{2max}$** [Nm] | **$P_t$** [kW] |
| **RA 612** | **11.14** | 67 | ***27.1*** | 3600 | 81 | ***30.8*** | 3410 | 130 | ***43.0*** | 2950 | 260 | ***70*** | 2400 | 14900 | 11 (N)<br>12 (T)<br>9 (F)<br>16 (P) |
| | **12.66** | 59 | ***27.1*** | 4090 | 71 | ***30.8*** | 3870 | 115 | ***43.0*** | 3350 | 229 | ***70*** | 2720 | 12800 | |
| | **16.00** | 46.9 | ***20.0*** | 3820 | 56 | ***22.8*** | 3620 | 91 | ***31.8*** | 3140 | 181 | ***51.7*** | 2550 | 11100 | |
| | **18.18** | 41.3 | ***20.0*** | 4340 | 49.5 | ***22.8*** | 4110 | 80 | ***31.8*** | 3560 | 160 | ***51.7*** | 2890 | 12800 | |
| **RA 613** | **40.11** | 18.7 | ***13.6*** | 6330 | 22.4 | ***16.1*** | 6270 | 36.1 | ***25.3*** | 6100 | 72 | ***48.6*** | 5860 | 14900 | 9 (N)<br>10 (T)<br>8 (F)<br>14 (P) |
| | **45.58** | 16.5 | ***10.6*** | 5640 | 19.7 | ***12.6*** | 5580 | 31.8 | ***19.8*** | 5430 | 64 | ***38.1*** | 5220 | 12800 | |
| | **47.36** | 15.8 | ***11.6*** | 6390 | 19.0 | ***13.8*** | 6330 | 30.6 | ***21.6*** | 6160 | 61 | ***41.6*** | 5920 | 14900 | |
| | **57.60** | 13.0 | ***9.7*** | 6460 | 15.6 | ***11.5*** | 6400 | 25.2 | ***18.0*** | 6220 | 50 | ***34.6*** | 5980 | 14900 | |
| | **65.45** | 11.5 | ***7.6*** | 5760 | 13.8 | ***9.0*** | 5700 | 22.2 | ***14.1*** | 5540 | 44.3 | ***27.1*** | 5330 | 12800 | |
| | **68.00** | 11.0 | ***8.3*** | 6530 | 13.2 | ***9.8*** | 6460 | 21.3 | ***15.4*** | 6280 | 42.6 | ***29.6*** | 6040 | 14900 | |
| | **78.51** | 9.6 | ***6.4*** | 5820 | 11.5 | ***7.6*** | 5760 | 18.5 | ***11.9*** | 5600 | 36.9 | ***22.8*** | 5380 | 12800 | |
| | **85.33** | 8.8 | ***6.7*** | 6610 | 10.5 | ***7.9*** | 6540 | 17.0 | ***12.4*** | 6370 | 34.0 | ***23.9*** | 6120 | 14900 | |
| | **96.97** | 7.7 | ***5.2*** | 5890 | 9.3 | ***6.2*** | 5830 | 15.0 | ***9.7*** | 5670 | 29.9 | ***18.7*** | 5450 | 12800 | |
| | **112.73** | 6.7 | ***4.5*** | 5940 | 8.0 | ***5.4*** | 5880 | 12.9 | ***8.4*** | 5720 | 25.7 | ***16.2*** | 5500 | 12800 | |
| **RA 614** | **160.36** | 4.7 | ***3.9*** | 7110 | 5.6 | ***4.6*** | 6920 | 9.0 | ***7.0*** | 6600 | 18.1 | ***13.5*** | 6340 | 14900 | 6 (N)<br>7 (T)<br>5 (F)<br>11 (P) |
| | **182.23** | 4.1 | ***3.1*** | 6310 | 4.9 | ***3.6*** | 6140 | 8.0 | ***5.5*** | 5880 | 15.9 | ***10.6*** | 5650 | 12800 | |
| | **196.45** | 3.8 | ***3.3*** | 7330 | 4.6 | ***3.8*** | 7140 | 7.4 | ***5.8*** | 6680 | 14.8 | ***11.1*** | 6420 | 14900 | |
| | **231.92** | 3.2 | ***2.9*** | 7520 | 3.9 | ***3.3*** | 7320 | 6.3 | ***5.0*** | 6810 | 12.5 | ***9.5*** | 6480 | 14900 | |
| | **263.54** | 2.8 | ***2.2*** | 6670 | 3.4 | ***2.6*** | 6490 | 5.5 | ***3.9*** | 6040 | 11.0 | ***7.5*** | 5770 | 12800 | |
| | **291.03** | 2.6 | ***2.4*** | 7780 | 3.1 | ***2.8*** | 7570 | 5.0 | ***4.1*** | 7050 | 10.0 | ***7.7*** | 6560 | 14900 | |
| | **313.85** | 2.4 | ***2.2*** | 7870 | 2.9 | ***2.6*** | 7660 | 4.6 | ***3.9*** | 7130 | 9.2 | ***7.2*** | 6590 | 14900 | |
| | **356.64** | 2.1 | ***1.7*** | 6990 | 2.5 | ***2.0*** | 6800 | 4.1 | ***3.0*** | 6320 | 8.1 | ***5.6*** | 5870 | 12800 | |
| | **393.85** | 1.9 | ***1.8*** | 7920 | 2.3 | ***2.1*** | 7840 | 3.7 | ***3.2*** | 7380 | 7.4 | ***5.8*** | 6680 | 14900 | |
| | **447.55** | 1.7 | ***1.4*** | 7230 | 2.0 | ***1.7*** | 7030 | 3.2 | ***2.5*** | 6540 | 6.5 | ***4.5*** | 5950 | 12800 | |
| | **491.52** | 1.5 | ***1.4*** | 7810 | 1.8 | ***1.7*** | 7730 | 3.0 | ***2.6*** | 7520 | 5.9 | ***4.8*** | 6870 | 14900 | |
| | **558.55** | 1.3 | ***1.2*** | 7480 | 1.6 | ***1.4*** | 7270 | 2.6 | ***2.1*** | 6770 | 5.2 | ***3.7*** | 6090 | 12800 | |
| | **629.37** | 1.2 | ***0.84*** | 5960 | 1.4 | ***0.99*** | 5900 | 2.3 | ***1.6*** | 5740 | 4.6 | ***3.0*** | 5520 | 12800 | |

## N (110-210-310-510-810) - P (110-210-310-510-610)




## T (240-310-510-810-1020-1520-2000) - TL (310-510) - P (810-1020)




n2 x h = 100000










**Fa2** [N]

| RE-RA | FS | | N | | P | | T | | TL | |
|---|---|---|---|---|---|---|---|---|---|---|
| | Fa2 (-) | Fa2 (+) | Fa2 (-) | Fa2 (+) | Fa2 (-) | Fa2 (+) | Fa2 (-) | Fa2 (+) | Fa2 (-) | Fa2 (+) |
| **110** | 6800 | 6800 | 19250 | 19250 | 19250 | 19250 | 22500 | 35500 | — | — |
| **210** | 6800 | 6800 | 19250 | 19250 | 19250 | 19250 | 22500 | 35500 | — | — |
| **240** | 7350 | 7350 | — | — | — | — | 25700 | 34400 | — | — |
| **310** | 10500 | 10500 | 39500 | 39500 | 58400 | 58400 | 57500 | 78500 | 48500 | 48500 |
| **510** | 10500 | 10500 | 39500 | 39500 | 58400 | 58400 | 57500 | 78500 | 48500 | 48500 |
| **610** | 10500 | 10500 | 39500 | 39500 | 58400 | 58400 | 57500 | 78500 | 48500 | 48500 |
| **810** | 21500 | 21500 | 58400 | 58400 | 58400 | 88500 | 58400 | 88500 | — | — |
| **1020** | 19000 | 19000 | — | — | 58400 | 88000 | 60500 | 104500 | — | — |
| **1520** | 27000 | 27000 | — | — | — | — | 73400 | 104500 | — | — |
| **2000** | 27000 | 27000 | — | — | — | — | 73400 | 104500 | — | — |

| | $n_2$ x h | | | | | | |
|---|---|---|---|---|---|---|---|
| | 20000 | 40000 | 60000 | 80000 | 100000 | 200000 | 400000 |
| $K_f$ | 1.7 | 1.3 | 1.15 | 1.06 | 1 | 0.8 | 0.63 |

# Simbologia e unità di misura

| Simbolo | Unità di misura | Descrizione |
|---|---|---|
| $_1$ | | valore riferito all'ingresso |
| $_2$ | | valore riferito all'uscita |
| **bu** | mm | altezza fascia dentata |
| **de** | mm | diametro esterno |
| **dp** | mm | diametro primitivo teorico |
| **fa** | N | carico assiale |
| $\mathbf{f_{amax}}$ | N | carico assiale massimo |
| $\mathbf{f_r}$ | N | carico radiale |
| **H** | mm | altezza pignone |
| $\mathbf{i_e}$ | - | rapporto di riduzione effettivo |
| **m** | mm | modulo |
| **n** | RPM | velocità |
| $\mathbf{n_{max}}$ | RPM | velocità massima |
| **nxh** | RPMxh | indice di durata |
| $\mathbf{P_1}$ | kW | potenza nominale |
| **pb** | bar | pressione apertura freno |
| **pmax** | bar | pressione massima freno |
| $\mathbf{P_t}$ | kW | potenza termica |
| **T** | Nm | coppia |
| $\mathbf{T_b}$ | Nm | coppia frenante |
| $\mathbf{T_{max}}$ | Nm | coppia massima |
| **X** | mm | distanza applicazione carico |
| **x** | - | correzione dentatura |
| **z** | - | numero di denti |

| Simbolo | Descrizione |
|---|---|
|  | Supporto in uscita |
|  | Entrata |
|  | Supporto in entrata |
|  ...Nm | Coppia di serraggio [Nm] |
|  | Quantità d'olio [litri] |
|  | Peso [kg] |
|  | Carico olio / sfiato |
|  | Livello olio |
|  | Scarico olio |
|  | Motori idraulici |
|  | Motori elettrici |
|  | Riduttore a vite senza fine |
|  M.. - 10.9<br>M.. - 12.9 | Vite di fissaggio raccomandata |

# Definizioni tecniche

Tutti i valori prestazionali indicati nel presente catalogo sono calcolati secondo le normative ISO 6336 e ISO 281,ma potrebbero non rispondere a ulteriori requisiti richiesti dai regolamenti interni degli Enti certificatori. Per selezioni in accordo con tali regolamenti contattare il servizio commerciale Dinamic Oil.

## $f_S$ - Fattore di servizio

è il fattore che tiene conto della gravosità dell'applicazione; dipende dalle condizioni di funzionamento, dal tipo di azionamento e dalla frequenza degli avviamenti.
I dati forniti nel presente catalogo sono calcolati per $f_s = 1$.
Il valore del fattore di servizio di un riduttore è calcolabile dividendo la sua potenza nominale per la potenza assorbita.

**Fattori di servizio**

| | CONDIZIONI DI FUNZIONAMENTO | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|
| | Uniforme U | | | Variabile con urti moderati M | | | Variabile con urti forti H | | |
| ore / giorno | AVVIAMENTI / ORA | | | | | | | | |
| | < 16 | 16 - 63 | 64 - 250 | < 16 | 16 - 63 | 64- 250 | < 16 | 16 - 63 | 64 - 250 |
| **< 0.5** | 0.9 | 1.3 | 1.5 | 0.9 | 1.3 | 1.5 | 1.2 | 1.5 | 1.8 |
| **0.5 - 3** | 0.9 | 1.3 | 1.5 | 1.2 | 1.5 | 1.8 | 1.7 | 2.0 | 2.3 |
| **3 - 8** | 1.2 | 1.5 | 1.8 | 1.4 | 1.8 | 2.0 | 1.9 | 2.3 | 2.8 |
| **8 - 24** | 1.4 | 1.8 | 2.0 | 1.7 | 2.0 | 2.5 | 2.4 | 2.8 | 3.0 |

## $P_1$ - Potenza nominale [kW]

è la potenza meccanica trasmissibile dal riduttore, riferita all'ingresso, alla quale con $f_s = 1$ il riduttore ha una durate di vita teorica pari a 10.000 ore secondo la norma ISO 6336. Tale valore non tiene conto di eventuali limiti di capacità termica del riduttore, ma si basa esclusivamente sulla tenuta meccanica in funzione della velocità di utilizzo.

## $P_a$ - Potenza assorbita [kW]

rispetto alla potenza installata o disponibile, è il valore di potenza realmente assorbita dall'applicazione, riferita all'ingresso del riduttore.

## $P_t$ - Potenza termica [kW]

è la massima potenza meccanica che il riduttore può trasmettere in funzionamento continuo, con lubrificazione a sbattimento, senza oltrepassare il livello termico limite (temperatura dell'olio non superiore a 90°C).
Potenze superiori possono essere trasmesse utilizzando tenute in viton e oli sintetici o appositi dispositivi di raffreddamento.
I valori indicati per le varie grandezze di riduttore si riferiscono ad un funzionamento continuo con velocità in ingresso di 1500 RPM, temperatura ambiente di 20°C, altitudine 0 / 500 m, applicazione al coperto.
Per diverse condizioni di impiego il valore di potenza termica deve essere moltiplicato per i fattori termici indicati nella seguente tabella. Per periodi di funzionamento limitati, seguiti da periodi di riposo sufficientemente lunghi da garantire un opportuno raffreddamento del riduttore, la potenza termica perde il suo significato e può essere trascurata.

**Fattori termici**

| Temperatura ambiente | Tempo di funzionamento [%] | | | | |
|---|---|---|---|---|---|
| | 100% | 80% | 60% | 40% | 20% |
| **10°** | 1.2 | 1.3 | 1.4 | 1.6 | 1.8 |
| **20°** | 1.0 | 1.1 | 1.3 | 1.4 | 1.6 |
| **30°** | 0.8 | 1.0 | 1.1 | 1.3 | 1.4 |
| **40°** | 0.7 | 0.8 | 1.0 | 1.1 | 1.3 |
| **50°** | 0.5 | 0.7 | 0.8 | 1.0 | 1.1 |

| Altitudine [m] | Velocità in ingresso [RPM] | | | | |
|---|---|---|---|---|---|
| | 400 | 800 | 1000 | 1500 | 2000 |
| **0** | 1.2 | 1.1 | 1.1 | 1.0 | 0.7 |
| **500** | 1.2 | 1.1 | 1.1 | 1.0 | 0.7 |
| **1000** | 1.1 | 1.0 | 1.0 | 0.9 | 0.6 |
| **1500** | 1.1 | 1.0 | 1.0 | 0.9 | 0.6 |
| **2000** | 1.1 | 1.0 | 1.0 | 0.9 | 0.6 |

## $P_d$ - Potenza da dissipare [kW]
rappresenta la potenza che un eventuale sistema di raffreddamento deve dissipare, nel caso in cui la potenza da trasmettere sia superiore alla potenza termica del riduttore.

## $\eta_m$ - Rendimento meccanico
è il rapporto tra potenza meccanica in uscita e potenza meccanica in ingresso; normalmente è considerato pari a 0.97 – 0.98 per ogni stadio di riduzione epicicloidale di cui è composto il riduttore e pari a 0.94 - 0.95 per l'eventuale coppia conica; il valore effettivo dipende da diversi fattori tra quali velocità, coppia, rapporto, posizione di montaggio e lubrificazione.

## $T_2$ - Coppia trasmessa [Nm]
è il valore di coppia applicata in continuo alla velocità $n_1$, alla quale il riduttore ha una durata di vita teorica di 10000 h per gli ingranaggi e 5000 h ($L_{h10}$) per i cuscinetti dell' ingranaggeria.

## $T_{max}$ - Coppia massima trasmissibile [Nm]
è la coppia massima trasmissibile dall'accessorio eventualmente fornito a corredo del riduttore. Questo valore potrebbe limitare la coppia massima trasmissibile dal riduttore.

## $T_{2max}$ - Coppia massima [Nm]
è la coppia massima d'uscita ammissibile come punta o per brevi durate (calcolata al 90% Rs del componente più debole). Per azionamenti che comportano un elevato numero di avviamenti o inversioni occorre considerare valori di coppia massima apportunamente ridotti.
Il valore indicato si riferisce alla versione con albero femmina scanalato (FS); versioni diverse potrebbero avere valori inferiori.

## $T_b$ - Coppia frenante [Nm]
è il valore della coppia frenante trasmissibile staticamente dal freno negativo.

## $n_1$ - Velocità in ingresso [RPM]
è la velocità al lato veloce del riduttore.

## $n_2$ - Velocità in uscita [RPM]
è la velocità al lato lento del riduttore.

## $n_{1max}$ - Velocità massima [RPM]
è la velocità massima in ingresso al freno. Per applicazioni con valori superiori rivolgersi al servizio commerciale Dinamic Oil per verificare la compatibilità con l'applicazione.

## $i_e$ - Rapporto di riduzione effettivo
è il rapporto di riduzione effettivo, cioè il rapporto tra la velocità di ingresso e quella di uscita dal riduttore.

## nxh - Indice di durata [RPMxh]
è il valore che equivale al prodotto tra la velocità e la durata di vita teorica espressa in ore. É espresso come $n_2$xh quando riferito alla velocità in uscita, come $n_1$xh quando riferito alla velocità in ingresso.

**Valori indicativi delle durate richieste per diverse applicazioni**

| Applicazione | Ore di vita richieste |
|---|---|
| Macchine agricole | 300 - 3000 |
| Macchine con funzionamento intermittente o per brevi periodi (macchine per l'edilizia) | 3000 - 8000 |
| Macchine con funzionamento intermittente o per brevi periodi con alta affidabilità operativa (montacarichi) | 8000 - 12000 |
| Macchine con funzionamento per 8 ore al giorno, ma non pienamente utilizzate (macchine varie per l'industria, frantoi rotativi) | 10000 - 25000 |
| Macchine con funzionamento per 8 ore al giorno pienamente utilizzate (macchine varie per l'industria, nastri trasportatori) | 20000 - 30000 |
| Macchine con funzionamento continuo (laminatoi, macchine tessili) | 40000 - 50000 |










## $k_f$ - Fattore di correzione
è il fattore da applicare per calcolare la durata teorica dei supporti con alberi maschio per valori di nxh diversi da quelli dei diagrammi riportati nel catalogo. Per tutti i riduttori le curve dei carichi esterni sono calcolate per:
- $n_2$xh = 100.000 per i supporti in uscita
- $n_1$xh = 1.500.000 per i supporti in ingresso

## $L_{min}$ - Lunghezza minima del braccio di reazione [mm]
è la lunghezza minima consigliata per il braccio di reazione da realizzarsi nelle applicazioni di tipo pendolare.

dinamic oil

# Symbols and Unit of Measurement

| Symbol | Unit of measurement | Description |
|---|---|---|
| $_1$ | | Input value |
| $_2$ | | Output value |
| **bu** | mm | Height of toothed set |
| **de** | mm | External diameter |
| **dp** | mm | Theoretical primitive diameter |
| **fa** | N | Axial load |
| $f_{amax}$ | N | Maximum axial load |
| $f_r$ | N | Radial load |
| **H** | mm | Pinion height |
| $i_e$ | - | Effective reduction ratio |
| **m** | mm | Module |
| **n** | RPM | Speed |
| $n_{max}$ | RPM | Maximum speed |
| **nxh** | RPMxh | Duration index |
| $P_1$ | kW | Rated power |
| **pb** | bar | Brake opening pressure |
| **pmax** | bar | Maximum brake pressure |
| $P_t$ | kW | Thermal power |
| **T** | Nm | Torque |
| $T_b$ | Nm | Braking torque |
| $T_{max}$ | Nm | Maximum torque |
| **X** | mm | Load application distance |
| **x** | - | Tooth correction |
| **z** | - | Number of teeth |

| Symbol | Description |
|---|---|
|  | Support at output |
|  | Input |
|  | Support at input |
|  ...Nm | Tightening torque [Nm] |
|   | Oil quantity [liters] |
|   | Weight [kg] |
|  | Oil fill / breather plug |
|  | Oil level |
|  | Oil drain |
|  | Hydraulic motors |
|  | Electrical motors |
|  | Wormgearbox |
|   | Recommended screw |

# Technical Definitions

All values specified in this catalogue were calculated using the ISO 6336 and ISO 281 standards, but may not meet additional requirements set by the internal regulations of certifying bodies.
To select products that comply with these regulations, contact Dinamic Oil's sales team.

## $f_S$ - Service Factor

this factor represents the application's industrial rating; it depends on operating conditions, type of drive and frequency of start-up.
The information provided in this catalog is calculated for $f_s = 1$. The service factor value of a gearbox may be calculated by dividing its nominal power by its absorbed power.

**Service factors**

| | OPERATING CONDITIONS | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|
| | **Uniform U** | | | With moderate shocks **M** | | | With heavy shocks **H** | | |
| hours / day | START-UPS / HOUR | | | | | | | | |
| | **< 16** | **16 - 63** | **64 - 250** | **< 16** | **16 - 63** | **64- 250** | **< 16** | **16 - 63** | **64 - 250** |
| **< 0.5** | 0.9 | 1.3 | 1.5 | 0.9 | 1.3 | 1.5 | 1.2 | 1.5 | 1.8 |
| **0.5 - 3** | 0.9 | 1.3 | 1.5 | 1.2 | 1.5 | 1.8 | 1.7 | 2.0 | 2.3 |
| **3 - 8** | 1.2 | 1.5 | 1.8 | 1.4 | 1.8 | 2.0 | 1.9 | 2.3 | 2.8 |
| **8 - 24** | 1.4 | 1.8 | 2.0 | 1.7 | 2.0 | 2.5 | 2.4 | 2.8 | 3.0 |

## $P_1$ - Nominal Power [kW]

the mechanical power transmitted by the gearbox, related to input. At fs = 1 the gearbox has a theoretical lifetime of 10000 hours under the ISO 6336 standard. This value does not take into account any limits on the gearbox's thermal capacity, as it is exclusively based on mechanical resistance in accordance with the speed of use.

## $P_a$ - Absorbed Power [kW]

relates to installed or available power, the amount of power actually absorbed by the application, at the gearbox input

## $P_t$ - Thermal Power [kW]

the maximum mechanical power the gearbox can transmit while in continuous operation, with splash lubrication, without going beyond its maximum temperature level (oil temperature below 90°C). More power may be transmitted using a Viton seal and synthetic oils or special cooling devices. The values indicated for various gearbox sizes refer to continuous operation with input speeds of 1500 RPM, at an ambient temperature of 20°C and an altitude of 0 / 500 m, for indoor applications.
Under different conditions of use, thermal power must be multiplied by the thermal factors identified in the tables below. For limited periods of operation, followed by periods of rest long enough to guarantee sufficient cooling of the gearbox, thermal power loses its significance and may be neglected.

**Thermal Factors**

| Ambient Temperature | Operating Time [%] | | | | |
|---|---|---|---|---|---|
| | 100% | 80% | 60% | 40% | 20% |
| 10° | 1.2 | 1.3 | 1.4 | 1.6 | 1.8 |
| 20° | 1.0 | 1.1 | 1.3 | 1.4 | 1.6 |
| 30° | 0.8 | 1.0 | 1.1 | 1.3 | 1.4 |
| 40° | 0.7 | 0.8 | 1.0 | 1.1 | 1.3 |
| 50° | 0.5 | 0.7 | 0.8 | 1.0 | 1.1 |

| Altitude [m] | Input Speed [RPM] | | | | |
|---|---|---|---|---|---|
| | 400 | 800 | 1000 | 1500 | 2000 |
| 0 | 1.2 | 1.1 | 1.1 | 1.0 | 0.7 |
| 500 | 1.2 | 1.1 | 1.1 | 1.0 | 0.7 |
| 1000 | 1.1 | 1.0 | 1.0 | 0.9 | 0.6 |
| 1500 | 1.1 | 1.0 | 1.0 | 0.9 | 0.6 |
| 2000 | 1.1 | 1.0 | 1.0 | 0.9 | 0.6 |

## $P_d$ - Power to be Dissipated [kW]
the power that a cooling system must dissipate if the power to be transmitted exceeds the gearbox's thermal power.

## $\eta_m$ - Mechanical Efficiency
The ratio between mechanical power output and input; normally considered equal to 0.97 ÷ 0.98 for each epicycloidal reduction stage in the gearbox, and equal to 0.94 ÷ 0.95 for bevel gear; the actual value depends on a number of factors including speed, torque, ratio, assembly position and lubrication.

## $T_2$ - Torque Transmitted [Nm]
this value represents torque continuously applied at a speed of $n_1$, at which the gearbox has a theoretical lifetime of 10000 h for gears, or 5000 h ($L_{h10}$ ) for the bearings in gear mechanisms.

## $T_{max}$ - Maximum Transmissible torque [Nm]
the maximum torque transmitted by the accessory supplied with the gearbox, if applicable. This value may limit the maximum transmissible torque of the gearbox.

## $T_{2max}$ - Maximum Torque [Nm]
the maximum admissible output torque, as a peak value or for brief periods of time (calculated at 90% Rs of the weakest component).
For drives with a high number of start-ups or inversions, appropriately reduced maximum torque values should be considered.
The value specified refers to the version with a splined female shaft (FS); different versions may have lower values.

## $T_b$ - Braking Torque [Nm]
the value of braking torque that may be conveyed statically by the negative brake.

### $n_1$ - Input Speed [RPM]
the speed on the fast side of the gearbox.

### $n_2$ - Output Speed [RPM]
the speed on the slow side of the gearbox.

### $n_{1max}$ - Maximum Speed [RPM]
the maximum input speed at the brake. For applications with higher values, contact Dinamic Oil's sales service to determine application compatibility.

### $i_e$ - Effective Reduction Ratio
the actual reduction ratio, meaning the ratio between the gearbox's input and output speeds.

### nxh - Duration Index [RPMxh]
the value of the product between speed and duration of theoretical lifetime in hours. This value is expressed as $n_2$xh when used with output speed, $n_1$xh with used with input speed.

**Duration Values Required for Different Applications**

| Application | Required Lifetime |
|---|---|
| Agricultural machinery | 300 - 3000 |
| Machines operated intermittently or for short periods of time (construction machines) | 3000 - 8000 |
| Machines operated intermittently or for short periods of time with high operational reliability (freight lifts) | 8000 - 12000 |
| Machines operated 8 hours a day but not all the time (various industrial machines, rotary mills) | 10000 - 25000 |
| Machines operated 8 hours a day all the time (various industrial machines, conveyor belts) | 20000 - 30000 |
| Machines operated continuously (rolling mills, textiles machines) | 40000 - 50000 |


### $k_f$ - Correction Factor
the factor applied to calculate the theoretical lifetime of bearings with male shafts for values of nxh other than those shown in catalog diagrams. External load curves are calculated for all gearboxes as:
- $n_2$xh = 100000 for output supports
- $n_1$xh = 1500000 for input supports

### $L_{min}$ - Minimum Length of Torque Arm [mm]
the minimum length recommended for the torque arm, applied to pendular applications.

## Order code

| RA | 21 | 3 | P | S | 78.7 | |
|---|---|---|---|---|---|---|

### OUTPUT VERSION




### OUTPUT SHAFT

**S** = Male spline
**F** = Female spline
**C** = Cylindrical shaft
**K** = Extended cylindrical shaft
**E** = Hexagonal shaft
**Q** = Hollow female shaft
**FS** = Female spline
**FC** = Female cylindrical shaft
**U** = Female cylindrical shaft

### NUMBER OF STAGES

**1 - 2 - 3 - 4 - 5 - 6**


### GEARBOX FRAME SIZE

| RE - RA | RE - RA | GB - GBA | GB - GBA |
|---|---|---|---|
| **110** | **1520** | **12010** | **61000** |
| **210** | **2000** | **16000** | **85000** |
| **240** | **2520** | **21000** | **110000** |
| **310** | **3000** | **26000** | **130000** |
| **510** | **3510** | **31000** | GB |
| **610** | **4800** | **40000** | **150000** |
| **810** | **6000** | **45000** | **205000** |
| **1020** | **8000** | **53000** | **235000** |


### REDUCTION RATIO

Please write the exact ratio as shown on the selection table

### EXECUTION



**RE - GB** = Linear



**RA - GBA** = Angular


### COMPOSITION

**/** = Standard
**L** = Light
**R** = Reinforced
**S** = Special

dinamic oil

ST | BB | B3 | 0 | BS

## OUTPUT ACCESSOIRES





**P** = Pinion
**FL** = Flange
**BS** = Splined bushing
**EP** = End plate
**ES** = Hexagonal bushing
**GA** = Shrink disc
**VE** = Expansion tank
**BF** = Splined bar
**BR** = Torque arm
**PH** = Foot support

## RIGHT ANGLE POSITIONING

## MOUNTING POSITION

## MOTOR ADAPTER CONFIGURATION




Electric motor

Orbit motor

Axial piston motor

Radial piston motor

## DIRECT INPUTS





The example shows the ordering code for a right angle planetery gearbox frame 210, with 3 reduction stages a foot mounted output support and a male splined shaft, and 78.7 reduction ratio, with a "ST" input and "SAE B", 16/32 15 teeth motor adapter flange. Horizontal mounting position and standard right angle positioning, and a splined bushing output accessory.

## Codice d'ordinazione

| RA | 21 | 3 | P | S | 78.7 | |
|---|---|---|---|---|---|---|

### VERSIONE USCITA

G-2




### ALBERO IN USCITA

**S** = Scanalato maschio
**F** = Scanalato femmina
**C** = Cilindrico
**K** = Cilindrico lungo
**E** = Esagonale
**Q** = Giunto di attrito
**FS** = Femmina scanalato
**FC** = Femmina cilindrico
**U** = Femmina cilindrico

### NUMERO STADI DI RIDUZIONE

**1 - 2 - 3 - 4 - 5 - 6**


### GRANDEZZA RIDUTTORE

| RE - RA | RE - RA | GB - GBA | GB - GBA |
|---|---|---|---|
| **110** | **1520** | **12010** | **61000** |
| **210** | **2000** | **16000** | **85000** |
| **240** | **2520** | **21000** | **110000** |
| **310** | **3000** | **26000** | **130000** |
| **510** | **3510** | **31000** | GB |
| **610** | **4800** | **40000** | **150000** |
| **810** | **6000** | **45000** | **205000** |
| **1020** | **8000** | **53000** | **235000** |


### RAPPORTO DI RIDUZIONE

Indicare il valore del rapporto (compreso virgola e decimale) riportato sulle pagine dei dati tecnici relative ad ogni grandezza

### ESECUZIONE



**RE - GB** = Lineare



**RA - GBA** = Angolare


### COMPOSIZIONE

**/** = Standard
**L** = Light
**R** = Rinforzato
**S** = Speciale

dinamic oil

**ST** **BB** **B3** **0** **BS**

## ACCESSORI IN USCITA





**P** = Pignone
**FL** = Flangia
**BS** = Boccola scanalata
**EP** = Fondello
**ES** = Manicotto esagonale
**GA** = Giunto di attrito
**VE** = Vaso di espansione
**BF** = Barra scanalata
**BR** = Braccio di reazione
**PH** = Piede

## ORIENTAMENTO RIDUTTORE ANGOLARE


## POSIZIONE DI MONTAGGIO

## PREDISPOSIZIONE MOTORE



Motore elettrico
Motore idraulico orbitale
Motore idraulico assiale
Motore idraulico a pistoni radiali

## ENTRATE DIRETTE




Nell'esempio è illustrato il codice di ordinazione di un riduttore planetario angolare, grandezza 210, tre stadi di riduzione, versione in uscita con i piedi e albero scanalato, rapporto di riduzione 78.7, entrata standard, predisposizione per motore "SAE B" albero 16/32 z=15, posizione di montaggio del riduttore in uscita orizzontale, orientamento del riduttore angolare standard, boccola scanalata in uscita

# LEGAL NOTES

All information in this catalogue has been checked; in case of possible mistakes, we decline all responsibility.

Dinamic Oil reserves the right to amend the technical data of this catalogue without prior notice.

For all further information please contact Dinamic Oil S.p.A. Commercial Department.

# NOTE LEGALI

Tutti i contenuti riportati nel presente catalogo sono stati controllati; in caso di eventuali errori viene comunque declinata ogni responsabilità.

Dinamic Oil si riserva la facoltà di modificare senza preavviso i dati tecnici riportati.

Per ulteriori informazioni contattare il servizio tecnico commerciale Dinamic Oil S.p.A.

dinamic oil

DINAMIC OIL S.p.A.
Via Togliatti,15 - 41030 - Bomporto - Modena - Italy
Phone: +39 059 812611 / Fax: +39 059 812600
E-mail: sales@dinamicoil.it - www.dinamicoil.com

DINAMIC OIL FRANCE
ZI Montbertrand BP 3612 - 38236 Charvieu Cedex - France
Phone: +33 (0) 472-46-23-18 / Fax: +33 (0) 472-46-23-27

DINAMIC OIL DEUTSCHLAND GmbH
Frankfurter Straße 151 b - D - 63303 Dreieich-Sprendlingen
Phone: +491736927478

DINAMIC OIL NORWAY A/S
Lindebergveien, 3 - 2016 Frogner
Office: +47 63825040 - Fax: +47 63825041 - Norway

DINAMIC OIL NORTH AMERICA INC.
511 Eagleton Downs Drive - Charlotte - NC - 28134 - USA
Phone: +1-704-587-4600 / Fax: +1-980-939-6297

DINAMIC OIL INDIA PVT LIMITED
Plot N°1295 a MIE Industrial Area Part B Bahadurgarh - Haryana 124507 - India
Phone: 0091 1276 267294 / 0091 1276 267295 - Fax: 0091 1276 267295 / 0091 1125 287537

DINAMIC OIL (Shanghai) Machinery Co.Ltd.
Building 2 No.128 Lane 168 Dieqiao Rd. Kangqiao Industry Park - Pudong - Shanghai – China
Zip Code: 201319 Phone 0086 21 68187100 Fax 0086 21 68187107

DINAMIC OIL ASIA PACIFIC Pte LTD
47L Tuas South Avenue 1 - Singapore 637249
Phone: +65-67910802 - Fax: +65-67912661